




Vision Sensor

FH Series

Vision System



Robot Connection Guide

OMRON TM Series Edition

Z447-E1-02

NOTE

- All rights reserved.
- No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.
- No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions.

Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Trademarks

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- This software is based in part on the work of the Independent JPEG Group.
- Microsoft, Windows, Windows Vista, Excel, and Visual Basic are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- Intel, Core and Pentium are trademarks of Intel Corporation in the U.S. and/or other countries.
- EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.
- The SD, SDHC, microSD, and microSDHC logos are trademarks of SD-3C, LLC.



- QR Code is a registered trademark of DENSO WAVE INCORPORATED.
- MELSEC is a registered trademarks of Mitsubishi Electric Corporation.

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Copyrights

Microsoft product screen shots used with permission from Microsoft.

CONTENTS

Introduction.....	2
Terms and Conditions Agreement	3
Safety Precautions	5
Warning	6
Precautions for Safe Use	7
Precautions for Correct Use.....	8
Regulations and Standards	9
Related Manuals	10
Revision History	12
1. Overview	13
1.1. Overview	13
1.2. Instructions for Building a 3D Robot Vision Application	13
1.3. Robot Programs Covered in this Manual	14
2. System Configuration.....	15
2.1. Cautions for Robot Equipment	15
2.2. When Using Vision Sensor FH Series 3D Vision Sensor.....	15
3. Connecting Vision Sensor to Robot Controller	18
3.1. Setting Communications for Robot controller.....	19
3.2. Connecting and Checking Vision Sensor and Robot Controller	22
3.3. Verify Commands Sent/Received	24
4. Coordinate System	28
4.1. Name of Coordinate System	28
5. How to Start the Setup Program	30
6. Description of the Sample Programs.....	31
6.1. Initialization of the Sample Program	33
6.2. Switching Scenes on the Vision Sensor.....	34
6.3. Moving Robot to Robot Image Position.....	36
6.4. Register the Current Robot Position in the Vision Sensor	38
6.5. Executing Measurements on Vision Sensor	38
6.6. Getting the Measurement Results.....	40
6.7. Moving Robot to Robot Command Position at Measurement.....	41
7. Component Reference.....	43
7.1. List of Components	43
7.2. Error Message.....	43
7.3. Component Details.....	44

Introduction

Thank you for purchasing the FH Series.

This manual contains information that is necessary to use the FH Series.

Please read this manual and make sure you understand the functionality and performance of the FH Series before you attempt to use it in a control system.

Keep this manual in a safe place where it will be available for reference during operation.

Terms and Conditions Agreement

Warranty, Limitations of Liability

Warranties

• Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

• Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

• Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

[See http://www.omron.com/global/](http://www.omron.com/global/) or contact your Omron representative for published information.

Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANYWAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Application Considerations

Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Disclaimers

Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Safety Precautions

For details on Safety Precautions, refer to Safety Precautions in the *Vision System FH Series 3D Robot Vision Application Construction Guide (Cat. No. Z446)*.

Warning

For details on Warning, refer to Warning in the *Vision System FH Series 3D Robot Vision Application Construction Guide (Cat. No. Z446)*.

Precautions for Safe Use

For details on Precautions for Safe Use, refer to Precautions for Safe Use in the *Vision System FH Series 3D Robot Vision Application Construction Guide (Cat. No. Z446)*.

Precautions for Correct Use

For details on Precautions for Correct Use, refer to Precautions for Correct Use in the *Vision System FH Series 3D Robot Vision Application Construction Guide (Cat. No. Z446)*.

Regulations and Standards

For details on Regulations and Standards, refer to Regulations and Standards in the *Vision System FH Series 3D Robot Vision Application Construction Guide (Cat. No. Z446)*.

Related Manuals

<Application Construction Guide>

Name of Manual	Cat. No.	Model	Purpose	Contents
Vision Sensor FH Series 3D Robot Vision Application Construction Guide	Z446	FH-505□ FH-SMDA-GS050B	When User want to know about the FH series 3D robot vision system.	Describes the soft functions, setup, and operations to use FH series 3D robot vision system.

<Robot Manual>

Name of Manual	Cat. No.	Model	Purpose	Contents
Regular Payload Series Hardware Installation Manual	I623	RT6-0□□□□□□	When User want to know the setup and hardware specification s of the TM Robot	Describes the specifications, external dimensions, names of parts, I/O, installation, and wiring of the cooperative robot TM5.
Medium & Heavy Payload Series Hardware Installation Manual	I624	RT6-1□□□□□□ RT6-2□□□□□□	When User want to know the setup and hardware specification s of the TM Robot	Describes the specifications, external dimensions, names of parts, I/O, installation, and wiring of the cooperative robot TM12, TM14.
TMflow Software Manual	I626	-	When User want to know how to configure TMflow	Describes the software functions, settings, and operations for using the collaborative robot TM.
TECHMAN ROBOT Safety System 3.3 Safety Manual	I648	-	When User Want to Know the Safety Features of the TM Robot	Describes the safety functions in Collaborative robot TM.
TM5S TM7S TM Collaborative Robot Hardware Installation Manual	I686	RT6-0□□□□□□ RT6-6□□□□□□	When User want to know the setup and hardware specification s of the TM S Robot	Describes the specifications, external dimensions, names of parts, I/O, installation, and wiring of the cooperative robot TM5S, TM7S.
TM12S TM14S TM Collaborative Robot Hardware Installation Manual	I687	RT6-1□□□□□□ RT6-2□□□□□□	When User want to know the setup and hardware specification s of the TM S Robot	Describes the specifications, external dimensions, names of parts, I/O, installation, and wiring of the cooperative robot TM12S, TM14S.

TM Collaborative Robot Software Manual TM Flow Version2	I689	-	When User want to know how to configure Tmflow	Describes the software functions, settings, and operations for using the collaborative robot TM S.
TM S Series TM Collaborative Robot Safety Manual	I688	-	When User Want to Know the Safety Features of the TM S Robot	Describes the safety functions in Collaborative robot TM S.

Revision History

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.

Cat. No.	Z447-E1-02
-----------------	-------------------

↑
Revision code

Rev. Code	Rev. Date	Revision Contents
01	Feb. 2021	Original product
02	Jun. 2024	Add a connected robot. - OMRON TM S series Additional support for FH-5051 and FH-5052. Revisions for update camera cables model. Added FZ-MEM16G.

1. Overview

1.1. Overview

This manual describes procedures for connections and settings required for constructing robot vision applications by connecting your robot controller to the Vision Sensor FH (hereafter referred to as Vision Sensor).

Utilizing this manual and Robot Vision Application Construction Guide can reduce man-hours to connect the Vision Sensor to your robot controller, set the Vision Sensor, and create robot programs.

1.2. Instructions for Building a 3D Robot Vision Application

Please follow the flow below for constructing 3D robot vision applications

Procedure	Reference
Creating Data Set for Robot Vision	[3D Robot Vision Application Construction Guide] Chapter 6
↓	
System Settings for the Vision Sensors	[3D Robot Vision Application Construction Guide] Chapter 7
↓	
Setting Communications for Robot controller	Refer to Chapter 3.1
↓	
Connecting Vision Sensor to Robot Controller	Refer to Chapter 3.2 Refer to Chapter 3.3
↓	
Robot Vision Settings for Vision Sensors	[3D Robot Vision Application Construction Guide] Chapter 8
↓	
Description of the sample programs	Refer to Chapter 6

1.3. Robot Programs Covered in this Manual

The two types of robot programs covered in this manual are output from the Robot Vision Dataset Output Tool. Each program is used for a different purpose.


Program	Project Name	Detail
Setup Program	FHSETUPMAIN	<p>This program allows the Vision Sensor to give operating instructions to the robot to configure the Vision Sensor for robot vision.</p> <p>This program consists of the following functions</p> <ul style="list-style-type: none">- Send the current robot position to the Vision Sensor.- Move to the indicated position on the Vision Sensor.
Sample Program	FHSAMPLEMAIN	<p>This program is a sample of the basic program flow for a pick application. In this program, the robot gives control instructions to the Vision Sensor. The program consists of the following functions</p> <ul style="list-style-type: none">- Connecting to the Vision Sensor- Scene switching of the Vision Sensor- Moving to the measurement position- Registering the current robot position to the Vision Sensor- Execute measurement instructions to the Vision Sensor- Receives the position of the workpiece to be recognized- Move to approach position- Move to the target work location (grasping position) <p>Based on this program, a pick-and-place application is built by adding the robot movement to operate the end-effector (hand) and to place the workpiece.</p>

2. System Configuration

This chapter describes the system configuration and target devices to construct robot vision applications.


2.1. Cautions for Robot Equipment

[RobotBase] and [NOTOOL] have been selected for the robot controller's coordinate system.



2.2. When Using Vision Sensor FH Series 3D Vision Sensor

2.2.1. System Configuration



2.2.2. Target Devices

Device name	Manuf acture	Name	Model	Remarks
Vision Sensor	OMRON	Vision Sensor FH Series	FH-505□	FH-5052: Ver.6.60 or higher FH-5051: Ver.6.51 FH-5050: Ver.6.40 to Ver.6.51 Controllers other than the FH-505□ are not supported.

3D Camera	OMRON	3D Vision Sensor	FH-SMDA-GS050B	
Camera Cable	OMRON	Ethernet cable super bending resistance	FHV-VNBX2□M FHV-VNLBX2□M	-
Camera I/O cable	OMRON	I/O cable super bending resistance	FH-VSDX-BX□M FH-VSDX-LBX□M	-
Calibration target	OMRON	Handeye Calibration Target	FH-XCAL-R	-
	OMRON	Camera Calibration Target	FH-XCAL-S	-
3D Software	OMRON	3D Robot Vision Software Installer	FH-UM3D1	-
Robot	OMRON	Collaborative Robot TM5-700	RT6-0□□70□□	
		TM5-900	RT6-0□□90□□	
Robot	OMRON	Collaborative Robot TM5S	RT6-0□□90□□	
		TM7S	RT6-6□□70□□	
		TM12S	RT6-1□□13□□	
		TM14S	RT6-2□□11□□	
PC software	OMRON	Data set output tool for 3D robot vision	—	Ver.1.00 Please contact us for how to obtain it.
	OMRON	Robot Programing Environment TMflow	—	Ver.1.80.5300 or later
	OMRON	Robot Programing environment (TM S) TMflow Version2	—	Ver.2.16.3500 or later
Switching hub	OMRON	Industrial switching hub	W4S1-□□□	Recommended product
USB memory	OMRON	USB memory	FZ-MEM16G	Recommended product



Precautions for Correct Use

Do not use any device except mentioned above for each device of the system configuration.



Additional Information

This manual does not provide operations, installation, and wiring methods for each device.

For details, refer to manuals noted in Related Manuals.

3. Connecting Vision Sensor to Robot Controller


This chapter describes procedures to connect the Vision Sensor to the robot controller.

Please follow the flow below for the settings.

The IP address of each device is described below.

Vision Sensor : 10.5.5.100

Robot controller: 10.5.5.101










The explanation of sending and receiving commands is explained using the node name (component) / device name (network) of TM Robot. For the TM S robots, see the table below.

	TM	TM S
Node name (Component)	fhsetup	FH_v200_fhsetup1
Device name (Network)	FH	ntd_FH


3.1. Setting Communications for Robot controller

Please follow the procedures below to set the communications for the robot controller. Connect a monitor, keyboard, and mouse to the robot's control box, and turn on the robot's power.

1	<p>Click [Get Control] on the robot startup screen to make the settings available.</p> <p>If the robot is in auto mode, switch to manual mode.</p>	
2	<p>Click the icon in the top left menu to display a list of the function menu.</p> <p>Click [System] – [Network].</p>	
3	<p>Click [Local Area Connection X] in Network setting.</p> <p>Set the IP Address and Subnet Mask.</p> <p>Set the IP address that does not overlap with the Vision Sensor and the PC where TMflow is running.</p>	


	Click [OK] and Click an icon enclosed in red square on the right figure to close to Network setting.	
4	Copy the "TM_Export" folder in the "RobotProgram" folder of the data output from the Data Set Output Tool for Robot Vision to the USB memory.	
5	Change the device name of the USB memory to "TMROBOT".	
6	Connect the USB memory to the USB port of the robot controller.	
7	Click the icon in the top left menu to display a list of the function menu. Click [System] – [Import/Export]	
8	Click [import] in the top left corner. The right dialog will be displayed, select "Configure Controller" and click [Finish].	

In Robot List ,
select FHRobotVision and click
[OK].




Select all files that appear in
Project, Component.

Click [Import] at the bottom
right.



When the import is complete
and "Import complete" is
displayed, click [OK].





Additional Information

The device name of the USB flash drive is "TMROBOT".

The program cannot be read with any other device name.




This manual does not provide operation, installation, and wiring methods for each device.

For details, refer to manuals noted in Related Manuals.


3.2. Connecting and Checking Vision Sensor and Robot Controller

Follow the procedures below to connect the Vision Sensor and the robot controller and to check the connection status.

3.2.1. Verifying Ethernet Communication (FH Series Vision Sensor)

1	Connect the Vision Sensor and the robot controller with LAN cables.	
2	(Operation of the Vision Sensor) Move the mouse cursor to lower left of the window to display [Start]. Select [Start] - [All Programs] - [Accessories] - [Command Prompt] to launch [Command Prompt].	
3	(Operation of the Vision Sensor) Execute PING command to the IP address of the robot controller.	
4	(Operation of the Vision Sensor) When 32-byte data could be successfully sent/received four times as shown in the figure on the right, that means that the communications have been established and the wiring and settings of Ethernet is correctly done.	

When 32-byte data cannot be sent/received four times and PING command timed out, check whether or not the robot controller is turned on, the wiring was correctly done, or communication settings are correct.



```
Command Prompt
Microsoft Windows [Version 6.1.7601]
Copyright (c) 2010 Microsoft Corporation. All rights reserved.

C:\Users\User>ping 10.5.5.101




Pinging 10.5.5.101 with 32 bytes of data:
Request timed out.
Request timed out.
Request timed out.
Request timed out.




Ping statistics for 10.5.5.101:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),

C:\Users\User>
```

3.3. Verify Commands Sent/Received

Execute the setup program on the robot controller and follow the steps below to confirm that commands can be sent and received from the Vision Sensor.


1	<p>(Operation of TMflow)</p> <p>On the robot controller side, select [Project].</p>	
2	<p>(Operation of TMflow)</p> <p>Like shown on the right figure, On the project editing screen, click the icon.</p> <p>Select [FHSETUPMAIN] from the list of projects and click [OK] to load the setup program.</p>	
3	<p>(Operation of TMflow)</p> <p>Like shown on the right figure, Click the icon to open the configuration dialog for [fhsetup] node.</p>	

<p>4</p>	<p>(Operation of TMflow) Select [RecvString] to open the Network Settings dialog.</p> <p>Make sure that [Choose Device] is set to FH. Click [Edit Device] to open the Device Settings screen.</p> <p>Set the IP address and port number of the Vision Sensor.</p> <p>Click [Done] to save the settings.</p>	
<p>5</p>	<p>(Operation of TMflow) Select [SendString] to open the Network Settings dialog.</p> <p>Make sure that [Choose Device] is set to FH.</p> <p>After confirming, close the [fhsetup] node configuration dialog.</p>	
<p>6</p>	<p>(Operation of TMflow) Like shown on the right figure, Click the icon to save the [FHSETUPMAIN] project to save your network settings.</p>	

7

(Operation of Robot Stick)

Press the [Play/Pause] button on the robot stick to run the project.



When the project is in the running state, the robot's ring will flash green.

8

(Operation of the Vision Sensor and TMflow)

Like shown on the right figure, when [Get] is clicked on the Main Window of the Vision Sensor and the current robot position on TMflow is displayed at the same position on the Main Window of the Vision Sensor, sending/receiving commands between them have been succeeded.


* The current robot position can be checked by clicking [Controller] on the project editing toolbar.

* Correspondence relation of notation

Vision Sensor	TMflow
W	Rx
P	Ry
R	Rz

Robot Error	Robot Current Pos.	Get
FH 3D Mcr. Ver. 2.00	X : 400.0000 W : 180.0000	
RB Prog. Ver. 2.00	Y : 0.0000 P : 0.0000	
	Z : 500.0000 R : -90.0000	

Step Run	Diagnosis	Point Manager	Base Manager	Controller	Variables
----------	-----------	---------------	--------------	------------	-----------



Jog Distance: Continuous Speed: 1.00 %

Direct Move

X	400.00
Y	0.00
Z	500.00
Rx	180.00
Ry	0.00
Rz	-90.00

0 mm
0 mm
0 mm
0 °
0 °
0 °

9

(Operation of the Vision Sensor)

Like shown on the right figure,

If the [Robot Error] button turns red, the connection has failed. Check the wiring and others.

Robot Error	Robot Current Pos.		Get	
FH 3D Mcr. Ver.	X :	0.0000	W :	0.0000
	Y :	0.0000	P :	0.0000
RB Prog. Ver.	Z :	0.0000	R :	0.0000

10

(Operation of Robot Stick)

When the Vision Sensor and the robot controller have exchanged commands, press the [Stop] button on the robot stick to stop the project.



Additional Information

This manual does not provide operation, installation, and wiring methods for each device.

For details, refer to manuals noted in Related Manuals.


4. Coordinate System

This chapter describes the coordinate system handled by the robot vision application.

4.1. Name of Coordinate System

The robot coordinate system of the Vision Sensor uses the name shown in the table below.

Coordinate System	Meaning
Robot Base Coordinate System	Coordinate system with the robot base as the origin
Local Coordinate System	User-defined coordinate system
Flange Coordinate system	Coordinate system defined on the flange surface of the robot
Tool Coordinate System	The coordinate system is defined in the tool center point by offsetting the origin of the flange coordinates system.
Camera Coordinate System	With the optical center of the camera as the starting point, the X and Y axes are the horizontal and vertical directions of the image, and the Z axis is the optical axis of the camera.



The orientation of the coordinate axes of each coordinate system depends on the robot. Please refer to the instruction manual for each robot.

There are the following differences between the names of the coordinate system in the Vision Sensor and the coordinate system in the OMRON TM series.


Vision Sensor	OMRON TM Series
Local Coordinate System	Base Coordinate System
Tool Coordinate System	Tool Coordinate System

5. How to Start the Setup Program

This chapter describes how to start the setup program. To set the robot vision of the Vision Sensor, the setup program must be running on the robot side. Establish the connection between the Vision Sensor and the robot controller by [3. Connecting Vision Sensor to Robot Controller]


(Operation of TMflow)
Like shown on the right figure,
On the project editing screen,
click the icon.

1
Select [FHSETUPMAIN] from
the list of projects and click
[OK] to load the setup
program.



(Operation of Robot Stick)
Press the [Play/Pause] button
on the robot stick to run the
project.


2
When the project is in the
running state, the robot's ring
will flash green.




6. Description of the Sample Programs

This chapter describes design examples of robot programs to construct applications using the sample program.

You can understand how to implement a robot program to control the Vision Sensor as shown in the following figure.



The sample program is implemented with the following procedures. When building an actual application, design, implement and test the robot program, utilizing the functions described in Chapter 7.

- 
- ```
graph TD; 6.1[6.1 Connecting the Vision Sensor to the robot controller] --> 6.2[6.2 Switching scenes on the Vision Sensor]; 6.2 --> 6.3[6.3 Moving the robot to the image position]; 6.3 --> 6.4[6.4 Register the current robot position in the Vision Sensor]; 6.4 --> 6.5[6.5 Executing measurements on the Vision Sensor]; 6.5 --> 6.6[6.6 Getting the measurement results]; 6.6 --> 6.7[6.7 Moving the robot to the robot command position at measurement];
```
- 6.1 Connecting the Vision Sensor to the robot controller
- 6.2 Switching scenes on the Vision Sensor
- 6.3 Moving the robot to the image position
- 6.4 Register the current robot position in the Vision Sensor
- 6.5 Executing measurements on the Vision Sensor
- 6.6 Getting the measurement results
- 6.7 Moving the robot to the robot command position at measurement

The explanation of the sample program is explained using the node name (component) / device name (network) of the TM robot. For the TM S robots, see the table below.

|                          | TM           | TM S                                |
|--------------------------|--------------|-------------------------------------|
| Node name<br>(Component) | fhdefglobal  | FH_v200_fhdefglobal1                |
|                          | ChangeScene  | FH_v200_fhrunsendcmd1               |
|                          | RecvResponse | FH_v200_fhrunrecvres1-fhrunrecvres2 |
|                          | RegistCurPos | FH_v200_fhsamplereregpos1           |
|                          | MEASURE      | FH_v200_fhrunsendcmd2               |
|                          | RecvVal      | FH_v200_fhrunrecvval1               |
| Device name<br>(Network) | FH           | ntd_FH                              |









### **Precautions for Correct Use**

The implementation procedures for robot programs noted in this chapter are a reference. You should design, implement, and test actually operating robot programs based on your specific environment and applications.

In the Main Window or “Layout setup” of the Vision Sensor, check that the “Output” of the current layout is ON. If the setting were OFF, the Vision Sensor will not output measurement values.






## 6.1. Initialization of the Sample Program




This section describes how to initialize global variables, set the IP address and port number of the Vision Sensor.

|   |                                                                                                                                                                                 |                                                                                                                   |
|---|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| 1 | Open [FHSAMPLEMAIN] sub-flow in the Project Edit page.                                                                                                                          |                                 |
| 2 | <p>The [fhdefglobal] component is placed at the beginning of the flow.</p> <p>This component initializes the global variables needed to communicate with the Vision Sensor.</p> |  <p>fhdefglobal Component</p>   |
| 3 | Select the ChangeScene node on the flow and click the pencil icon to open the settings dialog box.                                                                              |  <p>fhrunsendcmd Component</p> |
|   | Click [SendString] and make sure that [Choose Device] is "FH".                                                                                                                  |                               |
|   | Click Edit Device and set the IP address and port number of the Vision Sensor.                                                                                                  |                               |
|   | Click [Done] to close the dialog box.                                                                                                                                           |                                                                                                                   |
|   | <p>The communication device "FH" is commonly used in the sample program.</p> <p>It is not necessary to configure the communication setting for each node.</p>                   |                               |

## 6.2. Switching Scenes on the Vision Sensor

Sends a scene switching command to the Vision Sensor and receives the response to that command.

|   |                                                                                                                                          |                                                                                      |
|---|------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| 1 | <p>Select the [ChangeScene] node on the flow and click the pencil icon to open the settings screen.</p>                                  |    |
| 2 | <p>Click [input Argument] to open the configuration dialog box.</p>                                                                      |    |
|   | <p>Click [Variables(7)] to open the Variables configuration dialog box.</p>                                                              |   |
|   | <p>Make sure that [cmdName] is [SCENE].</p> <p>Sets the scene number to be used for [cmdArg[0]] argument.</p>                            |  |
| 3 | <p>Check for the error in the [ChangeScene] node.</p> <p>The error is stored in the global variable [g_FHRobotVision_OMRON_errCode].</p> |  |


|   |                                                                                                                                                                                                                                                                                                |                                                                                                                                                  |
|---|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
|   | If the error code is 0 (zero),<br>proceed to the next node.                                                                                                                                                                                                                                    |                                                                                                                                                  |
| 4 | The [RecvResponse] node<br>receives the response to the<br>scene switching command.                                                                                                                                                                                                            |  <p><i>RecvResponse</i><br/>e</p> <p>fhrunrecvres Component</p> |
| 5 | <p>Check for the error in the<br/>[RecvResponse] node.</p> <p>The error is stored in the<br/>global variable<br/>[g_FHRobotVision_OMRON_errCode].</p> <p>If the error code is 0 (zero),<br/>proceed to the next node.</p>                                                                      |                                                                |
| 6 | <p>Check the execution result<br/>(command response) of the<br/>[RecvResponse] node.</p> <p>The result of the execution is<br/>stored in the global variable<br/>[g_FHRobotVision_OMRON_param[0]].</p> <p>If the result of the execution<br/>is 1 (OK), then proceed to the<br/>next node.</p> |                                                               |

## 6.3. Moving Robot to Robot Image Position


Move the robot to the imaging position and register the imaging position in the variable.

1


Move the robot to the imaging position.



Click [Point Manager] to open the dialog box.




Select [imgPos] and click the pencil icon.




2

Click [Overwrite new pose to this point] to record the current robot position in [imgPos]



Click [X] to close the Point Manager dialog.



At the [imgPos] point node, the robot moves to the imaging position.



Point Node

## WARNING



3

- These operations drive the robot.
- Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.
- In the base list, select [RobotBase] as the current base.
- In the tool list, select [NOTOOL] as the current tool.





## 6.4. Register the Current Robot Position in the Vision Sensor

To register the current robot position to the Vision Sensor, use "fhsample\_regpos".

|   |                                                                                                                                                                                                           |                                                                                                                     |
|---|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
| 1 | <p>The [RegistCurPos] node registers the current robot position to the Vision Sensor.</p>                                                                                                                 |  <p>fhsample_regpos Component</p> |
| 2 | <p>Check for the error in the [RegistCurPos] node.</p> <p>The error is stored in the global variable [g_FHRobotVision_OMRON_errCode].</p> <p>If the error code is 0 (zero), proceed to the next node.</p> |                                   |

## 6.5. Executing Measurements on Vision Sensor

Send the measurement command to the Vision Sensor and receives a response to that command.

|   |                                                                                                                                                    |                                                                                                                    |
|---|----------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------|
| 1 | <p>Click the [MEASURE] node to open the configuration dialog box.</p>                                                                              |  <p>fhrunsendcmd Component</p> |
| 2 | <p>Click the [inputArgument] to open the configuration dialog box.</p> <p>Click [Variables(7)] to open the Variables configuration dialog box.</p> |                                |




|   |                                                                                                                                                                                                           |                                                                                                                                                                                                                                                                                                                         |
|---|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | <p>Make sure that [cmdName] is [MEASURE].</p> <p>By executing the [MEASURE] node, measurement command is sent to the Vision Sensor.</p>                                                                   | <pre> FHRobotVision_OMRON_FH_v200_fh runsendcmd_1_var_cmdArgumentNum FHRobotVision_OMRON_FH_v200_fh runsendcmd_1_var_cmdName FHRobotVision_OMRON_FH_v200_fh runsendcmd_1_var_cmdArgument[0] </pre> <p>0</p> <p>Number of command arguments</p> <p>"MEASURE"</p> <p>Non-procedure Communication Command</p> <p>empty</p> |
| 3 | <p>Check for the error in the [MEASURE] node.</p> <p>The error is stored in the global variable [g_FHRobotVision_OMRON_errCode].</p> <p>If the error code is 0 (zero), proceed to the next node.</p>      |                                                                                                                                                                                                                                                                                                                         |
| 4 | <p>The [RecvResponse] node receives the response to the measurement command.</p>                                                                                                                          | <p>fhrunrecvres Component</p>                                                                                                                                                                                                                                                                                           |
| 5 | <p>Check for the error in the [RecvResponse] node.</p> <p>The error is stored in the global variable [g_FHRobotVision_OMRON_errCode].</p> <p>If the error code is 0 (zero), proceed to the next node.</p> |                                                                                                                                                                                                                                                                                                                         |

6

Check the execution result (command response) of the [RecvResponse] node.

The result of the execution is stored in the global variable [g\_FHRobotVision\_OMRON\_param[0]].

If the result of the execution is 1 (OK), then proceed to the next node.




## 6.6. Getting the Measurement Results

The Vision Sensor measurements are received using "fhrunrecvval". In this sample program, it is assumed that the Vision Sensor measurements are sent in the order "TJG X Y Z W P R".

1

The [RecvVal] node receives the measurement result of the Vision Sensor and stores it in the g\_FHRobotVision\_OMRON\_param[0-6].

Each element contains the measurement results as shown in the table on the right.



fhrunrecvval Component


|                                |     |
|--------------------------------|-----|
| g_FHRobotVision_OMRON_param[0] | TJG |
| g_FHRobotVision_OMRON_param[1] | X   |
| g_FHRobotVision_OMRON_param[2] | Y   |
| g_FHRobotVision_OMRON_param[3] | Z   |
| g_FHRobotVision_OMRON_param[4] | W   |
| g_FHRobotVision_OMRON_param[5] | P   |
| g_FHRobotVision_OMRON_param[6] | R   |

2

Check for the error in the [RecvResponse] node.

The error is stored in the global variable [g\_FHRobotVision\_OMRON\_errCode].

If the error code is 0 (zero),




proceed to the next node.

3

Check the TJG of the Vision Sensor measurement result. The TJG of the Vision Sensor measurement result is stored in the global variable [g\_FHRobotVision\_OMRON\_param[0]].

If TJG is OK (1), proceed to the next node, otherwise exit the program.




## 6.7. Moving Robot to Robot Command Position at Measurement

Using the measurement results of the Vision Sensor the robot is moved to Robot Command Position via the approach position.

1

The [SetCmdPos] node sets the results of the Vision Sensor measurements to the point variable [resCmdPos].

You can grip the Robot Command position of the point variable [resCmdPos].



|       |                                                       |
|-------|-------------------------------------------------------|
| Point | ["resCmdPos = g_FHRobotVision_OMRON_param[1].Value[0] |
| Point | ["resCmdPos = g_FHRobotVision_OMRON_param[2].Value[1] |
| ...   |                                                       |
| Point | ["resCmdPos = g_FHRobotVision_OMRON_param[6].Value[5] |

2

Select the [SetApproDist] node and click the pencil icon to open the Settings dialog box.

Click [Variables(1)] and set the approach distance to var\_approDist.



Variables

Variables(1)




The approach position is the point of access to the Robot Command position.

```
float var_approDist = 30
```

The approach distance is the offset value in the Z direction(mm) in the robot base coordinate system.

3

The [SetApproPos] node calculates the approach position by adding the approach distance in the Z+ direction from the robot command position.




```
Point ["approPos"] = Point["resCmdPos"].Value
.Value
Point ["approPos"] = Point["approPos"].Value[2]
.Value[2] + var_approDist
```

4

The [aproPos] node moves the robot to the approach position.

Then, move to the robot command position [resCmdPos]. At this position, the workpiece can be grasped.

The sample program ends after moving to the robot command position.



## ⚠ WARNING

- These operations drive the robot.
- Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.
- In the base list, select [RobotBase] as the current base.
- In the tool list, select [NOTOOL] as the current tool.



## 7. Component Reference

This chapter describes the functions for building a robot vision application


### 7.1. List of Components

This is a list of functions that can be used by the actual driving robot program.

| Component Name | Description                                                 | Reference     |
|----------------|-------------------------------------------------------------|---------------|
| fhdefglobal    | Initialize a global variable.                               | Chapter 7.3.1 |
| fhsampleregpos | Register the current robot coordinates to the Vision Sensor | Chapter 7.3.2 |
| fhrunsendcmd   | Send a no-procedure command to the Vision Sensor            | Chapter 7.3.3 |
| fhrunrecvres   | Receive a command response from the Vision Sensor           | Chapter 7.3.4 |
| fhrunrecvval   | Receive numerical data from the Vision Sensor               | Chapter 7.3.5 |

### 7.2. Error Message

The error message will be displayed on the DisplayBoard of TMflow.



## 7.3. Component Details

### 7.3.1. fhdefglobal

#### ■ Function

Initialize a global variable.

#### ■ Input Parameters

None

#### ■ Output Parameters

None

#### ■ Exit Process

This component has one exit node as follows

NoError : Normal termination.

#### ■ Remarks

Define the global variables that are necessary to use the robot application.

#### ■ Return Value


None

#### ■ Precautions

Be sure to call this function before using any other function.

#### ■ Example

The following example initializes a global variable.



### 7.3.2. fhsampleregpos

#### ■ Function

Register the current robot position to the Vision Sensor.

#### ■ Input Parameters

| Setting Node | Setting Target | Data Type | Description                                   |
|--------------|----------------|-----------|-----------------------------------------------|
| SendString   | ChooseDevice   | device    | Communication Settings for the Vision Sensors |
|              | WaitTime       | int       | Communication waiting time(ms)                |
| RecvString   | ChooseDevice   | device    | Communication Settings for the Vision Sensors |
|              | WaitTime       | int       | Communication waiting time(ms)                |

#### ■ Output Parameters

None

#### ■ Exit Process

There are two exit nodes in this component as follows

NoError : Normal termination.

Error : Abnormal termination (Please check the message displayed in the view window.)

#### ■ Remarks

Get the current position of the robot in accordance with the selected coordinate system number and register the current position to the Vision Sensor.

Return an error if this function is called while the Vision Sensor is not connected.

Returns an error if a response of current position registration failure is received from the Vision Sensor.

#### ■ Return value

| Err. No. | Error Message                           | Description             |
|----------|-----------------------------------------|-------------------------|
| 0        | -                                       | normal termination      |
| -1800    | ERROR:fhsampleregpos():Trigger NG:-1800 | Response NG             |
| -1601    | ERROR:fhsendstring():NO_DATA:-1601      | Send string length 0    |
| -1601    | ERROR:fhsendstring():NO_CONNECT:-1601   | Unconnected state       |
| -1602    | ERROR:fhsendstring():STRING_LEN:-1602   | Send string length over |
| -1301    | ERROR:fhrecvstring():NO_CONNECT-1301    | Unconnected state       |


|       |                                       |                          |
|-------|---------------------------------------|--------------------------|
| -1301 | ERROR:fhrecvstring():NO_DATA:-1301    | Receive data length 0    |
| -1302 | ERROR:fhrecvstring():STRING_LEN:-1302 | Receive data length over |

#### ■ Precautions

None

#### ■ Example

In the following example, the current robot position is registered to the Vision Sensor.





### 7.3.3. fhrunsendcmd

#### ■ Function

Send a no-procedure command to the Vision Sensor

#### ■ Input Parameters

| Setting Node  | Setting Target | Data Type | Description                                                                        |
|---------------|----------------|-----------|------------------------------------------------------------------------------------|
| SendString    | ChooseDevice   | device    | Communication Settings for the Vision Sensors                                      |
|               | WaitTime       | int       | Communication waiting time(ms)                                                     |
| inputArgument | cmdArgNum      | int       | Number of no-procedural command arguments to be sent to the Vision Sensor (0 to 5) |
|               | cmdName        | String    | No-procedural commands to be sent to the Vision Sensor                             |
|               | cmdArg[0]      | String    | Argument 1 of the no-procedure command sent to the Vision Sensor(string).          |
|               | cmdArg[1]      | String    | Argument 2 of the no-procedure command sent to the Vision Sensor(string).          |
|               | cmdArg[2]      | String    | Argument 3 of the no-procedure command sent to the Vision Sensor(string).          |
|               | cmdArg[3]      | String    | Argument 4 of the no-procedure command sent to the Vision Sensor(string).          |
|               | cmdArg[4]      | String    | Argument 5 of the no-procedure command sent to the Vision Sensor(string).          |

#### ■ Output Parameters

None

#### ■ Exit Process

There are two exit nodes in this component as follows

NoError : Normal termination.

Error : Abnormal termination (Please check the message displayed in the view window.)

#### ■ Remarks

Sends a no-procedure command to the Vision Sensor, concatenating the parameters according to the following format.

If the number of no-protocol command arguments is out of the input range, an error is returned.

<Format>

|                     |        |                    |    |                    |    |     |                        |
|---------------------|--------|--------------------|----|--------------------|----|-----|------------------------|
| No-protocol command | SP(*1) | Command argument 1 | SP | Command argument 1 | SP | ... | Command argument n(*2) |
|---------------------|--------|--------------------|----|--------------------|----|-----|------------------------|

\*1: "SP" is space

\*2: The command argument n depends on the number of non-procedural command arguments.

#### Return Value

| Err. No. | Error Message                                            | Description                                                               |
|----------|----------------------------------------------------------|---------------------------------------------------------------------------|
| 0        | -                                                        | normal termination                                                        |
| -1506    | ERROR:fhrunsendcmd():Invalid Command Argument No.: -1506 | The number of non-procedural command arguments is out of the input range. |
| -1601    | ERROR:fhsendstring():NO_CONNECT: -1601                   | Unconnected state                                                         |
| -1601    | ERROR:fhsendstring():NO_DATA: -1601                      | Send string length 0                                                      |
| -1602    | ERROR:fhsendstring():STRING_LEN: -1602                   | Send string length over                                                   |

#### Precautions

The length of the string of the no-stepping command that can be sent is 127 bytes (not including the delimiter).

Set the input parameters so that the string length of the no-procedure command does not exceed 127 bytes.

#### Example

In the following example, we will switch to scene number 5.



### 7.3.4. fhrunrecvres

#### ■ Function

fhrunrecvres

#### ■ Input Parameters

| Setting Node | Setting Target | Data Type | Description                                   |
|--------------|----------------|-----------|-----------------------------------------------|
| RecvString   | ChooseDevice   | device    | Communication Settings for the Vision Sensors |
|              | WaitTime       | int       | Communication waiting time(ms)                |

#### ■ Output Parameters

| Variable Name                 | Data Type | Description                                                                            |
|-------------------------------|-----------|----------------------------------------------------------------------------------------|
| g_FHRobotVision_OMRON_param   | float[]   | param[0] : Command Response Results<br>(1: Command response "OK" - 1: other than "OK") |
| g_FHRobotVision_OMRON_errCode | int       | Execution Result(0: Normal termination<br>Other than 0: Error)                         |

#### ■ Exit Process

There are two exit nodes in this component as follows

NoError : Normal termination.

Error : Abnormal termination (Please check the message displayed in the view window.)

#### ■ Remarks

Receive the response (command response) to the no-procedure command sent to the Vision Sensor.

If the command response is OK, assign 1 to the global variable

g\_FHRobotVision\_OMRON\_param[0].

If the command response is not OK, assign "-1" to the global variable

g\_FHRobotVision\_OMRON\_param[0].

#### ■ Return Value


| Err. No. | Error Message                         | Description              |
|----------|---------------------------------------|--------------------------|
| 0        | -                                     | normal termination       |
| -1301    | ERROR:fhrecvstring():NO_CONNECT:-1301 | Unconnected state        |
| -1301    | ERROR:fhrecvstring():NO_DATA:-1301    | Receive data length 0    |
| -1302    | ERROR:fhrecvstring():STRING_LEN:-1302 | Receive data length over |

## ■ Precautions

None

## ■ Example

In the following example, the response to the measurement command is received and if the command response is not OK, the program is terminated.



### 7.3.5. fhrunrecvval

#### ■ Function

Receive numerical data from the Vision Sensor

#### ■ Input Parameters

| Setting Node | Setting Target | Data Type | Description                                   |
|--------------|----------------|-----------|-----------------------------------------------|
| RecvString   | ChooseDevice   | device    | Communication Settings for the Vision Sensors |
|              | WaitTime       | int       | Communication waiting time(ms)                |

#### ■ Output Parameters

| Variable Name                 | Data Type | Description                                                    |
|-------------------------------|-----------|----------------------------------------------------------------|
| g_FHRobotVision_OMRON_param   | float[]   | param[0] - param[9] : Received numeric data 0 - 9)             |
| g_FHRobotVision_OMRON_errCode | int       | Execution Result(0: Normal termination<br>Other than 0: Error) |

#### ■ Exit Process

There are two exit nodes in this component as follows

NoError : Normal termination.

Error : Abnormal termination (Please check the message displayed in the view window.)

#### ■ Remarks

This function stores the numerical data sent from the Vision Sensor into the global variable "g\_FHRobotVision\_OMRON\_param".

This function outputs up to 10 values.

If there are more than 11 numbers, this function outputs only the first 10.

If the length of the segmented string is longer than 12 bytes, this function returns an error of abnormal parameter length.

Returns an error if the number of numeric data is zero.

The following is an example of the output when a string is included.

<Conversion example>

| The string before conversion | The result of the analysis after conversion |
|------------------------------|---------------------------------------------|
| abc                          | 0                                           |
| 123abc                       | 123                                         |
| abc123                       | 0                                           |
| 1.00E+03                     | 1000                                        |

#### ■ Return Value

| Err. No. | Error Message                         | Description              |
|----------|---------------------------------------|--------------------------|
| 0        | -                                     | normal termination       |
| -1301    | ERROR:fhrecvstring():NO_CONNECT:-1301 | Unconnected state        |
| -1301    | ERROR:fhrecvstring():NO_DATA:-1301    | Receive data length 0    |
| -1302    | ERROR:fhrecvstring():STRING_LEN:-1302 | Receive data length over |

#### ■ Precautions

The maximum length of the string to be received is 127 bytes (not including the delimiter). if more than 128 bytes are received, an error is returned.

The measurement result received from the Vision Sensor will be stored in the g\_FHRobotVision\_OMRON\_param.

To get the measurement result with this function, Result Output (Message) must be placed in the flow, and the settings must be as follows


| Result Output (Message) Processing Item |                              | The destination of the received measurement results                        |
|-----------------------------------------|------------------------------|----------------------------------------------------------------------------|
| Setting Target                          | Setting details              |                                                                            |
| Output device                           | IoModule2: Serial (Ethernet) | -                                                                          |
| Termination string                      | \r (Carriage Return)         | -                                                                          |
| Delimiter string                        | \x20 (Space)                 | -                                                                          |
| Output Data 0 - 9                       | numerical data(*1)           | g_FHRobotVision_OMRON_param<br>[0] -<br>g_FHRobotVision_OMRON_param<br>[9] |

\*1: The output data format should be set as follows

- Data type: Number
- Digits of integer: 6
- Digits of decimal: 4

### ■ Example

In the following example, the robot moves after receiving the measurement result of the Vision Sensor (grasping position X, Y, Z, W, P, R).









## **OMRON Corporation Industrial Automation Company**

**Kyoto, JAPAN**

**Contact : [www.ia.omron.com](http://www.ia.omron.com)**

### ***Regional Headquarters***

#### **OMRON EUROPE B.V.**

Wegalaan 67-69, 2132 JD Hoofddorp  
The Netherlands  
Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

#### **OMRON ASIA PACIFIC PTE. LTD.**

438B Alexandra Road, #08-01/02 Alexandra  
Technopark, Singapore 119968  
Tel: (65) 6835-3011 Fax: (65) 6835-3011

#### **OMRON ELECTRONICS LLC**

2895 Greenspoint Parkway, Suite 200  
Hoffman Estates, IL 60169 U.S.A.  
Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

#### **OMRON (CHINA) CO., LTD.**

Room 2211, Bank of China Tower,  
200 Yin Cheng Zhong Road,  
PuDong New Area, Shanghai, 200120, China  
Tel: (86) 21-6023-0333 Fax: (86) 21-5037-2388

**Authorized Distributor:**

©OMRON Corporation 2021-2024 All Rights Reserved.  
In the interest of product improvement,  
specifications are subject to change without notice.

**Cat. No. Z447-E1-02** 0624