OMRON

Vision Sensor FH Series **Vision System**

Robot Connection Guide

OMRON Viper Series Edition

Z448-E1-02

- NOTE -

- All rights reserved.
- No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.
- No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions.

Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Trademarks

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- This software is based in part on the work of the Independent JPEG Group.
- Microsoft, Windows, Windows Vista, Excel, and Visual Basic are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- Intel, Core and Pentium are trademarks of Intel Corporation in the U.S. and/or other countries.
- EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.
- The SD, SDHC, microSD, and microSDHC logos are trademarks of SD-3C, LLC.



- QR Code is a registered trademark of DENSO WAVE INCORPORATED.
- MELSEC is a registered trademarks of Mitsubishi Electric Corporation.

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Copyrights

Microsoft product screen shots used with permission from Microsoft.

CONTENTS

Intro	duction	2	
Term	Terms and Conditions Agreement 3		
Safe	ty Precautions	5	
Wari	ng	6	
Prec	autions for Safe Use	7	
Prec	autions for Correct Use	8	
Real	lations and Standards	9	
Dolo		10	
Reia		. 10	
Revi	sion History	11	
1.	Overview	. 12	
1.1.	Overview	. 12	
1.2.	Instructions for building a 3D Robot Vision Application	. 12	
1.3.	Robot Programs Covered in this Manual	. 13	
2.	System Configuration	. 14	
2.1. 2.2.	Cautions for Robot Equipment When Using Vision Sensor FH Series 3D Vision Sensor	. 14 . 14	
3.	Connecting Vision Sensor to Robot Controller	. 16	
3.2. 3.3	Connecting and Checking Vision Sensor and Robot Controller	. 20	
4.	Coordinate System	. 25	
4.1.	Name of Coordinate System	. 25	
5.	How to Start the Setup Program	. 27	
6.	Description of the Sample Programs	. 28	
6.1.	Connecting Vision Sensor to Robot Controller	. 30	
6.2.	Switching Scenes on the Vision Sensor	. 31	
6.3.	Moving Robot to Robot Image Position	. 31	
6.4.	Register the Current Robot Position in the Vision Sensor	. 32	
6.5.	Executing Measurements on Vision Sensor	. 33	
0.0. 6 7	Getting the Measurement Results	. 34 ຊາ	
6.8.	Moving Robot to Robot Command Position at Measurement	. 36	
6.9.	Disconnecting Vision Sensor from Robot Controller	. 37	
7.	Function Reference	. 38	
7.1.	List of Functions	. 38	
7.2	Error Message	. 38	

Introduction

Thank you for purchasing the FH Series.

This manual contains information that is necessary to use the FH Series.

Please read this manual and make sure you understand the functionality and performance of the FH Series before you attempt to use it in a control system.

Keep this manual in a safe place where it will be available for reference during operation.

Terms and Conditions Agreement

Warranty, Limitations of Liability Warranties

• Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

• Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

<u>See http://www.omron.com/global/</u> or contact your Omron representative for published information.

Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANYWAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Application Considerations Suitability of Use

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Disclaimers

Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Safety Precautions

For details on Safety Precautions, refer to Safety Precautions in the Vision System FH Series 3D Robot Vision Application Construction Guide (Cat. No. Z446).

Waring

For details on Waring, refer to Waring in the Vision System FH Series 3D Robot Vision Application Construction Guide (Cat. No. Z446).

Precautions for Safe Use

For details on Precautions for Safe Use, refer to Precautions for Safe Use in the *Vision System FH Series 3D Robot Vision Application Construction Guide (Cat. No. Z446)*.

Precautions for Correct Use

For details on Precautions for Correct Use, refer to Precautions for Correct Use in the *Vision System FH Series 3D Robot Vision Application Construction Guide (Cat. No. Z446)*.

Regulations and Standards

For details on Regulations and Standards, refer to Regulations and Standards in the *Vision System FH Series 3D Robot Vision Application Construction Guide (Cat. No. Z446)*.

Related Manuals

<Application Construction Guide>

Name of Manual	Cat. No.	Model	Purpose	Contents
Vision Sensor	Z446	FH-5050	When User	Describes the soft
FH Series		FH-SMDA-GS050B	want to	functions, setup,
3D Robot Vision			the FH	series 3D
Application			series 3D	robot vision system.
Construction			robot vision	
Guide			system.	

<Robot Manual>

Name of Manual	Cat. No.	Model	Purpose	Contents
Viper 650/850 Robot with eMB-60R USER'S GUIDE	I599	17201-360 🗆 🗆	When User want to know the setup and hardware specification s of the Viper Robot	Describes the specifications, external dimensions, part names, settings, and maintenance of the Viper series.
T20 Pendant User's manual	I601	10046-010	When User want to know how to set up and use the teaching pendant	Describes the specifications, installation, operation, and maintenance of the T20 pendant.
SmartController EX User's Guide	I602	19300-000 19200-000	When User want to Know the Setup and Specification s of SmartContr ollerEX	Describes SmartControllerEX external dimensions, part names, I/O specifications, settings, and maintenance.
Automation Control Environment (ACE) User's Guide	I603	-	When User want to know how to operate ACE	Describes how to operate ACE
eV+ language User's Guide	I604	-	When User want to Know the eV+ Language Specification	Describes the specification of the eV+ language
Robot Safety Guide	1590	-	When User want to know how to handle an industrial robot safely	Describes precautions for safe handling of the robot.

Revision History

A manual revision code appears as a suffix to the catalog number on the front and back covers of the manual.



Rev. Code	Rev. Date	Revision Contents
01	Feb. 2021	Original product
02	Jun. 2021	Clerical corrections

1. Overview

1.1. Overview

This manual describes procedures for connections and settings required for constructing robot vision applications by connecting your robot controller to the Vision Sensor FH (hereafter referred to as Vision Sensor).

Utilizing this manual and Robot Vision Application Construction Guide can reduce man-hours to connect the Vision Sensor to your robot controller, set the Vision Sensor, and create robot programs.

1.2. Instructions for building a 3D Robot Vision Application

Procedure	Reference
Creating Data Sat for Debat Vision	[3D Robot Vision Application
Creating Data Set for Robot Vision	Construction Guide] Chapter 6
\downarrow	
System Sattings for Vision Sensors	[3D Robot Vision Application
System Settings for Vision Sensors	Construction Guide] Chapter 7
↓	
Setting Communications for Robot controller	Refer to Chapter 3.1
↓	
Connecting Vision Sensor to Pobot Controller	Refer to Chapter 3.2
	Refer to Chapter 3.3
\downarrow	
Pohot Vicion Sattings for Vicion Sonsors	[3D Robot Vision Application
Robot vision Settings for vision Sensors	Construction Guide] Chapter 8
\downarrow	
Description of the sample programs	Refer to Chapter 6

Please follow the flow below for constructing 3D robot vision applications

1.3. Robot Programs Covered in this Manual

The two types of robot programs covered in this manual are output from the Robot Vision Dataset Output Tool. Each program is used for a different purpose.

Program	Program Name	Detail
Setup Program	fhsetup_main	This program allows the Vision Sensor to give
Setup Program		operating instructions to the robot to
		configure the Vision Sensor for robot vision.
		This program consists of the following
		functions
		- Send the current robot position to the Vision
		Sensor.
		- Move to the indicated position on the Vision
		Sensor.
Sample Program	fhsample main	This program is a sample of the basic
Sample Program	mounple_main	program flow for a pick application.
		In this program, the robot gives control
		instructions to the Vision Sensor.
		The program consists of the following
		functions
		- Connecting to the Vision Sensor
		- Scene switching of the Vision Sensor
		- Moving to the measurement position
		- Registering the current robot position to
		the Vision Sensor
		- Execute measurement instructions to the
		Vision Sensor
		- Receives the position of the workpiece to
		be recognized
		- Move to approach position
		- Move to the target work location (grasping
		position)
		Based on this program, a pick-and-place
		application is built by adding the robot
		movement to operate the end-effector (hand)
		and to place the workpiece.

2. System Configuration

This chapter describes the system configuration and target devices to construct robot vision applications.

2.1. Cautions for Robot Equipment

none in particular

2.2. When Using Vision Sensor FH Series 3D Vision Sensor

2.2.1. System Configuration



2.2.2. Target Devices

Device name	Manufacturer	Name	Model	Remarks
Vision Sensor	OMRON	Vision Sensor FH Series	FH-5050	Ver. 6.40 or later Controllers other than FH-5050 are not supported.
3D Camera	OMRON	3D Vision Sensor	FH-SMDA-GS050B	-
Camera Cable	OMRON	Ethernet cable super bending resistance	FHV-VNBX□M FHV-VNLBX□M	-
Camera I/O cable	OMRON	I/O cable super bending resistance	FH-VSDX-BX□M FH-VSDX-LBX□M	-
Calibration	OMRON	Handeye Calibration	FH-XCAL-R	-

target		Target		
	OMRON	Camera Calibration Target	FH-XCAL-S	-
3D Software	OMRON	3D Robot Vision Software Installer	FH-UM3D1	-
Robot controller	OMRON	Robot controller SmartController EX	19300-000	-
Dahat	OMPON	Vertical multi-joint robot Viper 650	1720 - 36000 1720 - 36020 1720 - 36010	-
RODOL	OMRON	Viper 850	1720 38000 1720 38020 1720 38010	-
Teaching pendant	OMRON	Teaching pendant T20	10046-010	-
PC software	OMRON	Data set output tool for 3D robot vision	-	Ver.1.00 Please contact us for how to obtain it.
	OMRON	Software Automation Control Environment (ACE)	-	Ver. 3.7 or later
Switching hub	OMRON	Industrial switching hub	W4S1-□□	Recommended product
USB memory	OMRON	USB memory FZ-MEM8G		Recommended product

Precautions for Correct Use

Do not use any device except mentioned above for each device of the system configuration.

内

Additional Information

This manual does not provide operations, installation, and wiring methods for each device.

For details, refer to manuals noted in Related Manuals.

3. Connecting Vision Sensor to Robot Controller

This chapter describes procedures to connect the Vision Sensor to the robot controller. Please follow the flow below for the settings.

The IP address of each device is described below.

Vision Sensor : 10.5.5.100

Robot controller: 10.5.5.101

3.1	Setting communications for the robot controller	To modify the communication settings for the robot controller, connect the PC (ACE) and the robot controller. Modify the default IP address of the robot controller with PC (ACE) according to the communication settings in the Vision Sensor.
	▼	
3.2	Verifying Ethernet Communication	Check the connection status of Ethernet using PING command.
	▼	
3.3	Verify Commands Sent/Received	Run a robot program for startup to establish the TCP/IP connection between the Vision Sensor and the robot controller. Check the communication status by sending and receiving commands.

3.1.1. Setting Communications for Robot Controller

Please follow the procedures below to set the communications for the robot controller.



	The dialog shown on the right will be displayed, set the IP address and the subnet mask for the PC so that the IP address and network part of the referred robot controller are the same, but the host part is different.	Internet Protocol Version 4 (TCP/IPv4) Properties General You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings. Obtain an IP address automatically IP address: IP address: Subnet mask: Obtain DNS server address automatically Obtain DNS server address automatically Obtain DNS server address automatically IP address: IP address automatically IP use the following DNS server: IP addresserver: IP address
4	Launch ACE.	
5	Enter the IP address of the robot controller and click [OK].	Cetting Stande
6	Select "SmartController" in the Workspace Explorer and click [Configure]. The right dialog will be displayed, select "Configure Controller" and click [Finish].	Workspace Explorer Image: Controller 101/SmartController Image: Control is SmartController 101 Image: Control is Configure Image: SmartController 101 Image: Configure Control is Configure Image: SmartController 101 Image: Configure Configure Image: Configure Controller Image: Configure Configure Configure Image: Configure Controller Image: Configure Confi

	The right dialog will be displayed, select "SYSTEM SECTION" in the "Section" area and "ipaddress" in the "Statements" area and click [Edit].	V- System Configuration Configuration
		Save Add Edit Remove
	The right dialog will be	Edit Statement - ipaddress
	displayed, change the	Statement Type
	inaddress and click [Accent]	Item Values
		loaddress 10555101 O
	Set the IP address not to overlap with other devices.	Composed Statement <pre>(paddress>10.5.5.101) Accept Cancel</pre>
	Change the IP address of the	
_	PC again based on the	
/	changed one for the robot	
	controller.	
-	Reconnect to the robot	
8	controller.	
	Right-click "V+ User Module" in the Workspace Explorer and select "Load from V+ File".	Image: Signart Controller 101 Image: Configuration Image: Signart Controller 101 Image: Configuration Image: Signart Configuration
9	Select	Name
	OmronAdept_FHRobotLib,	OmronAdept FHRobotLib.v2
	OmronAdept_FHRobotSample	OmronAdept FHRobotSample.v2
	in the folder outputted by	
	using the data set output tool	
	for the robot vision.	

Additional Information

This manual does not provide operation, installation, and wiring methods for each device.

For details, refer to manuals noted in Related Manuals.

3.2. Connecting and Checking Vision Sensor and Robot Controller

Follow the procedures below to connect the Vision Sensor and the robot controller and to check the connection status.

3.2.1. Verifying Ethernet Communication (FH Series Vision Sensor)



When 32-byte data cannot be sent/received four times and PING command timed out, check whether or not the robot controller is turned on, the wiring was correctly done, or communication settings are correct. Command Prompt Thereosff Windows [Uersion 6.1.7601] Copyright (c: 2010 Microsoft Corporation. All rights reserved. C:\Users\User>ping 10.5.5.101 Finging 10.5.5.101 with 32 hytes of data: Request timed out. Request timed out. Request timed out. Ping statistics for 10.5.5.101: Packets: Sent = 4, Received = 0. Lost = 4 (100% loss), C:\Users\User>

3.3. Verify Commands Sent/Received

Execute the setup program on the robot controller and follow the steps below to confirm that commands can be sent and received from the Vision Sensor.







Additional Information

This manual does not provide operation, installation, and wiring methods for each device.

For details, refer to manuals noted in Related Manuals.

4. Coordinate System

This chapter describes the coordinate system handled by the robot vision application.

4.1. Name of Coordinate System

The robot coordinate system of the Vision Sensor uses the name shown in the table below.

Coordinate System	Meaning
Robot Base Coordinate	Coordinate system with the robot base as the
System	origin
Local Coordinate System	User-defined coordinate system
Flange Coordinate system	Coordinate system defined on the flange surface
	of the robot
Tool Coordinate System	The coordinate system is defined in the tool
	center point by offsetting the origin of the
	flange coordinates system.
Camera Coordinate System	With the optical center of the camera as the
	starting point, the X and Y axes are the
	horizontal and vertical directions of the image,
	and the Z axis is the optical axis of the camera.



The orientation of the coordinate axes of each coordinate system depends on the robot. Please refer to the instruction manual for each robot.

There are the following differences between the names of the coordinate system in the Vision Sensor and the coordinate system in the OMRON Viper series.

Vision Sensor	OMRON Viper Series
Local Coordinate System	Local reference coordinate System
Tool Coordinate System	Tool Coordinate System

5. How to Start the Setup Program

This chapter describes how to start the setup program. To set the robot vision of the Vision Sensor, the setup program must be running on the robot side. Establish the connection between the Vision Sensor and the robot controller by [3. Connecting Vision Sensor to Robot Controller]



6. Description of the Sample Programs

This chapter describes design examples of robot programs to construct applications using a sample program (fhsample_main()).

You can understand how to implement a robot program to control the Vision Sensor as shown in the following figure.



The sample program is implemented with the following procedures. When building an actual application, design, implement and test the robot program, utilizing the functions described in Chapter 7.



Precautions for Correct Use

r**h**ì

The implementation procedures for robot programs noted in this chapter are a reference. You should design, implement, and test actually operating robot programs based on your specific environment and applications.

In the Main Window or "Layout setup" of the Vision Sensor, check that the "Output" of the current layout is ON. If the setting were OFF, the Vision Sensor will not output measurement values.

6.1. Connecting Vision Sensor to Robot Controller

For connecting the Vision Sensor to the Robot Controller, follow the procedures below.

1	* Omitted (Refer to the source code)		
Ŧ	Declare internal variables.		
2	Execute the initialization function (fhdefglobal) for external variables. ; (2)Initialaize global variables CALL fhdefglobal() socket_no = 0 err_no = success cur_local_coord = 0 cur_tool_coord = 0 Cmd_res = 0 TYPE "Initialization Done."		
3	Set the IP address and the port number of the Vision Sensor to the variables. (When changing those from the default.) ; (1)Set the network configuration ; You have to configure the following communication settings. \$ip_address = "10.5.5.100" IP address \$port_no = "9876" Port number retries_connect = 2 ;times timeout_connect = 4 ;sec retries_connect = 2 ;times timeout_connect = 4 ;sec		
4	Set the variables as arguments for the connection function (fhconnect) to the Vision Sensor (FH server) and execute it. ; (2)Connect to the FH server ;; (2)Connected to the FH server ;; (2)Connected == 0 DO Connection function with the Vision Sensor (FH server) CALL fhconnect(\$ip_address, \$port_no, retries_connect, timeout_connect, socket_no, err_no) ; Error check IF err_no <> success THEN TYPE "ERROR: fhsample_main(): Connection failed. Exit:", err_no GOTO 11 END END TYPE "Connection Done."		

Set a scene number for the switching destination to a variable. 1 ; (1)Change the scene of the FH $\,$ You have to select a scene No. for your application. 0 : Workpiece picking scene 1 : Grasp adjustment scene 2: Workpiece picking scene Scene number scene no = 0Set the variables as arguments to the scene switching command execution 2 sample function (fhsample_chgscn) to the Vision Sensor and execute it. CALL fhsample_chgscn(socket_no, retry_count, time_out, scene_no, err_no) Scene switching command execution sample function ; Error check IF err_no <> success THEN TYPE "ERROR: fhsample_main(): Connection failed. Exit:", err_no **GOTO 10** END TYPE "Change scene No. Done."

For a processing to switch scenes on the Vision Sensor, follow the procedures below.

6.3. Moving Robot to Robot Image Position

For a processing to move the robot to the robot image position, follow the procedures below.





6.4. Register the Current Robot Position in the Vision Sensor

To register the current robot position to the Vision Sensor, use "fhsample_regpos".

6.5. Executing Measurements on Vision Sensor

Send the measurement command to the Vision Sensor and receives a response to that command.



6.6. Getting the Measurement Results

The Vision Sensor measurements are received using "fhrunrecvval". In this sample program, it is assumed that the Vision Sensor measurements are sent in the order "TJG X Y Z W P R".

1	In order to receive the measurement results from the Vision Sensor, we execute				
	unrecvval" and check the received overall judgment value.				
	;Get the Measurement Result				
	CALL fhrunrecvval(retry_count, time_out, socket_no, param[], err_no)				
	numerical sequence receiving function				
	;Error check				
	IF err_no <> success THEN				
	GOTO 10				
	END				
	;Total Judge Check				
	IF param[0] <> 1 THEN				
	GOTO 10 If the overall judgment is not OK, exit the program				
2	Set the measurement results to the variables.				
2	: Measurement results				
	res_cmd_pos_x = param [1]				
	res_cmd_pos_y = param [2]				
	res_cmd_pos_z = param [3]				
	res_cmd_pos_w = param [4]				
	res_cmd_pos_p= param [5]				
	res_cmd_pos_r = param [6]				
	I YPE "Measurement Done"				

6.7. Moving Robot to Robot Approach Position at Measurement.

For a processing to move the robot to the robot approach position at measurement, follow the procedures below.





6.8. Moving Robot to Robot Command Position at Measurement

For a processing to move the robot to the robot command position at measurement, follow the procedures below.

1	By the procedures at step 2 in Chapter 6.6, check that the measurement		
	results are stored in variables.		
2	Set the variables as arguments for the robot motion sample function		
2	(fhsample_move) and execute it.		
	; (6)Move the robot to the measuring position.		
	; You have to edit this section for your application.		
	; e.g: Adding an end effector control, depart path motion, etc.		
	;!!!!!!! CAUTION !!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!		
	; The following function drives a robot motion immediately.		
	; Confirm the settings before execution.		
	;11111111111111111111111111111111111111		
	CALL fhsample_move(res_cmd_pos_x, res_cmd_pos_y, res_cmd_pos_z, res_cmd_pos_w,		
	res cmd pos p, res cmd pos r)		
	; Error check Robot motion sample function		
	; Error check Robot motion sample function IF err_no <> success THEN		
	; Error check IF err_no <> success THEN TYPE "ERROR: fhsample_main(): The measuring robot position is out of range :", err_no		
	; Error check IF err_no <> success THEN TYPE "ERROR: fhsample_main(): The measuring robot position is out of range :", err_no GOTO 10		
	; Error check IF err_no <> success THEN TYPE "ERROR: fhsample_main(): The measuring robot position is out of range :", err_no GOTO 10 END		
	; Error check IF err_no <> success THEN TYPE "ERROR: fhsample_main(): The measuring robot position is out of range :", err_no GOTO 10 END TYPE "Move to the measuring position Done."		
	; Error check IF err_no <> success THEN TYPE "ERROR: fhsample_main(): The measuring robot position is out of range :", err_no GOTO 10 END TYPE "Move to the measuring position Done."		
	; Error check IF err_no <> success THEN TYPE "ERROR: fhsample_main(): The measuring robot position is out of range :", err_no GOTO 10 END TYPE "Move to the measuring position Done." END TYPE "Move to the measuring position Done."		
	<pre>; Error check ; Error check IF err_no <> success THEN TYPE "ERROR: fhsample_main(): The measuring robot position is out of range :", err_no GOTO 10 END TYPE "Move to the measuring position Done." • These operations drive the robot. • Operate the robot in the state whereby pressing the</pre>		

6.9. Disconnecting Vision Sensor from Robot Controller

For a processing to disconnect the Vision Sensor from the Robot Controller, follow the procedures below.



7. Function Reference

This chapter describes the functions for building a robot vision application

7.1. List of Functions

Function Name	Description	Reference
fhdefglobal	Initialize a global variable.	Chapter 7.3.1
fhconnect	Connect to the Vision Sensor	Chapter 7.3.2
fhclose	Disconnects from the Vision Sensor	Chapter 7.3.3
fhsample_chgscn	Switching the scene of the Vision Sensor	Chapter 7.3.4
fhsample_regpos	Register the current robot coordinates to the	Chapter 7.3.5
	Vision Sensor	
fhsample_trig	Sends measurement commands to the Vision	Chapter 7.3.6
	Sensor and receives the measurement results	
	from the Vision Sensor	
fhsample_move	Move the robot	Chapter 7.3.7
fhrunsendcmd	Send a no-procedure command to the Vision	Chapter 7.3.8
	Sensor	
fhrunrecvres	Receive a command response from the Vision	Chapter 7.3.9
	Sensor	
fhrunrecvval	Receive numerical data from the Vision Sensor	Chapter 7.3.10

This is a list of functions that can be used by the actual driving robot program.

7.2. Error Message

The error message will be displayed in the ACE monitor window.

7.3. Function Details

7.3.1. fhdefglobal

Function
 Initialize a global variable.

Syntaxfhdefglobal()

ParametersNone

Remarks

Define the global variables that are necessary to use the robot application.

Return Value None

PrecautionsBe sure to call this function before using any other function.

Example
 The following example defines a global variable.
 CALL fhdefglobal()

7.3.2. fhconnect

Function

Connect to the Vision Sensor

Syntax

fhconnect(\$ip_address, \$port_no, retries_connect, timeout_connect, socket_no, err_no)

Parameter Name	Input/Output	Data type	Description
\$ip_address	Input	String	IP address of the Vision Sensor
\$port_no	Input	String	Port number of the Vision Sensor
retries_connect	Input	Real	Number of connections retries (0 - 99)
timeout_connect	Input	Real	Connection Timeout Time (0 to 99sec)
socket_no	Output	Real	Number of sockets already connected
			to the Vision Sensor
err_no	Output	Real	Error number
			Store the result of the execution of this
			function.

Parameters

Remarks

Connect to the Vision Sensor specified in the IP address and port number parameters. Requests a connection every hour specified in the Connection Timeout Time parameter. Request a connection as many times as specified in the connection retry count parameter. Return an error if the connection fails.

Return an error if the parameter is out of the input range

	Return	Value
_		, and c

Err. No.	Error Message	Description	
0	-	normal termination	
-1200	ERROR:fhconnect():RETRY:-1200	Out of connection retry count input	
		range	
	ERROR:fhconnect():TIMEOUT:-1200	Connection Timeout Time Input	
		Range	
-1201	ERROR:fhconnect():ATTACH:-1201	attaching error	
		* This error occurs when the network	
		configuration for the device of the	
		specified IP address fails.	
-1202	ERROR:fhconnect():RETRY:-1202	Connection retry count over	
-1204	ERROR:fhconnect():TIMEOUT:-1204	Connection timeout time is over.	

Precautions

Only one Vision Sensor can be connected to the robot controller. If you want to connect to another Vision Sensor, disconnect from the connected Vision Sensor.

Example

In the following example, we will connect to the Vision Sensor with IP address "10.5.5.100" and port number "9876".

\$ip_address = "10.5.5.100"
\$port_no = "9876"
retries_connect = 2
timeout_connect = 4
socket_no = 0
CALL fhconnect(\$ip_address, \$port_no, retries_connect, timeout_connect, socket_no,
err_no)

7.3.3. fhclose

■ function

Disconnects from the Vision Sensor

Syntax

fhclose(socket_no, err_no)

Parameter

Parameter Name	Input/Output	Data type	Description
socket_no	Input	Real	Number of sockets already connected
			to the Vision Sensor
err_no	Output	Real	Error number
			Store the result of the execution of
			this function.

Remarks

Disconnects from the Vision Sensor

Return Value

Err. No.	Error Message	Description
0	-	normal termination
-1701	ERROR:fhclose():FCLOSE:-1701	disconnection failure
	ERROR:fhclose():DETCH:-1701	detachment failure
		* This error occurs when the specified
		socket is not released from the control
		of the application program.

Precautions

None

■ Example

The following example closes the connection to the Vision Sensor connected by fhconnect.

CALL fhclose(socket_no, err_no)

7.3.4. fhsample_chgscn

Function

Switching the scene of the Vision Sensor.

Syntax

fhsample_chgscn(socket_no, retry_count, time_out, scene_no, err_no)

Parameter			
Parameter Name	Input/Output	Data type	Description
socket_no	Input	Real	Number of sockets already connected
			to the Vision Sensor
retry_count	Input	Real	Number of receive retries (0 - 99)
time_out	Input	Real	Receive timeout time (0 to 99sec)
scene_no	Input	Real	Scene number to switch to (0 - 127)
err_no	Output	Real	error number
			Store the result of the execution of
			this function.

Remarks

Sends a command to the Vision Sensor to switch to the scene number specified in the parameter.

It returns an error if this command is not connected to the Vision Sensor.

Return an error is returned if the scene number specified in the parameters is out of the input range.

Returns an error if a response is received from the Vision Sensor indicating that the scene change command failed.

Err. No.	Error Message	Description
0	-	normal termination
-1000	ERROR:fhsample_chgscn():Invalid Scene	Out of scene numbering
	No.:-1000	range
-1300	ERROR:fhrecvstring():RETRY:-1300	Out of the range of receive
		retry count input
	ERROR:fhrecvstring():TIMEOUT:-1300	Out of the input range for the
		receive timeout count
-1301	ERROR:fhrecvstring():NO_CONNECTION:-	Calling in the unconnected
	1301	state
-1303	ERROR:fhrecvstring():RETRY:-1303	Receive retry count overrun

■ Return value

-1304	ERROR:fhrecvstring():TIMEOUT:-1304	Receive timeout time is over.
-1601	ERROR:fhsample_chgscn():No	Calling in the unconnected
	Connection:-1601	state
-1800	ERROR:fhsample_chgscn():Scene Change	Response NG
	Failed:-1800	

Precautions

None

■ Example

In the following example, we will switch to scene 0.

retry_count = 2 time_out = 4 scene_no = 0

CALL fhsample_chgscn(socket_no, retry_count, time_out, scene_no, err_no)

7.3.5. fhsample_regpos

Function

Register the current robot position to the Vision Sensor.

■ Syntax

fhsample_regpos(socket_no, retry_count, time_out, err_no)

Parameter				
Parameter	Input/Output	Data	Description	
Name		type		
socket_no	Input	Real	Number of sockets already connected to the	
			Vision Sensor	
retry_count	Input	Real	Number of receive retries (0 - 99)	
time_out	Input	Real	Receive timeout time (0 to 99sec)	
err_no	Output	Real	error number	
			Store the result of the execution of this	
			function.	

Remarks

Get the current robot position and register the current robot position to the Vision Sensor. Return an error if this function is called while the Vision Sensor is not connected. Returns an error if a response of current robot position registration failure is received from the Vision Sensor.

■ Return value

Err. No.	Error Message	Description
0	-	normal termination
-1300	ERROR:fhrecvstring():RETRY:-1300	Out of the range of receive
		retry count input
	ERROR:fhrecvstring():TIMEOUT:-1300	Out of the input range for the
		receive timeout count
-1303	ERROR:fhrecvstring():RETRY:-1303	Receive retry count overrun
-1304	ERROR:fhrecvstring():TIMEOUT:-1304	Receive timeout time is over.
-1601	ERROR:fhsample_regpos():No	Calling in the unconnected
	Connection:-1601	state
-1800	ERROR:fhsample_regpos():ERROR_TRIG:	Response NG
	-1800	

Precautions

None

■ Example

In the following example, the current robot position is registered to the Vision Sensor.

retry_count = 2 time_out = 4

CALL fhsample_regpos(socket_no, retry_count, time_out, err_no)

7.3.6. fhsample_trig

Function

Sends measurement commands to the Vision Sensor and receives the measurement results from the Vision Sensor

Syntax

fhsample_trig(socket_no, retry_count, time_out, param[], err_no)

Parameter	Input/Output	Data	Description
Name		type	
socket_no	Input	Real	Number of sockets already connected to the
			Vision Sensor
retry_count	Input	Real	Number of receive retries (0 - 99)
time_out	Input	Real	Receive timeout time (0 to 99sec)
param[]	Output	Real	param[0]:Target X coordinate
			param[1]:Target Y coordinate
			param[2]:Target Z coordinate
			param[3]:Target W(yaw) coordinate
			param[4]:Target P(pitch) coordinate
			param[5]:Target R (roll) coordinates
err_no	Output	Real	error number
			Store the result of the execution of this
			function.

Parameter

Remarks

Sends measurement commands to the Vision Sensor.

Receives the measurement results from the Vision Sensor and get the robot position.

Returns an error if called while not connected to the Vision Sensor.

Returns an error if a measurement command failure response is received from the Vision Sensor.

Returns an error if the Vision Sensor's overall judgment is NG.

Return Value

Err. No.	Error Message	Description
0	-	normal termination
-1300	ERROR:fhrecvstring():RETRY:-1300	Out of the range of
		receive retry count input
	ERROR:fhrecvstring():TIMEOUT:-1300	Out of the input range
		for the receive timeout
		count
-1303	ERROR:fhrecvstring():RETRY:-1303	Receive retry count
		overrun
-1304	ERROR:fhrecvstring():TIMEOUT:-1304	Receive timeout time is
		over.
-1502	ERROR:fhmeasureresult():PARAM_NUM:-	Abnormal number of
	1502	parameters
-1601	ERROR:fhsample_trig():No Connection:-	Calling in the
	1601	unconnected state
-1800	ERROR:fhmeasureresult():TRIG_NG:-1800	Response NG
-1801	ERROR:fhmeasureresult():TJG_NG:-1801	Overall judgment NG

Precautions

The measurement result received from the Vision Sensor will be stored in the param[]. To get the measurement result with this function, Result Output (Message) must be placed in the flow, and the settings must be as follows

Result Output (M	The destination of the	
Setting Target	Setting details	received measurement
		results
Output device	IoModule2: Serial (Ethernet)	-
Termination string	∖r (Carriage Return)	-
Delimiter string	∖x20 (Space)	-
Output data 0	Overall judgment(*1)	(Do not store)
Output data 1	Robot command position X(*1)	param[0]
Output data 2	Robot command position Y(*1)	param[1]
Output data 3	Robot command position Z(*1)	param[2]
Output data4	Robot command position W(*1)	param[3]
Output data 5	Robot command position P(*1)	param[4]
Output data6	Robot command position R(*1)	param[5]

*1: The output data format should be set as follows

- Data type: Number
- Digits of integer: 6
- Digits of decimal: 4

Example

In the following example, a measurement command is sent to the Vision Sensor, and after receiving the measurement result from the image sensor, the robot moves to the position of the measurement result.

retry_count = 2 time_out = 4

CALL fhsample_trig(socket_no, retry_count, time_out, param[], err_no)

res_cmd_pos_x = param[0]
res_cmd_pos_y = param[1]
res_cmd_pos_z = param[2]
res_cmd_pos_w = param[3]
res_cmd_pos_p = param[4]
res_cmd_pos_r = param[5]

CALL fhsample_move(res_cmd_pos_x, res_cmd_pos_y, res_cmd_pos_z, res_cmd_pos_w, res_cmd_pos_p, res_cmd_pos_r, err_no)

7.3.7. fhsample_move

FunctionMove the robot

Syntax

fhsample_move(pos_x, pos_y, pos_z, pos_w, pos_p, pos_r, err_no)

Parameter

Parameter Name	Input/Output	Data	Description
		type	
pos_x	Input	Real	Moving target robot coordinates X
pos_y	Input	Real	Moving target robot coordinates Y
pos_z	Input	Real	Moving target robot coordinates Z
pos_w	Input	Real	Moving target robot coordinates W
pos_p	Input	Real	Moving target robot coordinates P
pos_r	Input	Real	Moving target robot coordinates R
err_no	Output	Real	error number
			Store the result of the execution of this
			function.

Remarks

Moves the robot to the position specified by the parameter.

Returns an error if the target robot position is out of the movement range.

Return Value

Err. No.	Error Message	Description
0	-	normal termination
-1503	ERROR:fhsample_move():The Robot Position	out of range error
	is Out of Range:-1503	

Precautions

None

Example

In the following example, Move the robot to the (X,Y,Z,W,P,R) = (300,0,200,0,180,0)

pos_x = 300
pos_y = 0
pos_z = 200
pos_w = 0
pos_p = 180
pos_r = 0

CALL fhsample_move(pos_x, pos_y, pos_z, pos_w, pos_p, pos_r, err_no)

7.3.8. fhrunsendcmd

Function

Send a no-procedure command to the Vision Sensor

Syntax

fhrunsendcmd(socket_no, cmd_arg_num, \$cmd_name, \$cmd_arg[], err_no)

Parameter	Input/Output	Data	Description
Name		type	
socket_no	Input	Real	Number of sockets already connected to
			the Vision Sensor
cmd_arg_num	Input	Real	Number of no-procedural command
			arguments to be sent to the Vision Sensor
			(0 to 5)
\$cmd_name	Input	String	No-procedural commands to be sent to
			the Vision Sensor
\$cmd_arg[]	Input	String	cmd_arg[0]: Argument 1 of the no-
			procedure command sent to the Vision
			Sensor(string).
			cmd_arg[1]: Argument 2 of the no-
			procedure command sent to the Vision
			Sensor(string).
			cmd_arg[2]: Argument 3 of the no-
			procedure command sent to the Vision
			Sensor(string).
			cmd_arg[3]: Argument 4 of the no-
			procedure command sent to the Vision
			Sensor(string).
			cmd_arg[4]: Argument 5 of the no-
			procedure command sent to the Vision
			Sensor(string).
err_no	Output	Real	error number
			Store the result of the execution of this
			function.

Parameter

Remarks

Sends a no-procedure command to the Vision Sensor, concatenating the parameters according to the following format.

If the number of no-protocol command arguments is out of the input range, an error is returned.

<Format>

No-protocol	CD(*1)	Command	CD	Command	CD	 Command
command	SP(1)	argument 1	35	argument 2	35	 argument n(*2)

*1: "SP" is space

*2: The command argument n depends on the number of non-procedural command arguments.

Return Value

Err. No.	Error Message	Description
0	-	normal termination
-1506	ERROR:fhrunsendcmd():Invalid Command	The number of no-
	Argument No.:-1506	procedural command
		arguments is out of the
		input range.
-1601	ERROR:fhsendstring():NO_CONNECTION:-	Calling in the
	1601	unconnected state
	ERROR:fhsendstring():NO_DATA:-1601	Send string length 0
	ERROR:fhsendstring():WRITE:-1601	Send failure
-1602	ERROR:fhsendstring():STRING_LEN:-1602	Send string length over

Precautions

The length of the string of the no-stepping command that can be sent is 127 bytes (not including the delimiter).

Set the parameters of \$cmd_name and \$cmd_arg[] so that the length of the string of the no-procedure command to be sent does not exceed 127 bytes.

Example

The following example shows how to send the measurement command "MEASURE" to the Vision Sensor

\$cmd_name = "MEASURE" \$cmd_arg[0] = "" \$cmd_arg[1] = "" \$cmd_arg[2] = "" \$cmd_arg[3] = "" \$cmd_arg[4] = "" cmd_arg_num = 0

CALL fhrunsendcmd(socket_no, cmd_arg_num, \$cmd_name, \$cmd_arg[], err_no)

7.3.9. fhrunrecvres

Function

fhrunrecvres

Syntax

fhrunrecvres(retries_recv, timeout_recv, socket_no, cmd_res, err_no)

Parameter Name	Input/Output	Data	Description	
		type		
retries_recv	Input	Real	Number of receive retries (0 - 99)	
timeout_recv	Input	Real	Receive timeout time (0 to 99sec)	
socket_no	Input	Real	Number of sockets already connected to	
			the Vision Sensor	
cmd_res	Output	Real	Command response results	
			(1: Command response "OK" -1:	
			Command response other than "OK")	
err_no	Output	Real	error number	
			Store the result of the execution of this	
			function.	

Parameter

Remarks

Receive the response (command response) to the no-procedure command sent to the Vision Sensor.

If the command response is OK, assign 1 to the command response result cmd_res.

If the command response is not OK, assign "-1" to the command response result cmd_res.

Return Value

Err. No.	Error Message	Description
0	-	normal termination
-1300	ERROR:fhrecvstring():RETRY:-1300	Out of the range of
		receive retry count
		input
	ERROR:fhrecvstring():TIMEOUT:-1300	Out of the input
		range for the receive
		timeout count
-1301	ERROR:fhrecvstring():NO_CONNECTION:-1301	Calling in the
		unconnected state
-1303	ERROR:fhrecvstring():RETRY:-1303	Receive retry count
		overrun
-1304	ERROR:fhrecvstring():TIMEOUT:-1304	Receive timeout
		time is over.

Precautions

None

Example

In the following example, a command response is received from the Vision Sensor, and if the received command response is not OK (0), the program is terminated.

retry_count = 2
time_out = 4
CALL fhrunrecvres(retry_count, time_out, socket_no, cmd_res, err_no)

```
IF cmd_res <> 1 THEN
GOTO 10
END
```

7.3.10. fhrunrecvval

Function

Receive numerical data from the Vision Sensor

Syntax

fhrunrecvval(retries_recv, timeout_recv, socket_no, param[], err_no)

Parameter Name	Input/Output	Data	Description		
		type			
retries_recv	Input	Real	Number of receive retries (0 - 99)		
timeout_recv	Input	Real	Receive timeout time (0 to 99sec)		
socket_no	Input	Real	Number of sockets already connected to		
			the Vision Sensor		
param[]	Output	Real	Results of the analysis of the received		
			numerical sequence (Element count: 10)		
err_no	Output	Real	error number		
			Store the result of the execution of this		
			function.		

Parameter

Remarks

This function stores the numerical data sent from the Vision Sensor into the variable specified by the parameter.

This function outputs up to 10 values.

If there are more than 11 numbers, this function outputs only the first 10.

If the length of the segmented string is longer than 12 bytes, this function returns an error of abnormal parameter length.

Returns an error if the number of numeric data is zero.

The following is an example of the output when a string is included.

The string before conversion	The result of the analysis after conversion			
abc	0			
123abc	123			
abc123	0			
1.00E+03	1000			

<Conversion example>

Return Value

Err. No.	Error Message	Description
0	-	normal termination
-1300	ERROR:fhrecvstring():RETRY:-1300	Out of the range of
		receive retry count
		input
	ERROR:fhrecvstring():TIMEOUT:-1300	Out of the input
		range for the receive
		timeout count
-1301	ERROR:fhrecvstring():NO_DATA:-1301	Receive data length 0
	ERROR:fhrecvstring():NO_CONNECTION:-1301	Calling in the
		unconnected state
-1302	ERROR:fhrecvstring():STRING_LEN:-1302	Receive data length
		over
-1303	ERROR:fhrecvstring():RETRY:-1303	Receive retry count
		overrun
-1304	ERROR:fhrecvstring():TIMEOUT:-1304	Receive timeout
		time is over.
-1502	ERROR:fhparseval():PARAM_TOO_LONG:-1502	Abnormal parameter
		length
-1502	ERROR:fhparseval():PARAM_NUM:-1502	Abnormal number of
		parameters
-1504	ERROR:fhparseval():NO_CMD:-1504	The length of the
		string to be divided is
		0.

Precautions

The maximum length of the string to be received is 127 bytes (not including the delimiter). if more than 128 bytes are received, an error is returned.

The measurement result received from the Vision Sensor will be stored in the param[]. To get the measurement result with this function, Result Output (Message) must be placed in the flow, and the settings must be as follows

Result Output (M	The destination of the	
Setting Target	Setting details	received measurement
		results
Output device	IoModule2: Serial (Ethernet)	-
Termination string	∖r (Carriage Return)	-
Delimiter string	∖x20 (Space)	-
Output Data 0 - 9	numerical data(*1)	param[0] - param[9]

*1: The output data format should be set as follows

- Data type: Number
- Digits of integer: 6
- Digits of decimal: 4

Example

In the following example, the program receives a sequence of numbers sent by the Vision Sensor and exits the program if the first received data is not 1.

retry_count = 2 time_out = 4

CALL fhrunrecvval(retry_count, time_out, socket_no, param[], err_no)

```
IF param[0] <> 1 THEN
GOTO 10
END
```

OMRON Corporation Kyoto, JAPAN

Industrial Automation Company

Contact: www.ia.omron.com

Regional Headquarters OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD. No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2021 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. Z448-E1-02