# OMRON

**AC Servomotors/Servo Drives** 

1S-series with Built-in

# **EtherCAT® Communications**

# Incremental Encoder Type User's Manual

R88M-1L□/-1M□ (AC Servomotors)

R88D-1SN□-ECT (AC Servo Drives)







#### NOTE -

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.

No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

#### **Trademarks**

- Sysmac and SYSMAC are trademarks or registered trademarks of OMRON Corporation in Japan and other countries for OMRON factory automation products.
- EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- Safety over EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

# Introduction

Thank you for purchasing a 1S-series Servo Drive. This User's Manual describes the installation and wiring methods of the 1S-series Incremental Encoder Type Servomotors and parameter setting method which is required for the operation, as well as troubleshooting and inspection methods. For the contents that are not described in this manual, refer to the AC Servomotors/Servo Drives 1S-series with Built-in EtherCAT® Communications User's Manual (1586).

#### **Intended Audience**

This User's Manual is intended for the following personnel, who must also have electrical knowledge (certified electricians or individuals who have equivalent knowledge).

- · Personnel in charge of introducing the FA equipment
- · Personnel in charge of designing the FA systems
- · Personnel in charge of installing and connecting the FA equipment
- · Personnel in charge of managing the FA systems and facilities

#### **Notice**

This User's Manual contains information you need to know to correctly use the 1S-series Servo Drives and peripheral equipment.

Before using the Servo Drive, read this User's Manual and gain a full understanding of the information provided herein.

After you finished reading this User's Manual, keep it in a convenient place so that it can be referenced at any time.


Make sure this User's Manual is delivered to the end user.

# **Manual Structure**


This section explains the page structure and symbol icons.

# **Page Structure**

The following page structure is used in this manual.



Note The above page is only a sample for illustrative purposes. It is not the actual content of this User's Manual.



Note This illustration is provided only as a sample. It may not literally appear in this manual.

# **Special Information**

Special information in this manual is classified as follows:



#### **Precautions for Safe Use**

Precautions on what to do and what not to do to ensure safe usage of the product.



#### **Precautions for Correct Use**

Precautions on what to do and what not to do to ensure proper operation and performance.



#### **Additional Information**

Additional information to read as required.

This information is provided to increase understanding or make operation easier.



#### **Version Information**

Information on differences in specifications and functionality for Servo Drives with different unit versions and for different versions of the Sysmac Studio is given.


# **Manual Configuration**

This User's Manual consists of the following sections.

Read the necessary section or sections by reference to the following table.

	Section	Outline		
Section 1	Features and System Configuration	This section explains the features of the Servo Drive and name of each part.		
Section 2	Models and Exter- nal Dimensions	·····,		
Section 3	Specifications  This section provides the general specifications, characteristics, encoder specifications of the Servomotors and other peripheral devices.			
Section 4	Configuration and Wiring This section explains the conditions for installing Servomotors, the wiring methods including wiring conforming to EMC Directives.			
Section 5	Details on Servo Parameters This section explains the details related to the Servomotors, including the values, settings, and the display.			
Section 6	Operation This section provides the operational procedure and explains how in each mode.			
Section 7	Troubleshooting	This section explains the items to check when problems occur, and trouble-shooting by the use of error displays or operation state.		
Section 8	8 Maintenance and Inspection Inspection Maintenance and Inspection Inspection Maintenance and Inspection Maintenance Insp			
Appendices		The appendices provide explanation for the profile that is used to control the Servo Drive, lists of objects, and Sysmac error status codes.		

# **Sections in this Manual**



# **CONTENTS**

Ir	ntro	duction	1
M	lanı	ual Structure	2
M	lanı	ual Configuration	4
s	ecti	ions in this Manual	5
Te	erm	s and Conditions Agreement	10
		ty Precautions	
		s to Check After Unpacking	
		ted Manuals	
		inology	
R	Revis	sion History	31
Section	1	Features and System Configuration	
1	I-1	Outline	1-2 1-3
1	I- <b>2</b>	1-1-3 Object Dictionary  System Configuration	
	1-3	Names and Functions	
1	I-4	Applicable Standards  1-4-1 EU Directives  1-4-2 UL and CSA Standards  1-4-3 Korean Radio Regulations (KC)  1-4-4 SEMI F47  1-4-5 Australian EMC Labeling Requirements (RCM)	1-8 1-9 1-10
1	1-5	Unit Versions	<b>1-11</b> 1-11
Section	2	Models and External Dimensions	
2	2-1	Servo System Configuration	2-2
2	2-2	How to Read Model Numbers 2-2-1 Servomotor	
2	2-3	Model Tables	2-5 2-6 2-7
2	2-4	External and Mounting Dimensions	2-12

	2-4-1 Servomotor Dimensions	2-12
Section 3	Specifications	
3-1	Servo Drive Specifications	3-2
	3-1-1 Characteristics	
	3-1-2 Main Circuit and Motor Connections	
	3-1-3 Encoder Connector (CN2) Specifications	
	3-1-4 Overload Characteristics (Electronic Thermal Function)	
3-2	Servomotor Specifications	
	3-2-1 General Specifications	
	3-2-2 Encoder Specifications	
3-3	Cable and Connector Specifications	
3-3	3-3-1 Encoder Cable Specifications	
	3-3-2 Motor Power Cable Specifications	
	3-3-3 Resistance to Bending of Flexible Cable	
	3-3-4 Connector Specifications	
Section 4	Configuration and Wiring	
4-1	Installation Conditions	4.0
4-1	4-1-1 Servomotor Installation Conditions	
4.0		
4-2	Wiring4-2-1 Connector Attachment Procedure	
	4-2-2 Power/Brake Connector Attachment Procedure	
4-3	Wiring Conforming to EMC Directives	
	4-3-1 Peripheral Equipment Connection Examples	
Section 5	Details on Servo Parameters	
5-1	Object Description Format	5-2
5-2	External Device-related Objects	
5-3	Encoder-related Objects	
Section 6	Operation	
6-1	Operational Procedure	6-2
6-2	Preparing for Operation	6-3
	6-2-1 Items to Check Before Turning ON the Power Supply	
	6-2-2 Turning ON the Power Supply	6-4
	6-2-3 Checking the Displays	6-5
6-3	Test Run	6-7
	6-3-1 Preparations for Test Run	
	6-3-2 Test Run via USB Communications from the Sysmac Studio	6-8
Section 7	Troubleshooting	
7-1	Actions for Problems	7-2
• •	7-1-1 Preliminary Checks When a Problem Occurs	
	7-1-2 Precautions When a Problem Occurs	

		7-1-3 Replacing the Servomotor or Servo Drive	7-4
	7-2	Warnings	7-6
		7-2-1 Related Objects	7-6
		7-2-2 Warning List	7-8
	7-3	Errors	7-10
		7-3-1 Error List	
		7-3-2 Deceleration Stop Operation at Errors	7-12
	7-4	Information	7-13
		7-4-1 Related Objects	
		7-4-2 Information List	7-13
	7-5	Troubleshooting	7-14
		7-5-1 Troubleshooting Using Error Displays	7-14
		7-5-2 Troubleshooting Using AL Status Codes	
		7-5-3 Troubleshooting Using the Operation State	7-39
Sectio	n 8	Maintenance and Inspection	
	8-1	Periodic Maintenance	8-2
	8-2	Servo Drive Lifetime	8-3
	8-3	Servomotor Lifetime	8-4
Apper	dice	es e	
	A-1	Sysmac Error Status Codes	A-2
		A-1-1 Error List	A-2
		A-1-2 Error Descriptions	A-14
Index			

# **Terms and Conditions Agreement**

### Warranty, Limitations of Liability

### **Warranties**

#### Exclusive Warranty

Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

#### Limitations

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

#### Buyer Remedy

Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

# Limitation on Liability; Etc

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

### **Application Considerations**

### **Suitability of Use**

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

### **Programmable Products**

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

#### **Disclaimers**

### Performance Data

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

# **Change in Specifications**

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

#### **Errors and Omissions**


Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

# **Safety Precautions**

- To ensure that the 1S-series Servomotor/Servo Drive as well as peripheral equipment are used safely and correctly, be sure to read this Safety Precautions section and the main text before using the product. Learn all items you should know before use, regarding the equipment as well as the required safety information and precautions.
- · Make an arrangement so that this User's Manual also gets to the end user of this product.
- After reading this User's Manual, keep it in a convenient place so that it can be referenced at any time.

#### **Explanation of Displays**


- The precautions indicated here provide important information for safety. Be sure to heed the information provided with the precautions.
- The following signal words are used to indicate and classify precautions in this User's Manual.



Even those items denoted by the caution symbol may lead to a serious outcome depending on the situation. Accordingly, be sure to observe all safety precautions.

# **Explanation of Symbols**

This User's Manual uses the following symbols.





The filled circle symbol indicates operations that you must do.

The specific operation is shown in the circle and explained in text.

This example indicates a requirement for the ground.

### **Precautionary Information**

- Illustrations contained in this manual sometimes depict conditions without covers and safety shields
  for the purpose of showing the details. When you use this product, be sure to install the covers and
  shields as specified and use the product according to this manual.
- If the product has been stored for an extended period of time, contact your OMRON sales representative.

### **Handling of Safety Products**

If the functions of safety products cannot attain their full potential, it will result in minor or moderate injury, or may result in serious injury or death. When building the system, observe the following warnings and optimize safety product selection for your equipment and devices to ensure the integrity of the safety-related components.



### Setting Up a Risk Assessment System

The process of selecting these products should include the development and execution of a risk assessment system early in the design development stage to help identify potential dangers in your equipment and optimize safety product selection.

The following is an example of related international standards.

ISO12100 General Principles for Design - Risk Assessment and Risk Reduction

#### Protective Measure

When developing a safety system for the equipment and devices that use safety products, make every effort to understand and conform to the entire series of international and industry standards available, such as the examples given below.

The following are examples of related international standards.

- ISO12100 General Principles for Design Risk Assessment and Risk Reduction
- IEC60204-1 Electrical Equipment of Machines Part 1: General Requirements
- ISO13849-1, -2 Safety-related Parts of Control Systems
- ISO14119 Interlocking Devices Associated with Guards Principles for Design and Selection
- IEC/TS 62046 Application of Protective Equipment to Detect the Presence of Persons

#### Role of Safety Products

Safety products incorporate standardized safety functions and mechanisms, but the benefits of these functions and mechanisms are designed to attain their full potential only within properly designed safety-related systems. Make sure you fully understand all functions and mechanisms, and use that understanding to develop systems that will ensure optimal usage.

The following are examples of related international standards.

- ISO14119 Interlocking Devices Associated with Guards Principles for Design and Selection
- ISO13857 Safety Distances to Prevent Hazard Zones being Reached by Upper and Lower Limbs

#### Installing Safety Products

Qualified engineers must develop your safety-related system and install safety products in devices and equipment. Prior to machine commissioning, verify through testing that the safety products work as expected.

The following are examples of related international standards.

- ISO12100 General Principles for Design Risk Assessment and Risk Reduction
- IEC60204-1 Electrical Equipment of Machines Part 1: General Requirements
- ISO13849-1, -2 Safety-related Parts of Control Systems
- ISO14119 Interlocking Devices Associated with Guards Principles for Design and Selection

#### Observing Laws and Regulations

Safety products must conform to pertinent laws, regulations, and standards. Make sure that they are installed and used in accordance with the laws, regulations, and standards of the country where the devices and equipment incorporating these products are distributed.

#### Observing Usage Precautions

Carefully read the specifications and precautions as well as all items in the Instruction Manual for your safety product to learn appropriate usage procedures. Any deviation from instructions will lead to unexpected device or equipment failure not anticipated by the safety-related system.

#### Transferring Devices and Equipment

When you transfer devices and equipment, be sure to retain one copy of the Instruction Manual for safety devices and the User's Manual, and supply another copy with the device or equipment so the person receiving it will have no problems with operation and maintenance.

The following are examples of related international standards.

- ISO12100 General Principles for Design Risk Assessment and Risk Reduction
- IEC60204-1 Electrical Equipment of Machines Part 1: General Requirements
- · ISO13849-1, -2 Safety-related Parts of Control Systems
- IEC62061 Functional Safety of Safety-related Electrical, Electronic and Programmable Electronic Control Systems
- IEC61508 Functional Safety of Electrical/Electronic/Programmable Electronic Safety-related Systems

# **Transporting and Unpacking**



Do not damage, pull, or put excessive stress or heavy objects on the cables.

Doing so may cause electric shock, malfunction, or burning.



# Installation, Wiring and Maintenance

# **⚠** WARNING

Install the Servo Drive, Servomotor, and peripheral equipment before wiring.

Not doing so may cause electric shock.



Be sure to ground the 100-VAC or 200-VAC input model Servo Drive and Servomotor to 100  $\Omega$  or less, and the 400-VAC input model to 10  $\Omega$  or less.

Not doing so may cause electric shock.



Do not remove the front cover, terminal covers, cables, or peripheral equipment while the power is supplied.

Doing so may cause electric shock.



Before carrying out wiring or inspection, turn OFF the main circuit power and wait for at least the following specific time.

Not doing so may cause electric shock or burning.



R88D-1SN20F-ECT, R88D-1SN30F-ECT

15 minutes: R88D-1SN01L-ECT, R88D-1SN02L-ECT, R88D-1SN01H-ECT,

R88D-1SN02H-ECT, R88D-1SN04H-ECT

 $20 \ minutes: R88D-1SN04L-ECT, \ R88D-1SN08H-ECT, \ R88D-1SN10H-ECT, \\$ 

R88D-1SN15H-ECT, R88D-1SN20H-ECT, R88D-1SN30H-ECT

Do not damage, pull, or put excessive stress or heavy objects on the cables.

Doing so may cause electric shock, malfunction, or burning.



Use appropriate tools to wire terminals and connectors. Check that there is no short-circuit before use.

Not doing so may cause electric shock.



Connect the frame ground wire in the motor cable securely to the  $\fill \fill \fill$ 

Not doing so may cause electric shock.



# **Operation Check**

# **MARNING**

Use the Servomotor and Servo Drive in a specified combination.

Not doing so may cause fire or equipment damage.



### **Usage**

# **∕ ! WARNING**

Do not enter the operating area during operation.

Doing so may cause injury.



Do not touch the Servo Drive radiator, Regeneration Resistor, or Servomotor while the power is supplied or for a while after the power is turned OFF because they get hot.

Doing so may cause fire or a burn injury.



Take appropriate measures to ensure that the specified power with the rated voltage is supplied. Be particularly careful in locations where the power supply is unstable.

Not doing so may cause failure.



When the power is restored after a momentary power interruption, the machine may restart suddenly. Do not come close to the machine when restoring power.

Implement measures to ensure safety of people nearby even when the machine is restarted.



Doing so may cause injury.

Use appropriate tools to wire terminals and connectors. Check that there is no short-circuit before use.



Not doing so may cause electric shock.

Be sure to observe the radiator plate installation conditions that are specified in the manual. Not doing so may cause the Servo Drive or Servomotor to burn.



If the load that exceeds the allowable range is installed, it may cause the dynamic brake to be damaged. Be sure to use the appropriate load. For the selection of the appropriate load, refer to AC Servomotors/Servo Drives 1S-series with Built-in EtherCAT® Communications User's Manual (I586).



Not doing so may cause the Servo Drive to be damaged.

The dynamic brake is intended for the stop at the time of an error and therefore it has a short-time rating.



If the dynamic brake is activated, provide an interval of 3 minutes or more before the next activation to prevent a circuit failure and burning of the Dynamic Brake Resistor.

# **Transporting and Unpacking**

# ∕!∖ Caution

When transporting the Servo Drive, do not hold it by the cables or motor shaft.

Injury or failure may result.



Do not step on the Servo Drive or place heavy articles on it.

Injury may result.



Do not overload the product. (Follow the instructions on the product label.)

Injury or failure may result.



Be sure to observe the specified amount when piling up products.

Injury or failure may result.


The allowable number of piled-up products Servo Drive, Servomotor, Reactor:

Follow the instructions on the individual package.

External Regeneration Resistor: 12

External Regeneration Resistance Unit: 4

Noise Filter: 15



## Wiring

# **∕** Caution

Be careful about sharp parts such as the corner of the equipment when handling the Servo Drive and Servomotor.



Injury may result.

### **Security Measures**

# 

#### **Anti-virus protection**

Install the latest commercial-quality antivirus software on the computer connected to the control system and maintain to keep the software up-to-date.




#### Security measures to prevent unauthorized access

Take the following measures to prevent unauthorized access to our products.



- Install physical controls so that only authorized personnel can access control systems and equipment.
- Reduce connections to control systems and equipment via networks to prevent access from untrusted devices.
- Install firewalls to shut down unused communications ports and limit communications hosts and isolate control systems and equipment from the IT network.
- Use a virtual private network (VPN) for remote access to control systems and equipment.
- Adopt multifactor authentication to devices with remote access to control systems and equipment.
- · Set strong passwords and change them frequently.
- Scan virus to ensure safety of USB drives or other external storages before connecting them to control systems and equipment.

#### Data input and output protection





- · Checking the scope of data
- Checking validity of backups and preparing data for restore in case of falsification and abnormalities
- Safety design, such as emergency shutdown and fail-soft operation in case of data tampering and abnormalities

#### Data recovery

Backup data and keep the data up-to-date periodically to prepare for data loss.



When using an intranet environment through a global address, connecting to an unauthorized terminal such as a SCADA, HMI or to an unauthorized server may result in network security issues such as spoofing and tampering. You must take sufficient measures such as restricting access to the terminal, using a terminal equipped with a secure function, and locking the installation area by yourself.



When constructing an intranet, communication failure may occur due to cable disconnection or the influence of unauthorized network equipment. Take adequate measures, such as restricting physical access to network devices, by means such as locking the installation area.



When using a device equipped with the SD Memory Card function, there is a security risk that a third party may acquire, alter, or replace the files and data in the removable media by removing the removable media or unmounting the removable media.



Please take sufficient measures, such as restricting physical access to the Controller or taking appropriate management measures for removable media, by means of locking the installation area, entrance management, etc., by yourself.

#### **Precautions for Safe Use**

#### **General Precaution**

• Do not store or install the Servo Drive in the following locations. Doing so may result in electric shock, fire, equipment damage, or malfunction.

Locations subject to direct sunlight

Locations subject to temperatures outside the range specified in the specifications

Locations subject to humidity outside the range specified in the specifications

Locations subject to condensation as the result of severe changes in temperature

Locations subject to corrosive or flammable gases

Locations subject to dust (especially iron dust) or salts

Locations subject to exposure to water, oil, or chemicals

Locations subject to shock or vibration

- · Medical electronics such as cardiac pacemakers may malfunction or injury may result.
- Provide safety measures, such as a fuse, to protect against short circuiting of external wiring and failure of the Servo Drive. Fire may result.
- If an error occurs, remove the cause of the error and ensure safety, and then perform the error reset and restart the operation. Injury, equipment damage, or burning may result.

### Wiring

- Use a robot cable for the wiring to separately install the Servo Drive and Servomotor to moving and fixed parts of the equipment. Equipment damage may result.
- Connect the Servo Drive to the Servomotor without a contactor, etc. Malfunction or equipment damage may result.

#### **Precautions for Correct Use**

#### **General Precaution**

• Take appropriate and sufficient countermeasures to provide shielding when installing systems in the following locations. Not doing so may result in failure.

Locations subject to static electricity or other forms of noise

Locations subject to strong electromagnetic fields

Locations subject to possible exposure to radioactivity

Locations close to power lines

• When lifting a 20-kg or more Servo Drive during moving or installation, always have two people lift the product by grasping a metal part other than the shaft.

Do not grasp a plastic part. Injury or failure may result.

Relevant model: R88M-1M2K010T0-B $\square$ , R88M-1M3K010T- $\square$ , R88M-1M2K010C-B $\square$ ,and R88M-1M3K010C- $\square$ 

# Transporting and Unpacking

Check that the eye bolts are not loose after replacing them.

If they are loose, the screws can come off and the Servomotor may fall during the transportation by the use of eye bolts.

Do not put the human body under the Servomotor during the transportation.

### Installation

- · Be sure to observe the mounting direction. Failure may result.
- Provide the specified clearance between the Servo Drive and the inner surface of the control panel or other equipment. Fire or failure may result.
- Install the Servomotor, Servo Drive, and Regeneration Resistor on non-flammable materials such as metals. Fire may result.
- Do not apply strong impact on the motor shaft or Servo Drive. Failure may result.
- Do not touch the key grooves with bare hands if the Servomotor with shaft-end key grooves is used. Injury may result.
- Use non-magnetic mounting screws. Note also that the depth of any mounted screw does not reach the effective thread length. Equipment damage may result.
- · Be sure to observe the allowable axial load for the Servomotor. Equipment damage may result.
- Install equipment to prevent crash and reduce shock.
   Do not run the Servomotor outside the operable range by the use of the drive prohibition function such as overtravel.
  - Crash against the stroke edge may occur depending on stopping distance and equipment damage may result.
- Do not block the intake or exhaust openings. Do not allow foreign objects to enter the Servo Drive. Fire may result.
- Use the attached exclusive screws when you mount the Servo Drive to the Footprint-type Noise Filter. Electric shock or failure may result.

### Wiring

- · Wire the cables correctly and securely. Runaway motor, injury, or failure may result.
- Tighten the mounting screws, terminal block screws, and cable screws for the Servo Drive, Servomotor, and peripheral equipment to the specified torque. Failure may result.
- Use crimp terminals to wire screw type terminal blocks. Do not connect bare stranded wires directly to terminals blocks. Fire may result.
- · Always use the power supply voltage specified in this document. Burning may result.
- Do not apply a commercial power supply directly to the Servomotor. Fire or failure may result.
- When constructing a system that includes safety functions, be sure you understand the relevant safety standards and all related information in user documentation, and design the system to comply with the standards. Injury or equipment damage may result.
- Disconnect all connections to the Servo Drive and Servomotor before attempting a megger test (insulation resistance measurement) on the Servo Drive or Servomotor. Not doing so may result in Servo Drive or Servomotor failure. Do not perform a dielectric strength test on the Servo Drive or Servomotor. Doing so may result in damage of the internal elements.
- Keep conductive or flammable foreign objects such as screws, metal pieces, and oil out of the Servo
  Drive and connectors. Pay particular attention to the connector on the top part of Servo Drive. Fire or
  electric shock may result.
- Carefully perform the wiring and assembling. Injury may result.
- Wear the protective equipment when installing or removing the main circuit connector, main circuit connector A, main circuit connector B, control power supply connector, or motor connector. Do not apply a force after the protrusion of the connector opener reaches the bottom dead center. (As a guide, do not apply a force of 100 N or more.)
- Design the configuration to cut off the main circuit power supply when the ERR signal (normally close contact) of the control output function is output (open).
- Do not block the intake or exhaust openings. Do not allow foreign objects to enter the Servo Drive. Fire may result.
- Do not apply excessive force to wire terminals and connectors. Injury or failure may result.

- Be sure to install surge suppressors when you connect a load with an induction coil such as a relay to the control output terminal.
  - Malfunction or equipment damage may result.

### **Adjustment**

- Install an immediate stop device externally to the machine so that the operation can be stopped and the power supply is cut off immediately. Injury may result.
- Do not adjust or set parameters to extreme values, because it will make the operation unstable. Injury may result.
- Ensure that the Servomotor has a sufficient rigidity. Equipment damage or malfunction may result.
- If a problem occurs in serial communications or the computer during a test operation, you have no means to stop the Servomotor.
  - Connect an externally installed emergency stop switch, etc. to the Error Stop Input of the general-purpose input so that the Servomotor can be stopped without fail.
- When using the Servomotor with key, run the Servomotor in a state in which the key cannot jump out
  of the shaft.
  - Not doing so may result in hurting people around the equipment due to the jumping key.

### **Operation Check**

- Before operating the Servo Drive in an actual environment, check if it operates correctly based on the newly set parameters. Equipment damage may result.
- Do not adjust or set parameters to extreme values, because it will make the operation unstable. Injury may result.
- Do not drive the Servomotor by the use of an external drive source. Fire may result.
- Check the newly set parameters for proper execution before actually using them.

# Usage

- Tighten the mounting screws, terminal block screws, and cable screws for the Servo Drive, Servomotor, and peripheral equipment to the specified torque. Failure may result.
- Install a stopping device on the machine to ensure safety.
   The holding brake is not a stopping device to ensure safety. Injury may result.
- Install an immediate stop device externally to the machine so that the operation can be stopped and the power supply is cut off immediately. Injury may result.
- Conduct a test operation after confirming that the equipment is not affected. Equipment damage may result.
- Do not use the built-in brake of the Servomotor for normal braking operation. Failure may result.
- · After an earthquake, be sure to conduct safety checks. Electric shock, injury, or fire may result.
- Do not place flammable materials near the Servomotor, Servo Drive, or peripheral equipment. Fire may result.
- Connect an emergency stop (immediate stop) relay in series with the brake interlock output. Injury or failure may result.
- · Do not use the cable when it is laying in oil or water. Electric shock, injury, or fire may result.
- Install safety devices to prevent idling or locking of the electromagnetic brake or the gear head, or leakage of grease from the gear head. Injury, damage, or taint damage result.
- If the Servo Drive fails, cut off the power supply to the Servo Drive at the power supply. Fire may
  result
- Be sure to turn OFF the power supply when not using the Servo Drive for a prolonged period of time. Not doing so may result in injury or malfunction.


- When constructing a system that includes safety functions, be sure you understand the relevant safety standards and all related information in user documentation, and design the system to comply with the standards. Injury or equipment damage may result.
- If the Servomotor is not controlled, it may not be possible to maintain the stop. To ensure safety, install a stop device. Equipment damage or injury may result.
- Periodically run the Servomotor approximately one rotation when the oscillation operation continues at a small angle of 45° or smaller. Servomotor failure may result.
- Immediately stop the operation and cut off the power supply when unusual smell, noise, smoking, abnormal heat generation, or vibration occurs. Not doing so may result in Servo Drive or Servomotor damage or burning.
- Use an appropriate External Regeneration Resistor. Install an external protective device such as temperature sensor to ensure safety when using the External Regeneration Resistor.

#### **Maintenance**

- After replacing the Servo Drive, transfer to the new Servo Drive all data needed to resume operation, before restarting operation. Equipment damage may result.
- · Do not repair the Servo Drive by disassembling it. Electric shock or injury may result.

### Location of Warning Display

The Servo Drive bears a warning label at the following location to provide handling warnings. When you handle the Servo Drive, be sure to observe the instructions provided on this label.



# **Instructions on Warning Display**

	警告	WARNING	警告	<b>AVERTISSEMENT</b>
$\overline{\mathbb{V}}$	使用、設置、保守前に 必ず取扱説明書を読み、 指示に従うこと	Read the manual and follow the instruction before setting up.	在使用、安装、 维扩之前,请务必按照 使用说明书的指示操作	Lire le manuel et suivre les instructions avant la mise en service.
A	放電時間は15分です。 電源を切った後,15分間は 触らないこと! 感電の恐れあり!	Discharge time is 15min. After turn off power, wait 15min before service. Risk of electric shock.	电容放电需15分钟。 切断电源15分钟内请勿 協摸。 有触电的危险!	Le temps de décharge est de 15 min. Après avoir coupé l'alimentation, attendez 15 min avant la mise en service. Risque de choc électrique.
	必ずアースに配線すること! 感電の恐れあり	Connect ground! Risk of electric shock.	务必安装接地线! 以防航电	Connecter la mise à la terre! Risque de choc electrique
	ヒートシンクに触らないこと! やけどの恐れあり	Do not touch heatsink! Risk of burn.	请勿 <u>航</u> 模散热器! 以防灼伤	Ne pas toucher le dissipateur de chaleur! Risque de brûlure.
In Canada, translent surge suppression shall be installed on the line side of this equipment and shall be rated 277 V (phase to ground), suitable for overvoltage category III, and shall provide protection for a rated impulse withstand voltage peak of 6 kV.				

Note The above is an example of warning display.

# Disposal

Dispose of the Servo Drive as industrial waste.

# Items to Check After Unpacking


After you unpack the product, check the following items.

- · Is this the model you ordered?
- · Was there any damage sustained during shipment?


#### **Servo Drive**

### Nameplate of Servo Drive

The model, rating and lot number of the 1S-series Servo Drive are given on the product nameplate.



Name plate example: 100 VAC 100 W Servo Drive



\*1. The notifications and their meanings are explained below.

Notation: Lot No. DDMYY $\square$  xxxx

DDMYY: Lot number,  $\square :$  For use by OMRON, xxxx: Serial number

"M" gives the month (1 to 9: January to September, X: October, Y: November, Z: December)

#### **Accessories of Servo Drive**

This product comes with the following accessories.

- INSTRUCTION MANUAL × 1 copy
- Warning label × 1 sheet
- General Compliance Information and instructions for EU × 1 copy
- · Attached connectors (Depends on the model. Refer to the following table.)

When UL/CSA certification is required, attach the warning label to a place around the Servo Drive.

Connectors, mounting screws, mounting brackets, and other accessories other than those in the table below are not supplied. They must be prepared by the customer.

If any item is missing or a problem is found such as Servo Drive damage, contact the OMRON dealer or sales office where you purchased your product.

Specifications		Control I/O connector (CN1)	Brake interlock connector (CN12)	Main circuit connector and main circuit connector A (CNA)
	100 W			
Single-	200 W			Included <sup>*2 *4</sup>
phase/3-ph ase 200 VAC	400 W	Included <sup>*1</sup>	Included	Included
	750 W			
	1.5 kW			Included*3 *4
3-phase 200 VAC	1 kW			Included*2 *4

<sup>\*1.</sup> Four short-circuit wires are connected to the connector.

<sup>\*4.</sup> One opener is included.

Specifications		Main circuit connector B (CNB)	Motor connector (CNC)	Control power supply connector (CND)
	100 W			
Single- phase/3-ph ase 200 VAC	200 W		Included <sup>*2</sup>	
	400 W			
	750 W			
	1.5 kW	Included <sup>*1</sup>	Included*3	Included*4
3-phase 200 VAC	1 kW		Included*2	

<sup>\*1.</sup> One short-circuit wire is connected to the connector.

<sup>\*2.</sup> The connector with 11 terminals is included. Two short-circuit wires are connected.

<sup>\*3.</sup> The connector with 6 terminals is included. One short-circuit wire is connected.


<sup>\*2.</sup> The connector with 3 terminals is included.

<sup>\*3.</sup> The connector with 4 terminals is included.

<sup>\*4.</sup> One opener is included.

#### Servomotor

The model, rating and serial number of the 1S-series Servomotor are given on the product nameplate.




\*1. The weight is not given for the Servomotor with a flange size of 80 x 80 or less.

From the left,
Number of phases (Example: 3)
Rated voltage
(Example: 200 VAC)
Rated current
(Example: 8.6 A)
Rated output
(Example: 1.5 kW)

From the left, Insulation class (Example: F) Totally enclosed protection type motor (Example: TE) Operating ambient temperature (Example: 40°C)

Protective structure (Example: IP67)



# **Related Manuals**

The following are the manuals related to this manual. Use these manuals for reference.

Manual name	Cat. No.	Model numbers	Application	Description
AC Servomo-	1586	R88M-1L□/-1M□	Learning the functionality	An outline to the entire
tors/Servo Drives 1S-series with Built-in Ether- CAT® Communications User's		R88D-1SN□-ECT	and performance of 1S-series Servo Drives. Mainly information below is provided.	1S-series system is provided along with the following information on the Servomotors (with absolute encoder specifications)/Series Drives
Manual			EtherCAT Communications     Basic Control Functions     Applied Functions     Safety Function     Adjustment Functions	<ul> <li>ifications)/Servo Drives.</li> <li>Features and system configuration</li> <li>Outline</li> <li>Names and functions</li> <li>General specifications</li> <li>Installation and wiring</li> <li>Maintenance and inspections</li> </ul>
NX-series CPU Unit Hardware User's Manual	W535	NX701-□□□□	Learning the basic specifications of the NX-series CPU Units, including introductory information, designing, installation, and maintenance.  Mainly hardware information is provided.	An introduction to the entire NX-series system is provided along with the following information on the CPU Unit.  • Features and system configuration  • Introduction  • Part names and functions  • General specifications  • Installation and wiring  • Maintenance and inspection  Use this manual together with the NJ-series CPU Unit Software User's Manual (Cat. No. W501).
NJ-series CPU Unit Hardware User's Manual	W500	NJ501-□□□□ NJ301-□□□□ NJ101-□□□□	Learning the basic specifications of the NJ-series CPU Units, including introductory information, designing, installation, and maintenance.  Mainly hardware information is provided.	An introduction to the entire NJ-series system is provided along with the following infor- mation on the CPU Unit.  Features and system con- figuration  Introduction  Part names and functions  General specifications  Installation and wiring  Maintenance and inspec- tion  Use this manual together with the NJ-series CPU Unit Software User's Manual

Manual name	Cat. No.	Model numbers	Application	Description
Manual name NJ/NX-series CPU Unit Software User's Manual	W501	Model numbers  NX701-□□□□  NX1P2-□□□□  NJ501-□□□□  NJ301-□□□□  NJ101-□□□□	Application Learning how to program and set up an NJ/NX-series CPU Unit. Mainly software information is provided.	Description The following information is provided on a Controller built with an NJ/NX-series CPU Unit.  • CPU Unit operation • CPU Unit features • Initial settings • Programming based on IEC 61131-3 language specifications Use this manual together with the NX-series CPU Unit Hardware User's Manual
NJ/NX-series CPU Unit Motion Con- trol User's Manual	W507	NX701-□□□□  NX1P2-□□□□  NJ501-□□□□	Learning about motion control settings and programming concepts.	(Cat. No. W535) or NJ-series CPU Unit Hardware User's Manual (Cat. No. W500). The settings and operation of the CPU Unit and program- ming concepts for motion
		NJ301-□□□□ NJ101-□□□□		control are described.  When programming, use this manual together with the NX-series CPU Unit Hardware User's Manual (Cat. No. W535) or NJ-series CPU Unit Hardware User's Manual (Cat. No. W500) and with the NJ/NX-series CPU Unit Software User's Manual (Cat. No. W501).
NX-series Safety Control Units User's Manual	Z930	NX-SL□□□□  NX-SI□□□□  NX-SO□□□□	Learning how to use the NX-series Safety Control Units.	Describes the hardware, setup methods and functions of the NX-series Safety Con- trol Units.
Sysmac Studio Version 1 Opera- tion Manual	W504	SYSMAC-SE2	Learning about the operating procedures and functions of the Sysmac Studio.	Describes the operating procedures of the Sysmac Studio.
Sysmac Studio Drive Functions Operation Manual	1589	SYSMAC-SE2	Learning how to set up and adjust the Servo Drives.	Describes the operating procedures of the Sysmac Studio.
SYSMAC CJ-series Position Control Unit Oper- ation Manual	W487	CJ1W-NC281 CJ1W-NC481 CJ1W-NC881 CJ1W-NCF81 CJ1W-NC482 CJ1W-NC882 CJ1W-NCF82	Learning about the NC Units (CJ1W-NC281/ 481/ 881/ F81/ 482/ 882/ F82).	Describes the setup methods and operating procedures of the NC Units.
G9SP-series Safety Controller Operation Manual	Z922	G9SP-N10S G9SP-N10D G9SP-N20S	Learning how to use the G9SP-series safety Controllers.	Describes the hardware, setup methods and functions of the G9SP-series safety Controllers.

# **Terminology**


Term	Abbrevi- ation	Description
CAN application protocol over EtherCAT	CoE	A CAN application protocol service implemented on EtherCAT.
CAN in Automation	CiA	CiA is the international users' and manufacturers' group that develops and supports higher-layer protocols.
Device Profile		Collection of device dependent information and functionality providing consistency between similar devices of the same device type.
Distributed Clocks	DC	Method to synchronize slaves and maintain a global time base.
EtherCAT Slave Controller	ESC	A controller for EtherCAT slave communication.
EtherCAT Slave Information	ESI	An XML file that contains setting information for an EtherCAT slave.
EtherCAT State Machine	ESM	An EtherCAT communication state machine.
EtherCAT Technology Group	ETG	The ETG is a global organization in which OEM, End Users and Technology Providers join forces to support and promote the further technology development.
Fieldbus Memory Management Unit	FMMU	Single element of the fieldbus memory management unit: one correspondence between a coherent logical address space and a coherent physical memory location.
Index		Address of an object within an application process.
Object		Abstract representation of a particular component within a device, which consists of data, parameters, and methods.
Object Dictionary	OD	Data structure addressed by Index and Subindex that contains description of data type objects, communication objects and application objects.
Physical Device Internal Interface	PDI	A series of elements to access data link services from the application layer.
Power Drive System	PDS	A power drive system consisting of a Servo Drive, an inverter, and other components.
Process Data		Collection of application objects designated to be transferred cyclically or acyclically for the purpose of measurement and control.
Process Data Object	PDO	Structure described by mapping parameters that contain one or several process data entities.
Receive PDO	RxPDO	A process data object received by an EtherCAT slave.
safe state		The status of a device or piece of equipment when the risk of danger to humans has been reduced to an acceptable level.
safety control		A type of control that uses devices, functions, and data that are designed with special safety measures.
Safety over EtherCAT	FSoE	A system to communicate for the functional safety over EtherCAT.
safety process data communications		A type of I/O data communications that is used for safety control purposes.

Term	Abbrevi- ation	Description
safety reaction time		The time required for the system to enter a safe state in a worst-case scenario after the occurrence of a safety-related input (press of an emergency stop pushbutton switch, interruption of a light curtain, opening of a safety door, etc.) or device failure.
		The reaction time of the system includes the reaction times of sensors and actuators, just like the reaction time for a Controller or network.
Service Data Object	SDO	CoE asynchronous mailbox communications where all objects in the object dictionary can be read and written.
Slave Information Interface	SII	Slave information stored in the nonvolatile memory of each slave.
standard control		A type of control that use devices, functions, and data that are designed for general control purposes.  This term is used to differentiate from a safety con-
		trol.
Subindex		Sub-address of an object within the object dictionary.
Sync Manager	SM	Collection of control elements to coordinate access to concurrently used objects.
Transmit PDO	TxPDO	A process data object sent from an EtherCAT slave.

# **Revision History**

The manual revision code is a number appended to the end of the catalog number found in the front and back cover.

Example



Revision code	Date	Revised content
01	April 2018	Original production
02	September 2022	Revisions for adding safety precautions regarding security.

**Revision History** 



# Features and System Configuration

This section explains the features of the Servo Drive and name of each part. For the names and functions, system block diagram, and procedures to start operation of Servo Drives, refer to the AC Servomotors/Servo Drives 1S-series with Built-in EtherCAT® Communications User's Manual (I586).

1-1	Outline		1-2
	1-1-1	Features of 1S-series Servo Drives	1-2
	1-1-2	EtherCAT	1-3
	1-1-3	Object Dictionary	1-4
1-2	System	Configuration	1-5
1-3	Names	and Functions	1-6
	1-3-1	Servomotor Part Names	1-6
	1-3-2	Servomotor Functions	1-7
1-4	Applica	ble Standards	1-8
	1-4-1	EU Directives	1-8
	1-4-2	UL and CSA Standards	1-9
	1-4-3	Korean Radio Regulations (KC)	1-9
	1-4-4	SEMI F47	1-10
	1-4-5	Australian EMC Labeling Requirements (RCM)	1-10
1-5	Unit Versions 1-11		
	1-5-1	Confirmation Method	1-11
	1-5-2	Unit Versions and Sysmac Studio Versions	1-11

# **Outline**

The 1S-series Servo Drives with Built-in EtherCAT communications support 100-Mbps EtherCAT.

When you use the 1S-series Servo Drive with a Machine Automation Controller NJ/NX-series CPU Unit or Position Control Unit with EtherCAT (Model: CJ1W-NC□8□), you can construct a high-speed and sophisticated positioning control system.

You need only one communications cable to connect the Servo Drive and the Controller. Therefore, you can realize a position control system easily with reduced wiring effort.

With adjustment functions, adaptive notch filter, notch filter, and damping control, you can set up a system that provides stable operation by suppressing vibration in low-rigidity machines.

Moreover, with the two-degree-of-freedom (TDF) control structure, you can easily adjust high-precision positioning.

#### 1-1-1 Features of 1S-series Servo Drives

The 1S-series Servo Drives have the following features.

### Optimal Functionality and Operability by Standardizing Specifications

As a Sysmac Device, 1S-series Servo Drives with built-in EtherCAT communications is designed to achieve optimum functionality and ease of operation when it is used together with the NJ/NX-series Machine Automation Controller and the Sysmac Studio Automation Software.

Sysmac Device is a generic term for OMRON control devices such as an EtherCAT Slave, designed with unified communications specifications and user interface specifications.

# **Data Transmission Using EtherCAT Communications**

Combining the 1S-series Servo Drive with a Machine Automation Controller NJ/NX-series CPU Unit or Position Control Unit with EtherCAT (Model: CJ1W-NC 8 ) enables you to exchange all position information with the controller in high-speed data communications.

Since the various control commands are transmitted via data communications, Servomotor's operational performance is maximized without being limited by interface specifications such as the response frequency of the encoder feedback pulses.

You can use the Servo Drive's various control parameters and monitor data on a host controller, and unify the system data for management.

# EtherCAT Communications Cycle of 125 µs

Combination with an NX7 Machine Automation Controller enables high-speed and high-precision motion control at the communications cycle of 125 µs.

# High Equipment Utilization Efficiency with 400-V Models

The 400-V models are provided for use with large equipment, at overseas facilities and in wide-ranging applications and environment. Since the utilization ratio of facility equipment also increases, the TCO (Total Cost of Ownership) will come down.

### Safe Torque OFF (STO) Function to Ensure Safety

You can cut off the motor current to stop the motor based on a signal from an emergency stop button or other safety equipment. This can be used for an emergency stop circuit that is compliant with safety standards without using an external contactor. Even during the torque OFF status, the present position of the motor is monitored by the control circuits to eliminate the need to perform the homing at the time of restart.

### Achievement of Safety on EtherCAT Network

You can use NX-series Safety Control Units to integrate safety controls in a sequence and motion control system.

The 1S-series Servo Drive supports the FSoE (Safety over EtherCAT) protocol as the safety communications. You can build the safety system that uses the STO function from the safety controller on the EtherCAT network.

# Suppressing Vibration of Low-rigidity Machines During Acceleration/Deceleration

The damping control function suppresses vibration of low-rigidity machines or devices whose tips tend to vibrate. The function can also be used for damping control for larger constructions as it supports vibration ranging from 0.5 to 300 Hz. You can maximize the performance of the Servomotor by adjusting the trade-off between the damping time and the amount of peak control.

### **Easy Adjustment with TDF Control Structure**

The TDF control structure allows you to separately adjust the amount of overshooting and the resistance against disturbance. With this feature, you can easily achieve high-precision positioning, which is difficult to achieve with the one-degree-of-freedom (ODF) control.

### 1-1-2 EtherCAT

EtherCAT is an open high-speed industrial network system that conforms to Ethernet (IEEE 802.3). Each node achieves a short communications cycle time by transmitting Ethernet frames at high speed. A mechanism that allows sharing clock information enables high-precision synchronization control with low communications jitter.

#### 1-1-3 **Object Dictionary**

1S-series Servo Drives with Built-in EtherCAT Communications use the object dictionary for CAN application protocol over EtherCAT (CoE) as a base for communications.

An object is an abstract representation of a particular component within a device, which consists of data, parameters, and methods.

An object dictionary is a data structure that contains description of data type objects, communication objects and application objects.


All objects are assigned four-digit hexadecimal indexes in the areas shown in the following table.

Index (hex)	Area	Description
0000 to 0FFF	Data Type Area	Definitions of data types.
1000 to 1FFF	CoE Communications Area	Definitions of objects that can be used by all servers for designated communications.
2000 to 2FFF	Manufacturer Specific Area 1	Objects with common definitions for all OMRON products.
3000 to 5FFF	Manufacturer Specific Area 2	Objects with common definitions for all 1S-series
		Servo Drives (servo parameters).*1
6000 to DFFF	Device Profile Area	Variables defined in the Servo Drive's CiA402 drive profile.
E000 to EFFF	Device Profile Area 2	Objects defined in the Servo Drive's FSoE CiA402
		slave connection.
F000 to FFFF	Device Area	Objects defined in a device.

<sup>\*1.</sup> For details on servo parameters, refer to Section 5 Details on Servo Parameters.

# 1-2 System Configuration

The system configuration for a 1S-series Servo Drive with Built-in EtherCAT Communications connected to an Incremental Encoder Type Servomotor is shown below.




# **Names and Functions**

This section describes the names and functions of Servo Drive parts.

#### 1-3-1 **Servomotor Part Names**


The Servomotor part names are given below.

### Flange Size of 80 x 80 or less



200 VAC 200 W Servomotors (with Brake)

## Flange Size of 100 x 100 or more



200 VAC 1.5 kW Servomotors (with Brake)

### 1-3-2 Servomotor Functions

The functions of each part of the Servomotor are described below.

### **Shaft**

The load is mounted on this shaft.

The direction which is in parallel with the shaft is called the thrust direction, and the direction which is perpendicular to the shaft is called the radial direction.

### Flange

Used for mounting the Servomotor on the equipment.

Fit the mating part into the equipment and use the mounting holes to screw the Servomotor.

### **Power Connector**

Used for supplying power to the phase U, V, and W of the Servomotor.

For Servomotors with a brake and flange size of 100 x 100 or more, the pins for power and brake are set on the same connector.

### **Encoder Connector**

Used for supplying power to the encoder of the Servomotor and communicating with the Servo Drive.

### **Brake Connector**

Used for supplying power to the brake coil of the Servomotor.

This part is attached only to the Servomotors with a brake and flange size of 80 x 80 or less.

# **Applicable Standards**

This section describes applicable standards.

#### **EU Directives** 1-4-1

The 1S-series Servomotors, Servo Drives, and Footprint-type Noise Filters conform to the following standards.

EU Directives	Product	Applicable standards
EMC Directive	Servo Drives	EN61800-3 second environment,
		C3 Category
		(EN 61326-3-1 Functional Safety)
Low Voltage Directive Servo Drives		EN 61800-5-1
	Servomotors	EN 60034-1/-5
	Footprint-type Noise	EN 60939-2
	Filters	
Machinery Directive	Servo Drives	EN ISO 13849-1 (Cat.3)
		EN 61508
		EN 62061
		EN 61800-5-2

Note To conform to EMC Directives, install the Servo Drive and Servomotor under the conditions described in 4-3 Wiring Conforming to EMC Directives on page 4-8.

The Servo Drives and Servomotors comply with EN 61800-5-1 as long as the following installation conditions (a) and (b) are met.

- (a) Use the Servo Drive in pollution degree 2 or 1 environment as specified in IEC 60664-1. Example: Installation inside an IP54 control panel.
- (b) Be sure to connect a fuse, which complies with IEC 60269-1 CLASS gG, between the power supply and noise filter.

Select a fuse from the following table.

Servo Drive model	Fuse
R88D-1SN01H-ECT	CLASS gG 16A
R88D-1SN02H-ECT	CLASS gG 16A
R88D-1SN04H-ECT	CLASS gG 16A
R88D-1SN08H-ECT	CLASS gG 16A
R88D-1SN10H-ECT	CLASS gG 16A
R88D-1SN15H-ECT	CLASS gG 40A

#### 1-4-2 UL and CSA Standards

The 1S-series Servomotors, Servo Drives, and Footprint-type Noise Filters conform to the following standards.

Standard	Product	Applicable standards	File number
UL standards	Servo Drives	UL 61800-5-1	E179149
	Servomotors	UL 1004-1, UL 1004-6	E331224
	Footprint-type Noise Filters	UL1283	E191135
CSA standards*1	Servo Drives	CSA C22.2 No. 274	E179149
	Servomotors	CSA C22.2 No. 100	E331224

<sup>\*1.</sup> IN CANADA, TRANSIENT SURGE SUPPRESSION SHALL BE INSTALLED ON THE LINE SIDE OF THIS EQUIPMENT AND SHALL BE RATED 277 V (PHASE TO GROUND), SUITABLE FOR OVERVOLTAGE CATEGORY III, AND SHALL PROVIDE PROTECTION FOR A RATED IMPULSE WITHSTAND VOLTAGE PEAK OF 6 KV

The Servo Drives and Servomotors comply with UL 61800-5-1 as long as the following installation conditions (a) and (b) are met.

- (a) Use the Servo Drive in pollution degree 2 or 1 environment as specified in IEC 60664-1.
  - Example: Installation inside an IP54 control panel.
- (b) Be sure to connect a fuse, which is a UL-listed product with LISTED and (1) mark, between the power supply and noise filter.

Select the fuse from the following table.

Use copper wiring with a temperature rating of 75°C or higher.

Servo Drive model	Fuse
R88D-1SN01H-ECT	UL CLASS RK5 15 A
R88D-1SN02H-ECT	UL CLASS RK5 15 A
R88D-1SN04H-ECT	UL CLASS RK5 15 A
R88D-1SN08H-ECT	UL CLASS RK5 15 A
R88D-1SN10H-ECT	UL CLASS RK5 15 A
R88D-1SN15H-ECT	UL CLASS RK5 40 A

### 1-4-3 Korean Radio Regulations (KC)

· Observe the following precaution if you use this product in Korea.

A 급 기기 (업무용방송통신기자재) 이 기기는 업무용(A 급) 전저파작합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

Class A Device (Broadcasting Communications Device for Office Use)

This device obtained EMC registration for office use (Class A), and it is intended to be used in places other than homes. Sellers and/or users need to take note of this.

- The 1S-series Servo Drives comply with the Korean Radio Regulations (KC).
- The 1S-series Servomotors are exempt from the Korean Radio Regulations (KC).

#### 1-4-4 SEMI F47

- The main power supply inputs can conform to the SEMI F47 standard for momentary power interruptions (voltage sag immunity) for no-load operation.
- This standard applies to semiconductor manufacturing equipment.



#### **Precautions for Correct Use**

- This standard does not apply to the 24-VDC control power input. Use the power supply.
- This standard does not apply to single-phase 100-V Servo Drives.
- Be sure to perform evaluation tests for SEMI F47 compliance in the entire machine and system.

#### **Australian EMC Labeling Requirements (RCM)** 1-4-5

- The 1S-series Servo Drives comply with the Australian EMC Labeling Requirements (RCM).
- The 1S-series Servomotors comply with the Australian EMC Labeling Requirements (RCM).


# 1-5 Unit Versions

The 1S-series Servo Drive uses unit versions.

Unit versions are used to manage differences in supported functions due to product upgrades, etc.

### 1-5-1 Confirmation Method

The unit version of 1S-series is displayed at the location shown below.



### 1-5-2 Unit Versions and Sysmac Studio Versions

For 1S-series Incremental Encoder Type Servomotors, you must use the 1S-series Servo Drives unit version 1.2 or later, and Sysmac Studio version 1.22 or higher.



# **Models and External Dimensions**


This section explains the models of Servomotors and peripheral devices, and provides the external dimensions and mounting dimensions.

For the models and external dimensions of Servo Drives, refer to the AC Servomotors/Servo Drives 1S-series with Built-in EtherCAT® Communications User's Manual (1586).


2-1	Servo S	Servo System Configuration			
2-2	How to	Read Model Numbers	. 2-4		
	2-2-1	Servomotor	. 2-4		
2-3	Model	Tables	. 2-5		
	2-3-1	Servomotor Model Tables	. 2-5		
	2-3-2	Servo Drive and Servomotor Combination Tables	. 2-6		
	2-3-3	Servomotor and Decelerator Combination Tables	. 2-7		
	2-3-4	Cable and Connector Model Tables	. 2-7		
2-4	Externa	al and Mounting Dimensions	2-12		
	2-4-1	Servomotor Dimensions	2-12		

### **Servo System Configuration** 2-1

This section shows the Servo system configuration that consists of Controllers, Servo Drives, Servomotors and other devices.



\*1. You cannot use the CX-One to make the settings of 1S-series Servo Drives. Obtain the Sysmac Studio.



#### **How to Read Model Numbers** 2-2

This section describes how to read and understand the model numbers of Servo Drives and Servomo-

#### 2-2-1 Servomotor

The Servomotor model number tells the Servomotor type, rated output, rated rotation speed, voltage,

R88M-1M10030H-BOS2

1S-series Servomotor -Servomotor type -L : Low inertia : Middle inertia Rated output -100 : 100 W 200 : 200 W 400 : 400 W 750 : 750 W 1K0 : 1 kW 1K5 : 1.5 kW Rated rotation speed 20 : 2,000 r/min : 3,000 r/min 30 Servo Drive main power supply voltage and encoder type -: 200 VAC incremental encoder

Options

Brake None: Without brake

: With 24-VDC brake

Oil seal

None: Without oil seal : With oil seal

Key and tap

None: Straight shaft S2 : With key and tap

### **Combinations of Options**

	Without oil seal		With oil seal		
	Straight shaft	With key and tap	Straight shaft	With key and tap	
Without brake	None	-S2	-0	-OS2	
With brake	-B	-BS2	-BO	-BOS2	

# 2-3 Model Tables

This section lists the models of Servo Drives, Servomotors, cables, connectors, peripheral devices, etc. in the tables.

### 2-3-1 Servomotor Model Tables

The following tables list the Servomotor models by the rated motor speed.

### 3,000-r/min Servomotors

			Model				Refer-
	Specifications		Without oil seal		With oil seal		
			Straight shaft	With key and tap	Straight shaft With key and tap		ence ence
With	200 VAC	100 W		R88M- 1M10030H-S2	,		P. 2-12
Without brake		200 W		R88M- 1M20030H-S2			P. 2-14
ke		400 W		R88M- 1M40030H-S2			P. 2-14
		750 W	:	R88M- 1M75030H-S2	,		P. 2-16
		1 kW	:	R88M- 1L1K030H-S2	,		P. 2-18
		1.5 kW		R88M- 1L1K530H-S2			P. 2-18
With	200 VAC	100 W		R88M- 1M10030H-BS2			P. 2-13
With brake		200 W		R88M- 1M20030H-BS2			P. 2-15
		400 W		R88M- 1M40030H-BS2			P. 2-15
		750 W		R88M- 1M75030H-BS2			P. 2-17
		1 kW		R88M- 1L1K030H-BS2			P. 2-19
		1.5 kW		R88M- 1L1K530H-BS2			P. 2-19

### 2,000-r/min Servomotors

		Model				Refer-
Specifications		Without oil seal		With oil seal		
		Straight shaft	With key and tap	Straight shaft	With key and tap	ence
≥ 200 VAC	1 kW		R88M- 1M1K020H-S2			P. 2-20
Without brake	1.5 kW	<b></b> .	R88M- 1M1K520H-S2		,	P. 2-20
₹ 200 VAC	1 kW	<b></b> .	R88M- 1M1K020H-BS2	<b></b> .		P. 2-21
brake	1.5 kW		R88M- 1M1K520H-BS2			P. 2-21

#### 2-3-2 **Servo Drive and Servomotor Combination Tables**

The following tables show the possible combinations of 1S-series Servo Drives and Servomotors. The Servomotors and Servo Drives can only be used in the listed combinations. "

" at the end of the motor model number is for options, such as the shaft type and brake.

## 3,000-r/min Servomotors and Servo Drives

Main circuit power supply voltage	Servomotor rated output	Servomotor	Servo Drive
Single-phase/3-phase	100 W	R88M-1M10030H-□	R88D-1SN01H-ECT
200 VAC	200 W	R88M-1M20030H-□	R88D-1SN02H-ECT
	400 W	R88M-1M40030H-□	R88D-1SN04H-ECT
	750 W	R88M-1M75030H-□	R88D-1SN08H-ECT
3-phase 200 VAC	1 kW	R88M-1L1K030H-□	R88D-1SN10H-ECT
Single-phase/3-phase 200 VAC	1.5 kW	R88M-1L1K530H-□	R88D-1SN15H-ECT

## 2,000-r/min Servomotors and Servo Drives

Main circuit power supply voltage	Servomotor rated output	Servomotor	Servo Drive
3-phase 200 VAC	1 kW	R88M-1M1K020H-□	R88D-1SN10H-ECT
Single-phase/3-phase 200 VAC	1.5 kW	R88M-1M1K520H-□	R88D-1SN15H-ECT

### 2-3-3 Servomotor and Decelerator Combination Tables

You cannot use a 1S-series Incremental Encoder Type Servomotor in combination with a Decelerator.

### 2-3-4 Cable and Connector Model Tables

The following tables list the models of cables and connectors. The cables include encoder cables, motor power cables, and brake cables.

### **Encoder Cables (Standard Cable)**

	Applicable Servomotor	Model	
200 V	3,000-r/min Servomotors	3 m	R88A-CR1A003C
	of 100 W, 200 W, 400 W, and 750 W	5 m	R88A-CR1A005C
		10 m	R88A-CR1A010C
		15 m	R88A-CR1A015C
		20 m	R88A-CR1A020C
		30 m	R88A-CR1A030C
		40 m	R88A-CR1A040C
		50 m	R88A-CR1A050C
	3,000-r/min Servomotors of 1kW or more	3 m	R88A-CR1B003N
	2,000-r/min Servomotors	5 m	R88A-CR1B005N
		10 m	R88A-CR1B010N
		15 m	R88A-CR1B015N
		20 m	R88A-CR1B020N
		30 m	R88A-CR1B030N
		40 m	R88A-CR1B040N
		50 m	R88A-CR1B050N

## **Motor Power Cables (Standard Cable)**

Applicable Servemeter			Model			
	Applicable Servomotor		Without brake wire	With brake wire		
200 V	3,000-r/min Servomotors	3 m	R88A-CA1A003S			
	of 100 W, 200 W, 400 W, and 750 W	5 m	R88A-CA1A005S			
		10 m	R88A-CA1A010S			
		15 m	R88A-CA1A015S			
		20 m	R88A-CA1A020S			
		30 m	R88A-CA1A030S			
		40 m	R88A-CA1A040S			
		50 m	R88A-CA1A050S			
	3,000-r/min Servomotors of 1 kW	3 m	R88A-CA1B003S	R88A-CA1B003B		
	2,000-r/min Servomotors of 1 kW	5 m	R88A-CA1B005S	R88A-CA1B005B		
		10 m	R88A-CA1B010S	R88A-CA1B010B		
		15 m	R88A-CA1B015S	R88A-CA1B015B		
		20 m	R88A-CA1B020S	R88A-CA1B020B		
		30 m	R88A-CA1B030S	R88A-CA1B030B		
		40 m	R88A-CA1B040S	R88A-CA1B040B		
		50 m	R88A-CA1B050S	R88A-CA1B050B		
	3,000-r/min Servomotors of 1.5 kW	3 m	R88A-CA1C003S	R88A-CA1C003B		
	2,000-r/min Servomotors of 1.5 kW	5 m	R88A-CA1C005S	R88A-CA1C005B		
		10 m	R88A-CA1C010S	R88A-CA1C010B		
		15 m	R88A-CA1C015S	R88A-CA1C015B		
		20 m	R88A-CA1C020S	R88A-CA1C020B		
		30 m	R88A-CA1C030S	R88A-CA1C030B		
		40 m	R88A-CA1C040S	R88A-CA1C040B		
		50 m	R88A-CA1C050S	R88A-CA1C050B		

## Brake Cables (Standard Cable)

Applicable Servomotor			Model
200 V	3,000-r/min Servomotors	3 m	R88A-CA1A003B
	of 100 W, 200 W, 400 W, and 750 W	5 m	R88A-CA1A005B
			R88A-CA1A010B
		15 m	R88A-CA1A015B
		20 m	R88A-CA1A020B
		30 m	R88A-CA1A030B
		40 m	R88A-CA1A040B
		50 m	R88A-CA1A050B

## **Encoder Cables (Flexible Cable)**

	Applicable Servomotor	Model	
200 V	3,000-r/min Servomotors	3 m	R88A-CR1A003CF
	of 100 W, 200 W, 400 W, and 750 W	5 m	R88A-CR1A005CF
		10 m	R88A-CR1A010CF
		15 m	R88A-CR1A015CF
		20 m	R88A-CR1A020CF
		30 m	R88A-CR1A030CF
		40 m	R88A-CR1A040CF
		50 m	R88A-CR1A050CF
	3,000-r/min Servomotors of 1kW or more	3 m	R88A-CR1B003NF
	2,000-r/min Servomotors	5 m	R88A-CR1B005NF
		10 m	R88A-CR1B010NF
		15 m	R88A-CR1B015NF
		20 m	R88A-CR1B020NF
		30 m	R88A-CR1B030NF
		40 m	R88A-CR1B040NF
		50 m	R88A-CR1B050NF

## **Motor Power Cables (Flexible Cable)**

	Appliable Contemptor	Model			
	Applicable Servomotor		Without brake wire	With brake wire	
200 V	3,000-r/min Servomotors	3 m	R88A-CA1A003SF		
	of 100 W, 200 W, 400 W, and 750 W	5 m	R88A-CA1A005SF		
	, , ,	10 m	R88A-CA1A010SF		
		15 m	R88A-CA1A015SF		
		20 m	R88A-CA1A020SF		
		30 m	R88A-CA1A030SF		
		40 m	R88A-CA1A040SF		
		50 m	R88A-CA1A050SF		
	3,000-r/min Servomotors of 1 kW	3 m	R88A-CA1B003SF	R88A-CA1B003BF	
	2,000-r/min Servomotors of 1 kW	5 m	R88A-CA1B005SF	R88A-CA1B005BF	
		10 m	R88A-CA1B010SF	R88A-CA1B010BF	
		15 m	R88A-CA1B015SF	R88A-CA1B015BF	
		20 m	R88A-CA1B020SF	R88A-CA1B020BF	
		30 m	R88A-CA1B030SF	R88A-CA1B030BF	
		40 m	R88A-CA1B040SF	R88A-CA1B040BF	
		50 m	R88A-CA1B050SF	R88A-CA1B050BF	
	3,000-r/min Servomotors of 1.5 kW	3 m	R88A-CA1C003SF	R88A-CA1C003BF	
	2,000-r/min Servomotors of 1.5 kW	5 m	R88A-CA1C005SF	R88A-CA1C005BF	
		10 m	R88A-CA1C010SF	R88A-CA1C010BF	
		15 m	R88A-CA1C015SF	R88A-CA1C015BF	
		20 m	R88A-CA1C020SF	R88A-CA1C020BF	
		30 m	R88A-CA1C030SF	R88A-CA1C030BF	
		40 m	R88A-CA1C040SF	R88A-CA1C040BF	
		50 m	R88A-CA1C050SF	R88A-CA1C050BF	

## **Brake Cables (Flexible Cable)**

	Applicable Servomotor	Model	
200 V	3,000-r/min Servomotors	3 m	R88A-CA1A003BF
	of 100 W, 200 W, 400 W, and 750 W		R88A-CA1A005BF
		10 m	R88A-CA1A010BF
		15 m	R88A-CA1A015BF
		20 m	R88A-CA1A020BF
		30 m	R88A-CA1A030BF
		40 m	R88A-CA1A040BF
		50 m	R88A-CA1A050BF

### Peripheral Connector

### Servo Drive side connector

Name and application	Model
Main circuit connector (CNA)*1	R88A-CN102P*4
For R88D-1SN01L-ECT/ -1SN02L-ECT/ -1SN04L-ECT/ -1SN01H-ECT/	
-1SN02H-ECT/ -1SN04H-ECT/ -1SN08H-ECT/ -1SN10H-ECT	
Main circuit connector A (CNA)*2	R88A-CN103P*4
For R88D-1SN15H-ECT/ -1SN20H-ECT/ -1SN30H-ECT/ -1SN06F-ECT/	
-1SN10F-ECT/ -1SN15F-ECT/ -1SN20F-ECT/ -1SN30F-ECT	
Main circuit connector B (CNB)*2	R88A-CN104P*4
For R88D-1SN15H-ECT/ -1SN20H-ECT/ -1SN30H-ECT/ -1SN06F-ECT/	
-1SN10F-ECT/ -1SN15F-ECT/ -1SN20F-ECT/ -1SN30F-ECT	
Motor connector (CNC)	R88A-CN101A*4
For R88D-1SN01L-ECT/ -1SN02L-ECT/ -1SN04L-ECT/	
-1SN01H-ECT/-1SN02H-ECT/ -1SN04H-ECT/ -1SN08H-ECT/ -1SN10H-ECT	
Motor connector (CNC)	R88A-CN102A <sup>*4</sup>
R88D-1SN15H-ECT/ -1SN20H-ECT/ -1SN30H-ECT/ -1SN06F-ECT/	
-1SN10F-ECT/ -1SN15F-ECT/ -1SN20F-ECT/ -1SN30F-ECT	
Control power supply connector (CND)	R88A-CN101P*4
For R88D-1SN15H-ECT/ -1SN20H-ECT/ -1SN30H-ECT/ -1SN06F-ECT/	
-1SN10F-ECT/ -1SN15F-ECT/ -1SN20F-ECT/ -1SN30F-ECT	
Control I/O connector (CN1)*3	R88A-CN101C
Encoder connector (CN2)	R88A-CN101R
Brake interlock connector (CN12)	R88A-CN101B

<sup>\*1.</sup> Two short-circuit wires are connected to the connector.

<sup>\*2.</sup> One short-circuit wire is connected to the connector.

<sup>\*3.</sup> Four short-circuit wires are connected to the connector.

<sup>\*4.</sup> One opener is included.

### Servomotor side connector

Na	Model			
Encoder connector	oder connector 200 V For 3,000 r/min (100 to 750 W)			
	200 V	For 3,000 r/min (1 to 1.5 kW) For 2,000 r/min	R88A-CN104R	
Power connector (for 750 W ma	R88A-CN111A			
Brake connector (for 750 W ma	R88A-CN111B			

# **External and Mounting Dimensions**

This section provides the external dimensions and mounting dimensions of Servo Drives, Servomotors and peripheral devices.


#### 2-4-1 **Servomotor Dimensions**

Servomotors are grouped by rated rotation speed, and described in order of increasing rated output.

### 3,000-r/min Servomotors (200 V)


### • 100 W (without Brake)

R88M-1M10030H-S2



Model	Dimensions [mm]
Wodei	LL
R88M-1M10030H-S2	89±1


Note The standard shaft type is with a key and tap.



Model	Dimensions [mm]							
Wiodei	QA	QK	W	T	U	QE	LT	
R88M-1M10030H-S2	2	12	3 <sup>0</sup> -0.025	3	1.2 0 -0.2	M3	8	


### • 100 W (with Brake)

R88M-1M10030H-BS2



Model	Dimensions [mm]		
iviodei	LL		
R88M-1M10030H-BS2	125±1		

Note The standard shaft type is with a key and tap.




Model	Dimensions [mm]						
Model	QA	QK	W	Т	U	QE	LT
R88M-1M10030H-BS2	2	12	3 <sup>0</sup> -0.025	3	1.2 0	М3	8

### • 200 W/400 W (without Brake)


R88M-1M20030H-S2

R88M-1M40030H-S2



Model	Dimensions [mm]				
Wiodei		S	LL		
R88M-1M20030H-S2	11	0 -0.011 dia.	78.5±1		
R88M-1M40030H-S2	14	0 -0.011 dia.	104.5±1		

Note The standard shaft type is with a key and tap.




Model	Dimensions [mm]							
Wiodei	QA	QK	W	Т	U	QE	LT	
R88M-1M20030H-S2	2	20	4 0 -0.03	4	1.5 0	M4	10	
R88M-1M40030H-S2	2	20	5 -0.03	5	2 0 -0.2	M5	12	

### • 200 W/400 W (with Brake)


R88M-1M20030H-BS2

R88M-1M40030H-BS2



Model	Dimensions [mm]					
Wiodei	S	LL				
R88M-1M20030H-BS2	11 0 -0.011 dia.	106.5±1				
R88M-1M40030H-BS2	14 0 -0.011 dia.	132.5±1				


Note The standard shaft type is with a key and tap.




Model	Dimensions [mm]							
Wiodei	QA	QK	W	T	U	QE	LT	
R88M-1M20030H-BS2	2	20	4 0 -0.03	4	1.5 0	M4	10	
R88M-1M40030H-BS2	2	20	5 0 -0.03	5	2 0 -0.2	M5	12	

### • 750 W (without Brake)


### R88M-1M75030H-S2





Model	Dimensions [mm]
Wiodei	LL
R88M-1M75030H-S2	116.3±1


Note The standard shaft type is with a key and tap.




Model	Dimensions [mm]							
Model	QA	QK	W	T	U	QE	LT	
R88M-1M75030H-S2	3.	24	6 -0.03	6	2.5 0 -0.2	M5	12	

### • 750 W (with Brake)


#### R88M-1M75030H-BS2





Model	Dimensions [mm]
Wiodei	LL
R88M-1M75030H-BS2	152±1

Note The standard shaft type is with a key and tap.




Model	Dimensions [mm]							
Wodei	QA	QK	W	Т	U	QE	LT	
R88M-1M75030H-BS2	3	24	6 -0.03	6	2.5 0 -0.2	M5	12	

### • 1 kW/1.5 kW (without Brake)


R88M-1L1K030H-S2

R88M-1L1K530H-S2



Model	Dimensions [mm]							
Wiodei	LL	KB1	KB2	KL2				
R88M-1L1K030H-S2	168±2	85±1	153±2	97±2				
R88M-1L1K530H-S2	168±2	85±1	153±2	97±2				

Note The standard shaft type is with a key and tap.




Model	Dimensions [mm]							
Wodel	QA	QK	W	T	U	QE	LT	
R88M-1L1K030H-S2	3,	42	6 -0.03	6	2.5 <sup>0</sup> -0.2	M5	12	
R88M-1L1K530H-S2	3,	42	6 -0.03	6	2.5 0	M5	12	

### • 1 kW/1.5 kW (with Brake)


R88M-1L1K030H-BS2

R88M-1L1K530H-BS2



Model	Dimensions [mm]						
Wodel	LL	KB1	KB2	KL2			
R88M-1L1K030H-BS2	209±3	85±1	194±2	97±2			
R88M-1L1K530H-BS2	209±3	85±1	194±2	97±2			

Note The standard shaft type is with a key and tap.




Model	Dimensions [mm]							
Wiodei	QA	QK	W	T	U	QE	LT	
R88M-1L1K030H-BS2	3	42	6 -0.03	6	2.5 0	M5	12	
R88M-1L1K530H-BS2	3,	42	6 -0.03	6	2.5 0	M5	12	

## 2,000-r/min Servomotors (200 V)

### • 1 kW/1.5 kW (without Brake)


R88M-1M1K020H-S2

R88M-1M1K520H-S2



Model	Dimensions [mm]						
Wiodei	LL	KB1	KB2	KL2			
R88M-1M1K020H-S2	120.5±2	63±1	109±2	118±2			
R88M-1M1K520H-S2	138±2	79±1	125±2	118±2			

Note The standard shaft type is with a key and tap.




Model	Dimensions [mm]						
Woder	QA	QK	W	Т	U	QE	LT
R88M-1M1K020H-S2	3	42	8 <sup>0</sup> -0.036	7	3 0 -0.4	M5	12
R88M-1M1K520H-S2	3	42	8 <sup>0</sup> -0.036	7	3 0 -0.4	M5	12

### • 1 kW/1.5 kW (with Brake)


R88M-1M1K020H-BS2

R88M-1M1K520H-BS2



Model	Dimensions [mm]				
Model	LL	KB1	KB2	KL2	
R88M-1M1K020H-BS2	162±2	63±1	149±2	118±2	
R88M-1M1K520H-BS2	179±2	79±1	166±2	118±2	

Note The standard shaft type is with a key and tap.



Model	Dimensions [mm]						
Wiodei	QA	QK	W	Т	U	QE	LT
R88M-1M1K020H-BS2	3	42	8 0 -0.036	7	3 -0.4	M5	12
R88M-1M1K520H-BS2	3	42	8 -0.036	7	3 -0.4	M5	12



# **Specifications**

This section provides the general specifications, characteristics, encoder specifications of the Servomotors and other peripheral devices.

For the general specifications, connector specifications and I/O circuits of the Servo Drives, refer to the AC Servomotors/Servo Drives 1S-series with Built-in EtherCAT® Communications User's Manual (I586).

3-1	Servo	Drive Specifications	3-2
	3-1-1	Characteristics	3-2
	3-1-2	Main Circuit and Motor Connections	3-4
	3-1-3	Encoder Connector (CN2) Specifications	3-8
	3-1-4	Overload Characteristics (Electronic Thermal Function)	3-8
3-2	Servor	motor Specifications	3-10
	3-2-1	General Specifications	3-10
	3-2-2	Encoder Specifications	
	3-2-3	Characteristics	
3-3	Cable	and Connector Specifications	3-17
	3-3-1	Encoder Cable Specifications	3-17
	3-3-2	Motor Power Cable Specifications	3-22
	3-3-3	Resistance to Bending of Flexible Cable	3-34
	3-3-4	Connector Specifications	3-36

# **Servo Drive Specifications**

Select a Servo Drive that matches the Servomotor to be used. Refer to 2-3-2 Servo Drive and Servomotor Combination Tables on page 2-6.

#### 3-1-1 **Characteristics**

The characteristics of the Servo Drives are shown below.

### 200-VAC Input Models

S	Servo Drive mode	I (R88D-)	1SN01H-ECT	1SN02H-ECT	1SN04H-ECT	1SN08H-ECT		
	Item		100 W	200 W	400 W	750 W		
Input Main circuit Power supply voltage			Single-phase and 3-phase 200 to 240 VAC (170 to 252 V)*1					
		Frequency		50/60 Hz (47	.5 to 63 Hz)*1			
	Control circuit	Power sup- ply voltage						
		Current consumption*2		600	mA			
	Rated current [A (rms)]	Single- phase	1.8	2.7	4.6	7.3		
	(Main circuit power supply voltage: 240 VAC)	3-phase	1.0	1.5	2.7	4.0		
Out-	Rated current [A	(rms)]	0.8	1.5	2.5	4.6		
put	Maximum current	t [A (rms)]	3.1	5.6	9.1	16.9		
	num power loss of a conversion	Servo Drive at	10% (Load condition: rated output)					
Applic [W]	able Servomotor r	ated output	100	200	400	750		
3,000- tor (R8	r/min Servomo- 38M-)	23-bit INC	1M10030H	1M20030H	1M40030H	1M75030H		
2,000- tor (R8	r/min Servomo- 38M-)	23-bit INC						
Hold time at momentary power interruption (Main circuit power supply voltage: 200 VAC)					ion: rated output) <sup>*(</sup>			
Weigh	t [kg]		1.2	1.2	1.5	2.0		

Servo Drive model (R88D-)			1SN10H-ECT	1SN15H-ECT	
	ltem		1 kW	1.5 kW	
Input	Main circuit	Power sup- ply voltage	3-phase 200 to 240 VAC (170 to 252 V)*1	Single-phase and 3-phase 200 to 240	
				VAC (170 to 252 V)*1	
Frequenc		Frequency		.5 to 63 Hz) <sup>*1</sup>	
	Control circuit	Power sup- ply voltage	24 VDC (21	.6 to 26.4 V)	
		Current con- sumption*2	600 mA	900 mA	
	Rated current [A (rms)]	Single- phase		15.7	
	(Main circuit power supply voltage: 240 VAC)	3-phase	5.8	9.0	
Out-	Rated current [A	(rms)]	7.7	9.7	
put Maximum current [A (rms)]		t [A (rms)]	16.9	28.4	
Maxin sion	num power loss at	power conver-	10% (Load condition: rated output)		
Applic [W]	able Servomotor r	ated output	1,000	1,500	
3,000-r/min Servomotor (R88M-)		23-bit INC	1L1K030H	1L1K530H	
2,000-r/min Servomo- tor (R88M-)		1M1K020H	1M1K520H		
Hold time at momentary power interruption		10 ms (Load condi	tion: rated output) <sup>*3</sup>		
(Main circuit power supply voltage: 200 VAC)					
Weigh	<u>'</u>		2.0	3.4	

<sup>\*1.</sup> The values outside parentheses indicate the rated value, and the values inside parentheses indicate the range of acceptable variation.

The rated current value that is printed on the product nameplate is a condition to apply the 1S-series product for the UL/Low Voltage Directive.

Therefore, you do not need to consider it when you select a DC power supply for each model

\*3. The control power supply is not specified here as long as a DC power supply that meets the following conditions is used.

Reinforced insulation or double insulation, and the output hold time of 10 ms or more

<sup>\*2.</sup> Select a DC power supply in consideration of the current values that are specified in the current consumption.

#### 3-1-2 **Main Circuit and Motor Connections**


When you wire the main circuit, use proper wire sizes, grounding systems, and noise resistance.

### R88D-1SN01H-ECT/-1SN02H-ECT/-1SN04H-ECT/-1SN08H-ECT /-1SN10H-ECT

### Main Circuit Connector (CNA) Specifications

Pin No.	Symbol	Name	Specifications
1	L1	Main circuit power sup-	R88D-1SN□H-ECT
3	L2 L3	ply input	Single-phase <sup>*1</sup> 200 to 240 VAC (170 to 252 V) 50/60 Hz (47.5 to 63 Hz)
			R88D-1SN□H-ECT
			3-phase 200 to 240 VAC (170 to 252 V) 50/60 Hz (47.5 to 63 Hz)
4	B3	External Regeneration	When the Internal Regeneration Resistor is used:
5	B2	Resistor connection ter-	Open between B1 and B2.
6	P/B1	minals	Short-circuit B2 and B3.
			When the External Regeneration Resistor is used:
			Connect the External Regeneration Resistor between B1 and B2.
			Open between B2 and B3.
7	N1	DC reactor connection	When the DC reactor is not used:
8	N2	terminals	Short-circuit N1 and N2.
9	N3		When the DC reactor is used:
			Connect the DC reactor between N1 and N2.
10	24V	Control circuit power	24 VDC (21.6 to 26.4 V)
11	Ø	supply input	Measured current value: 600 mA

<sup>\*1.</sup> For single-phase, connect between any two phases out of the following: L1, L2, and L3.



### Motor Connector (CNC) Specifications

Pin No.	Symbol	Name		Specifications
1	U	Motor connection termi-	Phase U	These are output terminals to the Servomotor.
2	V	nals	Phase V	
3	W		Phase W	




# R88D-1SN15H-ECT

### • Main Circuit Connector A (CNA) Specifications


Symbol	Name	Specifications
B1	External Regeneration	When the Internal Regeneration Resistor is used:
B2	Resistor connection termi-	Open between B1 and B2.
В3	nals	Short-circuit B2 and B3.
		When the External Regeneration Resistor is used:
		Connect the External Regeneration Resistor between B1 and B2.
		Open between B2 and B3.
L3	Main circuit power supply	R88D-1SN15H-ECT
L2	input	Single-phase *1 200 to 240 VAC (170 to 252 V) 50/60 Hz (47.5 to 63
L1		Hz)
		R88D-1SN15H-ECT/-1SN20H-ECT/-1SN30H-ECT
		3-phase 200 to 240 VAC (170 to 252 V) 50/60 Hz (47.5 to 63 Hz)

<sup>\*1.</sup> For single-phase, connect between any two phases out of the following: L1, L2, and L3.



### • Main Circuit Connector B (CNB) Specifications

Symbol	Name	Specifications
N3	DC reactor connection ter-	When the DC reactor is not used:
N2	minals	Short-circuit N1 and N2.
N1		When the DC reactor is used:
P		Connect the DC reactor between N1 and N2.




### • Control Circuit Connector (CND) Specifications

Pin No.	Symbol	Name	Specifications
1	+24V	Control circuit power sup-	24 VDC (21.6 to 26.4 V)
2	0 V	ply input	Measured current value: 900 mA
3			Do not connect.



### Motor Connector (CNC) Specifications

Symbol	Name	Specifications			
W	Motor connection terminals	Phase W	These are output terminals to the Servomotor.		
V		Phase V	Be sure to wire them correctly.		
U		Phase U			
FG		FG			



# **Terminal Block Wire Sizes**

The following tables show the rated current that flows to the terminal block on the Servo Drive and the applicable wire sizes. Use the wire with the rated voltage of 600 V or higher for the main circuit.

The wire size is determined for when the heat-resistant polyvinyl chloride insulated wire (HIV) is used at the ambient temperature of 50°C.

### ■ Wire Sizes for 200-VAC Input Model: R88D-1SN□H-ECT

ltow		11.74		Mo	odel (R88D-1S	SN)		
Item	1	Unit	01H-ECT	02H-ECT	04H-ECT	08H-ECT	10H-ECT	
Power supply cap	oacity	kVA	0.6	0.6	1.0	1.4	2.0	
Main circuit power supply input (L1, L2, and L3) *1	Rated cur- rent	A(rms)	1.8/1.0 <sup>*2</sup>	2.7/1.5 <sup>*2</sup>	4.6/2.7 <sup>*2</sup>	7.3/4.0 <sup>*2</sup>	5.8	
	Wire size		AWG 22 to 14, 0.32 to 2.0 mm <sup>2</sup>	AWG 20 to 14, 0.5 to 2.0 mm <sup>2</sup>	AWG 18 to 14, 0.75 to 2.0 mm <sup>2</sup>	AWG16 to 14, 1.3 to 2.0 mm <sup>2</sup>		
Control circuit power supply input (24 V, Ø)	Wire size		AWG 20 to 16, 0.5 to 1.5 mm <sup>2</sup>					
Motor connection terminals	Rated cur- rent	A(rms)	0.8	1.5	2.5	4.6	7.7	
(U, V, and W) <sup>*3*4</sup>	Wire size			2 to 14, 2.0 mm <sup>2</sup>	AWG 20 to 14, 0.5 to 2.0 mm <sup>2</sup>	AWG 18 to 14, 0.75 to 2.0 mm <sup>2</sup>	AWG16 to 14, 1.3 to 2.0 mm <sup>2</sup>	
Protective earth	Wire size		AWG 12, 2.5 mm <sup>2</sup>					
<b>\\ \\ \</b>	Screw size			M4				
	Tightening torque	N·m		1.2				

			Model (R88D-1SN)
Item		Unit	15H-ECT
Power supply capac	ity	kVA	2.5
Main circuit power supply input (L1,	Rated cur- rent	А	15.7/ 9.0 <sup>*2</sup>
L2, and L3) *1	Wire size		AWG 12 to 8, 3.3 to 8.4 mm <sup>2</sup>
Control circuit power supply input (+24 V and 0 V)	Wire size		AWG 20 to 16, 0.5 to 1.5 mm <sup>2</sup>
Motor connection terminals (U, V,	Rated cur- rent	А	9.7
and W) *3*4	Wire size		AWG 14 to 8, 2.0 to 8.4 mm <sup>2</sup>
Protective earth	Wire size		AWG 12, 2.5 mm <sup>2</sup>
	Screw size		M4
	Tightening torque	N·m	1.2

<sup>\*1.</sup> For single-phase, connect between any two phases out of the following: L1, L2, and L3.

# Wire Sizes and Allowable Current (Reference)

The following table shows the allowable currents for each wire size.

Select wires carefully so that the specified allowable currents are not exceeded.

### • 600-V Heat-resistant Vinyl Wire (HIV)

AWG size	Nominal cross-sec- Configuration		Conductive resistance	Allowable current [A] for ambient temperature		
AVVO SIZE	tional area [mm²]	[wires/mm <sup>2</sup> ]	[wires/mm <sup>2</sup> ] $[\Omega/km]$		<b>40</b> °C	<b>50</b> °C
20	0.5	19/0.18	39.5	6.6	5.6	4.5
	0.75	30/0.18	26.0	8.8	7.0	5.5
18	0.9	37/0.18	24.4	9.0	7.7	6.0
16	1.25	50/0.18	15.6	12.0	11.0	8.5
14	2.0	7/0.6	9.53	23	20	16
12	3.5	7/0.8	5.41	33	29	24
10	5.5	7/1.0	3.47	43	38	31
8	8.0	7/1.2	2.41	55	49	40
6	14.0	7/1.6	1.35	79	70	57
4	22.0	7/2.0	0.85	99	88	70

<sup>\*2.</sup> The first value is for single-phase input power and the second value is for 3-phase input power.

<sup>\*3.</sup> Connect OMRON Power Cables to the motor connection terminals.

<sup>\*4.</sup> Use the wire with the same current capacity for the wiring of the motor connection terminals and for that of B1 and B2.

#### 3-1-3 **Encoder Connector (CN2) Specifications**

The specifications of the encoder connectors are shown below.

Pin No.	Symbol	Name		
1	E5V	Encoder power supply voltage		
2	E0V	Encoder power supply GND		
3	Not used.	NC		
4	Not used.	NC		
5	PS+	Encoder + phase S I/O		
6	PS-	Encoder - phase S I/O		
Shell	FG	Frame ground		

### Connectors for CN2 (6 Pins)

Name	Model	Manufacturer	OMRON model
Receptacle	3E206-0100KV	3M	R88A-CN101R
Shell kit	3E306-3200-008	3M	

#### 3-1-4 Overload Characteristics (Electronic Thermal Function)

The overload protection function (electronic thermal) is built into the Servo Drive to protect the Servo Drive and Servomotor from overloading.

If an overload occurs, first eliminate the cause of the overload and then wait for the Servomotor temperature to drop before you turn ON the power again.

If the error reset is repeated at short intervals, the Servomotor windings may burn out.

## **Overload Characteristics Graphs**


The following graphs show the electronic thermal operation time after continuous operation with 100% load (hot start).

The electronic thermal operation time after a continuous 0% load state (cold start) is longer than that for a hot start.

In cases where models with an oil seal or with a brake have different characteristics, each of their characteristics is described.

The characteristics are the same as those of models with no option unless otherwise specified.

#### 200-VAC Servomotors



# **Servomotor Specifications**

The following 1S-Series Incremental Encoder Type Servomotors are available.

- 3,000-r/min Servomotors
- 2,000-r/min Servomotors

There are various options available, such as models with brakes, or different shaft types.

Select a Servomotor based on the mechanical system's load conditions and the installation environment.

#### 3-2-1 **General Specifications**

	Item		Specifications		
	ambient ten	nperature	0 to 40°C		
and humidity			20% to 90% (with no condensation)		
Storage a	mbient temp	erature and	-20 to 65°C		
humidity			20% to 90% (with no condensation)		
Operating	and storage	atmosphere	No corrosive gases		
Vibration r	esistance <sup>*1</sup>		Acceleration of 49 m/s <sup>2</sup>		
			24.5 m/s <sup>2</sup> max. in X, Y, and Z directions when the motor is stopped		
Impact res	sistance		Acceleration of 98 m/s <sup>2</sup> max. 3 times each in X, Y, and Z directions		
Insulation resistance			Between power terminals and FG terminals: 10 M $\Omega$ min. (at 500 VDC Megger)		
Dielectric	strength		Between power terminals and FG terminals: 1,500 VAC for 1 min (voltage 100 V, 200 V)		
			Between power terminals and FG terminals: 1,800 VAC for 1 min (voltage 400 V)		
			Between brake terminal and FG terminals: 1,000 VAC for 1 min		
Insulation	class		Class F		
Protective	structure		IP67 (except for the through-shaft part and connector pins)		
			IP20 if you use a 30-meter or longer encoder cable.		
Interna-	EU Direc-	Low Volt-	EN 60034-1/-5		
tional	tives age Direc-				
standard		tive			
	UL standar	ds	UL 1004-1/-6		
	CSA stand	ards	CSA C22.2 No.100 (with cUL mark)		

<sup>\*1.</sup> The amplitude may be increased by machine resonance. As a guideline, 80% of the specified value must not be exceeded.

Note 1. Do not use the cable when it is laying in oil or water.

2. Do not expose the cable outlet or connections to stress due to bending or its own weight.

# 3-2-2 Encoder Specifications

The encoder specifications are shown below.

Item	Specifications
Encoder system	Optical incremental encoder
Resolution per rotation	23 bits
Power supply voltage	5 VDC±10%
Current consumption	230 mA max.
Output signal	Serial communications
Output interface	RS485 compliant

#### Characteristics 3-2-3

# 3,000-r/min Servomotors

Mo			del (R88M-)		200	VAC	
	Iter	n	Unit	1M10030H	1M20030H	1M40030H	1M75030H
Rated ou	tput* <sup>1</sup> * <sup>2</sup>		W	100	200	400	750
Rated tor			N·m	0.318	0.637	1.27	2.39
Rated rot	ation speed	d* <sup>1</sup> * <sup>2</sup>	r/min		3,0	000	
Maximun	n rotation s	peed	r/min		6,0	000	
Momenta	ıry maximu	m torque*1	N·m	1.11	2.2	4.5	8.4
Rated cu	rrent*1*2		A (rms)	0.84	1.5	2.5	4.6
Momenta	ıry maximu	m current*1	A (rms)	3.10	5.6	9.1	16.9
Rotor ine		Without brake	× 10 <sup>-4</sup>	0.0890	0.2232	0.4452	1.8242
			kg⋅m²				
		With brake	× 10 <sup>-4</sup>	0.0968	0.2832	0.5052	2.0742
			kg⋅m²				
Applicabl	e load iner	ia	× 10 <sup>-4</sup>	1.62	4.80	8.40	19.4
			kg⋅m²				
Torque co	onstant* <sup>1</sup>		N·m/ A	0.42	0.48	0.56	0.59
•			(rms)				
Power ra	te* <sup>1</sup> * <sup>3</sup>		kW/s	11.9	18.5	36.6	31.4
Mechanio	cal time cor	nstant* <sup>3</sup>	ms	1.2	0.78	0.56	0.66
Electrical	time const	ant	ms	0.83	2.4	2.6	3.3
Allowable	e radial load	d* <sup>4</sup>	N	68	245	245	490
Allowable	thrust load	d* <sup>4</sup>	N	58	88	88	196
Weight	With	nout brake	kg	0.52	1.0	1.4	2.9
	With	n brake	kg	0.77	1.3	1.9	3.9
Radiator	plate dimer	nsions (material)	mm	250 × 250 × t6 (aluminum)			
Brake	Excitation	n voltage* <sup>5</sup>	V		24 DC	±10%	
specifi- cations	Current of (at 20°C)	consumption	А	0.27	0.32	0.32	0.37
	Static fric	tion torque	N·m	0.32 min.	1.37 min.	1.37 min.	2.55 min.
	Attraction	n time	ms	25 max.	30 max.	30 max.	40 max.
	Release	time* <sup>6</sup>	ms	15 max.	20 max.	20 max.	35 max.
Backlash		0	1.2 max.	1.2 max.	1.2 max.	1.0 max.	
	Allowable braking work		J	9	60	60	250
	Allowable total work		J	9,000	60,000	60,000	250,000
	Allowable angular acceleration		rad/s <sup>2</sup>		10,000	) max.	
	Brake life tion/dece	etime (accelera- eleration)		10 million times min.			
	Insulation	n class			Clas	ss F	


		Mod	del (R88M-)	200	VAC
	Iter		Unit	1L1K030H	1L1K530H
Rated out	tput <sup>*1*2</sup>		W	1,000	1,500
Rated tor			N·m	3.18	4.77
Rated rot	ation speed	d*1*2	r/min	3,0	000
	rotation s		r/min	5,0	000
Momenta	ry maximu	m torque*1	N·m	9.55	14.3
Rated cur			A (rms)	5.2	8.8
Momenta	ry maximu	m current*1	A (rms)	16.9	28.4
Rotor ine		Without brake	× 10 <sup>-4</sup>	2.1042	2.1042
			kg·m <sup>2</sup>		
		With brake	× 10 <sup>-4</sup>	2.5542	2.5542
			kg⋅m²		
Applicable	e load iner	tia	× 10 <sup>-4</sup>	35.3	47.6
			kg⋅m²		
Torque co	nstant* <sup>1</sup>		N·m/ A	0.67	0.58
·			(rms)		
Power rat	te* <sup>1*3</sup>		kW/s	48	108
	al time cor		ms	0.58	0.58
	time const		ms	5.9	6.1
Allowable	radial load	d <sup>*4</sup>	N	490	
Allowable	thrust load		N	196	
Weight		nout brake	kg	5.7	5.7
- " -		n brake	kg	7.4 7.4	
		nsions (material)	mm	400 × 400 × t20 (aluminum)	
Brake specifi-		n voltage <sup>*5</sup>	V		C±10%
cations	(at 20°C)	consumption	Α	0.70	0.70
	,	tion torque	N·m	9.3 min.	9.3 min.
	Attraction	•	ms	100 max.	100 max.
	Release	time <sup>*6</sup>	ms	30 max.	30 max.
Backlash		٥	1.0 max.	1.0 max.	
	Allowable braking work		J	500	500
Allowable total work		J	900,000	900,000	
	Allowable angular acceleration		rad/s <sup>2</sup>	10,000	0 max.
		time (accelera-		10 million	times min.
	tion/dece	· · · · · · · · · · · · · · · · · · ·			
	Insulation	n class		Class F	

<sup>\*1.</sup> This is a typical value for when the Servomotor is used at a normal temperature (20°C, 65%) in combination with a Servo Drive.

<sup>\*2.</sup> The rated values are the values with which continuous operation is possible at an ambient temperature of 40°C when the Servomotor is horizontally installed on a specified radiator plate.

<sup>\*3.</sup> This value is for models without options.


The allowable radial loads are applied as shown in the following diagram.



- \*5. This is a non-excitation brake. It is released when excitation voltage is applied.
- \*6. This value is a reference value.

# Torque-Rotation Speed Characteristics for 3,000-r/min Servomotors (200 VAC)

The following graphs show the characteristics with a 3-m standard cable and a 3-phase 200-VAC or single-phase 220-VAC input.



Note The continuous operation range is the range in which continuous operation is possible at an ambient temperature of 40°C when the Servomotor is horizontally installed on a specified radiator plate.

Continuous operation at the maximum speed is also possible. However, doing so will reduce the output torque.

# 2,000-r/min Servomotors

Mod		del (R88M-)	200	VAC	
	Iter	n	Unit	1M1K020H	1M1K520H
Rated out	tput <sup>*1*2</sup>		W	1,000	1,500
Rated tor	que*1*2		N·m	4.77	7.16
Rated rot	ation speed	d* <sup>1</sup> * <sup>2</sup>	r/min	2,0	000
	rotation s		r/min	3,0	000
Momenta	ry maximu	m torque*1	N·m	14.3	21.5
Rated cui			A (rms)	5.2	8.6
Momenta	ry maximu	m current*1	A (rms)	16.9	28.4
Rotor ine		Without brake	10 <sup>-4</sup>	6.0042	9.0042
			kg⋅m <sup>2</sup>		
		With brake	10 <sup>-4</sup>	6.5042	9.5042
			kg·m <sup>2</sup>		
Applicable	e load inert	ia	10 <sup>-4</sup>	59.0	79.9
			kg⋅m²		
Torque co	nstant* <sup>1</sup>		N·m/A	0.93	0.83
			(rms)		
Power rat	:e* <sup>1*3</sup>		kW/s	38	57
Mechanic	al time cor	ıstant* <sup>3</sup>	ms	0.94	0.78
Electrical	time const	ant	ms	13	15
Allowable	radial load	j*4	N	490	
Allowable	thrust load	J* <sup>4</sup>	N	196	
Weight	With	out brake	kg	6.6	8.5
	With	n brake	kg	8.6	10.5
Radiator	plate dimer	nsions (material)	mm	400 × 400 × t20	470 × 470 × t20
	T			(aluminum) (aluminum)	
Brake		n voltage <sup>*5</sup>	V	24 VD	C±10%
specifi- cations	Current of (at 20°C)	onsumption	Α	0.51	0.51
		tion torque	N·m	9.0 min.	9.0 min.
	Attraction	ı time	ms	100 max.	100 max.
	Release	time <sup>*6</sup>	ms	30 max.	30 max.
Backlash		0	0.6 max.	0.6 max.	
	Allowable braking work		J	1,000	1,000
	Allowable total work		J	3,000,000	3,000,000
	Allowable angular acceleration		rad/s <sup>2</sup>	10,00	0 max.
	Brake life	time (accelera- leration)		10 million	times min.
	Insulation			Cla	ss F


<sup>\*1.</sup> This is a typical value for when the Servomotor is used at a normal temperature (20°C, 65%) in combination with a Servo Drive.

<sup>\*2.</sup> The rated values are the values with which continuous operation is possible at an ambient temperature of 40°C when the Servomotor is horizontally installed on a specified radiator plate.

<sup>\*3.</sup> This value is for models without options.

\*4. The allowable radial and thrust loads are the values determined for a limit of 20,000 hours at normal operating temperatures.

The allowable radial loads are applied as shown in the following diagram.




- \*5. This is a non-excitation brake. It is released when excitation voltage is applied.
- \*6. This value is a reference value.


# Torque-Rotation Speed Characteristics for 2,000-r/min Servomotors (200 VAC)

The following graphs show the characteristics with a 3-m standard cable and a 3-phase 200-VAC or single-phase 220-VAC input.

#### • R88M-1M1K020H

#### R88M-1M1K520H





Note The continuous operation range is the range in which continuous operation is possible at an ambient temperature of 40°C when the Servomotor is horizontally installed on a specified radiator plate.

Continuous operation at the maximum speed is also possible. However, doing so will reduce the output torque.

# 3-3 Cable and Connector Specifications

This section describes the specifications of the cables to connect between Servo Drives and Servomotors, and the connectors to be used.

Select an appropriate cable for the Servomotor.

### 3-3-1 Encoder Cable Specifications

These cables are used to connect the Servo Drive with an encoder installed in the Servomotor. Select an appropriate cable for the Servomotor.



#### **Precautions for Correct Use**

If the cable is used in a moving part, use a flexible cable.

The protective structure rating of the Servomotor with an encoder cable whose length [L] is 30 m or more is IP20.

### **Encoder Cables (Standard Cable)**

#### ■ R88A-CR1A□□□C

Applicable Servomotors


200 V:


3,000-r/min Servomotors of 100 W, 200 W, 400 W, and 750 W

#### Cable types

Model	Length [L]	Outer diameter of sheath	Weight
R88A-CR1A003C	3 m	5.3 dia.	Approx. 0.3 kg
R88A-CR1A005C	5 m		Approx. 0.4 kg
R88A-CR1A010C	10 m		Approx. 0.7 kg
R88A-CR1A015C	15 m		Approx. 1.0 kg
R88A-CR1A020C	20 m		Approx. 1.4 kg
R88A-CR1A030C	30 m	6.0 dia.	Approx. 2.2 kg
R88A-CR1A040C	40 m		Approx. 3.0 kg
R88A-CR1A050C	50 m		Approx. 3.7 kg

#### Connection configuration and external dimensions [mm]





#### ● R88A-CR1B□□□N

Applicable Servomotors


200 V:


3,000-r/min Servomotors of 1 kW, 2,000-r/min Servomotors

#### Cable types

Model	Length [L]	Outer diameter of sheath	Weight
R88A-CR1B003N	3 m	6.0 dia.	Approx. 0.3 kg
R88A-CR1B005N	5 m		Approx. 0.4 kg
R88A-CR1B010N	10 m		Approx. 0.8 kg
R88A-CR1B015N	15 m		Approx. 1.1 kg
R88A-CR1B020N	20 m		Approx. 1.5 kg
R88A-CR1B030N	30 m		Approx. 2.3 kg
R88A-CR1B040N	40 m		Approx. 3.0 kg
R88A-CR1B050N	50 m		Approx. 3.7 kg

#### Connection configuration and external dimensions [mm]





# Encoder Cables (Flexible Cable)

#### ● R88A-CR1A□□□CF

Applicable Servomotors


200 V:

3,000-r/min Servomotors of 100 W, 200 W, 400 W, and 750 W


#### Cable types

Model	Length [L]	Outer diame- ter of sheath	Minimum bending radius	Weight
R88A-CR1A003CF	3 m	5.3 dia.	33 mm	Approx. 0.3 kg
R88A-CR1A005CF	5 m			Approx. 0.4 kg
R88A-CR1A010CF	10 m			Approx. 0.7 kg
R88A-CR1A015CF	15 m			Approx. 1.0 kg
R88A-CR1A020CF	20 m			Approx. 1.4 kg
R88A-CR1A030CF	30 m	6.0 dia.	42 mm	Approx. 2.2 kg
R88A-CR1A040CF	40 m			Approx. 3.0 kg
R88A-CR1A050CF	50 m			Approx. 3.7 kg

### Connection configuration and external dimensions [mm]



### Wiring



Servo Drive side connector

AWG22 × 2C + AWG24 × 1P UL20276 (3 to 20 m) AWG18 × 2C + AWG24 × 1P UL20276 (30 to 50 m)

Connector model Receptacle: 3E206-0100KV (3M)

Shell kit: 3E306-3200-008 (3M)

Servomotor side connector

Angle clamp model

JN6FR07SM1 (Japan Aviation Electronics)

Connector pin model

LY10-C1-A1-10000 (Japan Aviation Electronics)

#### ● R88A-CR1B□□□NF

Applicable Servomotors


200 V:

3,000-r/min Servomotors of 1 kW and 2,000-r/min Servomotors


#### Cable types

Model	Length [L]	Outer diame- ter of sheath	Minimum bending radius	Weight
R88A-CR1B003NF	3 m	6.0 dia.	33 mm	Approx. 0.3 kg
R88A-CR1B005NF	5 m			Approx. 0.4 kg
R88A-CR1B010NF	10 m			Approx. 0.8 kg
R88A-CR1B015NF	15 m			Approx. 1.1 kg
R88A-CR1B020NF	20 m			Approx. 1.5 kg
R88A-CR1B030NF	30 m		42 mm	Approx. 2.3 kg
R88A-CR1B040NF	40 m			Approx. 3.0 kg
R88A-CR1B050NF	50 m			Approx. 3.7 kg

#### Connection configuration and external dimensions [mm]



#### Wiring



Servo Drive side connector

AWG22 × 2C + AWG24 × 1P UL20276 (3 to 20 m) AWG18 × 2C + AWG24 × 1P UL20276 (30 to 50 m)

Connector model

Receptacle: 3E206-0100KV (3M) Shell kit: 3E306-3200-008 (3M) Servomotor side connector Straight plug model

JN2DS10SL1-R

(Japan Aviation Electronics)

Contact model JN1-22-22S-10000

(Japan Aviation Electronics)

#### **Motor Power Cable Specifications** 3-3-2

These cables are used to connect the Servo Drive and Servomotor. Select an appropriate cable for the Servomotor.



#### **Precautions for Correct Use**

If the cable is used in a moving part, use a flexible cable.

## **Power Cables without Brake Wire (Standard Cable)**

#### ■ R88A-CA1A□□□S

Applicable Servomotors


200 V:


3,000-r/min Servomotors of 100 W, 200 W, 400 W, and 750 W

#### Cable types

Model	Length [L]	Outer diameter of sheath	Weight
R88A-CA1A003S	3 m	6.8 dia.	Approx. 0.4 kg
R88A-CA1A005S	5 m		Approx. 0.6 kg
R88A-CA1A010S	10 m		Approx. 1.1 kg
R88A-CA1A015S	15 m		Approx. 1.5 kg
R88A-CA1A020S	20 m		Approx. 2.0 kg
R88A-CA1A030S	30 m		Approx. 3.0 kg
R88A-CA1A040S	40 m		Approx. 4.0 kg
R88A-CA1A050S	50 m		Approx. 5.0 kg

#### Connection configuration and external dimensions [mm]





#### ● R88A-CA1B□□□S

Applicable Servomotors


200 V:


3,000-r/min Servomotors of 1 kW and 2,000-r/min Servomotors of 1 kW

#### Cable types

Model	Length [L]	Outer diameter of sheath	Weight
R88A-CA1B003S	3 m	10.8 dia.	Approx. 1.0 kg
R88A-CA1B005S	5 m		Approx. 1.6 kg
R88A-CA1B010S	10 m		Approx. 2.9 kg
R88A-CA1B015S	15 m		Approx. 4.3 kg
R88A-CA1B020S	20 m		Approx. 5.7 kg
R88A-CA1B030S	30 m		Approx. 8.4 kg
R88A-CA1B040S	40 m		Approx. 11.1 kg
R88A-CA1B050S	50 m		Approx. 13.8 kg

#### Connection configuration and external dimensions [mm]





#### ● R88A-CA1C□□□S

Applicable Servomotors


200 V:


3,000-r/min Servomotors of 1.5 kW and 2,000-r/min Servomotors of 1.5 kW

#### Cable types

Model	Length [L]	Outer diameter of sheath	Weight
R88A-CA1C003S	3 m	10.8 dia.	Approx. 1.0 kg
R88A-CA1C005S	5 m		Approx. 1.6 kg
R88A-CA1C010S	10 m		Approx. 2.9 kg
R88A-CA1C015S	15 m		Approx. 4.3 kg
R88A-CA1C020S	20 m		Approx. 5.7 kg
R88A-CA1C030S	30 m		Approx. 8.4 kg
R88A-CA1C040S	40 m		Approx. 11.1 kg
R88A-CA1C050S	50 m		Approx. 13.8 kg

#### Connection configuration and external dimensions [mm]





### **Power Cables without Brake Wire (Flexible Cable)**

#### ■ R88A-CA1A□□□SF

Applicable Servomotors


200 V:


3,000-r/min Servomotors of 100 W, 200 W, 400 W, and 750 W

#### Cable types

Model	Length [L]	Outer diame- ter of sheath	Minimum bending radius	Weight
R88A-CA1A003SF	3 m	6.8 dia.	40 mm	Approx. 0.4 kg
R88A-CA1A005SF	5 m			Approx. 0.6 kg
R88A-CA1A010SF	10 m			Approx. 1.1 kg
R88A-CA1A015SF	15 m			Approx. 1.5 kg
R88A-CA1A020SF	20 m			Approx. 2.0 kg
R88A-CA1A030SF	30 m			Approx. 3.0 kg
R88A-CA1A040SF	40 m			Approx. 4.0 kg
R88A-CA1A050SF	50 m			Approx. 5.0 kg

#### Connection configuration and external dimensions [mm]





#### ● R88A-CA1B□□□SF

Applicable Servomotors


200 V:


3,000-r/min Servomotors of 1 kW and 2,000-r/min Servomotors of 1 kW

#### Cable types

Model	Length [L]	Outer diame- ter of sheath	Minimum bending radius	Weight
R88A-CA1B003SF	3 m	10.8 dia.	90 mm	Approx. 1.0 kg
R88A-CA1B005SF	5 m			Approx. 1.6 kg
R88A-CA1B010SF	10 m			Approx. 2.9 kg
R88A-CA1B015SF	15 m			Approx. 4.3 kg
R88A-CA1B020SF	20 m			Approx. 5.7 kg
R88A-CA1B030SF	30 m			Approx. 8.4 kg
R88A-CA1B040SF	40 m			Approx. 11.1 kg
R88A-CA1B050SF	50 m			Approx. 13.8 kg

#### Connection configuration and external dimensions [mm]





#### ● R88A-CA1C□□□SF

Applicable Servomotors

200 V:


3,000-r/min Servomotors of 1.5 kW


2,000-r/min Servomotors of 1.5 kW

#### Cable types

Model	Length [L]	Outer diame- ter of sheath	Minimum bending radius	Weight
R88A-CA1C003SF	3 m	10.8 dia.	90 mm	Approx. 1.0 kg
R88A-CA1C005SF	5 m			Approx. 1.6 kg
R88A-CA1C010SF	10 m			Approx. 2.9 kg
R88A-CA1C015SF	15 m			Approx. 4.3 kg
R88A-CA1C020SF	20 m			Approx. 5.7 kg
R88A-CA1C030SF	30 m			Approx. 8.4 kg
R88A-CA1C040SF	40 m			Approx. 11.1 kg
R88A-CA1C050SF	50 m			Approx. 13.8 kg

### Connection configuration and external dimensions [mm]





### **Power Cables with Brake Wire (Standard Cable)**

#### ■ R88A-CA1B□□□B

Applicable Servomotors

200 V:


3,000-r/min Servomotors of 1 kW

2,000-r/min Servomotors of 1 kW

#### Cable types

Model	Length [L]	Outer diameter of sheath	Weight
R88A-CA1B003B	3 m	12.5 dia.	Approx. 1.2 kg
R88A-CA1B005B	5 m		Approx. 1.9 kg
R88A-CA1B010B	10 m		Approx. 3.5 kg
R88A-CA1B015B	15 m		Approx. 5.1 kg
R88A-CA1B020B	20 m		Approx. 6.7 kg
R88A-CA1B030B	30 m		Approx. 10.0 kg
R88A-CA1B040B	40 m		Approx. 13.2 kg
R88A-CA1B050B	50 m		Approx. 16.5 kg

#### Connection configuration and external dimensions [mm]



#### ● R88A-CA1C□□□B

Applicable Servomotors

200 V:


3,000-r/min Servomotors of 1.5 kW


2,000-r/min Servomotors of 1.5 kW

#### Cable types

Model	Length [L]	Outer diameter of sheath	Weight
R88A-CA1C003B	3 m	12.5 dia.	Approx. 1.2 kg
R88A-CA1C005B	5 m		Approx. 1.9 kg
R88A-CA1C010B	10 m		Approx. 3.5 kg
R88A-CA1C015B	15 m		Approx. 5.1 kg
R88A-CA1C020B	20 m		Approx. 6.7 kg
R88A-CA1C030B	30 m		Approx. 10.0 kg
R88A-CA1C040B	40 m		Approx. 13.2 kg
R88A-CA1C050B	50 m		Approx. 16.5 kg

### Connection configuration and external dimensions [mm]





### **Power Cables with Brake Wire (Flexible Cable)**

#### ● R88A-CA1B□□□BF

Applicable Servomotors

200 V:


3,000-r/min Servomotors of 1 kW


2,000-r/min Servomotors of 1 kW

#### Cable types

Model	Length [L]	Outer diame- ter of sheath	Minimum bending radius	Weight
R88A-CA1B003BF	3 m	12.5 dia.	90 mm	Approx. 1.2 kg
R88A-CA1B005BF	5 m			Approx. 1.9 kg
R88A-CA1B010BF	10 m			Approx. 3.5 kg
R88A-CA1B015BF	15 m			Approx. 5.1 kg
R88A-CA1B020BF	20 m			Approx. 6.7 kg
R88A-CA1B030BF	30 m			Approx. 10.0 kg
R88A-CA1B040BF	40 m			Approx. 13.2 kg
R88A-CA1B050BF	50 m			Approx. 16.5 kg

Connection configuration and external dimensions [mm]





#### ● R88A-CA1C□□□BF

Applicable Servomotors

200 V:


3,000-r/min Servomotors of 1.5 kW


2,000-r/min Servomotors of 1.5 kW

#### Cable types

Model	Length [L]	Outer diame- ter of sheath	Minimum bending radius	Weight
R88A-CA1C003BF	3 m	12.5 dia.	90 mm	Approx. 1.2 kg
R88A-CA1C005BF	5 m			Approx. 1.9 kg
R88A-CA1C010BF	10 m			Approx. 3.5 kg
R88A-CA1C015BF	15 m			Approx. 5.1 kg
R88A-CA1C020BF	20 m			Approx. 6.7 kg
R88A-CA1C030BF	30 m			Approx. 10.0 kg
R88A-CA1C040BF	40 m			Approx. 13.2 kg
R88A-CA1C050BF	50 m			Approx. 16.5 kg

### Connection configuration and external dimensions [mm]





# **Brake Cables (Standard Cable)**

### ■ R88A-CA1A□□□B

Applicable Servomotors


200 V:

3,000-r/min Servomotors of 100 W, 200 W, 400 W, and 750 W

#### Cable types

Model	Length [L]	Outer diameter of sheath	Weight
R88A-CA1A003B	3 m	5.0 dia.	Approx. 0.2 kg
R88A-CA1A005B	5 m		Approx. 0.3 kg
R88A-CA1A010B	10 m		Approx. 0.5 kg
R88A-CA1A015B	15 m		Approx. 0.7 kg
R88A-CA1A020B	20 m		Approx. 0.9 kg
R88A-CA1A030B	30 m		Approx. 1.4 kg
R88A-CA1A040B	40 m		Approx. 1.8 kg
R88A-CA1A050B	50 m		Approx. 2.3 kg

#### Connection configuration and external dimensions [mm]



#### Wiring



Servomotor side connector

Connector

JN6FR02SM1 (Japan Aviation Electronics)

Socket contact

LY10-C1-A1-10000 (Japan Aviation Electronics)

# **Brake Cables (Flexible Cable)**

### ● R88A-CA1A□□□BF

Applicable Servomotors


200 V:

3,000-r/min Servomotors of 100 W, 200 W, 400 W, and 750 W

#### Cable types

Model	Length [L]	Outer diame- ter of sheath	Minimum bending radius	Weight
R88A-CA1A003BF	3 m	5.0 dia.	30 mm	Approx. 0.2 kg
R88A-CA1A005BF	5 m			Approx. 0.3 kg
R88A-CA1A010BF	10 m			Approx. 0.5 kg
R88A-CA1A015BF	15 m			Approx. 0.7 kg
R88A-CA1A020BF	20 m			Approx. 0.9 kg
R88A-CA1A030BF	30 m			Approx. 1.4 kg
R88A-CA1A040BF	40 m			Approx. 1.8 kg
R88A-CA1A050BF	50 m			Approx. 2.3 kg

#### Connection configuration and external dimensions [mm]



#### Wiring



Servomotor side connector

Connector

JN6FR02SM1 (Japan Aviation Electronics)

Socket contact

LY10-C1-A1-10000 (Japan Aviation Electronics)

#### **Resistance to Bending of Flexible Cable** 3-3-3

If the cable is used in a moving part, use a flexible cable.


The flexing life of a Flexible Cable is estimated under the following conditions.



#### **Precautions for Correct Use**

- · Because the lifetime data on resistance to bending is intended for reference only, use the cable with a sufficient margin.
- · The minimum bending radius refers to the value at which the core conductor provides electrical continuity without causing cracks and scratches that can have functional impact on the sheath, which does not cover the disconnection of shielded wire.
- · Malfunction or grounding fault due to dielectric breakdown may occur if cables are used at a radius smaller than the minimum bending radius.

## **Moving Bend Test**



### Encoder Cable

	Bend test	Bend test conditions		
Model	Minimum bending radius [R]	Stroke	Estimated life	
R88A-CR1A□□□CF*1	33 mm	500 to 1,000 mm	20 million times	
R88A-CR1B□□□NF*1				
R88A-CR1A△△△CF <sup>*2</sup>	42 mm	500 to 1,000 mm	20 million times	
R88A-CR1B $\triangle\triangle\triangle$ NF $^{*2}$				

<sup>\*1.</sup>  $\square\square\square$  represents a number between 003 and 020.

When 030 to 050 cables are used, the bending position on the cables must be at least 100 mm away from the Servomotor's connector.

<sup>\*2.</sup>  $\triangle\triangle\triangle$  represents a number between 030 and 050.

### Power Cables without Brake Wire

	Bend test		
Model	Minimum bending Stroke		Estimated life
R88A-CA1A□□□SF <sup>*1</sup>	40 mm	500 mm	10 million times
R88A-CA1B□□□SF*1	90 mm	500 to 1,000 mm	20 million times
R88A-CA1C□□□SF*1			

<sup>\*1.</sup>  $\square\square\square$  represents a number between 003 and 050.

### Power Cables with Brake Wire

	Bend test		
Model	Minimum bending radius [R]	Stroke	Estimated life
R88A-CA1B□□□BF <sup>*1</sup>	90 mm	500 to 1,000 mm	20 million times
R88A-CA1C□□□BF*1			
R88A-CA1D□□□BF*1			

<sup>\*1.</sup>  $\square\square\square$  represents a number between 003 and 050.

### Brake Cable

	Bend test		
Model	Minimum bending radius [R]	Stroke	Estimated life
R88A-CA1A□□□BF <sup>*1</sup>	30 mm	500 to 1,000 mm	20 million times

<sup>\*1.</sup>  $\square\square\square$  represents a number between 003 and 050.

#### **Connector Specifications** 3-3-4


# **Encoder Cable Connectors**


These connectors are used for encoder cables.

Use them when you prepare an encoder cable by yourself.

### Servo Drive Connector


1	tem	Specifications
Applicable Servomo	tor	1S-series Servomotors of all capacities
Connector		This is a soldering-type connector.
	Receptacle	3E206-0100KV (3M)
	Shell kit	3E306-3200-008 (3M)
	Receptacle and	R88A-CN101R (OMRON)
	shell kit	
Applicable cable	Applicable wire	AWG 18 max.
	Insulating cover	2.1 mm dia. max.
	outer diameter	
	Outer diameter of	5.4 to 7.5 mm dia.
	sheath	







### Servomotor Connector


ltem		Specifications
Applicable Servo-	200 V	3,000-r/min Servomotors of 100 to 750 W
motor		
Connector		This is a crimping-type connector. For required tools, contact the
		manufacturers directly.
	Angle plug	JN6FR07SM1 (Japan Aviation Electronics)
	Connector pin	LY10-C1-A1-10000 (Japan Aviation Electronics)
	Angle plug and con-	R88A-CNK02R (OMRON)
	nector pin	
Applicable cable	Applicable wire	AWG 22 max.
	Insulating cover	1.3 mm dia. max.
	outer diameter	
	Outer diameter of	5.0±0.5 mm dia.
	sheath	





Item		Specifications
Applicable Servo-	200 V	3,000-r/min Servomotors of 1 to 1.5 kW
motor		2,000-r/min Servomotors of 1 to 1.5 kW
Connector		This is a crimping-type connector. For required tools, contact the manufacturers directly.
	Straight plug	JN2DS10SL1-R (Japan Aviation Electronics)
	Contact	JN1-22-22S-10000 (Japan Aviation Electronics)
	Straight plug and contact	R88A-CN104R (OMRON)
Applicable cable	Applicable wire	AWG 20 max.
	Outer diameter of sheath	5.7 to 7.3 mm dia.







# Power Cable Connector

This connector is used for power cables.

Use it when you prepare a power cable by yourself.

Item		Specifications
Applicable Servo- motor	200 V	3,000-r/min Servomotors of 100 to 750 W
Connector		This is a crimping-type connector. For required tools, contact the manufacturers directly.
	Angle plug	JN6FS05SJ2 (Japan Aviation Electronics)
	Socket contact	ST-JN6-S-C1B-2500 (Japan Aviation Electronics)
	Angle plug and socket contact	R88A-CN111A (OMRON)
Applicable cable	Applicable wire	AWG 18
	Insulating cover outer diameter	1.7 to 1.9 mm dia.
	Outer diameter of sheath	6.4 to 7.2 mm dia.







# **Brake Cable Connector**

This connector is used for brake cables.

Use it when you prepare a brake cable by yourself.

Item		Specifications
Applicable Servo- motor	200 V	3,000-r/min Servomotors of 100 to 750 W
Connector		This is a crimping-type connector. For required tools, contact the manufacturers directly.
	Angle plug	JN6FR02SM1 (Japan Aviation Electronics)
	Socket contact	LY10-C1-A1-10000 (Japan Aviation Electronics)
	Angle plug and socket contact	R88A-CN111B (OMRON)
Applicable cable	Applicable wire	AWG 22 to 26
	Insulating cover outer diameter	0.8 to 1.3 mm dia.
	Outer diameter of sheath	4.5 to 5.5 mm dia.







# **Configuration and Wiring**

This section explains the conditions for installing, Servomotors, and the wiring methods including wiring conforming to EMC Directives.

For the Servo Drive installation conditions, the regenerative energy calculation methods, and the performance of External Regeneration Resistors, refer to the AC Servo-motors/Servo Drives 1S-series with Built-in EtherCAT® Communications User's Manual (I586).

4-1	Installa	tion Conditions	4-2
	4-1-1	Servomotor Installation Conditions	4-2
4-2	Wiring		4-5
	4-2-1	Connector Attachment Procedure	. 4-5
	4-2-2	Power/Brake Connector Attachment Procedure	. 4-7
4-3	Wiring	Conforming to EMC Directives	4-8
	4-3-1	Peripheral Equipment Connection Examples	. 4-9
	4-3-2	Selecting Connection Component	4-18

# **Installation Conditions**

This section explains the conditions for installing Servo Drives, Servomotors and noise filters.

#### 4-1-1 **Servomotor Installation Conditions**

## **Operating Environment Conditions**

· The environment in which the Servomotor is operated must meet the following conditions. Operating the Servomotor outside of the following ranges may result in malfunction of the Servomotor.


Operating temperature: 0 to 40°C (The temperature at a point 50 mm from the Servomotor)

Operating humidity: 20% to 90% max. (with no condensation)

Operating ambient atmosphere: No corrosive gases.

## **Impact and Load**


- The Servomotor is resistant to vibration of up to 49 m/s<sup>2</sup>.
- If the Servomotor is mounted on a thin plate, the rigidity may decrease and severe vibration may occur.
- The Servomotor is resistant to impacts of up to 98 m/s<sup>2</sup>. Do not apply heavy impacts or loads during transport, installation, or removal of the Servomotor.
- When transporting the Servomotor hold the motor body itself. And do not hold the encoder, cable, or connector areas. Failure to follow this guideline may result in damaging the Servomotor.
- Always use a pulley remover to remove pulleys, couplings, or other parts from the shaft.
- · Connect cables and connectors carefully so that they are not strained. After assembly, secure cables so that there is no impact or load placed on the cable outlet.
- As a magnetic sensor is used for the encoder of the Servomotor, do not apply external magnetic force on the Servomotor (10 mT at the encoder cover surface).



## **Connecting to Mechanical Systems**

- For the allowable axial loads for Servomotors, refer to 3-2-3 Characteristics on page 3-12. If an axial load greater than that specified is applied to a Servomotor, it may reduce the limit of the motor bearings and may break the motor shaft.
- When you connect the Servomotor to a load, use couplings that can sufficiently absorb mechanical eccentricity and declination.
- When you connect or disconnect loads (or couplings) to or from the Servomotor, be careful not to apply an impact on the motor shaft. Do not allow the thrust load and radial load to exceed the values that are specified in the manual or catalog while you connect a load to the Servomotor.
- If an abnormal noise is generated from couplings, adjust the shaft center again to eliminate the noise.
- When you align the shaft center of the couplings, turn both the Servomotor side shaft and equipment side shaft.
- For spur gears, an extremely large radial load may be applied depending on the gear precision. Use spur gears with a high degree of precision (for example, JIS class 2: normal line pitch error of 6 μm max. for a pitch circle diameter of 50 mm).
- If the gear precision is not adequate, allow backlash to ensure that no radial load is placed on the motor shaft.
- When you use bevel gears, a load is applied in the thrust direction depending on the assembly precision, the gear precision, and temperature changes. Provide appropriate backlash or take other measures to ensure


appropriate backlash or take other measures to ensure that a thrust load larger than the specified level is not applied.





- When you connect the Servomotor to a V-belt or timing belt, consult the manufacturer for belt selection and tension.
- A radial load twice as large as the belt tension will be placed on the motor shaft. Do not allow a load that exceeds the allowable radial load to be placed on the motor shaft. If an excessive radial load is applied, the motor shaft and bearings may be damaged.


Set up a movable pulley in the middle of the motor shaft and the load shaft so that the belt tension can be adjusted.


Install the Servo Drive so that its bottom faces the gravity direction.











## Water and Drip Resistance

The protective structure rating of the Servomotor is IP67, except for the through-shaft part and connector pins.

It is IP20 if you use a 30-meter or longer encoder cable.


## **Oil-water Measures**

Do not use the Servomotors in an environment where oil drops can adhere to the through-shaft part.

### **Radiator Plate Installation Conditions**

When you mount a Servomotor onto a small device, be sure to provide enough radiation space on the mounting area because the heat is radiated from the mounting surface. Otherwise the Servomotor temperature may rise too high. One of the preventive measures is to install a radiator plate between the motor attachment area and the motor flange. (See the following figure)

Failure to follow this guideline may result in damaging the Servomotor due to a temperature rise. Refer to 3-2 Servomotor Specifications on page 3-10 for the radiator plate specifications.



- The temperature rise depends on the mounting part materials and the installation environment. Check the actual temperature rise by using a real Servomotor.
- Depending on the environment, such as when the Servomotor is installed near a heating element, the Servomotor temperature may rise significantly. In this case, take any of the following measures.
  - a) Lower the load ratio.
  - b) Review the heat radiation conditions of the Servomotor.
  - c) Install a cooling fan and apply forced air cooling to the Servomotor.

### **Other Precautions**

Take measures to protect the motor shaft from corrosion. The motor shaft is coated with anti-corrosion oil when it is shipped, but you should also apply anti-corrosion oil or grease when you connect the components that apply load to the shaft.





Do not apply a commercial power supply directly to the motor.

Fire may result.



Do not repair the Servo Drive by disassembling it. Electric shock or injury may result.


# 4-2 Wiring

This section gives the examples of connection with peripheral equipment and wirig such as connection of the main circuit and Servomotor.


### 4-2-1 Connector Attachment Procedure

This section describes the procedure for attaching a connector to a Servomotor with a flange size of 80 x 80 or less. This example uses an encoder connector.

**1** Align the connector's orientation with the key position, and fit the connector into place.




2 Tighten the screws to fix the connector after it is fitted.



Example of a gap


Note Make sure that the connector is securely fitted into place without a gap or tilt.

Do not tighten the screws if the connector is not securely fitted into place. Doing so may result in a damage. Tighten the four screws evenly.



Example of a gap

Example: tighten the screws in the order of 1, 4, 3, and then 2.




Example of screw tightening order


#### 4-2-2 Power/Brake Connector Attachment Procedure

This section describes the procedure for attaching the Servomotor power/brake connector. Use the following procedure to fit the connectors.

## **1** Align of the main keys of the plug and receptacle.




\* The arrow mark on the receptacle shell indicates the position of the main key.




## **2** Press in the plug gently and turn the coupling nut clockwise.

Fitting is completed when the turned coupling nut clicks into place.



When fitting is completed, the arrow marks of the plug and receptacle are aligned.



Note Before starting the fitting procedure, make sure that there is no dirt, foreign materials, etc. adhered to the fitting surfaces.

Do not perform the procedure in an environment where water or oil can adhere to these surfaces. After fitting is completed, pull the plug gently (20 N max.) to confirm that it does not come out.

# Wiring Conforming to EMC Directives

1S-series Servo Drives conform to the EMC Directives (EN 61800-3) under the wiring conditions described in this section.


The following conditions are determined so that 1S-series products can conform to EMC Directives. When the products are installed in the equipment, the customer must perform the check to confirm that the overall machine conforms to EMC Directives.

The following are the conditions required for conformance to the EMC Directives.

- · Install the Servo Drive on the ground plate.
- · Install a noise filter and lightening surge absorbing element (surge absorber) on the power line.
- Use braided-shield cables for the I/O signals and encoder. Tinned soft steel wires must be used for the shields.
- · Ground the shield of each cable.

## 4-3-1 Peripheral Equipment Connection Examples

# R88D-1SN01H-ECT/-1SN02H-ECT/-1SN04H-ECT/-1SN08H-ECT



Note For single-phase inputs, connect between any two phases out of the following: L1, L2, and L3.

- Provide single-point grounding of the ground plate for unit frame grounding as shown in the above diagram.
- Use a protective earth wire with a minimum thickness of 2.5 mm<sup>2</sup> and arrange the wiring so that the protective earth wire is as short as possible.
- Install a surge absorber and noise filter near the main circuit connector A of Servo Drive. Separate I/O wires from each other for the wiring.

#### Device Details

Symbol	Name	Manufacturer	Model	Remarks
SG	Surge absorber	Soshin Electric Co.,	LT-C32G801WS	3-phase 200 VAC
		Ltd.		
NF	Noise filter	Soshin Electric Co.,	HF3020C-SZC-33DDD	3-phase 200 VAC (20 A)
		Ltd.	*1	
		OMRON	R88A-FI1S202	3-phase R88D-1SN01H-ECT
				3-phase R88D-1SN02H-ECT
			R88A-FI1S203	3-phase R88D-1SN04H-ECT
			R88A-FI1S208	3-phase R88D-1SN08H-ECT
SD	Servo Drive	OMRON		*2
SM	Servomotor	OMRON		*2
FC1	Ferrite core	NEC TOKIN	ESD-SR-250	
FC2	Ferrite core	SEIWA ELECTRIC	E04SR301334	
		MFG		
	I/O slave			
	Controller			


<sup>\*1.</sup> Consult Soshin Electric Co., Ltd. for the specifications.

#### Cable Details

No.	Interface	Max. cable	Cable clas	Cable classification		
NO.	interrace	length, shield	EN/IEC 61800-3	EN/IEC 61326-3-1	core	
1	Power supply cable	3 m	Power supply port	AC input power sup-	None	
	(main circuit)	Non-shielded		ply port		
2	Power supply cable	3 m	Port for process mea-	Signal and control	2 turns	
	(control circuit)	Non-shielded	surement and control	line		
4	Motor cable (Servomo-	20 m	Power supply inter-	Signal and control	2 turns	
	tor)	Shielded	face	line		
5	EtherCAT communica-	20 m	Signal interface	Signal and control	1 turn	
	tions cable (ECAT IN)	Shielded		line		
6	EtherCAT communica-	20 m	Signal interface	Signal and control	1 turn	
	tions cable (ECAT OUT)	Shielded		line		
7	Safety/control	20 m	Signal interface	Signal and control	None	
	I/O cables	Shielded		line		
		20 m	Signal interface	Signal and control	None	
		Shielded		line		
9	Encoder cable	20 m	Signal interface	Signal and control	None	
		Shielded		line		
10	Brake interlock cable	20 m	Signal interface	Signal and control	None	
		Non-shielded		line		

<sup>\*2.</sup> Refer to 2-3-2 Servo Drive and Servomotor Combination Tables on page 2-6 for Servo Drive and Servomotor combinations.

## R88D-1SN10H-ECT



- Provide single-point grounding of the ground plate for unit frame grounding as shown in the above diagram.
- Use a protective earth wire with a minimum thickness of 2.5 mm<sup>2</sup> and arrange the wiring so that the protective earth wire is as short as possible.
- Install a surge absorber and noise filter near the main circuit connector of Servo Drive.
   Separate I/O wires from each other for the wiring.

#### Device Details

Symbol	Name	Manufacturer	Model	Remarks
SG	Surge absorber	Soshin Electric Co., Ltd.	LT-C32G801WS	3-phase 200 VAC
NF	Noise filter	Soshin Electric Co., Ltd.	HF3020C-SZC-33DDD *1	3-phase 200 VAC (20 A)
		OMRON	R88A-FI1S208	3-phase R88D-1SN10H-ECT
SD	Servo Drive	OMRON	R88D-1SN10H-ECT	*2
SM	Servomotor	OMRON		*2
FC1	Ferrite core	NEC TOKIN	ESD-SR-250	
FC2	Ferrite core	SEIWA ELECTRIC MFG	E04SR301334	
	I/O slave			
	Controller			


<sup>\*1.</sup> Consult Soshin Electric Co., Ltd. for the specifications.

## Cable Details

No.	Interface	Max. cable	Cable clas	Ferrite	
NO.	interrace	length, shield	EN/IEC 61800-3	EN/IEC 61326-3-1	core
1	Power supply cable	3 m	Power supply port	AC input power sup-	None
	(main circuit)	Non-shielded		ply port	
2	Power supply cable	3 m	Port for process mea-	Signal and control	2 turns
	(control circuit)	Non-shielded	surement and control	line	
4	Motor cable (Servomo-	20 m	Power supply inter-	Signal and control	2 turns
	tor)	Shielded	face	line	
5	EtherCAT communica-	20 m	Signal interface	Signal and control	1 turn
	tions cable (ECAT IN)	Shielded		line	
6	EtherCAT communica-	20 m	Signal interface	Signal and control	1 turn
	tions cable (ECAT	Shielded		line	
	OUT)				
7	Safety/control	20 m	Signal interface	Signal and control	None
	I/O cables	Shielded		line	
		20 m	Signal interface	Signal and control	None
		Shielded		line	
9	Encoder cable	20 m	Signal interface	Signal and control	None
		Shielded		line	
10	Brake Interlock cable	20 m	Signal interface	Signal and control	None
		Shielded		line	

<sup>\*2.</sup> Refer to 2-3-2 Servo Drive and Servomotor Combination Tables on page 2-6 for Servo Drive and Servomotor combinations.

## R88D-1SN15H-ECT



Note For single-phase inputs, connect between any two phases out of the following: L1, L2, and L3.

- Provide single-point grounding of the ground plate for unit frame grounding as shown in the above diagram.
- Use a protective earth wire with a minimum thickness of 2.5 mm<sup>2</sup> and arrange the wiring so that the protective earth wire is as short as possible.
- Install a surge absorber and noise filter near the main circuit connector A of Servo Drive. Separate I/O wires from each other for the wiring.

#### Device Details

Symbol	Name	Manufacturer	Model	Remarks
SG	Surge absorber	Soshin Electric Co., Ltd.	LT-C32G801WS	3-phase 200 VAC
NF	Noise filter	Soshin Electric Co., Ltd.	HF3020C-SZC-33DDD *1	3-phase 200 VAC (20 A)
		OMRON	R88A-FI1S216	3-phase R88D-1SN15H-ECT
				3-phase R88D-1SN20H-ECT
				3-phase R88D-1SN30H-ECT
SD	Servo Drive	OMRON		*2
SM	Servomotor	OMRON		*2
FC1	Ferrite core	NEC TOKIN	ESD-SR-250	
	I/O slave			
	Controller			

<sup>\*1.</sup> Consult Soshin Electric Co., Ltd. for the specifications.

#### Cable Details

No.	Interface	Max. cable	Cable clas	Cable classification		
NO.	interrace	length, shield	EN/IEC 61800-3	EN/IEC 61326-3-1	core	
1	Power supply cable	3 m	Power supply port	AC input power sup-	None	
	(main circuit)	Non-shielded		ply port		
2	Power supply cable	3 m	Port for process mea-	Signal and control	2 turns	
	(control circuit)	Non-shielded	surement and control	line		
4	Motor cable (Servomo-	20 m	Power supply inter-	Signal and control	None	
	tor)	Shielded	face	line		
5	EtherCAT communica-	20 m	Signal interface	Signal and control	1 turn	
	tions cable (ECAT IN)	Shielded		line		
6	EtherCAT communica-	20 m	Signal interface	Signal and control	1 turn	
	tions cable (ECAT OUT)	Shielded		line		
7	Safety/control	20 m	Signal interface	Signal and control	None	
	I/O cables	Shielded		line		
		20 m	Signal interface	Signal and control	None	
		Shielded		line		
9	Encoder cable	20 m	Signal interface	Signal and control	None	
		Shielded		line		
10	Brake Interlock cable	20 m	Signal interface	Signal and control	None	
		Shielded		line		

<sup>\*2.</sup> Refer to 2-3-2 Servo Drive and Servomotor Combination Tables on page 2-6 for Servo Drive and Servomotor combinations.

# **Noise Filter for Power Input**

The following noise filters are recommended for Servo Drives.

The noise filter comes in two types: book type and footprint type. Both types conform to the EMC Directives.

Applica	able Servo Drive				
Phase	Model	Model	Rated current	Leakage current	Manufacturer
Single-	R88D-1SN□□□-E	HF2020A-SZC-33	20 Arms	8.5 mA max.	Soshin Electric
phase	CT	DDD		(at 250 VAC 60 Hz)	Co., Ltd.
3-phase	R88D-1SN□□H-E	HF3020C-SZC-33	20 Arms	3.5 mA max.	
	CT <sub>1</sub>	DDD		(at 400 VAC 50 Hz by	
				UL1283 <sup>*2</sup> ),	
				4.0 mA max.	
				(at 200 VAC 60 Hz, delta	
				connection and	
				single-phase ground)	


<sup>\*1.</sup> Consult Soshin Electric Co., Ltd. for the specifications.


<sup>\*2.</sup> When you use a neutral grounded 3-phase power supply, the leakage current does not flow normally.

	Applicat	ole Servo Drive	Fo	Footprint-type Noise Filter			
Phase	Voltage	Model	Model	Rated current	Leakage current	Manu- facturer	
Single-	200 V	R88D-1SN01H-ECT	R88A-FI1S103	3 Arms	6.6 mA (at 200	OMRON	
phase		R88D-1SN02H-ECT			VAC 60Hz)		
		R88D-1SN04H-ECT	R88A-FI1S105	5 Arms			
		R88D-1SN08H-ECT	R88A-FI1S109	9 Arms			
		R88D-1SN15H-ECT	R88A-FI1S116	16 Arms			
3-phase	200 V	R88D-1SN01H-ECT	R88A-FI1S202*1	2 Arms	35 mA		
		R88D-1SN02H-ECT			(at 200 VAC 60Hz,		
					with delta connec-		
					tion and single		
					phase ground)		
		R88D-1SN01H-ECT	R88A-FI1S203*1	3 Arms	14 mA		
		R88D-1SN02H-ECT			(at 200 VAC 60Hz,		
		R88D-1SN04H-ECT			with delta connec-		
		R88D-1SN08H-ECT	R88A-FI1S208	8 Arms	tion and single		
		R88D-1SN10H-ECT			phase ground)		
		R88D-1SN15H-ECT	R88A-FI1S216	16 Arms			


<sup>\*1.</sup> Select a Noise Filter in accordance with the amount of the leakage current. If there is no problem with the amount of the leakage current, you can select the R88A-FI1S202.


 Place the noise filter as close as possible to the opening of the control panel. Use the diagram below to the left for wiring.





· The power cables must be twisted or tightly bundled.






· Wire the power and signal lines separately.


### • External Dimensions of Book-type Noise Filter

HF2020A-SZC-33DDD/HF3020C-SZC (-33DDD)




## • Circuit Diagram of Book-type Noise Filter

HF2020A-SZC-33DDD



HF3020C-SZC-33DDD



#### 4-3-2 **Selecting Connection Component**

This section describes the criteria for selecting connection components that are required to improve noise immunity.

Thoroughly understand the characteristics such as capacity, performance, and the range of application of the connection components before you select them.

Consult the manufacturer for details of the parts.

## Molded Case Circuit Breaker (MCCB)

Select a molded case circuit breaker based on the maximum input current and inrush current.

#### Maximum input current

- The momentary maximum output of the Servo Drive is approximately three times as much as the rated output, and the maximum output duration is three seconds. Therefore, select a molded case circuit breaker which can operate 10 seconds or more at 300% of the rated current.
- Select a molded case circuit breaker with a rated current larger than the sum of the effective load current (when multiple Servo Drives are used). Refer to Main Circuit and Motor Connections on page 3-4 for the rated current of the power supply input for each motor.
- · When you select a molded case circuit breaker, add the current consumption by other devices such as the Controller.

#### Inrush Current

- The following table shows the inrush current of the Servo Drives.
- The amount of inrush current that a low-speed type molded case circuit breaker can flow for 0.02 seconds is approximately 10 times higher than the rated current.
- To turn ON the power supply for multiple Servo Drives simultaneously, select a molded case circuit breaker whose allowable current in 20 ms is larger than the sum of the inrush currents shown in the following table.
- The inrush current of the control power supply is limited by the output capacity of the DC power supply in use.

Servo Drive model	Inrush current (Ao-p)
Servo Drive model	Main circuit power supply
R88D-1SN01H-ECT	16 A <sup>*1</sup>
R88D-1SN02H-ECT	16 A <sup>*1</sup>
R88D-1SN04H-ECT	16 A <sup>*1</sup>
R88D-1SN08H-ECT	16 A <sup>*1</sup>
R88D-1SN10H-ECT	16 A <sup>*1</sup>
R88D-1SN15H-ECT	29 A

<sup>\*1.</sup> If an external regeneration resistor is attached, the inrush currents of the main circuit power supplies in the above table will be increased.

(Increase in current =  $\sqrt{2}$  × main circuit power supply voltage/external regeneration resistance)

The value of the inrush current varies depending on the input voltage to the Servo Drive. The values shown above are for the following input voltages.

Model	Main circuit power supply voltage
R88D-1SN□H-ECT	240 VAC

## Leakage Breaker

- Select a leakage breaker which is made for high frequency and surge resistance.
- When you determine the threshold value for leakage current detection, add the total leakage current from all devices that are connected to the same breaker.
- Refer to the catalogs from the manufacturers for details on how to select a leakage breaker and ensure a sufficient margin.

Servo Drive model (R88D-)	Servomotor model (R88D-)	Input power	Leakage current (3 m cable)	Increase per 10 m of cable length
1SN01H-ECT	1M10030H	Single-phase 200 V	1.5 mA	1.3 mA
		3-phase 200 V		
1SN02H-ECT	1M20030H	Single-phase 200 V		
		3-phase 200 V		
1SN04H-ECT	1M40030H	Single-phase 200 V		
		3-phase 200 V		
1SN08H-ECT	1M75030H	Single-phase 200 V		
		3-phase 200 V		
1SN10H-ECT	1L1K030H	3-phase 200 V		
	1M1K020H	3-phase 200 V		
1SN15H-ECT	1L1K530H	Single-phase 200 V	2.2 mA	1.9 mA
		3-phase 200 V		
	1M1K520H	Single-phase 200 V		
		3-phase 200 V		

Note These values vary greatly depending of the installation conditions of the motor power cable and the measurement conditions. Use the values just as a reference.


## **Surge Absorber**

- Use a surge absorber to absorb the lightning surge voltage and the abnormal voltage from the power input line.
- The following table gives the recommended surge absorber specifications.


Servo Drive voltage	Surge current tolerance	Recommended manufacturer	Recommended model
Single-phase 200 VAC	410 V±20%, 2500 A	Soshin Electric Co., Ltd.	LT-C12G801WS
3-phase 200 VAC	410 V±20%, 2500 A	Soshin Electric Co., Ltd.	LT-C32G801WS

- Note 1. Refer to the catalogs from the manufacturer for how to use.
  - 2. The surge current tolerance is the value for the standard impulse current of  $8/20 \mu s$ . For a greater pulse width, reduce the current or change the surge absorber to the one with a higher capacity.
  - 3. Select a CSA-certified product when you use a surge absorber.

#### External Dimensions



### Equivalent Circuit



## **Surge Suppressors**

- · Install surge suppressors for a load with an induction coil such as a relay, solenoid, and clutch.
- The following table gives the types of surge suppressors and the recommended products.

Туре	Feature	Recommended product
Diode	Diodes are used for relatively small loads such as relays when the reset time is not an issue.  The surge voltage at power cutoff is the lowest, but the reset time takes longer.  Used for 24/48-VDC systems.	Use a high-speed diode, especially the fast-recovery diode with short reverse recovery time such as RU2 made by Sanken Electronic Co., Ltd.
Varistor	Thyristors and varistors are used for loads when an induction coil is large, as in a solenoid, and when reset time is an issue.  The surge voltage at power cutoff is approximately 1.5 times the varistor voltage.	Select the varistor voltage according to the following list.  • 24-VDC type: varistor voltage 39 V  • 100-VDC type: varistor voltage 200 V  • 100-VAC type: varistor voltage 270 V  • 200-VAC type: varistor voltage 470 V
Capacitor and resistor	The combination of capacitor and resistor is used to absorb vibration in the surge at power cutoff. You can shorten the reset time by selecting the appropriate capacitance and resistance.	Okaya Electric Industries Co., Ltd. XEB12002 0.2 μF - 120 $\Omega$ XEB12003 0.3 μF - 120 $\Omega$

<sup>•</sup> The manufacturer of varistor is shown below. Refer to the catalogs from the manufacturer for details. Varistor: SEMITEC Corporation, Panasonic Corporation

### Contactor

Select a contactor based on the inrush current that flows through circuits and the maximum momentary phase current.

For details on the inrush current of the Servo Drives, refer to *Molded Case Circuit Breaker (MCCB)* on page 4-18.

# Improving Noise Immunity of Control I/O Signals

The I/O signals may malfunction if control I/O is affected by noise.

- Use the control I/O power supply (especially 24 VDC) which is completely separated from the external power supply used for operation. Especially, be careful not to connect the ground wires of these two power supplies.
- Install a noise filter on the primary side of the control I/O power supply.
- When you use a motor with a brake, do not share the 24 VDC power supply between the brake and the control I/O (24 VDC). Also, do not connect the ground wires. Doing so may cause I/O signals to malfunction.
- If there is a long wiring for the control I/O power supply, you can improve its noise immunity by adding an approximately 1-µF laminated ceramic capacitor between the control I/O power supply and the ground at the Servo Drive's input section or the Controller's output section.

# Reactor for Harmonic Current Reduction


### Countermeasure against Harmonic Current

- · Use a reactor to suppress the harmonic current. A reactor can suppress a sharp change in cur-
- · Select the reactor according to the model of your Servo Drive.

Ар	plicable Servo Drive	DC Reactor				
Voltage	Model	Model	Rated current	Inductance (0% to 20%)		
200 VAC	R88D-1SN01H-ECT	R88A-PD2002	1.6 A	21.4 mH		
	R88D-1SN02H-ECT					
	R88D-1SN04H-ECT	R88A-PD2004	3.2 A	10.7 mH		
	R88D-1SN08H-ECT	R88A-PD2007	6.1 A	6.75 mH		
	R88D-1SN10H-ECT	R88A-PD2015	9.3 A	3.51 mH		
	R88D-1SN15H-ECT					

#### DC Reactor Connection

As shown in the following figure, remove the short-circuit wire between N1 and N2, and connect the DC Reactor between N1 and N2.



Remove the short-circuit wire between N1 and N2.



# **Details on Servo Parameters**

This section explains the details on Servomotor-related parameters, including the set values, settings, and the display.

For the details on Servo Drive-related parameters, refer to the *AC Servomotors/Servo Drives 1S-series with Built-in EtherCAT® Communications User's Manual (I586)*.

5-1	Object Description Format	5-2
5-2	External Device-related Objects	5-4
5-3	Encoder-related Objects	5-6

# **Object Description Format**

The 1S-series Servo Drives with built-in EtherCAT communications use the servo parameters that are defined with objects. For information on the objects, refer to 1-1-3 Object Dictionary on page 1-4.

In this manual, objects are described in the following format.

Index (hex)	Subindex (hex)	Object name	Setting range	Unit	Default setting	Data attri- bute	Size	Access	PDO map	Complete access	Modes of operation
<index></index>	<subindex></subindex>	<object< td=""><td><range></range></td><td><unit></unit></td><td><default></default></td><td><attri-< td=""><td><size></size></td><td><access></access></td><td><pdo< td=""><td><complete< td=""><td><modes of<="" td=""></modes></td></complete<></td></pdo<></td></attri-<></td></object<>	<range></range>	<unit></unit>	<default></default>	<attri-< td=""><td><size></size></td><td><access></access></td><td><pdo< td=""><td><complete< td=""><td><modes of<="" td=""></modes></td></complete<></td></pdo<></td></attri-<>	<size></size>	<access></access>	<pdo< td=""><td><complete< td=""><td><modes of<="" td=""></modes></td></complete<></td></pdo<>	<complete< td=""><td><modes of<="" td=""></modes></td></complete<>	<modes of<="" td=""></modes>
		name>				bute>			map>	access>	operation>

Data is indicated in pointed brackets <>. Details on data are as follows.

Item	Description
Index	Object index given by a four-digit hexadecimal number.
Subindex	Object subindex given by a two-digit hexadecimal number.
Object name	The object name. For a subindex, the subindex name is given.
Setting range	Indicates the range of data that can be set for a writable object.
Unit	Physical units.
Default setting	Default value set before shipment.
Data attribute	The timing when a change in the contents is updated for a writable object.
	A: Always updated
	D: Possible to change only when the EtherCAT communications state is Pre-Opera-
	tional (Pre-Op)
	E: Servo ON
	R: Updated after the control power is reset or restarted
	-: Write prohibited
Size	Gives the object size.
Access	Indicates whether the object is to read only, or read and write.
	RO: Read only
	RW: Read and write (Saved in non-volatile memory)
	W: Read and write (Not saved in non-volatile memory)
PDO map	Indicates the PDO mapping attribute.
	RxPDO: Reception PDOs can be mapped
	TxPDO: Transmission PDOs can be mapped
	-: PDOs cannot be mapped
Complete access	Indicates whether Complete access is allowed or not.
Modes of operation	The profile mode in which the object is enabled.
	-: Independent of the Modes of operation
	csp: Cyclic synchronous position mode
	csv: Cyclic synchronous velocity mode
	cst: Cyclic synchronous torque mode
	pp: Profile position mode
	pv: Profile velocity mode
	hm: Homing mode

# **Mirror Objects**

For 1S-series Servo Drives, a special object called "mirror object" is defined.

A mirror object enables access to the same object from different object numbers. Accessing the mirror object and accessing the original object cause the same operation.

More specifically, the mirror objects are used to assign the Servo Drive profile objects (index number 6000s) to the servo parameter objects (index number 3000s to 4000s).

#### **5-2 External Device-related Objects**

These objects are used for the motor information display.

Index (hex)	Sub- index (hex)	Object name	Setting range	Unit	Default setting	Data attri- bute	Size	Access	PDO map	Complete access	Modes of oper- ation
4410		Motor Identity								Possible	
	00	Number of entries			FF hex		1 byte (U8)	RO			
	81	Motor Model					20 bytes (VS)	RO			
	82	Serial Number					16 bytes (VS)	RO			
	83	Last Connected Motor Model					20 bytes (VS)	RO			
	84	Last Connected Serial Number					16 bytes (VS)	RO			
	90	Motor Type					2 bytes (U16)	RO			
	92	Motor Manufacturer					20 bytes (VS)	RO			
	F1	Motor Setup			0	Α	4 bytes (INT32)	W			
	FF	Setup Status					4 bytes (INT32)	RO			

# Subindex 81 hex: Motor Model

• Gives the model of the motor which is connected to the Servo Drive.

## Subindex 82 hex: Serial Number

• Gives the serial number of the motor which is connected to the Servo Drive.

# **Subindex 83 hex: Last Connected Motor Model**

· Gives the model of the motor which was connected the last time.

## **Subindex 84 hex: Last Connected Serial Number**

• Gives the serial number of the motor which was connected the last time.

# **Subindex 90 hex: Motor Type**

- · Gives the type of connected motor.
- · Mirror object of 6402 hex

# **Subindex 92 hex: Motor Manufacturer**

- Gives the motor manufacturer name.
- · Mirror object of 6404 hex

# **Subindex F1 hex: Motor Setup**

• The Motor ID Setup is executed by the writing of 7465 736D hex.

# Subindex FF hex: Setup Status

· Gives the execution status of Motor Setup.

### Description of Set Values

Set value	Description				
0	Setup is not executed or completed				
1	Setup in execution				

# **Encoder-related Objects**

These objects are used for the encoder setting.

Index (hex)	Sub- index (hex)	Object name	Setting range	Unit	Default setting	Data attri- bute	Size	Access	PDO map	Complete access	Modes of operation
4510		Encoder								Possible	
	00	Number of entries			FF hex		1 byte (U8)	RO			
	01	Operation Selection when Using Absolute Encoder	0 to 2		2	R	4 bytes (INT32)	RW			
	02	Absolute Encoder Counter Overflow Warn- ing Level	0 to 32,767	rotation	32,000	A	4 bytes (INT32)	RW			
-	81	Serial Number					16 bytes (VS)	RO			
	82	Resolution per Rotation					4 bytes (INT32)	RO			
	84	One-rotation Data		Encoder unit			4 bytes (U32)	RO			
	85	Multi-rotation Data		rotation	1	1	4 bytes (INT32)	RO	I		
	86	Encoder Com- munications Error Count					4 bytes (INT32)	RO			
	87	Electric Angle		٥			4 bytes (INT32)	RO			
	88	Mechanical Angle		٥			4 bytes (U32)	RO			
	89	Encoder Tem- perature		°C			4 bytes (INT32)	RO			
,	F1	Absolute Encoder Setup	0000 0000 to FFFFFFF hex		0	A	4 bytes (U32)	W	-		
	F2	Encoder Com- munications Error Count Clear	0000 0000 to FFFFFFF hex		0	A	4 bytes (U32)	W			
	FF	Clear Status					4 bytes (U32)	RO			

## Subindex 01 hex: Operation Selection when Using Absolute **Encoder**

· Selects the operating method for the absolute encoder.

#### Description of Set Values

• When you use the Incremental Encoder Type Servomotors, you do not need to set this object.

Set value	Description
0	Use as the absolute encoder
1	Use as the incremental encoder
2	Used as the absolute encoder and ignore the absolute encoder counter overflow.

# Subindex 02 hex: Absolute Encoder Counter Overflow Warning Level

- · Sets the level to notify the warning.
- When the **Operation Selection when Using Absolute Encoder** is set to 0 (use as the absolute encoder), if the absolute value of encoder multi-rotation number exceeds the set value, the Absolute Encoder Counter Overflow Warning is output.

## Subindex 81 hex: Serial Number

· Gives the encoder serial number.

## Subindex 82 hex: Resolution per Rotation

· Gives the resolution per rotation.

### Subindex 84 hex: One-rotation Data

• Gives the one-rotation position of the encoder. When the phase-Z position is 0, if the motor rotates counterclockwise as viewed from the motor load side, the encoder value increases.

## Subindex 85 hex: Multi-rotation Data

- Gives the number of encoder rotations. The encoder value increases each time the motor rotates counterclockwise as viewed from the motor load side.
- When you use the Incremental Encoder Type Servomotors, the encoder value is always set to 0.

## **Subindex 86 hex: Encoder Communications Error Count**

· Obtains the total number of encoder errors via serial communications.

## Subindex 87 hex: Electric Angle

- · Gives the electric angle.
- In the counterclockwise rotation, 0° indicates the position which is the zero cross point (rising) of the phase-U inductive voltage.
- The encoder value increases when the motor rotates counterclockwise, and the display range is from 0 to 359°.

## Subindex 88 hex: Mechanical Angle

- · Gives the one-rotation data of the encoder as the mechanical angle.
- The encoder value increases when the motor rotates counterclockwise, and the display range is from 0 to 359°.

# **Subindex 89 hex: Encoder Temperature**

Gives the internal temperature of the encoder which is mounted on the motor, or the internal temperature of the motor.

## Subindex F1 hex: Absolute Encoder Setup

- · Clears the multi-rotation counter of the absolute encoder. Clear is executed by the writing of 6A646165 hex to this object.
- When you use the Incremental Encoder Type Servomotors, clear is not executed.

# Subindex F2 hex: Encoder Communications Error Count Clear

• Clears the Encoder Communications Error Count. Clear is executed by the writing of 1 to this object.

## **Subindex FF hex: Clear Status**

• Gives the status of the multi-rotation counter of the absolute encoder and Encoder Communications Error Count Clear.

#### Description of Set Values

Set value Description		Description	
Bit 0		Status of Absolute Encoder Setup	
0		Clear is not executed or completed	
1		Clear in execution	
Bit 1	•	Status of Encoder Communications Error Count Clear	
0 Clear is not executed or completed		Clear is not executed or completed	
	1	Clear in execution	



# **Operation**

This section provides the operational procedure and explains how to operate in each mode.

6-1	Operation	onal Procedure	6-2					
6-2	Preparing for Operation							
	6-2-1	Items to Check Before Turning ON the Power Supply	6-3					
	6-2-2	Turning ON the Power Supply	6-4					
	6-2-3	Checking the Displays	6-5					
6-3	Test Run							
	6-3-1	Preparations for Test Run	6-7					
	6-3-2	Test Run via USB Communications from the Sysmac Studio	6-8					

#### **Operational Procedure** 6-1

Perform installation and wiring correctly, and turn ON the power supply to check the operation of the individual Servomotor and Servo Drive.

Then make the function settings as required according to the use of the Servomotor and Servo Drive.

If the objects are set incorrectly, there is a risk of unexpected motor operation, which can be dangerous. Set the objects accurately according to the setting methods in this manual.

Item	Description	Reference
Installation and mounting	Install the Servomotor and Servo Drive according to the installation conditions. Do not connect the Servomotor to mechanical systems before checking the operation without any load.	Section 4, 4-1
$\overline{\qquad}$		
Wiring and con- nections	Connect the Servomotor and Servo Drive to the power supply and peripheral equipment.  Satisfy specified installation and wiring conditions, particularly for models that conforms to the EU Directives.	Section 4, 4-2
<b>+</b>		
Preparing for operation	Check the necessary items and then turn ON the commercial power supply.  Check on the display to see whether there are any internal errors in the Servo Drive.	Section 6, 6-2
<b>↓</b>		
Function set- tings	Set the objects related to the functions required for application conditions.	Section 5
$\downarrow$		
Test run	First, check motor operation without any load. Then turn the power supply OFF and connect the Servomotor to mechanical systems.	
	Execute the Unit Restart or cycle the power supply, and check to see whether protective functions, such as the immediate stop and operational limits, operate properly.	Section 6, 6-3
	Check operation at both low speed and high speed using the system without a workpiece, or with dummy workpieces.	
<b>—</b>		
Adjustment	Manually adjust the set values of objects such as gain if necessary.	I586
Operation	Operation can now be started.	
	If any problems should occur, refer to Section 7 Troubleshooting.  Perform homing after the power supply is turned ON.	Section 7

# 6-2 Preparing for Operation

This section explains the procedure that you perform to prepare the system for operation after installation and wiring of the Servomotor and Servo Drive are completed. It explains items to check both before and after turning ON the power supply.

## 6-2-1 Items to Check Before Turning ON the Power Supply

# **Checking Power Supply Voltage**

Check to be sure that the power supply voltage is within the ranges shown below.

Model	Main circuit	Control circuit
Model	power supply	power supply
R88D-1SN01H-ECT/-1SN02H-ECT/	Single-phase/	24 VDC (21.6
-1SN04H-ECT/-1SN08H-ECT/-1SN15H-ECT	3-phase 200 to 240	to 26.4 V)
(Single-phase/3-phase 200-VAC input)	VAC (170 to 252 V)	
	50/60 Hz	
R88D-1SN10H-ECT	3-phase 200 to 240	24 VDC (21.6
(3-phase 200-VAC input)	VAC (170 to 252 V)	to 26.4 V)
	50/60 Hz	

# **Checking Terminal Block Wiring**

- The main circuit power supply inputs (L1/L2/L3) must be properly connected to the terminal block.
- The control circuit power supply inputs (24V, Ø or +24 V, 0V) must be properly connected to the terminal block.
- The motor's red (U), write (V), and blue (W) power lines and the green (⊕) must be properly connected to the terminal block.

## **Checking the Servomotor**

- There should be no load on the Servomotor. Do not connect mechanical systems.
- The Servomotor side power lines and the power cables must be securely connected.

## **Checking the Encoder Wiring**


- The encoder cable must be securely connected to the encoder connector (CN2) at the Servo Drive.
- The encoder cable must be securely connected to the encoder connector of the Servomotor.

## **Checking the EtherCAT Communications Connectors**

Do not connect the EtherCAT Communications Cables to the EtherCAT Communications Connectors (ECAT IN and ECAT OUT).

## **Checking the Node Address Setting**

Make sure that the node address is correctly set on the ID switches.



	Description	
ID switch setting	Connection to NJ/NX-series CPU Unit or	
	Position Control Unit (Model: CJ1W-NC□8□)	
00	The controller sets the node address.	
01 to FF	The ID switches set the node address.	



#### **Precautions for Correct Use**

The ID switch setting is read only once when the Unit power supply is turned ON. Although the setting is changed after the Unit power supply is ON, it is not reflected in the control. It is enabled the next time the Unit power supply is turned ON.

#### 6-2-2 **Turning ON the Power Supply**

Turn ON the control circuit power after you finish the checks which you must conduct before turning ON the power supply. You can turn ON the main circuit power, but it is not a required.


## 6-2-3 Checking the Displays


## 7-segment LED Display

The following figure shows the 7-segment LED display located on the front panel.

When the power is turned ON, it shows the node address that is set by the ID switches. Then the display changes according to the setting of the **LED Display Selection** (4210-01 hex).

An error code is displayed if an error occurs. A warning code is displayed if a warning occurs.






The node address is displayed as follows.

Node address	Expression	Display example
0 to 255	Expressed as 2-digit hexadecimal numbers from "0" to "FF".	; <b>FF</b>
		1 255 (FF hex)
256 to 511	The dot of the indicator is lit. The address is expressed as numbers from ".0" to "F.F".	256 (100 hex) 511 (1FF hex)
512 or more	Expressed as "0.0".	512 or more

Numbers from 0 to F hex are displayed as follows.



## **EtherCAT Status Indicators**

Check the status of the status indicators.

If the RUN indicator does not turn ON or the ERR indicator does not turn OFF, refer to AC Servomotors/Servo Drives 1S-series with Built-in EtherCAT® Communications User's Manual (I586).

### 6-3 Test Run

When you finished installation, wiring, and switch settings, and confirmed that the status was normal after turning ON the power supply, perform test run. The main purpose of test run is to confirm that the servo system operation is electrically correct.

If an error occurs during test run, refer to Section 7 Troubleshooting and eliminate the cause. Then check for safety, and retry test run.

### 6-3-1 Preparations for Test Run

### **Inspections Before Test Run**

Check the following items.

### Wiring

- Make sure that there are no wiring errors (especially for the power supply input and motor output).
- Make sure that there are no short circuits. (Check the ground for short circuits as well.)
- · Make sure that there are no loose connections.
- · Make sure that the EtherCAT cable is pulled out.

### Power Supply and Voltage

- Make sure that the power voltage is within the specified range.
- · Make sure that there is no voltage fluctuation.

#### Servomotor Installation

· Make sure that the Servomotor is securely installed.

### Disconnection from Mechanical Systems

• If necessary, make sure that the load is disconnected from mechanical systems.

#### Brake Released

· Make sure that the brake is released.

### Connection to Mechanical Systems

- · Make sure that the load and Servomotor shaft are properly aligned.
- · Make sure that the load on the Servomotor shaft is within specifications.

#### Test Run via USB Communications from the Sysmac Studio 6-3-2

- 1 Connect a sensor or other device to the control I/O connector (CN1).
- Turn ON the Servo Drive power supply.
- Connect a USB cable to the USB connector (CN7).
- Start the Sysmac Studio and go online with the Servo Drive via USB communications.
- In the Sysmac Studio, right-click the target Servo Drive under Configurations and Setup, and select Test Run.
- Click the **Servo ON** button to apply the servo lock to the Servomotor.
- Click the or button to start the Servomotor.

For how to use the Sysmac Studio, refer to the Sysmac Studio Drive Functions Operation Manual (Cat. No. 1589).



#### **Precautions for Correct Use**

- A test run can be performed in the Profile position mode (pp) or Profile velocity mode (pv). If the torque compensation is set, the axes move because the compensation command is output when the Servo is turned ON.
- When you perform a test run via USB communications, pull out the EtherCAT cable before you turn ON the power supply to the Servo Drive.
- When you perform a test run from the Sysmac Studio without EtherCAT connection, you cannot use the STO function via EtherCAT communications. If you need the STO function, use the STO function via safety input signals. In this case, display the test run pane so that you can reset STO status via safety input signals.
- · If you need EtherCAT connection while you perform a test run from the Sysmac Studio without EtherCAT connection, first terminate the test run function and then perform EtherCAT connection.



#### **Additional Information**

When you use an NJ/NX-series CPU Unit, you can perform a test run from the Sysmac Studio via EtherCAT. In this case, you can use the STO function via EtherCAT communications.



# **Troubleshooting**

This section explains the items to check when problems occur, and troubleshooting by the use of error displays or operation state.

7-1	Actions	s for Problems	7-2
	7-1-1	Preliminary Checks When a Problem Occurs	7-2
	7-1-2	Precautions When a Problem Occurs	7-3
	7-1-3	Replacing the Servomotor or Servo Drive	7-4
7-2	Warning	gs	7-6
	7-2-1	Related Objects	7-6
	7-2-2	Warning List	7-8
7-3	Errors		-10
	7-3-1	Error List	-10
	7-3-2	Deceleration Stop Operation at Errors	-12
7-4	Informa	ation	-13
	7-4-1	Related Objects	-13
	7-4-2	Information List	
7-5	Trouble	eshooting	-14
	7-5-1	Troubleshooting Using Error Displays	-14
	7-5-2	Troubleshooting Using AL Status Codes	
	7-5-3	Troubleshooting Using the Operation State	-39

#### 7-1 **Actions for Problems**

If any problems should occur, take the following actions.

#### 7-1-1 **Preliminary Checks When a Problem Occurs**

This section explains the preliminary checks required to determine the cause of a problem if one occurs.

### **Checking the Power Supply Voltage**

Check the voltage at the power supply input terminals.

Input terminal	Model	Voltage
Main circuit power supply input (L1, L2, L3)	R88D-1SN□H-ECT	Single-phase/3-phase 200 to 240 VAC (170 to 252 V)*1 50/60 Hz
Control Circuit Power Supply Input Termi-		24 VDC (21.6 to 26.4V)
nals (24 V, $\emptyset$ or +24 V, 0V)		

<sup>\*1.</sup> The values outside parentheses indicate the rated value, and the values inside parentheses indicate the range of acceptable variation. If the voltage is out of this range, operation failure may result. Be sure that the power supply is within the specified range.

Make sure that the power supply voltage for control input signals is within the range of 12 VDC-5% to 24 VDC+5%, and the power supply voltage for safety input signals is within the range of 24 VDC±5%. If the voltage is out of this range, operation failure may result. Be sure that the power supply is within the specified range.

### **Checking the Error Occurrence**

Check whether an error exists by the use of the 7-segment LED display on the front of the Servo Drive or from the Sysmac Studio.

#### When an Error Exists

Check the error display ( $\square\square$ ) and make an analysis based on the error that is indicated. Refer to 7-5-1 Troubleshooting Using Error Displays on page 7-14.


#### When an Error Does Not Exist

Make an analysis according to the error conditions.

Refer to 7-5-3 Troubleshooting Using the Operation State on page 7-39.


The following figure shows the 7-segment display when an error exists.

Error display and warning display
 The preset character, main code and sub code are displayed in turns.
 Example) Encoder Communications Error: 2101 hex




 Information display ST is displayed.

Example) STO Detected: C000 hex



Numbers from 0 to F hex are displayed as follows.



### 7-1-2 Precautions When a Problem Occurs

When you check and verify I/O after a problem occurred, the Servo Drive may suddenly start to operate or suddenly stop, so always take the following precautions.

You should assume that anything not described in this manual is not possible with this product.

### **Precautions**

- Disconnect the wiring before checking for cable breakage. If you test conduction with the cable connected, test results may not be accurate due to conduction via bypassing circuit.
- If the encoder signal is lost, the Servomotor may run away, or an error may occur. Be sure to disconnect the Servomotor from mechanical systems before you check the encoder signal.
- When you perform tests, first check that there are no persons in the vicinity of the equipment, and
  that the equipment will not be damaged even if the Servomotor runs away.
   Before you perform the tests, verify that you can immediately stop the machine by the use of functions such as the immediate stop in case the machine runs out of control.

#### 7-1-3 Replacing the Servomotor or Servo Drive

Use the following procedure to replace the Servomotor or Servo Drive.

### Replacing the Servomotor

- 1 Replace the Servomotor.
- In the position control, perform origin adjustment.
  - When you replace the motor, the motor's origin position (phase Z) may deviate, so you must perform origin adjustment.
  - · Refer to the position controller's manual for details on performing origin adjustment.



#### **Additional Information**

With the Sysmac Studio, you can clear the Motor Operating Time retained by the Servo Drive.

### Replacing the Servo Drive

Take a record of all object settings.

Use the Sysmac Studio to read all of the servo parameters in the Parameters tab page and save them in a file.

- Replace the Servo Drive.
- Set the objects.

Use the Sysmac Studio to write all of the servo parameters in the Parameters tab page.

- Perform the Motor Setup.
  - When the Motor Replacement Detected (Error No. 95.05) occurs on the Servo Drive, use the Sysmac Studio to clear the Motor Replacement Detected.
  - When you use the Incremental Encoder Type Servomotors, you do not need to perform the Motor Setup.



#### **Precautions for Correct Use**

- Confirm that the charge lamp is not lit before you perform replacement of the Servo Drive.
- Usually, it takes at least 10 minutes to discharge electricity.
- · The models with a regeneration resistor can discharge electricity in a short period of time when there is no error in its circuits and the main circuit power supply is cut off while the control power supply is ON.

### **Clearing Motor Replacement Detected**

When you use the Incremental Encoder Type Servomotors, you do not need to perform the following procedure.

- **1** Start the Sysmac Studio and go online with the Servo Drive via EtherCAT or USB communications.
- 2 In the Sysmac Studio, right-click the target Servo Drive under Configurations and Setup, and select Motor and Encoder.
- 3 Click the Reset Motor Replacement Detection error button in the Encoder Properties pane.
- **4** Execute the Unit Restart or turn the control power supply to the Servo Drive OFF and then ON again.

### 7-2 Warnings

This function outputs a warning signal to enable you to check a state such as an overload before an error occurs.

With Warning Customization (4020 hex), you can select whether or not to detect warnings and whether or not to hold the warning state. Also, you can set this object to be notified of warnings as errors.

If Warning Customization - Warning Hold Selection (4020-04 hex) is set to a not hold, a warning is cleared automatically when the cause of warning is eliminated. If it is set to a hold, perform the normal procedure to clear errors after you remove the cause of the error.

#### 7-2-1 **Related Objects**

Index (hex)	Subindex (hex)	Name	Description	Refer- ence
4020		Warning Customi-	Sets the warning detection function.	1586
		zation		
	01	Warning Mask 1	When a bit is set to 1, the detection of the corresponding	1586
		Selection	warning is disabled.	
			bit 0: Overload Warning	
			bit 1: Regeneration Overload Warning	
bit 2: Encoder Communications Warning		bit 2: Encoder Communications Warning		
			bit 3: Motor Vibration Warning	
			bit 4: Capacitor Lifetime Warning	
			bit 5: Inrush Current Prevention Relay Lifetime Warning	
			bit 7: Brake Interlock Output Relay Lifetime Warning	
			bit 9: Lifetime Information Corruption Warning	
			bit 10: Encoder Lifetime Warning	
			bit 11: Fan Rotation Warning	
			bit 12: Absolute Encoder Counter Overflow Warning	
	03	Warning Mask 3	When a bit is set to 1, the detection of the corresponding	1586
		Selection	warning is disabled.	
			bit 0: Data Setting Warning	
			bit 1: Command Warning	
			bit 2: EtherCAT Communications Warning	

Index (hex)	Subindex (hex)	Name	Description	Refer- ence
4020	04	Warning Hold Selection	Selects whether to hold or not the warning state.	1586
			Bit 0:	
			0: Not hold the warning enabled in Warning Mask 1 Selection.	
			The warning is automatically cleared when the cause of the warning is eliminated. However, the warning is held for at least 1 second.	
			1: Hold the warning enabled in Warning Mask 1 Selection.	
			After the cause of the warning is eliminated, the error reset command must be sent.	
			Bit 2:	
			0: Not hold the warning enabled in Warning Mask 3 Selection.	
			The warning is automatically cleared when the cause of the warning is eliminated. However, the warning is held for at least 1 second.	
			1: Hold the warning enabled in Warning Mask 3 Selection.	
			After the cause of the warning is eliminated, the error reset command must be sent.	
	05	Warning Level Change 1 Selec-	When a bit is set to 1, the level of the corresponding warning is set as the error.	1586
		tion	bit 0: Overload Warning	
			bit 1: Regeneration Overload Warning	
			bit 2: Encoder Communications Warning	
			bit 3: Motor Vibration Warning	
			bit 4: Capacitor Lifetime Warning	
			bit 5: Inrush Current Prevention Relay Lifetime Warning	
			bit 7: Brake Interlock Output Relay Lifetime Warning	
			bit 9: Lifetime Information Corruption Warning	
			bit 10: Encoder Lifetime Warning	
			bit 11: Fan Rotation Warning	
			bit 12: Absolute Encoder Counter Overflow Warning	
	07	Warning Level	When a bit is set to 1, the level of the corresponding warning is get as the error	1586
		Change 3 Selection	ing is set as the error.	
			bit 0: Data Setting Warning	
			bit 1: Command Warning	
			bit 2: EtherCAT Communications Warning	

#### **Warning List** 7-2-2

### **General Warnings**

Error No.				Warning Mask 1	
Main (hex)	Sub (hex)	Warning name	Warning condition	Selection*1 (4020-01 hex) Warning Level Change 1 Selection (4020-05 hex) corresponding bit	
A0	00	Overload Warning	The load ratio of Servo Drive or motor (4150-81 hex) exceeded the level set in <b>Overload - Warning Notification Level</b> (4150-01 hex).	Bit 0	
A1	00	Regeneration Overload Warning	The Regeneration Load Ratio (4310-81 hex) exceeded 85% of the regeneration overload ratio.	Bit 1	
A3	00	Fan Rotation Warning	The rotation speed of the fan is 80% or less of the rating and the cooling performance decreases.	Bit 11	
A4	00	Encoder Communications Warning	Encoder communications errors occurred in series more frequently than the specified value.	Bit 2	
A6	00	Motor Vibration Warning	The motor vibration, which was higher than or equal to the level set in the <b>Vibration Detection - Detection Level</b> (3B70-01 hex), was detected.	Bit 3	
A7	01	Capacitor Lifetime Warning	The capacitor built into the Servo Drive reached the service life of the manufacturer's guarantee.	Bit 4	
	02	Inrush Current Prevention Relay Lifetime Warning	The inrush current prevention relay built into the Servo Drive reached the service life of the manufacturer's guarantee.	Bit 5	
	04	Brake Interlock Output Relay Lifetime Warning	The brake interlock output (BKIR) relay built into the Servo Drive reached the service life of the manufacturer's guarantee.	Bit 7	
	05	Lifetime Information Corruption Warning	An error was detected in the saved lifetime information.	Bit 9	
	06	Encoder Lifetime Warning	The encoder lifetime is close to the end.	Bit 10	
AB	00	Absolute Encoder Counter Overflow Warning	The multi-rotation counter of the encoder exceeded the value set in Encoder - Absolute Encoder Counter Overflow Warning Level (4510-02 hex).	Bit 12	

<sup>\*1.</sup> For Warning Mask 1 Selection, when a bit is set to 1, the detection of the corresponding warning is disabled.



### **Precautions for Correct Use**

You can clear these warnings by executing the error rest command. The command does clear the warning even if the cause of the warning is not removed, but the same warning will occur again.

### **EtherCAT Communications Warning**

Main (hex)	Sub (hex)	Warning name	Warning condition	Warning Mask 3 Selection*1 (4020-03 hex), Warning Level Change 3 Selection (4020-07 hex) corresponding bit
В0	00	Data Setting Warning	The object set value is out of the range.	Bit 0
B1	00	Command Warning	A command could not be executed.	Bit 1
B2	00	EtherCAT Communications Warning*2	An EtherCAT communications error occurred more than one time.	Bit 2

<sup>\*1.</sup> For Warning Mask 3 Selection, when a bit is set to 1, the detection of the corresponding warning is disabled.

<sup>\*2.</sup> This warning also occurs when the power supply to the master unit is turned OFF after EtherCAT communication establishment. For this reason, a warning may be recorded in the error history if the power supply to the 1S-series Servo Drive is turned OFF immediately after the power supply to the master unit is turned OFF.

#### **Errors** 7-3

If the Servo Drive detects an abnormality, it outputs an error (/ERR), turns OFF the power drive circuit, and displays the error number (main and sub) on the front panel.



### **Precautions for Correct Use**

- Refer to 7-5-1 Troubleshooting Using Error Displays on page 7-14 for information on troubleshooting.
- You can reset the error by turning OFF the power supply and then ON again, or executing the error reset command via EtherCAT communications or on the Sysmac Studio. Be sure to remove the cause of the error first.
- · Some errors are reset only by turning the power supply OFF then ON again. For details, refer to 7-3-1 Error List on page 7-10.
- If nothing is displayed on the 7-segment display even when the control power supply is ON, it indicates that the internal MPU is malfunctioning. If you find this symptom, cut off the power supply immediately.

#### 7-3-1 **Error List**

Erro	r No.		Attı	ibute
Main	Sub	Error name	Can be	Deceleration
(hex)	(hex)		reset*1	operation*2
12	00	Overvoltage Error		В
13	00	Main Power Supply Undervoltage (insufficient voltage between P and N)	Yes	В
	01	Main Circuit Power Supply Phase Loss Error	Yes	В
14	00	Overcurrent Frror		В
14	01	Power Module Error		В
				В
	02	Regeneration Circuit Error Detected during Power ON*3		_
15	00	Servo Drive Overheat	Yes	В
	01	Motor Overheat Error	Yes	В
16	00	Overload Error	Yes	В
18 00 Regeneration Overload Error		Regeneration Overload Error		В
	02	Regeneration Processing Error		В
20	00	Runaway Detected*4		В
21	00	Encoder Communications Disconnection Error		В
	01	Encoder Communications Error		В
24	00	Excessive Position Deviation Error	Yes	А
	01	Excessive Speed Deviation Error	Yes	А
26	00	Excessive Speed Error	Yes	А
27	01	Absolute Value Cleared		В
28	00	Pulse Output Overspeed Error	Yes	А
	01	Pulse Output Setting Error		А
29	03	Following Error Counter Overflow		В
33	00	General Input Allocation Duplicate Error		А
	09	General Output Allocation Duplicate Error		А
34	01	Software Limit Exceeded	Yes	А

Erro	r No.		Att	Attribute		
Main	Sub	Error name	Can be	Deceleration		
(hex)	(hex)		reset*1	operation*2		
35	00	FPGA WDT Error		В		
	01	System Error		В		
	02	Self-diagnosis Error		В		
36	00	Non-volatile Memory Data Error		Α		
37	00	Non-volatile Memory Hardware Error		Α		
38	00	Drive Prohibition Input Error	Yes	Α		
	01	Drive Prohibition Detected	Yes	Α		
41	00	Absolute Encoder Counter Overflow Error		Α		
43	01	Encoder Memory Error		В		
44	00	1-rotation Counter Error		В		
45	00	Absolute Encoder Multi-rotation Counter Error*5		В		
	01	Absolute Position Detection Error		В		
47				В		
58	00 Overspeed Error 00 Main Circuit Temperature Monitoring Circuit Failure			В		
59	00	Fan Error	Yes	A		
62	00	Control Right Release Error	Yes	A		
70	00	Safety Parameter Error	Yes	A		
70	01	Safety Communications Setting Error	Yes	A		
	02	FSoE Slave Address Error	Yes	A		
	03	Safety Frame Error	Yes	A		
	04	Safety Communications Timeout	Yes	A		
83 01		EtherCAT State Change Error	Yes	A		
83	02	EtherCAT Illegal State Change Error	Yes	A		
	03	Communications Synchronization Error	Yes	A		
	04	Synchronization Error	Yes <sup>*6</sup>	A		
	05	Sync Manager WDT Error	Yes	A		
07	06	Bootstrap State Transition Request Error	Yes	A		
87	00	Error Stop Input	Yes	A		
88	01	ESC Initialization Error		A		
	02	Synchronization Interruption Error		A		
	03	SII Verification Error		A		
	04	ESC Error		A		
90	00	Mailbox Setting Error	Yes	A		
	01	PDO WDT Setting Error	Yes	A		
	02	SM Event Mode Setting Error	Yes	A		
	03	DC Setting Error	Yes	A		
	04	Synchronization Cycle Setting Error	Yes	Α		
	05	RxPDO Setting Error	Yes	Α		
	06	TxPDO Setting Error	Yes	Α		
	07	RxPDO Mapping Error	Yes	Α		
	80	TxPDO Mapping Error	Yes	Α		
	09	Node Address Updated		Α		
91	01	Command Error	Yes	A		
93	00	Electronic Gear Setting Error		A		
94	00	Function Setting Error	Yes	A		
95	01	Motor Non-conformity		A		
	05	Motor Replacement Detected*4		A		
97	00	Brake Interlock Error		В		

<sup>\*1. &</sup>quot;Yes" means that you can clear the error by executing the error reset command. The mark "---" means that you need to cycle the power supply or execute **Unit Restart** (2400 hex) to clear the error.

- \*2. The deceleration operation shows the operation (Operation A or Operation B) that is used when Fault reaction option code (605E hex) is set to -4 to -7.
- \*3. This error can occur in the unit version 1.2 or later.
- \*4. This error can occur in the unit version 1.1 or later.
- \*5. This error cannot occur in the Incremental Encoder Type Servomotors.
- \*6. "---" is specified for the unit version 1.0.


#### **Deceleration Stop Operation at Errors** 7-3-2

The deceleration stop function controls the motor and decelerates it to stop if an error that causes the deceleration stop occurs.

### **Related Objects**

Index (hex)	Subindex (hex)	Name	Description	Refer- ence
605E	00	Fault reaction option	Sets the state during deceleration and after	1586
		code	stopping for when an error occurs.	
3B21		Deceleration Stop	Sets the torque for deceleration stop.	
	01	Torque	Sets the torque limit value during deceleration	1586
			stop.	

### **Deceleration Stop Operation**



## 7-4 Information

Information is an event other than errors of which you are notified.

You can change information to errors by changing its level.

### 7-4-1 Related Objects

Index (hex)	Subindex (hex)	Name	Description	Refer- ence
4030		Information Customi- zation	Sets the information.	1586
	01	Information Level Change Selection	Sets the level change of information.  When a bit is set to 1, the level of the corresponding information is set as the error.  Bit 0: STO	I586

### 7-4-2 Information List

Error No.				Information Level Change
Main (hex)	Sub (hex)	Information name	Warning condition	Selection <sup>*1</sup> (4030-01 hex)
C0	00	STO Detected	STO status	Bit 0

<sup>\*1.</sup> For **Information Level Change Selection**, when a bit is set to 1, the level of the corresponding information is set as the error.

### **7-5 Troubleshooting**

If an error occurs in the Servo Drive or operation, identify the cause of the error and take appropriate measures as shown below.

- · For the error occurrence, check its frequency, timing, and the environment in which the error
- · You can reduce errors that occur temporarily by taking noise countermeasures such as wiring a thick ground wire as short as possible.
- For details on noise countermeasures, refer to 4-3 Wiring Conforming to EMC Directives on page 4-8.

#### 7-5-1 **Troubleshooting Using Error Displays**

When an error or warning occurs, the error number is displayed on the 7-segment LED display the front of the Servo Drive.

### **Error List**

Erro	r No.				
Main	Sub	Name	Cause		Measures
(hex)	(hex)				
12	00	Overvoltage Error	The main circuit power supply voltage (P-N voltage) exceeded the	The P-N voltage exceeded the specified value.	Input the correct voltage.
			operation guarantee range.	The input voltage increased.	Use appropriately external devices such as UPS.
				The Regeneration Resistor wiring is bro- ken.	If a resistance value of the external resistor is infinite between the terminal B1 and B2 of the Servo Drive, the wiring is broken. Replace the external resistor.
				The External Regeneration Resistor is set or selected inappropriately.	Confirm the necessary regeneration processing capacity, and connect an appropriate External Regeneration Resistor. Also, set the parameters of the External Regeneration Resistor to the resistance value of the External Regeneration Resistor in use.
				Servo Drive failure	If this event occurs again after you performed all corrections shown above, replace the Servo Drive.

Erro	r No.				
Main	Sub	Name	Ca	use	Measures
(hex)	(hex)				
13	00	Main Power Supply Undervolt- age (insuffi-	supply voltage fell below the operation guaran-	Incorrect wiring of the main circuit power supply	If the power supply cables are not wired to the main circuit power supply terminals (L1 , L2 , L3), connect them.
		cient voltage between P and N)	ON.	The low power supply voltage is applied to the Servo Drive.	Increase the power supply capacity if it is small. Measure the applied power supply voltage, and apply the voltage according to the specification.
				The long time was set in Momentary Hold Time and the voltage was decreased momentarily.	Remove the cause that momentarily decreased the voltage. Set a short time in the Momentary Hold Time so as not to detect this error due to a momentary decrease in voltage.
				Servo Drive failure	If this event occurs again after you performed all corrections shown above, replace the Servo Drive.
	01	Main Circuit Power Sup- ply Phase Loss Error	Bup- main circuit power sup- se ply was detected.	Incorrect wiring, for example the single- phase power supply is input to a 3-phase input type Servo Drive.	Confirm the Servo Drive specifications, and perform the correct wiring.
					In the case where the single-phase power supply is input to a single- and 3-phase input type Servo Drive, the phase loss detection is enabled.
				The power supply voltage is low or insufficient.	Improve power supply conditions by increasing the power supply capacity or the like.
				Broken wiring of the main circuit power supply input	Replace the main circuit power supply input cable.
				Servo Drive failure	If this event occurs again after you performed all corrections shown above, replace the Servo Drive.

Erro	r No.				
Main	Sub	Name	Ca	use	Measures
(hex)	(hex)				
14	00	Overcurrent Error	The current flowing to the motor exceeded the protection level.	There is a short circuit, ground fault, or contact failure on the U, V, or W motor cable.	Correct the connection of the U, V, or W motor cable.
				There is a short circuit on the wiring of External Regeneration Resistor.	Correct the wiring of External Regeneration Resistor.
				The insulation resistance failed between the U, V, or W motor cable and the motor ground wire.	Replace the motor.
				False detection due to the noise	Take noise countermeasures.
				Servo Drive failure	If this event occurs again after you performed all corrections shown above, replace the Servo Drive.
	01	Power Mod- ule Error	An error was detected in the power module.	There is a short circuit, ground fault, or contact failure on the U, V, or W motor cable.	Correct the connection of the U, V, or W motor cable.
				There is a short circuit on the wiring of External Regeneration Resistor, or the value of resistance became too small.	If there is a short-circuit on the wiring of External Regeneration Resistor, correct the wiring.
				The insulation resistance failed between the U, V, or W motor cable and the motor ground wire.	Replace the motor.
				Servo Drive failure	If this event occurs again after you performed all corrections shown above, replace the Servo Drive.

Error No.					
Main	Sub	Name	Cause		Measures
(hex)	(hex)				33300000
14	02	Regenera- tion Circuit Error Detected during Power ON*1	An error of the Regeneration Circuit was detected at power ON.	<ul> <li>Power supply voltage is insufficient at power ON, or rising slowly.</li> <li>Power supply voltage fluctuated at power ON.</li> <li>L1, L2, and L3 terminals are not connected or disconnected.</li> <li>N1 and N2 terminals are opened.</li> </ul>	Cut off the main circuit power supply immediately and check whether charge lamp is turned ON/OFF.  If the charge lamp is turned OFF, remove the wiring and make the following check.  • Check whether there is an abnormality in the appearence of the Servo Drive, and that the wiring is properly done.  • Check that the resistance value and the power of the External Regeneration Resistor is correct.  • Wait until the voltage between P and N1 goes to less than 1 V to check the resistance value between P and N1. (If it is less than 10 kΩ, replace the Servo Drive.)  • Wait until the voltage get stable to check the resistance value between B2 and N1. (If it is less than 100 kΩ, replace the Servo Drive.)  • Check whether fluctuation in the power supply voltage or power supply occurs or not. (Make sure that an instantaneous power drop does not occur, and that the power rise time is 500 ms or shorter.)  If the charge lamp is turned ON, check whether fluctuation in the power supply voltage or power supply occurs or not. (Make sure that an instantaneous power drop does not occur, and that the power supply occurs or not. (Make sure that an instantaneous power drop does not occur, and that the power supply occurs or not. (Make sure that an instantaneous power drop does not occur, and that the power rise time is 500 ms or shorter.)  If this event occurs again after you
					performed all corrections shown above, replace the Servo Drive.

Erro	r No.					
Main			use	Measures		
(hex)	(hex)					
15	00	Servo Drive Overheat	The internal temperature of Servo Drive exceeded the circuit protection level.	The ambient temperature of the Servo Drive exceeded the specified value.	Improve the ambient temperature and the cooling conditions of the Servo Drive.	
				Overload	Increase the setting of the acceleration/deceleration time or stopping time to lighten the load. Or, increase the capacities of the Servo Drive and the motor.	
	01	Motor Over- heat Error	The encoder detected the temperature that exceeded the protec-	The temperature is high around the motor.	Adjust the temperature around the motor to be within the range of the operating temperature.	
			tion level of motor.	The motor is over-	Adjust the motor load ratio to be	
				loaded.	within the specified range.	
				Encoder failure	Replace the motor if this event occurs repeatedly.	
16	00	Overload Error		Operation was continued for a long time with high load.	Take the following actions according to conditions.  Increase the set value of the	
			, 5,000 20 2 100 7.1		acceleration/deceleration time or the stop time.	
					Lighten the load.	
					Adjust the gain or inertia ratio.	
						If torque waveforms oscillate excessively, adjust the system by the tuning so that the oscillation does not occur.
					<ul> <li>Set the appropriate brake timing.</li> <li>Increase the capacities of the Servo Drive and the motor.</li> </ul>	
				There is incorrect wir-	Connect the motor cable as	
				ing of the motor cable or	shown in the wiring diagram. If	
				a broken cable.	the cable is broken, replace it. Or, connect the motor cable and encoder cable that are used	
					together to the same motor.	
					Measure the voltage at the brake terminal. If the brake is applied, release it.	
				Increase in friction	Check machine conditions and remove the cause of the friction.	

Frro	r No.				
Main	Sub	Name	Ca	use	Measures
(hex)	(hex)				
18	00	Regenera- tion Over- load Error	The Regeneration Load Ratio (4310-81 hex) exceeded the regenera- tion overload ratio.	The regeneration processing is set inappropriately.	Check the regeneration processing setting, and set the same value as the resistance value of the Regeneration Resistor in use.
				The Regeneration Resistor is selected inappropriately.	Check the operation pattern by the velocity monitor. Check the load ratio of Regeneration Resistor, and perform the following corrections accordingly.
					Increase the deceleration time and stopping time.
					Decrease the command velocity to the motor.
					Use an External Regeneration Resistor.
				The Regeneration	Increase the capacities of the Servo Drive and the motor.  The Regeneration Resistor cannot
				Resistor is used for continuous regenerative braking.	be used for continuous regenerative braking.
				The applied power supply voltage is higher than the specified value.	Apply the specified power supply voltage.
				Regeneration Resistor failure	Check whether the Regeneration Resistor is faulty, and use one with- out failures.
	02	Regenera- tion Process- ing Error	The regeneration processing was stopped to protect the Regeneration Resistor.	The regeneration processing is set inappropriately.	Check the regeneration processing setting, and set the same value as the resistance value of the Regeneration Resistor in use.
			This error occurs when the regeneration pro- cessing continues for 500 ms or more.	The Regeneration Resistor is selected inappropriately.	Check the operation pattern by the velocity monitor. Check the load ratio of Regeneration Resistor, and perform the following corrections accordingly.
					Increase the deceleration time and stopping time.
					Decrease the command velocity to the motor.
					Use an External Regeneration Resistor.
				The Regeneration	Increase the capacities of the Servo Drive and the motor.  The Regeneration Resistor cannot
				Resistor is used for continuous regenerative braking.	be used for continuous regenerative braking.
				The applied power supply voltage is higher than the specified value.	Apply the specified power supply voltage.
				Regeneration Resistor failure	Check whether the Regeneration Resistor is faulty, and use one without failures.

Erro	r No.				
Main (box)	Sub	Name	Cause		Measures
<b>(hex)</b> 20	( <b>hex</b> )	Runaway Detected*2	The motor rotated in the direction opposite to the	There is incorrect wiring of the motor cable or a broken cable.	Connect the motor cable as shown in the wiring diagram. If the cable is
			command.	a broken cable.	broken, replace it.  Or, connect the motor cable and encoder cable that are used together to the same motor.
				The motor rotated in the direction opposite to the command by external	Take countermeasures so that the motor is not subjected to external forces.
				forces.	Set Runaway Detection - Enable (3B71-01 hex) to 0 (disabled) when the motor runs as intended.
21	00	Encoder Communica- tions Discon- nection Error	The communications disconnection was detected between the encoder and the Servo Drive.  This error is detected if	Noise into the encoder cable	<ul> <li>Separate the motor cable and the encoder cable if they are bundled together.</li> <li>Connect the shield to FG.</li> <li>Confirm that the motor ground</li> </ul>
			the encoder communications timeout occurs four times in a row.	Contact failure of the signal line, and disconnection of the encoder  Power supply undervolt-	wire is connected to FG.  Replace the encoder cable if it is broken. Firmly connect the encoder connector to the Servo Drive.  Use the recommended encoder
				age to the encoder Encoder failure	cable.  If this event occurs after you performed all corrections shown above, replace the motor.
	01	Encoder Communica- tions Error	Illegal data was received from the encoder the specified number of times.  This error is detected if	Noise into the encoder cable	<ul> <li>Separate the motor cable and the encoder cable if they are bundled together.</li> <li>Connect the shield to FG.</li> <li>Check that the motor ground wire</li> </ul>
			the data error occurs four times in a row during communications with the encoder.	Contact failure of the signal line, and disconnection of the encoder  Power supply undervolt-	is connected to FG.  Replace the encoder cable if it is broken. Firmly connect the encoder connector to the Servo Drive.  Use the recommended encoder
				age to the encoder	cable.

Erro	r No.				
Main	Sub	Name	Са	use	Measures
(hex) 24	00	Excessive Position Deviation Error	The position deviation is greater than or equal to the value set in the Following error window.	The motor operation does not follow the command.	Identify and remove a cause that limits the motor operation.  During the acceleration/deceleration, the command may not be followed depending on operation patterns. In that case, adjust the gain, increase the acceleration/deceleration time or the like.
				The value of Following error window is small.	Increase the setting of the Following error window to an acceptable range.
	01	Excessive Speed Devia- tion Error	The speed deviation is greater than or equal to the value set in the Excessive Velocity Deviation Detection Level.	The motor operation does not follow the command because a parameter value is inappropriate.  The output axis of motor is limited on the operation by external forces.	Adjust the gain to improve the following ability. Or, increase the acceleration/deceleration time for the internal position command velocity.  Take countermeasures so that the output axis is not limited on the operation by external forces.
				The value of the Excessive Velocity Deviation Detection Level is inappropriate.	Increase the setting of the Excessive Velocity Deviation Detection Level to an acceptable range. Disable the Excessive Velocity Deviation Detection if it is unnecessary to monitor the velocity deviation.
26	00	Excessive Speed Error	The feedback motor speed is greater than or equal to the value set in the Excessive Speed Detection Level.	The velocity command value is too large.  Overshooting occurred.	Do not give the excessive velocity command. Check whether the electronic gear ratio is set correctly.  If overshooting occurred due to faulty gain adjustment, adjust the gain.
	04	Abaduta	The moulti materian equation	The motor is rotated by external forces.	Check whether the motor is rotated by external forces.
27	01	Absolute Value Cleared	The multi-rotation counter was cleared.	i oi ine adsolute encoder	This operation is performed for safety and is not an error.
28	00	Pulse Output Overspeed Error	The speed, which exceeded the frequency that could be output by the Encoder Dividing Pulse Output function, was detected.	The dividing ratio setting is inappropriate for the actual usage condition.	Correct the setting of Encoder Dividing Pulse Output - Dividing Denominator and Dividing Numerator.
	01	Pulse Output Setting Error	The dividing numerator education denominator when the Erroutput - Dividing Denomination other than 0.	ncoder Dividing Pulse	Correct the setting of Encoder Dividing Pulse Output - Dividing Denominator and Dividing Numerator.

Erro	r No.				
Main	Sub	Name	Ca	use	Measures
(hex)	(hex)			I =	
29	03	Following Error Counter Overflow	The following error value exceeded the range from -2,147,483,648 to 2,147,483,647.	The motor operation does not follow the command.  The motor is rotated or	Identify and remove a cause that limits the motor operation.  During the acceleration/deceleration, the command may not be followed depending on operation patterns. In that case, change the operation pattern by increasing the acceleration/deceleration time or the like.  Take countermeasures so that the
				limited on the operation	motor is not subjected to external
33	00	General Input	More than one function ir	by external forces.	forces.  Correct the duplicate general input
33		Allocation Duplicate Error	general input.		allocation.
	09	General Output Allocation Duplicate Error	More than one function o general output.		Correct the duplicate general output allocation.
34	01	Software Limit	The Position actual value detected the posi-	Incorrect setting of Soft- ware Position Limit	Correct the setting of Software Position Limit.
		Exceeded	tion that exceeded the value set in the Soft-ware Position Limit, and stopped the operation according to the user setting.	When the Software Position Limit - Stop Selection was set to a Stop according to the setting of Fault reaction option code, the position exceeded the value set in the Software Position Limit.	Set the command value to be within the range of Software Position Limit.
35	00	FPGA WDT Error	An FPGA error was detected.	False detection due to a data read error that was caused by excessive noise  Hardware failure	If this event does not occur after you cycled the power supply, use the product continuously. It is supposed that a temporary error occurred due to a read error.  If this event occurs again, the hardware is faulty. Replace the Servo Drive.
	01	System Error	A hardware error due to the self-diagnosis and a fatal software error were detected.	False detection due to a data read error that was caused by excessive noise A fatal software error was detected. Hardware failure	If this event does not occur after you cycled the power supply, use the product continuously. It is supposed that a temporary error occurred due to a read error. If this event occurs again, a fatal error exists. Replace the Servo Drive.
	02	Self-diagnosis Error	An error was detected by the self-diagnosis of the safety function.	False detection due to a data read error that was caused by excessive noise  Hardware failure	If this event does not occur after you cycled the power supply, use the product continuously. It is supposed that a temporary error occurred due to a read error.  If this event occurs again, replace the Servo Drive.

Error No.					
Main	Sub	Name	Cause		Measures
(hex)	(hex)				
36	00	Non-volatile Memory Data Error	An error of data saved in the non-volatile memory was detected.	Power interruption or noise occurred while parameters other than the safety were saved  Power interruption or noise occurred while the motor identity information was saved	Save data after setting the parameter again, and cycle the power supply.  Execute Motor Setup, and cycle the power supply.
				Power interruption or noise occurred while safety parameters were saved	Clear the FSoE slave address, execute FSoE Enable Reset, and cycle the power supply.
37	00	Non-volatile Memory Hardware Error	An error occurred on the non-volatile memory.	False detection due to a data read error that was caused by excessive noise  Non-volatile memory failure	After you cycled the power supply, if this error occurs continuously although the error is reset, the non-volatile memory is faulty.  Replace the Servo Drive.
38	00	Drive Prohibition Input Error	Both the Positive Drive Prohibition (POT) and the Negative Drive Pro- hibition Input (NOT) turned ON.	An error occurred on the switch, wire, power supply, and wiring that was connected to the Positive Drive Prohibition Input (POT) or Negative Drive Prohibition Input (NOT).  False detection occurred because the control signal power	Check and correct an error on the switch, wire, power supply, and wiring that is connected to the Positive Drive Prohibition Input or Negative Drive Prohibition Input.  Check whether the control signal power supply (12 to 24 VDC) is turned ON slowly, and adjust the
	01	Drive Prohibition Detected	The operation was stopped according to the user setting because the motor ran in the prohibited direction when the Drive Prohibition was enabled.	supply was turned ON slowly.  Incorrect or broken wiring of Positive Drive Prohibition Input (POT) or Negative Drive Prohibition Input (NOT)  Incorrect setting of the Drive Prohibition Input	timing if it is slow.  Correct the wiring if the Positive Drive Prohibition Input (POT) or Negative Drive Prohibition Input (NOT) is wired incorrectly.  If the cable is broken, replace it.  Review the setting of the drive prohibition input port and set it correctly.
41	00	Absolute Encoder Counter Overflow Error	The multi-rotation counter of the encoder exceeded the maximum number of rotations.	An inappropriate value was set in the Encoder - Operation Selection when Using Absolute Encoder (4510-01 hex). The multi-rotation number of the encoder exceeded the maximum number of rotations.	Set the appropriate value in the Encoder - Operation Selection when Using Absolute Encoder (4510-01 hex).  Set the travel distance so that the multi-rotation number does not exceed the maximum number of rotations.

Erro	r No.				
Main	Sub	Name	Ca	use	Measures
(hex)	(hex)				
43	01	Encoder Memory Error	The encoder detected a non-volatile memory error.	False detection due to a data read error that was caused by excessive noise  Non-volatile memory failure	If this event occurs after you cycled the power supply, the encoder is faulty. Replace the motor.
44	00	1-rotation Counter Error	The encoder detected a one-rotation counter error.	There is excessive noise. Failure due to vibration, impact, condensation or foreign matter, etc.	Take noise countermeasures. If this event occurs after you performed noise countermeasures, the motor is faulty. Replace the motor.
45	00	Absolute Encoder Multi-rotation Counter Error	The encoder detected a multi-rotation counter error.	A temporary error occurred in the encoder multi-rotation detection function due to vibration, impact, or condensation.  Encoder failure	Use the product continuously if this event does not occur after improving the operating environment.  Replace the motor if this event occurs again.
	01	Absolute Position Detection Error	The encoder detected a multi-rotation counter error.	A detection error was detected in the multi-rotation detection section of the encoder.	Perform the Absolute Encoder Setup after cycling the power sup- ply, and update the multi-rotation number.
				There is excessive noise.	Take noise countermeasures.  Replace the motor if this event occurs repeatedly.
47	00	Overspeed Error	The encoder detected the overspeed.	The motor is rotated by external forces.	Take countermeasures so that the motor is not subjected to external forces if the motor is rotated by external forces.
				Encoder failure and false detection	If this event occurs repeatedly, the encoder is faulty. Replace the motor.
58	00	Main Circuit Temperature Monitoring Circuit Fail- ure	A temperature monitoring circuit failure was detected on the main circuit.		If this event occurs repeatedly after you cycled the power supply, Replace the Servo Drive.
59	00	Fan Error	The rotation speed of the fan is 40% or less of the rating and the cool- ing performance	There is a foreign mat- ter in the cooling fan and it blocks the rota- tion.	Check whether there is a foreign matter in the fan. If you find a foreign matter, remove it.
			decreases.	Cooling fan failure	If there is no improvement after you performed the correction above, replace the Servo Drive.

Erro	r No.				
Main	Sub	Name	Ca	use	Measures
(hex)	(hex)			I =	
62	00	Control Right Release Error	Communications between the Sysmac Studio and Servo Drive were interrupted while a specific function was	The USB cable or EtherCAT cable was disconnected during the connection with the Sysmac Studio.	Connect the USB cable or Ether- CAT cable between the Servo Drive and the computer that controls the Servo Drive if it is disconnected.
			used from the Sysmac Studio.	There is excessive noise.	Take noise countermeasures for the USB cable or EtherCAT cable.
			This error is detected when the FFT, test run, or control output check function is used.	A command sent from the Sysmac Studio was not sent to the Servo Drive because the com- puter was in a busy state or the like.	Finish other applications to reduce the processing load of the computer.
70	00	Safety Parameter Error	Safety process data com established with the Safe incorrect parameter was	ty CPU Unit because an	Check whether the connected safety slave model matches the safety slave model that is set from the Sysmac Studio, and correct it.
	01	Safety Com- munications Setting Error	Safety process data communications were not established with the Safety CPU Unit because of an incorrect communications setting.	The watchdog time was set incorrectly.	If the watchdog time of the safety process data communications setting was set to a value inappropriate for the communications cycle or the configuration, correct it, and transfer the setting to the Safety CPU Unit.
				The processing was not completed within the watchdog time because communications were not established due to the noise.	If there is no improvement after you performed noise countermeasures, set the longer watchdog time, and transfer the setting to the Safety CPU Unit.
	02	FSoE Slave Address Error	Safety process data com established with the Safe an incorrect FSoE slave	munications were not ty CPU Unit because of	Perform the FSoE Slave Address Clear for the Servo Drive.
	03	Safety Frame Error	Safety process data communications were not established with the Safety CPU Unit because an incorrect frame was received.	An incorrect frame was received in safety process data communications.	The Servo Drive model does not match the safety slave model that is sent from the safety master.  Check the connection configuration and configure it correctly.
				noise.	Take noise countermeasures.
	04	Safety Com- munications Timeout	A communications time- out occurred in safety process data communi- cations with the Safety	A setting is not correct. The setting of the safety task period of the Safety CPU Unit is too short.	Increase the safety task period of the Safety CPU Unit and then trans- fer the settings to the Safety CPU Unit.
			CPU Unit.	There is excessive noise.  The Safety CPU Unit or safety slave entered a status where it could not continue safety process data communications.	Take noise countermeasures.  Check the status of the Safety CPU Unit or safety slave.

Erro	r No.				
Main	Sub	Name	Cause		Measures
(hex)	(hex)				
83	01	EtherCAT State Change Error	received for which the current communications state could not be changed.		Check the command specifications for communications state transitions in the host controller and correct host controller processing.
	02	EtherCAT Illegal State Change Error	An undefined communication mand was received.	ations state change com-	Check the command specifications for communications state transitions in the host controller and correct host controller processing.
	03	Communications Synchronization Error	Communications were not established consecutively because the synchronization with the EtherCAT Master could not be achieved.	The power supply to the host controller was interrupted during PDO communications.	Reset the error in the host control- ler. This event reports an error that was detected when the power sup- ply to the host controller was inter- rupted. It does not indicate that an error currently exists.
				An EtherCAT communications cable is disconnected, loose, broken, or has a contact failure.	Connect the EtherCAT communications cable securely. If the cable is broken, replace it.
				Noise	Take noise countermeasures if excessive noise affects the Ether-CAT communications cable.
	04	Synchronization Error		Noise	Take noise countermeasures if excessive noise affects the Ether-CAT communications cable.
				Error of the EtherCAT slave communications controller	If this event occurs again after you cycled the power supply, replace the Servo Drive.
	05	Sync Man- ager WDT Error	PDO communications were interrupted for the allowable period or longer.	An EtherCAT communications cable is disconnected, loose, or broken.	Connect the EtherCAT communications cable securely.
				Host controller error	Check the operation of the host controller. Take appropriate countermeasures if there is a problem.
	06	Bootstrap State Transi- tion Request Error	The state transition to un requested.	supported Bootstrap was	Check the EtherCAT master setting so that the EtherCAT master does not request the transition to Bootstrap.
87	00	Error Stop Input	The Error Stop Input (ESTP) is active.	The Error Stop Input (ESTP) was input.	Remove the cause of Error Stop Input (ESTP).
				The Error Stop Input (ESTP) is incorrectly wired.	Correct the wiring if the Error Stop Input (ESTP) is incorrectly wired.

Erro	r No.				
Main	Sub	Name	Ca	use	Measures
(hex)	(hex)				
88	01	ESC Initial- ization Error	The initialization of EtherCAT slave communications controller failed.	Data was incorrectly written in the non-volatile memory of the EtherCAT slave communications controller.  Failure of the EtherCAT slave communications controller	If this event does not occur after you cycled the power supply, use the product continuously. It is supposed that a temporary error occurred due to a read error.  If this event occurs again, replace the Servo Drive.
	02	Synchronization Interruption Error	Synchronization inter- ruption did not occur within the specified period.	Incorrect EtherCAT synchronization setting of the host controller.  Failure of the EtherCAT slave communications controller or false detection	Set the synchronization setting of the host controller according to the synchronization specifications for the EtherCAT slave.  If this event does not occur after you cycled the power supply, use the product continuously. It is supposed that a temporary error occurred due to a read error. If this event occurs again, the Servo Drive is faulty. Replace the Servo Drive.
	03	SII Verifica- tion Error	An error occurred in SII data of the EtherCAT slave communications controller.	Data was incorrectly overwritten in the non-volatile memory of the EtherCAT slave communications controller.  Failure of the EtherCAT slave communications controller or false detection	If this event does not occur after you cycled the power supply, use the product continuously. It is supposed that a temporary error occurred due to a read error.  If this event occurs again, replace the Servo Drive.
	04	ESC Error	An error occurred in the Ecations controller.	EtherCAT slave communi-	If this event occurs repeatedly after you cycled the power supply, the EtherCAT slave communications controller is faulty. Replace the Servo Drive.

Error No.					
Main	Sub	Name	Ca	use	Measures
(hex)	(hex)				
90	00	Mailbox Set- ting Error	An incorrect mailbox setting of Sync Manager was detected.		Check the mailbox setting, and then download it to the EtherCAT master again.
	01	PDO WDT Setting Error	An incorrect PDO WDT s	-	Check the PDO WDT setting, and then download it to the EtherCAT master again.
	02	SM Event Mode Set- ting Error	The unsupported SM Event Mode was set.		Check the synchronization setting, and then download it to the Ether-CAT master again.
	03	DC Setting Error	A mistake was made in the setting.	ne DC Mode operation	Check the DC Mode setting, and then download it to the EtherCAT master again.
	04	Synchronization Cycle Setting Error	When the DC mode was established, the cycle time was set to the inoperable value.  In the variable PDO mapping, the maximum number of objects you	The variable PDO mapping is used, and the number of objects is more than the maximum number of mapped objects for the cycle time.	Set the number of objects to a value smaller than the maximum number of mapped objects for the cycle time.
			can map is specified as follows: 6 for both RxPDO and TxPDO for the communication period of 125 µs, 10 for both RxPDO and TxPDO for other communication periods. An error occurs if you map a larger number of objects than that specified above.  This error is also detected in the following case: the cycle time is an integral multiple of 125 µs and is not 10 ms or lower.	The cycle time setting is incorrect.	Correct the cycle time setting.
	05	RxPDO Set- ting Error	An RxPDO setting error was detected.	The RxPDO setting of EtherCAT master is incorrect.  Servo Drive failure	Correct the RxPDO setting according to the definition of ESI of Servo Drive, and then download it to the EtherCAT master again.  If this event occurs repeatedly after the download to the EtherCAT master, the Servo Drive is faulty.  Replace the Servo Drive.
	06	TxPDO Set- ting Error	A TxPDO setting error was detected.	The TxPDO setting of EtherCAT master is incorrect.  Servo Drive failure	Correct the TxPDO setting according to the definition of ESI of Servo Drive, and then download it to the EtherCAT master again.  If this event occurs repeatedly after the download to the EtherCAT master, the Servo Drive is faulty.  Replace the Servo Drive.

Error No.				
Main	Sub	Name	Cause	Measures
(hex)	(hex)			
90		RxPDO Map- ping Error	An incorrect RxPDO was set, such as out of the allowable range of Index, Subindex, or size.  This error is detected when the following settings are made.	Correct the RxPDO setting, and then download it to the EtherCAT master again.
			<ul><li> If an object which cannot be mapped as a PDO is mapped</li><li> If the total size of objects mapped as the safety</li></ul>	
			<ul> <li>process data exceeds the specified size</li> <li>If the total size of objects mapped to Sync Manager 2 PDO Assignment is one byte</li> </ul>	
			If the total size of objects mapped as the variable PDOs exceeds the maximum size	
			If 1710 hex is not mapped while 1B10 hex is mapped (in 1B10 hex/1710 hex mapping)      The state of the	
			If there were too many or too little data in 1710 hex	
		T 550 M	If the process data components were included in PDOs other than 1710 hex	
	80	TxPDO Map- ping Error	An incorrect TxPDO was set, such as out of the allowable range of Index, Subindex, or size.	Correct the TxPDO setting, and then download it to the EtherCAT
		F9 =	This error is detected when the following settings are made.	master again.
			If an object which cannot be mapped as a PDO is mapped	
			If the total size of objects mapped as the safety process data exceeds the specified size	
	If the total size of objects mapped to Sync Manager 3 PDO Assignment is one byte     If the total size of objects mapped as the variable PDOs exceeds the maximum size			
			If 1B10 hex is not mapped while 1710 hex is mapped (in 1710 hex/1B10 hex mapping)	
			If there were too many or too little data in 1B10 hex	
			If the process data components were included in PDOs other than 1B10 hex	
	09	Node Address Updated	The node address is changed from a set value in Sysmac Studio to a value of the ID switches.	Check the node address value. Set a correct value if it is wrong.

Error No.					
Main (hex)	Sub (hex)	Name	Са	use	Measures
91	01	Command Error	A mistake was made in using a command.	When bit 9 (Remote) of the Statusword was set to 1 (remote), and the Servo Drive was in Operation enabled state (Servo ON), the Servo Drive received a command to change the communications state from Operational to another state (Init, Pre-Operational, or Safe-Operational).  A mode of operation other than the hm mode was set during the homing operation.  Modes of operation was set to pp, pv or hm mode when the communications period was set to shorter than 250 µs.	Check the Servo Drive specifications and use the command correctly.
93	00	Electronic Gear Setting Error	The electronic gear ratio range. You can set the electronic from 1/2,000 to 2,000 tim	gear ratio to the range	Correct the electronic gear ratio to the range from 1/2,000 to 2,000 times.
94	00	Function Setting Error	The function that was set does not support the communications period.	The electronic gear ratio was not 1:1 when the communications period was set to 125 μs.  The Backlash Compensation was enabled when the communications period was set to 125 μs.	Correct the electronic gear ratio to 1:1, or set the communications period to longer than 125 µs.  Disable the Backlash Compensation, or set the communications period to longer than 125 µs.
95	01	Motor Non-confor- mity	The Servo Drive and mot rect.	or combination is not cor-	Replace the motor with one that matches the Servo Drive.
	05	Motor Replace- ment Detected	The connected motor is different from the motor that was connected the last time.	The motor was replaced. The Servo Drive was replaced.	Perform the Motor Setup and Absolute Encoder Setup.  Perform the Motor Setup.
97	00	Brake Inter- lock Error	The Brake Interlock Output (BKIR) was output by the Timeout at Servo OFF.	The Brake Interlock Output (BKIR) was output because the motor rotation speed did not decrease to or less than the speed set in the Threshold Speed at Servo OFF within the time set in the Timeout at Servo OFF when Servo OFF was performed during the motor operation.	Increase the set value of the Timeout at Servo OFF according to actual operation conditions.

Error No.						
Main	Sub	Name	Ca	use	Measures	
(hex)	(hex)					
A0	00	Overload Warning	The load ratio of Servo Drive or motor (4150-81 hex) exceeded the level set in the Overload - Warning Notification Level.	Operation was continued for a long time with high load.	Perform the following corrections accordingly.  Increase the set value of the acceleration/deceleration time or the stop time.  Lighten the load.  Adjust the gain and inertia ratio.  If torque waveforms oscillate excessively, adjust the system by the tuning so that the oscillation does not occur.  Set the appropriate brake timing.	
				There is incorrect wiring of the motor cable or a broken cable.	Servo Drive and the motor.  Connect the motor cable as shown in the wiring diagram. If the cable is broken, replace it. Or, connect the motor cable and encoder cable that are used together to the same motor.  Measure the voltage at the brake terminal. If the brake is applied, release it.	
				Increase in friction	Check machine conditions and remove the cause of the friction.	
A1	00	Regenera- tion Over- load Warning	The Regeneration Load Ratio (4310-81 hex) exceeded 85% of the regeneration overload ratio.	The regeneration processing is set inappropriately.  The Regeneration Resistor is selected inappropriately.	Check the regeneration processing setting, and set the same value as the resistance value of the Regeneration Resistor in use.  Check the operation pattern by the velocity monitor. Check the load ratio of Regeneration Resistor, and perform the following corrections accordingly.  Increase the deceleration time and stopping time.  Decrease the command velocity to the motor.	
				This Regeneration Resistor is used for continuous regenerative braking. The applied power supply voltage is higher than the specified value. Regeneration Resistor failure	Use an External Regeneration Resistor.     Increase the capacities of the Servo Drive and the motor.  The Regeneration Resistor cannot be used for continuous regenerative braking.  Apply the specified power supply voltage.  Check whether the Regeneration Resistor is faulty, and use one without failures.	

Erro	r No.				
Main	Sub	Name	Ca	use	Measures
(hex)	(hex)				
Warning the fan is the rating	The rotation speed of the fan is 80% or less of the rating and the cool- ing performance	There is a foreign matter in the cooling fan and it blocks the rotation.	Check whether there is a foreign matter in the fan. If you find a foreign matter, remove it.		
			decreases.	Cooling fan failure	If there is no improvement after you performed the correction above, replace the Servo Drive.
A4	00	Encoder Communica- tions Warning	Encoder communications errors occurred in series more frequently than the specified value.	Noise into the encoder cable	<ul> <li>Separate the motor cable and the encoder cable if they are bundled together.</li> <li>Connect the shield to FG.</li> </ul>
			This warning is detected if encoder communica-		Check that the motor ground wire is connected to FG.
			tion fails twice in a row due to events such as a timeout or data error.	Contact failure of the encoder cable	Check whether the connector is disconnected. Connect the connector firmly if it is disconnected or loose. Check that the encoder cable is not broken. Replace the encoder cable if it is broken.
				Power supply undervoltage to the encoder	Use the recommended encoder cable.
A6	00	Motor Vibra- tion Warning	The motor vibration, which was higher than or equal to the level set in the <b>Vibration Detec-</b>	The control parameter is set inappropriately.	Set the control parameters such as inertia ratio, gain, and filter to appropriate values by gain tuning or manually.
			tion - Detection Level (3B70-01 hex), was detected.	The rigidity decreased due to mechanical looseness or wear.	Check whether the mechanical system is not loose and secure it firmly. If the rigidity of mechanical system is changed, adjust the control parameter again.

Erro	r No.					
Main (hex)	Sub (hex)	Name	Ca	use	Measures	
A7	01	Capacitor Lifetime Warning	The capacitor built into the Servo Drive reached the service life.	The operating time of the capacitor in the Servo Drive exceeded the service life.	Send the Servo Drive for repair or replace the Servo Drive with a new one. It is necessary to replace the component that reached the service	
	02	Inrush Cur- rent Preven- tion Relay Lifetime Warning	The inrush current prevention relay built into the Servo Drive reached the service life.	The number of operating times of the inrush current prevention relay in the Servo Drive exceeded the service life.*3	life.	
	04	Brake Inter- lock Output Relay Life- time Warning	The brake interlock output (BKIR) relay built into the Servo Drive reached the service life.	The number of operating times of the brake interlock output in the Servo Drive exceeded the service life.*3		
	05	Lifetime Information Corruption Warning	An error was detected in the saved lifetime information.	The lifetime information corruption was detected when the power supply was turned ON.	Perform the Lifetime Information Clear. Note that the lifetime may not be detected correctly after the clear operation because the value of life- time information is cleared. If this event occurs repeatedly, the	
					area to save lifetime information is faulty. Replace the Servo Drive.	
	06	Encoder Life- time Warning	The encoder lifetime is close to the end.	Temporary noise The end of the encoder life	If this event occurs repeatedly, the lifetime is close to the end. Replace the motor.	
AB	00	Absolute Encoder Counter Overflow Warning	The multi-rotation counter of the encoder exceeded the value set in Encoder - Absolute Encoder Counter	An inappropriate value was set in the Encoder - Operation Selection when Using Absolute Encoder (4510-01 hex).	Set an appropriate value in the Encoder - Operation Selection when Using Absolute Encoder (4510-01 hex).	
			Overflow Warning Level (4510-02 hex).	The multi-rotation number of the encoder exceeded the warning level.	Set the travel distance so that the multi-rotation number does not exceed the value set in the Encoder - Absolute Encoder Counter Overflow Warning Level (4510-02 hex).	
B0	00	Data Setting Warning	The object set value is ou	ut of the range.	Correct the object setting to be within the specified range.	

Erro	r No.				
Main	Sub	Name	Са	use	Measures
(hex)	(hex)				
B1	00	Command Warning	A command could not be executed.	The Switch on command was received.	Send the <i>Switch on</i> command with the main circuit power supply ON.
				The Enable operation command was received.	Send the <i>Enable operation</i> command under the following conditions.
					In supported operation mode
					The motor rotation speed is 30 r/min or less.
					In the free-run mode, the interpolation time period is the integral multiple of the communications cycle.
				An operation command in the prohibition direction was received after the immediate stop by the Drive Prohibition Input or Software Position Limit.	Check status of the Drive Prohibition Input and Software Position Limit by the Digital inputs, Statusword, and Software Position Limit. Then, do not issue the command in the drive prohibition direction.
				Homing started.	Set a supported number of the Homing method for homing.
					Start homing at the timing of when homing is not performed.
				The positioning start command was received in the Profile position mode.	Set a supported value for bit 5 and 6 in the Controlword.
B2	00	EtherCAT Communica- tions Warning	An EtherCAT communications error occurred more than one time.	An EtherCAT communications cable has a contact failure, or is connected incorrectly or broken.	Connect the EtherCAT communications cable securely. If the cable is broken, replace it.
				Noise	Take noise countermeasures so that the noise does not affect the EtherCAT communications cable.
C0	00	STO Detected	The safety input OFF state was detected via the safety input signal or	The cable is disconnected or broken.	Reconnect the input wiring for safety inputs 1 and 2. If the cable is broken, replace it.
			EtherCAT communications.	The STO input was turned OFF via Ether-CAT communications.	Remove the cause that turned OFF the safety input signal of the Safety Input Unit.

<sup>\*1.</sup> This error can occur in the unit version 1.2 or later.

<sup>\*2.</sup> This error can occur in the unit version 1.1 or later.

<sup>\*3.</sup> Refer to AC Servomotors/Servo Drives 1S-series with Built-in EtherCAT® Communications User's Manual (1586) for the lifetime of components.

### 7-5-2 Troubleshooting Using AL Status Codes

The AL status codes notify users of errors related to EtherCAT communications.

This section gives errors that 1S-series Servo Drives notify to the host controllers with AL status codes, as well as their causes and remedies.

### **AL Status Code List**

AL status code (hex)	Name	Са	use	Measures
0011	EtherCAT State Change Error	A communications state characteristic received for which the curre could not be changed.	_	Check the command specifications for communications state transitions in the host controller and correct host controller processing.
0012	EtherCAT Illegal State Change Error	An undefined communications state change command was received.		Check the command specifications for communications state transitions in the host controller and correct host controller processing.
0013	Bootstrap State Transi- tion Request Error	The state transition to unsu requested by the EtherCAT		Check the EtherCAT master setting so that the EtherCAT master does not request the transition to Bootstrap.
0014	SII Verifica- tion Error	An error occurred in SII data of the EtherCAT slave communications controller.	Data was incorrectly overwritten in the non-volatile memory of the EtherCAT slave communications controller.  Failure of the EtherCAT slave communications controller or false detection	If this event does not occur after you cycled the power supply, use the product continuously. It is supposed that a temporary error occurred due to a read error.  If this event occurs again, replace the Servo Drive.
0016	Mailbox Set- ting Error	An incorrect mailbox setting detected.	g of Sync Manager was	Check the mailbox setting, and then download it to the EtherCAT master again.
001B	Sync Man- ager WDT Error	PDO communications were interrupted for the allowable period or longer.	An EtherCAT communications cable is disconnected, loose, or broken  Host controller error	Connect the EtherCAT communications cable securely.  Check the operation of the host controller. Take appropriate
001D	RxPDO Set- ting Error	An RxPDO setting error was detected.	The RxPDO setting of EtherCAT master is incorrect.  Servo Drive failure	countermeasures if there is a prob- lem.  Correct the RxPDO setting accord- ing to the definition of ESI of Servo Drive, and then download it to the EtherCAT master again.  If this event occurs repeatedly after the download to the EtherCAT mas- ter, the Servo Drive is faulty. Replace the Servo Drive.

AL status code (hex)	Name	Ca	use	Measures
001E	TxPDO Set- ting Error	A TxPDO setting error was detected.	The TxPDO setting of EtherCAT master is incorrect. Servo Drive failure	Correct the TxPDO setting according to the definition of ESI of Servo Drive, and then download it to the EtherCAT master again.  If this event occurs repeatedly after the download to the EtherCAT master, the Servo Drive is faulty.  Replace the Servo Drive.
001F	PDO WDT Setting Error	An incorrect PDO WDT set	I ting was detected.	Check the PDO WDT setting, and then download it to the EtherCAT master again.
0024	TxPDO Mapping Error	An incorrect TxPDO was seable range of Index, Subinot This error is detected when made.  If an object which cannot mapped  If the total size of objects cess data exceeds the sponsor of the total size of objects a PDO Assignment is or If the total size of objects PDOs exceeds the maximum. If 1B10 hex is not mapped (in 1710 hex/1B10 hex mum.)  If there were too many or If the process data composition of the pools other than 1B10 here.	the following settings are be mapped as a PDO is mapped as the safety pro- pecified size mapped to <b>Sync Manager</b> ne byte mapped as the variable num size d while 1710 hex is mapped apping) too little data in 1B10 hex ponents were included in	Correct the TxPDO setting, and then download it to the EtherCAT master again.
0025	RxPDO Mapping Error	An incorrect RxPDO was seable range of Index, Subinot This error is detected when made.  If an object which cannot mapped  If the total size of objects cess data exceeds the sp.  If the total size of objects 2 PDO Assignment is or.  If the total size of objects PDOs exceeds the maxim.  If 1710 hex is not mapped (in 1B10 hex/1710 hex m.)  If there were too many or.  If the process data comport PDOs other than 1710 hes.	the following settings are be mapped as a PDO is mapped as the safety pro- pecified size mapped to <b>Sync Manager</b> ne byte mapped as the variable num size d while 1B10 hex is mapped apping) too little data in 1710 hex ponents were included in	Correct the RxPDO setting, and then download it to the EtherCAT master again.
0028	SM Event Mode Setting Error	The unsupported SM Event	t Mode was set.	Check the synchronization setting, and then download it to the Ether-CAT master again.

AL status	Name	Ca	use	Measures
002C	Synchroniza-	A signal for synchronous	Noise	Take noise countermeasures if
	tion Error	communications could not be detected.		excessive noise affects the Ether-CAT communications cable.
			Error of the EtherCAT slave communications controller	If this event occurs again after you cycled the power supply, replace the Servo Drive.
002D	Synchroniza- tion Interrup- tion Error	Synchronization interruption did not occur within the specified period.	Incorrect EtherCAT syn- chronization setting of the host controller.	Set the synchronization setting of the host controller according to the synchronization specifications for the EtherCAT slave.
			Failure of the EtherCAT slave communications controller or false detection	If this event does not occur after you cycled the power supply, use the product continuously. It is supposed that a temporary error occurred due to a read error. If this event occurs again, the Servo Drive is faulty. Replace the Servo Drive.
0030	DC Setting Error	A mistake was made in the	DC Mode operation setting.	Check the DC Mode setting, and then download it to the EtherCAT master again.
0034	Communications Synchronization Error	Communications were not established consecutively because the synchronization with the EtherCAT Master could not be achieved.	The power supply to the host controller was interrupted during PDO communications.	Reset the error in the host control- ler. This event reports an error that was detected when the power sup- ply to the host controller was inter- rupted. It does not indicate that an error currently exists.
			An EtherCAT communications cable is disconnected, loose, broken, or has a contact failure.	Connect the EtherCAT communications cable securely. If the cable is broken, replace it.
			Noise	Take noise countermeasures if excessive noise affects the Ether-CAT communications cable.
0035	Synchroniza- tion Cycle Setting Error	When the DC mode was established, the cycle time was set to the inoperable value.  In the variable PDO mapping, the maximum num-	The variable PDO mapping is used, and the number of objects is more than the maximum number of mapped objects for the cycle time.  The cycle time setting is	Set the number of objects to a value smaller than the maximum number of mapped objects for the cycle time.  Correct the cycle time setting.
		ber of objects you can map is specified as follows: 6 for both RxPDO and TxPDO for the communication period of 125 µs, 10 for both RxPDO and TxPDO for other communication periods. An error occurs if you map a larger number of objects than that specified above.	incorrect.	Correct the cycle time setting.
		This error is also detected in the following case: the cycle time is an integral multiple of 125 µs and is not 10 ms or lower.		

AL status code (hex)	Name	Ca	use	Measures
0050	ESC Error	An error occurred in the EtherCAT slave communications controller.	Error access from the non-OMRON EtherCAT master	Please contact the manufacturer of EtherCAT master.
0051			Error of the EtherCAT slave communications controller or false detec- tion	If this event occurs repeatedly after you cycled the power supply, the EtherCAT slave communications controller is faulty. Replace the Servo Drive.
0061	Node Address Updated	The node address is changed to a value of the ID switches.  The node address is changed from a set value in Sys-		Check the node address value. Set a correct value if it is wrong.
_		mac Studio to a value of the ID switches.		
8000	Unit Restarted	Restart was performed.		

### 7-5-3 Troubleshooting Using the Operation State

Symptom	Probable cause	Check items	Measures
The 7-segment dis-	The control power is not sup-	Check to see if the power sup-	Supply the correct power sup-
play does not light.	plied.	ply input is within the allowed	ply voltage.
		power supply voltage range.	
		Check to see if the power sup-	Wire correctly.
		ply input is wired correctly.	
The ECAT ERR indi-	A communications-related error	Refer to EtherCAT Communication	ons Warning on page 7-9.
cator flashes or lights.	occurred.		
The L/A IN and L/A	A link in the EtherCAT physical	Check to see if the communica-	Connect the communications
OUT indicators are	communications layer is not	tions cable is connected cor-	cable correctly.
OFF.	established.	rectly.	
		Check to see if the host control-	Start the host controller.
		ler started.	
An error occurred.	Read the error number and the	Check the cause listed in 7-5-1 7	Troubleshooting Using Error Dis-
	error log.	plays on page 7-14.	
The Servo does not	The power cable is not con-	Check to see if the motor power	Wire the motor power cable
lock.	nected correctly.	cable is connected properly.	correctly.
	The Servomotor power supply	Check the main circuit wiring	Input the correct power and
	is not ON.	and power voltage.	voltage for the main circuit.
	Positive Drive Prohibition Input	Check to see if the input for	Turn ON POT and NOT. Input
	(POT) or Negative Drive Prohi-	POT or NOT is OFF.	+24 VIN correctly.
	bition Input (NOT) is OFF.	Check the input of +24 VIN to	
		CN1.	
	The torque limit is set to 0.	Check to see if the torque limits	Set the maximum torque that
	·	in the <b>Positive torque limit</b>	you use for each of these
		value (60E0 hex) and the Neg-	objects.
		ative torque limit value (60E1	
		hex) are set to 0.	
	The Servo Drive is in a safe	Check the wiring of the safety	Wire correctly.
	state (STO).	input.	-
	Communications with the	When you use the STO func-	Make the settings for the Safety
	Safety CPU Unit are not estab-	tion via EtherCAT communica-	CPU Unit.
	lished.	tions, confirm that	
		communications with the	
		Safety CPU Unit are per-	
		formed.	
	The Servo Drive is broken		Replace the Servo Drive.
	down.		

Symptom	Probable cause	Check items	Measures
The Servo locks but	The host controller does not	For a position command, check	Enter position and speed data.
the Servomotor does	give a command.	to see if the speed and position	Start the Servomotor.
not rotate.		are set to 0.	
	The Servo Drive received a	Check to see if the Servo Drive	Set the Servo Drive so that it
	command but it is not	retains the object value for two	retains the object value for two
	accepted.	communications cycles or more	communications cycles or
	10:1	in Profile position mode (pp).	more.
	It is hard to determine if the	Check to see if the velocity	Check the velocity command
	Servomotor is rotating.	command given by the host controller is too small.	from the host controller.
	The holding brake is operating.	Check the Brake Interlock Out-	Chack to see if the holding
	The holding brake is operating.	put (BKIR) signal and the +24	Check to see if the holding brake on a Servomotor with
		VDC power supply.	brake is released when the
		VDC power suppry.	Servo is locked.
	The torque limits set in the	Check to see if the torque limits	Set the maximum torque that
	Positive torque limit value	in objects 60E0 hex and 60E1	you use for each of these
	(60E0 hex) and the <b>Negative</b>	hex are set to a value close to	objects.
	torque limit value (60E1 hex)	0.	,
	are too small.		
	Positive Drive Prohibition Input	Check the ON/OFF state of the	Turn ON the POT and NOT
	(POT) or Negative Drive Prohi-	POT and NOT signals from the	signals.
	bition Input (NOT) is OFF.	Sysmac Studio.	Disable them in the settings
			when the POT and NOT sig-
			nals are not used.
	The motor power cable is wired	Check the wiring.	Wire correctly.
	incorrectly.		
	The encoder cable is wired		
	incorrectly.		
	Power is not supplied.	Check the power supply and	Turn ON the power.
		the 7-segment display.	
		Check the voltage between the	Wire the power-ON circuit cor-
		power terminals.	rectly.
	The Servo Drive is broken		Replace the Servo Drive.
	down.		
The Servomotor oper-	1	Check the position data and the	Set the correct data.
ates momentarily, but	are too little.	electronic gear ratio at the host	
then it does not oper-	<del></del>	controller.	) AAC (1
ate after that.	The motor power cable is wired	Check the wiring of the motor	Wire correctly.
	incorrectly.	power cable's phases U, V, and W.	
	The encoder cable is wired	Check the encoder cable's wir-	Wire correctly.
	incorrectly.	ing.	vviie correctly.
The Servomotor	There are inputs of small val-	Check if there is an input in	Set the velocity command to 0.
rotates without a com-	ues in velocity control mode.	velocity control mode.	Alternatively, change the mode
mand.	and in voicing defined in the control of the contro		to position control mode.
	The motor power cable is wired	Check the wiring.	Wire correctly.
	incorrectly.		
When the runaway	The Servomotor power cable is	Check the wiring.	Wire correctly.
detection function is	wired incorrectly, and condi-	]	,
	tions under which the runaway		
enabled, the	nons under windir the fullaway		
enabled, the Servomotor rotates without a command.	detection function cannot work		

Symptom	Probable cause	Check items	Measures
The Servomotor rotates in the reverse direction from the command.	The value set in Motor Rotation Direction Selection (3000-01 hex) is incorrect.	Check the value of Motor Rotation Direction Selection.	Change the value of Motor Rotation Direction Selection.
	The command given by the host controller is incorrect.	<ul> <li>The size of the absolute command is set incorrect.</li> <li>The polarity of an incremental command is set incorrect.</li> </ul>	Check the actual and target values.     Check the rotation direction.
	The Servomotor power cable is wired incorrectly.	Check the wiring.	Wire correctly.
When the runaway detection function is enabled, the	The value set in Motor Rotation Direction Selection (3000-01 hex) is incorrect.	Check the value of Motor Rotation Direction Selection.	Change the value of Motor Rotation Direction Selection.
Servomotor rotates in the reverse direction from the command.	The command given by the host controller is incorrect.	<ul> <li>The size of the absolute command is set incorrect.</li> <li>The polarity of an incremental command is set incorrect.</li> </ul>	Check the actual and target values.     Check the rotation direction.
	The Servomotor power cable is wired incorrectly.	Check the wiring.	Wire correctly.
	The Servomotor power cable is wired incorrectly, and conditions under which the runaway detection function cannot work are satisfied.		
The holding brake does not work.	Power is supplied to the holding brake.	Check to see if power is supplied to the holding brake.	Check the Brake Interlock     Output (BKIR) signal and the     relay circuit.
			Check to see if the holding brake is worn down.
Motor rotation is unstable.	The motor power cable or encoder cable is wired incorrectly.	Check the wiring of the motor power cable's phases U, V, W and check the encoder cable's wiring.	Wire correctly.
	Low rigidity is causing vibration.	Measure the vibration frequency of the load.	Enable the damping control. Set the damping filter frequency.
	The load's moment of inertia exceeds the Servo Drive's allowable value.	Calculate the load inertia.	Check if manual tuning can achieve proper adjustment.     Increase the Servomotor capacity.
	Loose joint and/or large clearance with the machine.	Check the joint with the machine.	Remove the joint looseness with the machine.
	The load and gain do not match.	Check the response waveforms for speed and torque.	Perform the tuning again to stabilize the rotation.

Symptom	Probable cause	Check items	Measures
The Servomotor is overheating.	The ambient temperature is too high.  The heat radiation condition for	Check to see if the ambient temperature around the Servomotor is over 40°C.	Lower the ambient temperature around the Servomotor to 40°C or less. (Use a fan or air conditioner.)     Lower the load ratio.
	the Servomotor is inappropriate.	<ul> <li>Check to see if the specified radiation conditions are observed.</li> <li>For a Servomotor with a brake, check the load ratio.</li> </ul>	<ul><li>Improve the radiation conditions.</li><li>Reduce the load.</li><li>Improve ventilation.</li></ul>
	The Servomotor is overloaded. The Servomotor vibrates during rotation.	Check the torque with the Sysmac Studio.	<ul> <li>Decrease the acceleration and deceleration rates.</li> <li>Lower the speed and check the load.</li> </ul>
The machine position is misaligned.	The coupling of the motor shaft and the machine is abnormal.	Check to see if the coupling of the Servomotor and the machine is misaligned.	<ul> <li>Tighten the coupling again.</li> <li>Replace the coupling with a coupling that has no looseness.</li> </ul>
	The host controller gave a deceleration stop command.	Check the control ladder program in the host controller.	Review the control in the host controller.
	The gain is wrong.		Check if manual tuning can achieve proper adjustment.
	The load inertia is too large.	Check the load inertia. Check the Servomotor rotation speed.	<ul> <li>Review the load inertia.</li> <li>Replace the Servomotor and Servo Drive with proper ones.</li> </ul>
	The power supply was turned ON while the encoder multi-rotation exceeded the limit value.	Check Encoder - Multi- rotation Data.	Perform the operation within the multi-rotation range.
	The command value from the host controller is not correct.	Check the control ladder program and settings in the host controller.	Review the control and settings in the host controller.
	The home position was shifted.	<ul> <li>Check the home position of the absolute encoder.</li> <li>Check whether homing is performed normally.</li> </ul>	<ul> <li>Adjust the mechanical home and home position of the absolute encoder.</li> <li>Change the setting or input signals so that the correct home position can be defined during homing.</li> </ul>
	The set values of the Servo Drive do not match the machine.	Check the settings of gear ratio, gain, maximum torque, etc.	Adjust the set values so that they match the machine.
The Servomotor does not stop or is hard to stop even if the Servo is turned OFF while	The load inertia is too large.	Check the load inertia. Check the Servomotor rotation speed.	<ul> <li>Review the load inertia.</li> <li>Replace the Servomotor and Servo Drive with proper ones.</li> </ul>
the Servomotor is rotating.	The dynamic brake is disabled.	Check if the dynamic brake is disabled or broken.	<ul> <li>Enable the dynamic brake, if it is disabled.</li> <li>Replace the dynamic brake if it is broken.</li> </ul>

Symptom	Probable cause	Check items	Measures
The Servomotor or the load generates abnormal noise or	Vibration occurs due to improper mechanical installation.	Check to see if the Servomotor's mounting screws are loose.	Retighten the mounting screws.
vibration.		Check the load for eccentricity.	Eliminate the eccentricity. It results in torque fluctuation and noise.
		Check to see if the coupling with the load is unbalanced.	Balance the rotation.
		Check to see if the decelerator is generating any abnormal noise.	Check the decelerator specifications. Check the decelerator for malfunctions.
	Vibration occurs due to low mechanical rigidity.	Check to see if the vibration frequency is 100 Hz or lower.	If the frequency is 100 Hz or lower, set the correct damping frequency for the damping filter to eliminate the vibration.
	Vibration occurs due to machine resonance.	Check to see if the resonance frequency is high or low.	If the resonance frequency is high, set the adaptive filter to eliminate the resonance. Alternatively, measure the resonance frequency and set 1st Notch Filter and 2nd Notch Filter.
	There is a problem with the bearings.	Check for noise or vibration around the bearings.	Check to see if the bearings are mounted properly, and adjust them if necessary.
	The gain is too high.		Use the Sysmac Studio to measure the response and adjust the gain.
	Velocity Command Filter (3021 hex) is wrong.	Check the set value of <b>Velocity</b> Command Filter.	Return the setting to the default value of 0. Alternatively, set a large value and operate the Servomotor.

Symptom	Probable cause	Check items	Measures
The Servomotor or	1st Torque Command Filter	Review the set value of the	Set a small value for the torque
the load generates	(3233 hex) or <b>2nd Torque</b>	torque command filter.	command filter to eliminate the
abnormal noise or	Command Filter (3234 hex)		vibration.
vibration.	does not match the load.		
	1st Position Control Gain	Review the setting of the posi-	Use the Sysmac Studio to mea-
	(3213 hex) or 2nd Position	tion control gain.	sure the response and adjust
	Control Gain (3214 hex) is too	S .	the gain.
	large.		
	Proportional Gain and Inte-	Review the set values of the	-
	gral Gain in 1st Velocity Con-	velocity control gain.	
	trol Gain (3223 hex) and 2nd	, 3	
	Velocity Control Gain (3224		
	hex) are balanced incorrectly.		
	Noise is entering into the con-	Check the length of the control	Shorten the control I/O signal
	trol I/O signal cable because	I/O signal cable.	cable to 3 m or less.
	the cable is longer than the		
	specified length.		
	Noise is entering into the cable	Check to see if it is a shielded	Use an encoder cable that
	because the encoder cable	twisted-pair cable with core	meets specifications.
	does not meet specifications.	wires that are at least 0.12	
	· ·	mm <sup>2</sup> .	
	Noise is entering into the	Check the length of the	Shorten the encoder cable to
	encoder cable because the	encoder cable.	less than 50 m.
	cable is longer than the speci-	Chicago dabio.	loos than oo m.
	fied length.		
	Noise is entering into the signal	Check the encoder cable for	Correct the encoder cable's
	lines because the encoder	damage.	pathway.
	cable is stuck or the sheath is	damage.	pailway.
	damaged.		
	Excessive noise on encoder	Check to see if the encoder	Install the encoder cable where
	cable.	cable is bound together with or	it won't be subjected to surges.
		too close to high-current lines.	
	The FG's potential is fluctuating	Check for ground problems	Ground the equipment prop-
	due to devices near the Servo-	(loss of ground or incomplete	erly and prevent current from
	motor, such as welding	ground) at equipment such as	flowing to the encoder FG.
	machines.	welding machines near the Ser-	
		vomotor.	
	Errors are caused by excessive	There are problems with	Reduce the mechanical vibra-
	vibration or shock on the	mechanical vibration or Servo-	tion or correct the Servomotor's
	encoder.	motor installation (such as the	installation.
		precision of the mounting sur-	
		face, attachment, or axial off-	
		set).	
Overshooting at	1st Position Control Gain	Review the setting of the posi-	Use the Sysmac Studio to mea-
startup or when stop-	(3213 hex) or 2nd Position	tion control gain.	sure the response and adjust
ping	Control Gain (3214 hex) is too		the gain.
-	large.		
	Proportional Gain and Inte-	Review the set values of the	1
	gral Gain in 1st Velocity Con-	velocity control gain.	
	trol Gain (3223 hex) and 2nd		
	Velocity Control Gain (3224		
	hex) are balanced incorrectly.		
	The set inertia ratio differs from	Review the set value of the	Adjust the set value of the Iner-
	the load.	Inertia Ratio (3001-01 hex).	tia Ratio.
	l	<u>'</u>	

Symptom	Probable cause	Check items	Measures
Vibration is occurring at the same fre-	Inductive noise is occurring.	Check to see if the drive control signal lines are too long.	Shorten the control signal lines.
quency as the power supply.		Check to see if the control sig- nal lines and power supply lines are bound together.	<ul> <li>Separate control signal lines from power supply lines.</li> <li>Use a low-impedance power supply for control signals.</li> </ul>
The command velocity or torque is not reached.	The input command value exceeds the velocity limit value or the torque limit value.	Check to see if the Internal limit active bit of Statusword is active.	Input the command value that does not exceed the velocity limit value or the torque limit value from the host controller.



# **Maintenance and Inspection**

This section explains maintenance and inspection of the Servomotors and Servo Drives.

8-1	Periodic Maintenance	8-2
8-2	Servo Drive Lifetime	8-3
8-3	Servomotor Lifetime	8-4

## **Periodic Maintenance**

# Caution

After replacing the Servo Drive, transfer to the new Servo Drive all data needed to resume operation, before restarting operation. Equipment damage may result.



Do not repair the Servo Drive by disassembling it. Electric shock or injury may result.



Servomotors and Servo Drives contain many components and will operate properly only when each of the individual components is operating properly.

Some of the electrical and mechanical components require maintenance depending on application conditions. Periodic inspection and replacement are necessary to ensure proper long-term operation of Servomotors and Servo Drives. (Quoted from The Recommendation for Periodic Maintenance of a General-purpose Inverter published by JEMA.)

The periodic maintenance cycle depends on the installation environment and application conditions of the Servomotors and Servo Drives.

Recommended maintenance times are given below for Servomotors and Servo Drives. Use these for reference in periodic maintenance.

## 8-2 Servo Drive Lifetime

- The lifetime of Servo Drive depends on application conditions. When the ambient temperature is 40°C and the average output is 70% of the rated output, the design life expectancy is ten years.
- The use of the Servo Drive in a hot environment shortens its lifetime. We recommend that the ambient temperature and the power supply ON time be reduced as much as possible to lengthen the lifetime of the Servo Drive.
- The lifetimes for the different parts of Servo Drive are given below.

Name	Lifetime
Inrush current prevention relay	Approx. 36,500 operations (lifetime depends on application conditions.)
Brake interlock output relay	Approx. 36,500 operations (lifetime depends on application conditions.)

## **Servomotor Lifetime**

The lifetimes for the different motor parts are listed below.

Name	Lifetime
Bearing	20,000 hours
Decelerator*1	20,000 hours
Oil seal*1	5,000 hours (models with oil seal)*1
Brake	ON/OFF 1,000,000 times

<sup>\*1.</sup> These parts are not included in the Incremental Encoder Type Servomotors.

The operating conditions are determined as follows.

- · Operating ambient temperature: 40°C
- · Within the range of allowable axial load
- Rated operation (rated torque and rated rotation speed)
- · Installation as specified in this manual
- Operation is not repeated with the motor shaft rotation at an angle of 45° or less, which causes the fretting.

Oil seal can be replaced for repair.

When the Servomotor is used for a belt hook such as timing pulley, the radial load during motor operation is generally two or more times the static load. Consult with the belt and pulley manufacturers to adjust designs and system settings so that the motor allowable axial load is not exceeded even during operation. If the Servomotor is used under a shaft load that exceeds the allowable limit, the motor shaft can be broken and the bearings can be damaged.



#### **Additional Information**

If the Encoder Lifetime Warning occurs, we recommend you to replace the encoder within a few weeks.



# **Appendices**

The appendices provide explanation for the profile that is used to control the Servo Drive, lists of objects, and Sysmac error status codes.

A-1	Sysmac	Error Status Codes	A-2
	A-1-1	Error List	. A-2
	A-1-2	Error Descriptions	A-14

# **A-1 Sysmac Error Status Codes**

This section lists and describes the error event codes that you can see in Sysmac Studio.

### A-1-1 Error List

The errors (events) that can occur in 1S-series AC Servo Drives with Built-in EtherCAT Communications are given on the following pages.

Event levels are given in the table as follows:

Min: Minor fault level Obs: Observation Info: Information

Refer to the *NJ/NX-series Troubleshooting Manual* (Cat. No. W503) for all of the event codes that may occur in an NJ/NX-series Controller.

Event code				I	_eve	l	Refer-
(hex)	Event name	Description	Assumed cause	Min	sqo	Info	ence
04B30000	Regeneration Circuit Error Detected during Power ON*1	An error of the Regeneration Circuit was detected at power ON.	<ul> <li>Power supply voltage is insufficient at power ON, or rising slowly.</li> <li>Power supply voltage fluctuated at power ON.</li> <li>L1, L2, and L3 terminals are not connected or disconnected.</li> <li>N1 and N2 terminals are opened.</li> <li>Servo Drive failure.</li> </ul>	<b>√</b>			P. A-15
05430000	ESC Error	An error occurred in the EtherCAT slave communications controller.	Error of the EtherCAT slave communications controller or false detection when the AL status code is 0051 hex     Error access from the non-OMRON EtherCAT master when the AL status code is 0050 hex	<b>√</b>			P. A-17
08390000	Power Module Error	An error was detected in the power module.	There is a short-circuit, ground fault, or contact failure on the U, V, or W motor cable There is a short-circuit on the wiring of External Regeneration Resistor or the resistance value is small The insulation resistance failed between the U, V, or W motor cable and the motor ground wire Servo Drive failure	<b>V</b>			P. A-18

Event code				I	Leve	ı	Refer-
(hex)	Event name	Description	Assumed cause	Min	Obs	Info	ence
083B0000	Self-diagnosis Error	An error was detected by the self-diagnosis of the safety function.	False detection due to a data read error that was caused by excessive noise     Hardware failure	1			P. A-19
083C0000	Main Circuit Tem- perature Monitoring Circuit Failure	A temperature monitoring circuit failure was detected on the main circuit.	Broken wiring of the therm- istor, temperature monitor- ing circuit failure	1			P. A-19
083D 0000	Fan Error	The rotation speed of the fan is 40% or less of the rating and the cooling performance decreases.	There is a foreign matter in the cooling fan and it blocks the rotation Cooling fan failure	√			P. A-20
083F0000	Regeneration Processing Error	The regeneration processing was stopped to protect the Regeneration Resistor.	The regeneration processing is set inappropriately The Regeneration Resistor is selected inappropriately The Regeneration Resistor is used for continuous regenerative braking The applied power supply voltage is higher than the specified value Regeneration Resistor failure	1			P. A-21
08410000	Overvoltage Error	The main circuit power supply voltage (P-N voltage) exceeded the operation guarantee range.	<ul> <li>The P-N voltage exceeded the specified value</li> <li>The input voltage increased</li> <li>The Regeneration Resistor wiring is broken</li> <li>The External Regeneration Resistor is set or selected inappropriately</li> <li>Servo Drive failure</li> </ul>	√			P. A-22
08420000	Motor Overheat Error	The encoder detected the temperature that exceeded the protection level of motor.	The temperature is high around the motor The motor is overloaded Encoder failure	1			P. A-23
08430000	1-rotation Counter Error	The encoder detected a one-rotation counter error.	<ul> <li>There is excessive noise</li> <li>Failure due to vibration, impact, condensation, for- eign matter, etc.</li> </ul>	1			P. A-23
08440000	Overspeed Error	The encoder detected the overspeed.	The motor was rotated by external forces Encoder failure and false detection	<b>V</b>			P. A-24
08450000	Encoder Memory Error	The encoder detected a non-volatile memory error.	False detection due to a data read error that was caused by excessive noise     Non-volatile memory failure	1			P. A-24

Event code					_eve	el	Refer-
(hex)	Event name	Description	Assumed cause	Min	ops	Info	ence
08460000	Absolute Position Detection Error	The encoder detected a multi-rotation counter error.	A detection error was detected in the multi-rotation detection section of the encoder      There is excessive noise	<b>V</b>			P. A-25
08480000	Main Power Supply Undervoltage (insuf- ficient voltage between P and N)	The main circuit power supply voltage fell below the operation guarantee range during Servo ON.	Incorrect wiring of the main circuit power supply The low power supply voltage is applied to the Servo Drive The long time was set in Momentary Hold Time and the voltage was decreased momentarily Servo Drive failure	<b>√</b>			P. A-26
08490000	Overcurrent Error	The current flowing to the motor exceeded the protection level.	There is a short-circuit, ground fault, or contact failure on the U, V, or W motor cable There is a short-circuit on the wiring of External Regeneration Resistor The insulation resistance failed between the U, V, or W motor cable and the motor ground wire False detection due to the noise Servo Drive failure	1			P. A-27
084A0000	Encoder Communications Disconnection Error	The communications disconnection was detected between the encoder and the Servo Drive.	<ul> <li>Noise into the encoder cable</li> <li>Contact failure of the signal line, and disconnection of the encoder</li> <li>Power supply undervoltage to the encoder</li> <li>Encoder failure</li> </ul>	<b>√</b>			P. A-28
084B0000	Encoder Communications Error	Illegal data was received from the encoder the specified number of times.	<ul> <li>Noise into the encoder cable</li> <li>Contact failure of the signal line, and disconnection of the encoder</li> <li>Power supply undervoltage to the encoder</li> </ul>	<b>V</b>			P. A-29
084D 0000	Non-volatile Memory Hardware Error	An error occurred on the non-volatile memory.	<ul> <li>False detection due to a data read error that was caused by excessive noise</li> <li>Non-volatile memory failure</li> </ul>	<b>V</b>			P. A-30

Event code				I	Leve	ı	Refer-
(hex)	Event name	Description	Assumed cause	Min	Obs	Info	ence
1823 0000	Absolute Encoder Multi-rotation Counter Error	The encoder detected a multi-rotation counter error.	A temporary error occurred in the encoder multi-rotation detection function due to vibration, impact, or condensation     Encoder failure	<b>V</b>			P. A-30
18380000	System Error	A hardware error due to the self-diagnosis and a fatal software error were detected.	<ul> <li>False detection due to a data read error that was caused by excessive noise</li> <li>A fatal software error was detected</li> <li>Hardware failure</li> </ul>	<b>V</b>			P. A-31
183A0000	Non-volatile Memory Data Error	An error of data saved in the non-volatile memory was detected.	Power interruption or noise occurred while parameters other than the safety were saved     Power interruption or noise occurred while the motor identity information was saved     Power interruption or noise occurred while safety parameters were saved	√			P. A-31
246D0000	Motor Non-conformity	The Servo Drive and motor combination is not correct.	The Servo Drive and motor combination is not correct	<b>V</b>			P. A-32
28080000	Main Circuit Power Supply Phase Loss Error	The phase loss of the main circuit power supply was detected	<ul> <li>Incorrect wiring, for example the single-phase power supply is input to a 3-phase input type Servo Drive</li> <li>In the case where the single-phase power supply is input to a single- and 3-phase input type Servo Drive, the phase loss detection is enabled.</li> <li>The power supply voltage is low or insufficient</li> <li>Broken wiring of the main circuit power supply input</li> <li>Servo Drive failure</li> </ul>	<b>V</b>			P. A-33
280D0000	Runaway Detected*2	The motor rotated in the direction opposite to the command.	<ul> <li>There is incorrect wiring of the motor cable or a broken cable.</li> <li>The motor rotated in the direction opposite to the command by external forces.</li> </ul>	<b>V</b>			P. A-34
357D0000	DC Setting Error	A mistake was made in the DC Mode operation setting.	A mistake was made in the DC Mode operation setting	√			P. A-35

_				ı	_eve	ı	
Event code (hex)	Event name	Description	Assumed cause	Min	sqo	lufo	Refer- ence
357E0000	Synchronization Cycle Setting Error	When the DC mode was established, the cycle time was set to the inoperable value.	The variable PDO mapping is used, and the number of objects is more than the maximum number of mapped objects for the cycle time The cycle time setting is incorrect	<b>√</b>			P. A-35
357F0000	Mailbox Setting Error	An incorrect mailbox setting of Sync Manager was detected.	An incorrect mailbox set- ting of Sync Manager was detected	<b>V</b>			P. A-36
35800000	RxPDO Setting Error	An RxPDO setting error was detected.	The RxPDO setting of EtherCAT master is incorrect Servo Drive failure	<b>V</b>			P. A-36
35810000	TxPDO Setting Error	A TxPDO setting error was detected.	The TxPDO setting of EtherCAT master is incorrect Servo Drive failure	1			P. A-37
35820000	RxPDO Mapping Error	An incorrect RxPDO was set.	An incorrect RxPDO was set, such as out of the allowable range of Index, Subindex, or size	1			P. A-37
35830000	TxPDO Mapping Error	An incorrect TxPDO was set.	An incorrect RxPDO was set, such as out of the allowable range of Index, Subindex, or size	1			P. A-38
35840000	PDO WDT Setting Error	An incorrect PDO WDT setting was detected.	An incorrect PDO WDT set- ting was detected	1			P. A-38
35850000	Node Address Updated	The node address is changed to a value of the ID switches.	The node address is changed from a set value in Sysmac Studio to a value of the ID switches	√			P. A-39
35860000	SM Event Mode Set- ting Error	The unsupported SM Event Mode was set.	The unsupported SM Event Mode was set	<b>V</b>			P. A-39
38570000	Function Setting Error	The function that was set does not support the communications period.	<ul> <li>The electronic gear ratio was not 1:1 when the communications period was set to 125 µs.</li> <li>The Backlash Compensation was enabled when the communications period was set to 125 µs.</li> </ul>	<b>√</b>			P. A-40
38780000	General Input Allo- cation Duplicate Error	More than one function input is allocated to one general input.	More than one function input is allocated to one general input	<b>V</b>			P. A-41
38790000	General Output Allo- cation Duplicate Error	More than one function output is allocated to one general output.	More than one function out- put is allocated to one gen- eral output	<b>V</b>			P. A-41
387B0000	Pulse Output Setting Error	The dividing numerator exceeded the dividing denominator when the Encoder Dividing Pulse Output - Dividing Denominator was set to a value other than 0.	The dividing numerator exceeded the dividing denominator when the Encoder Dividing Pulse Output - Dividing Denominator was set to a value other than 0	<b>V</b>			P. A-42

Event code				I	Leve	el	Refer-
(hex)	Event name	Description	Assumed cause	Min	Obs	Info	ence
387C0000	Motor Replacement Detected	The connected motor is dif- ferent from the motor that was connected the last time.	The motor was replaced The Servo Drive was replaced	<b>V</b>			P. A-42
387F0000	Electronic Gear Setting Error	The electronic gear ratio exceeded the allowable range.	The electronic gear ratio exceeded the allowable range	1			P. A-43
38800000	Servo Drive Over- heat	The internal temperature of Servo Drive exceeded the circuit protection level.	The ambient temperature of the Servo Drive exceeded the specified value  Overload	√			P. A-43
38810000	Overload Error	The Load Ratio of Servo Drive or motor (4150-81 hex) exceeded 100%.	<ul> <li>Operation was continued for a long time with high load</li> <li>There is incorrect wiring of the motor cable or a broken cable</li> <li>Increase in friction</li> </ul>	1			P. A-44
38820000	Regeneration Overload Error	The Regeneration Load Ratio (4310-81 hex) exceeded the regeneration overload ratio.	The regeneration processing is set inappropriately The Regeneration Resistor is selected inappropriately The Regeneration Resistor is used for continuous regenerative braking The applied power supply voltage is higher than the specified value Regeneration Resistor failure	1			P. A-45
38830000	Excessive Position Deviation Error	The position deviation is greater than or equal to the value set in the Following error window.	The motor operation does not follow the command The value of Following error window is small	1			P. A-46
3884 0000	Excessive Speed Deviation Error	The speed deviation is greater than or equal to the value set in the Excessive Velocity Deviation Detection Level.	The motor operation does not follow the command because a parameter value is inappropriate The output axis of motor is limited on the operation by external forces The value of the Excessive Velocity Deviation Detection Level is inappropriate	<b>√</b>			P. A-47
38850000	Excessive Speed Error	The feedback motor speed is greater than or equal to the value set in the Excessive Speed Detection Level.	The velocity command value is too large  Overshooting occurred  The motor was rotated by external forces	<b>V</b>			P. A-48

Event code				L	_eve	l	Refer-
(hex)	Event name	Description	Assumed cause	Min	Obs	Info	ence
38860000	Following Error Counter Overflow	The following error value exceeded the range from -2147483648 to 2147483647.	The motor operation does not follow the command The motor is rotated or limited on the operation by external forces	<b>V</b>			P. A-49
38870000	Absolute Encoder Counter Overflow Error	The multi-rotation counter of the encoder exceeded the maximum number of rotations.	An inappropriate value was set in the Encoder - Operation Selection when Using Absolute Encoder (4510-01 hex)     The multi-rotation number of the encoder exceeded the maximum number of rotations	<b>√</b>			P. A-49
38880000	Safety Communications Setting Error	Safety process data communications were not established with the Safety CPU Unit because of an incorrect communications setting.	The watchdog time was set incorrectly The processing was not completed within the watchdog time because communications were not established due to the noise	<b>V</b>			P. A-50
38890000	Safety Frame Error	Safety process data communications were not established with the Safety CPU Unit because an incorrect frame was received.	An incorrect frame was received in safety process data communications     There is excessive noise	√			P. A-51
388A0000	Safety Parameter Error	Safety process data com- munications were not estab- lished with the Safety CPU Unit because an incorrect parameter was received.	The set safety slave model is incorrect	<b>V</b>			P. A-51
388B0000	FSoE Slave Address Error	Safety process data com- munications were not estab- lished with the Safety CPU Unit because of an incorrect FSoE slave address.	The setting of the FSoE slave address in the safety process data communications settings is different from the setting in the Unit	<b>V</b>			P. A-52
48080000	FPGA WDT Error	An FPGA error was detected.	False detection due to a data read error that was caused by excessive noise     Hardware failure	1			P. A-52
64E30000	Drive Prohibition Input Error	Both the Positive Drive Prohibition (POT) and the Negative Drive Prohibition Input (NOT) turned ON.	An error occurred on the switch, wire, power supply, and wiring that were connected to the Positive Drive Prohibition (POT) or Negative Drive Prohibition Input (NOT)     False detection occurred because the control signal power supply was turned ON slowly	<b>V</b>			P. A-53

Front sods				I	Leve	el	Defer
Event code (hex)	Event name	Description	Assumed cause	Min	ops	Info	Refer- ence
68200000	Drive Prohibition Detected	The operation was stopped according to the user setting because the motor ran in the prohibited direction when the Drive Prohibition was enabled.	Incorrect or broken wiring of Positive Drive Prohibition Input (POT) or Negative Drive Prohibition Input (NOT)     Incorrect setting of the Drive Prohibition Input	<b>V</b>			P. A-54
68210000	Control Right Release Error	Communications between the Sysmac Studio and Servo Drive were inter- rupted while a specific func- tion was used from the Sysmac Studio.	The USB cable or EtherCAT cable was disconnected during the connection with the Sysmac Studio There is excessive noise A command sent from the Sysmac Studio was not sent to the Servo Drive because the computer was in a busy state or the like	√			P. A-55
68220000	Error Stop Input	The Error Stop Input (ESTP) is active.	The Error Stop Input (ESTP) was input The Error Stop Input (ESTP) is incorrectly wired	<b>V</b>			P. A-56
68230000	Software Limit Exceeded	The Position actual value detected the position that exceeded the value set in the Software Position Limit, and stopped the operation according to the user setting.	Incorrect setting of Software Position Limit     When the Software Position Limit - Stop Selection was set to Stop according to the setting of Fault reaction option code, the position exceeded the value set in the Software Position Limit	√			P. A-56
78200000	Pulse Output Over- speed Error	The speed, which exceeded the frequency that could be output by the Encoder Dividing Pulse Output function, was detected.	The dividing ratio setting is inappropriate for the actual usage condition	<b>V</b>			P. A-57
78210000	Brake Interlock Error	The Brake Interlock Output (BKIR) was output by the Timeout at Servo OFF.	The Brake Interlock Output (BKIR) was output because the motor rotation speed did not decrease to or less than the speed set in the Threshold Speed at Servo OFF within the time set in the Timeout at Servo OFF when Servo OFF was performed during the motor operation	<b>√</b>			P. A-57

Event code				ı	_eve	I	Refer-
(hex)	Event name	Description	Assumed cause	Min	sqo	Info	ence
78230000	Command Error	A mistake was made in using a command.	<ul> <li>When bit 9 (Remote) of the Statusword was set to 1 (remote), and the Servo Drive was in Operation enabled state (Servo ON), the Servo Drive received a command to change the communications state from Operational to another state (Init, Pre-Operational, or Safe-Operational)</li> <li>A mode of operation other than the hm mode was set during the homing operation</li> <li>Modes of operation was set to pp, pv or hm mode when the communications period was set to shorter than 250 µs</li> </ul>	<b>V</b>			P. A-58
84B10000	EtherCAT State Change Error	A communications state change command was received for which the current communications state could not be changed.	A communications state change command was received for which the cur- rent communications state could not be changed	<b>V</b>			P. A-59
84B20000	EtherCAT Illegal State Change Error	An undefined communications state change command was received.	An undefined communica- tions state change com- mand was received	<b>V</b>			P. A-59
84B40000	Synchronization Error	A signal for synchronous communications could not be detected.	Noise     Error of the EtherCAT slave communications controller	1			P. A-60
84B50000	Sync Manager WDT Error	PDO communications were interrupted for the allowable period or longer.	An EtherCAT communications cable is disconnected, loose, or broken     Host controller error	1			P. A-60
84B60000	ESC Initialization Error	The initialization of Ether-CAT slave communications controller failed.	Data was incorrectly over- written in the non-volatile memory of the EtherCAT slave communications con- troller     Failure of the EtherCAT slave communications con- troller	<b>V</b>			P. A-61
84B70000	SII Verification Error	An error occurred in SII data of the EtherCAT slave communications controller.	Data was incorrectly overwritten in the non-volatile memory of the EtherCAT slave communications controller     Failure of the EtherCAT slave communications controller or false detection	<b>V</b>			P. A-61

Event code	code				Leve	el	Refer-
(hex)	Event name	Description	Assumed cause	Min	sqo	Info	ence
84B90000	Synchronization Interruption Error	Synchronization interruption did not occur within the specified period.	<ul> <li>Incorrect EtherCAT synchronization setting of the host controller</li> <li>Failure of the EtherCAT slave communications controller or false detection</li> </ul>				P. A-62
84BA0000	Bootstrap State Transition Request Error	The state transition to unsupported Bootstrap was requested.	The EtherCAT master requested the transition of unsupported Bootstrap	1			P. A-62
88100000	Communications Synchronization Error	Communications were not established consecutively because the synchronization with the EtherCAT Master could not be achieved.	The power supply to the host controller was interrupted during PDO communications  An EtherCAT communications cable is disconnected, loose, broken, or has a contact failure  Noise	<b>√</b>			P. A-63
88120000	Safety Communications Timeout	A communications timeout occurred in safety process data communications with the Safety CPU Unit.	<ul> <li>A setting is not correct. The setting of the safety task period of the Safety CPU Unit is too short</li> <li>There is excessive noise</li> <li>The Safety CPU Unit or safety slave entered a status where it could not continue safety process data</li> </ul>				P. A-64
98200000	Absolute Value Cleared	The multi-rotation counter of the absolute encoder was cleared.	The multi-rotation counter of the absolute encoder was cleared	<b>V</b>			P. A-64
081C0000	Capacitor Lifetime Warning	The capacitor built into the Servo Drive reached the service life.	The operating time of the capacitor in the Servo Drive exceeded the service life		<b>V</b>		P. A-65
081D0000	Inrush Current Prevention Relay Lifetime Warning	The inrush current prevention relay built into the Servo Drive reached the service life.	The number of operating times of the inrush current prevention relay in the Servo Drive exceeded the service life		1		P. A-65
081F0000	Brake Interlock Out- put Relay Lifetime Warning	The brake interlock output (BKIR) relay built into the Servo Drive reached the service life.	The number of operating times of the brake interlock output in the Servo Drive exceeded the service life		1		P. A-66
083A0000	Encoder Communications Warning	Encoder communications errors occurred in series more frequently than the specified value.	<ul> <li>Noise into the encoder cable</li> <li>Contact failure of the encoder cable</li> <li>Power supply undervoltage to the encoder</li> </ul>		<b>V</b>		P. A-67
08470000	Encoder Lifetime Warning	The encoder lifetime is close to the end.	<ul><li>Temporary noise</li><li>The end of the encoder life</li></ul>		1		P. A-68

Event code				l	_eve	I	Refer-
(hex)	Event name	Description	Assumed cause	Min	ops	Info	ence
084C0000	Fan Rotation Warning	The rotation speed of the fan is 80% or less of the rating and the cooling performance decreases.	<ul> <li>There is a foreign matter in the cooling fan and it blocks the rotation</li> <li>Cooling fan failure</li> </ul>		<b>V</b>		P. A-68
084E0000	Absolute Encoder Counter Overflow Warning	The multi-rotation counter of the encoder exceeded the value set in Encoder - Absolute Encoder Counter Overflow Warning Level (4510-02 hex).	An inappropriate value was set in the Encoder - Operation Selection when Using Absolute Encoder (4510-01 hex)     The multi-rotation number of the encoder exceeded the warning level		<b>V</b>		P. A-69
18390000	Lifetime Information Corruption Warning	An error was detected in the saved lifetime information.	The lifetime information cor- ruption was detected when the power supply was turned ON		1		P. A-70
34E00000	Data Setting Warn- ing	The object set value is out of the range.	The object set value is out of the range		<b>V</b>		P. A-70
387A0000	Overload Warning	The Load Ratio of Servo Drive or motor (4150-81 hex) exceeded the level set in Overload - Warning Notification Level (4150-01 hex).	<ul> <li>Operation was continued for a long time with high load.</li> <li>There is incorrect wiring of the motor cable or a broken cable</li> <li>Increase in friction</li> </ul>		<b>V</b>		P. A-71
387D0000	Regeneration Overload Warning	The Regeneration Load Ratio (4150-81 hex) exceeded 85%.	The regeneration processing is set inappropriately The Regeneration Resistor is selected inappropriately The Regeneration Resistor is used for continuous regenerative braking The applied power supply voltage is higher than the specified value Regeneration Resistor failure		V		P. A-72
387E0000	Motor Vibration Warning	The motor vibration, which was higher than or equal to the level set in the Vibration Detection - Detection Level (3B70-01 hex), was detected.	The control parameter is set inappropriately The rigidity decreased due to mechanical looseness or wear		1		P. A-73

Event code				Level		el	Refer-
(hex)	Event name	Description	Assumed cause	Min	sqo	Info	ence
78220000	Command Warning	A command could not be executed.	The Switch ON command was received The Enable operation command was received An operation command in the prohibition direction was received after the immediate stop by the Drive Prohibition Input or Software Position Limit Homing started The positioning start command was received in the Profile position mode		V		P. A-74
84B00000	EtherCAT Communications Warning	An EtherCAT communications error occurred more than one time.	An EtherCAT communications cable has a contact failure, or is connected incorrectly or broken     Noise		1		P. A-75
90A00000	Unit Restarted	Restart was performed.	Restart was performed			$\sqrt{}$	P. A-75
98210000	STO Detected	The safety input OFF state was detected via the safety input signal or EtherCAT communications.	The cable is disconnected or broken  The STO input was turned OFF via EtherCAT communications			√	P. A-76
98220000	Memory All Cleared	The Unit setting was cleared.	Clear All Memory was per- formed			1	P. A-76
98240000	Event Log Cleared	The event log was cleared.	Clear Event Log was per- formed			<b>V</b>	P. A-77

<sup>\*1.</sup> This error can occur in the unit version 1.2 or later.

<sup>\*2.</sup> This error can occur in the unit version 1.1 or later.

### A-1-2 Error Descriptions

This section describes errors.

### **Error Table**

The items that are used to describe individual errors (events) are described in the following copy of an error table.

Event name	Gives the name	of the error (even	t).	Event code	Gives the code or	f the error (event).	
Description	Gives a short de	escription of the er	ror (event).				
Source	Gives the source (event).	e of the error	Source details	Gives details on the source of the error.	Detection timing	Tells when the error is detected.	
Error attributes	Level	Tells the influence on control.*1	Recovery	Gives the recovery method.*2	Log category  Tells which log the error is saved in.		
Effects	User program	Tells what will happen to execution of the user program.*3	Operation	Provides special results from the e	information on the rror (event).	operation that	
	EtherCAT NET		EtherCAT NET E	RR	EtherCAT LINK/	ACT	
Indicators			•	ouilt-in EtherCAT pon n Module and the E			
System	Variable		Data type	Name			
-defined variables		• •	_	for system-defined that contain setting	-		
Cause and	Assumed caus	e	Correction		Prevention		
correction	Lists the possib	le causes, correcti	ons, and preventiv	e measures for the	error (event).		
Attached information	Provides the ad	Provides the additional information that is displayed by the Sysmac Studio or an NS-series PT.					
Precautions/ Remarks	Provides precau	utions, restrictions,	and supplemental	information.			

<sup>\*1.</sup> One of the following:

Minor fault: Minor fault level

Observation

Information

#### \*2. One of the following:

Automatic recovery: Normal status is restored automatically when the cause of the error is removed.

Error reset: Normal status is restored when the error is reset after necessary measures are taken.

Cycle the power supply: Normal status is restored when the power supply is turned OFF and then back ON after necessary measures are taken.

Replace the Servo Drive: Normal status is restored when the Servo Drive is replaced with a new one.

\*3. "Continues." indicates that execution of the user program will continue.

## **Error Descriptions**

Event name	Regeneration Circuit Error Detected during Po			Event code	04B30000 hex*1		
Meaning	An error of the F	Regeneration Circ	uit was detected at	power ON.			
Source	EtherCAT Maste	therCAT Master Function Mod- le		Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	rCAT NET ERR		ACT	
muicators							
System	Variable Da		Data type		Name		
-defined variables	None None		None		None		

	Assumed cause	Correction	Prevention
	Power supply voltage is insuffi-	Cut off the main circuit power sup-	If you are using the External
	cient at power ON, or rising slowly.  • Power supply voltage fluctuated at power ON.	ply immediately and check whether charge lamp is turned ON/OFF.	Regeneration Resistor, make sure that an appropriate resistance value is set and that it is a resistor for the electric power.
Cause and correction	<ul> <li>L1, L2, and L3 terminals are not connected or disconnected.</li> <li>N1 and N2 terminals are opened.</li> </ul>	<ul> <li>If the charge lamp is turned OFF, remove the wiring and make the following check.</li> <li>Check whether there is an abnormality in the appearence of the Servo Drive, and that the wiring is properly done.</li> <li>Check that the resistance value and the power of the External Regeneration Resistor is correct.</li> <li>Wait until the voltage between P and N1 goes to less than 1 V to check the resistance value between P and N1. (If it is less than 10 kΩ, replace the Servo Drive.)</li> <li>Wait until the voltage get stable to check the resistance value between B2 and N1. (If it is less than 100 kΩ, replace the Servo Drive.)</li> <li>Check whether fluctuation in the power supply voltage or power supply occurs or not. (Make sure that an instantaneous power drop does not occur, and that the power supply voltage or power supply occurs or not. (Make sure that an instantaneous power drop does not occur, and that the power supply voltage or power supply occurs or not. (Make sure that an instantaneous power drop does not occur, and that the power supply occurs or not. (Make sure that an instantaneous power drop does not occur, and that the power supply occurs or not. (Make sure that an instantaneous power drop does not occur, and that the power</li> </ul>	<ul> <li>Increase the power supply capacity to improve the power environment.</li> <li>Separate the Servo Drive and cables from the noise source, or install other devices separately with the power line of the Servo Drive so that the surge voltage that is too large is not imposed.</li> <li>Power rise time must be 500 ms or shorter.</li> <li>Check that the wiring for the following terminals is properly done: L1, L2, L3, N1, N2, N3, B1, B2, B3, and P.</li> </ul>
	Servo Drive failure	rise time is 500 ms or shorter.)  If this event occurs again after you performed all corrections shown	None
		above, replace the Servo Drive.	
Attached information	Attached information 1: System in		
Precautions/ Remarks	AL status code: -, Error No.: 1402	hex	
*1. This error ca	an occur in the unit version 1.2 or la	iter.	

<sup>\*1.</sup> This error can occur in the unit version 1.2 or later.

Event name	ESC Error			Event code	0543 0000 hex			
Meaning	An error occurre	An error occurred in the EtherCAT slave communications controller.						
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	At power ON		
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log		
Effects	User program	Continues.	Operation	Power drive circu	it is OFF			
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	/ACT		
indicators								
System	Variable		Data type		Name			
-defined variables	None None			None				
			Correction		Prevention			
Cause and correction			If this event occu after you cycled t the EtherCAT sla tions controller is the Servo Drive. Please contact th of EtherCAT mas	he power supply, ve communica-faulty. Replace	None			
Attached information Precautions/	None  AL status code:	0050 hex or 0051	hex, Error No.: 88	04 hex				

Event name	Power Module B	Error		Event code	08390000 hex		
Description	An error was de	tected in the powe	er module.				
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET RUN		EtherCAT NET E	RR	EtherCAT LINK/	ACT	
indicators							
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed caus	e	Correction		Prevention		
	There is a short fault, or contact V, or W motor c	failure on the U,	Correct the conne or W motor cable	- , ,   -		nfirm that the motor cables are broken and connect them corly.	
Cause and correction	ing of External F	-circuit on the wir- Regeneration resistance value	ing of External Re	is a short-circuit on the wir- xternal Regeneration r, correct the wiring.  Wire the External Regeneration Resistor correctly when Use the recommended Regeneration Resistor. tance value of the External Regeneration Resistor. tance value of the External Regeneration Resistor.		y when using it. ended External esistor. If a resis- e External Regen- is small,	
	The insulation rebetween the U, cable and the m		Replace the motor.		Confirm that the insulation resistance is insulated between the U, V, and W motor cable and the motor ground wire before using the motor.		
	Servo Drive faile	ure	If this event occurs again after you performed all corrections shown above, replace the Servo Drive.		Do not perform Servo ON/OFF frequently. Doing so may cause a Servo Drive failure.		
Attached information		ation 1: System in					
Precautions/ Remarks	AL status code:	-, Error No.: 1401	hex				

Event name	Self-diagnosis E	rror		Event code	083B 0000 hex		
Description	An error was de	tected by the self-	-diagnosis of the sa	fety function.			
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	•	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
mulcators							
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed cause		Correction		Prevention		
Cause and	False detection read error that vexcessive noise	vas caused by	If this event does not occur after you cycled the power supply, use the product continuously. It is sup-		If the normal operation can restar after you cycled the power supply consider noise countermeasures.		
correction	Hardware failure		posed that a temporary error occurred due to a read error. If this event occurs again, replace the Servo Drive.				
Attached information	Attached information 1: System information						
Precautions/ Remarks	AL status code:	-, Error No.: 3502	hex				

Event name	Main Circuit Temperature Monitoring Circuit Failure			Event code	083C 0000 hex	
Description	A temperature n	nonitoring circuit fa	t.	_		
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	
Indicators	EtherCAT NET RUN		EtherCAT NET E	RR	EtherCAT LINK/	ACT
illuicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed caus	e	Correction		Prevention	
Cause and	Broken wiring o	f the thermistor,	If this event occu	rs repeatedly	None	
correction	temperature mo	nitoring circuit	after you cycled t			
	failure		replace the Servo Drive.			
Attached	None					
information						
Precautions/	AL status code:	-, Error No.: 5800	hex			
Remarks						

Event name	Fan Error			Event code	083D0000 hex		
Description	The rotation spe	The rotation speed of the fan is 40% or less of the rating and the cooling performance decreases.					
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error nattributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	iit is OFF		
Indicators	EtherCAT NET RUN		EtherCAT NET E	RR	EtherCAT LINK/	ACT	
illuicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed caus	е	Correction		Prevention		
	There is a foreig		Check whether there is a foreign		Do not use the fan in an area sur-		
Cause and	cooling fan and it blocks the rota-		matter in the fan. If you find a for-		rounded by excessive foreign mat-		
correction	tion		eign matter, remove it.		ter. Also, do not allow foreign		
	Cooling fan failure		If there is no improvement after		objects to enter.		
				e correction			
			above, replace th	e Servo Drive.			
Attached	None						
information							
Precautions/	AL status code:	-, Error No.: 5900	hex				
Remarks							

Event name	Regeneration P	rocessing Error		Event code	083F0000 hex		
Description	The regeneration	n processing was	stopped to protect	the Regeneration	Resistor.		
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program		<b>Operation</b> Power drive circu		uit is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	ACT	
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed caus	e	Correction		Prevention		
	The regeneration set inappropriat		Check the regen- ing setting, and s as the resistance Regeneration Re	et the same value value of the		given for correc- and take counter- puired.	
	The Regeneration Resistor is selected inappropriately		Check the operation pattern by the velocity monitor. Check the load ratio of Regeneration Resistor, and perform the following corrections accordingly.  Increase the deceleration time and stopping time.				
Cause and correction			<ul> <li>Decrease the ofto the motor.</li> <li>Use an Externation Resistor.</li> <li>Increase the care</li> </ul>	Use an External Regeneration			
			Servo Drive and the motor.				
	The Regenerati used for continutive braking	ious regenera-	_	The Regeneration Resistor can- not be used for continuous regen- erative braking.		Regeneration inuous regenera-	
	The applied pov age is higher the value		Apply the specific voltage.	Apply the specified power supply		tive braking.  Review the power supply voltage to be the specified value before use.	
	Regeneration Resistor failure		Check whether the Regeneration Resistor is faulty, and use one without failures.		Confirm that the Resistor is not fa	-	
Attached information	None						
Precautions/ Remarks	AL status code:	-, Error No.: 1802	AL status code: -, Error No.: 1802 hex				

Event name	Overvoltage Err	or		Event code	08410000 hex		
Meaning	The main circuit	power supply volt	age (P-N voltage)	exceeded the oper	ration guarantee ra	ange.	
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circuit is OFF			
Indicators	EtherCAT NET RUN		EtherCAT NET E	RR	EtherCAT LINK/	ACT	
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed caus	e	Correction		Prevention		
	The P-N voltage exceeded the specified value		Input the correct voltage.		Input the correct voltage.		
	The input voltag	The input voltage increased		Use appropriately external devices such as UPS.		y external devices	
	The Regenerati	on Resistor wir-	If a resistance val		Check a resistan external resistor.	ce value of the	
	ing is broken	ing is broken		resistor is infinite between the ter- minal B1 and B2 of the Servo			
			Drive, the wiring is broken. Replace the external resistor.				
Cause and							
correction		The External Regeneration		Confirm the necessary regenera-		Select an External Regeneration	
	Resistor is set of	or selected inap-	tion processing capacity, and con-			culating the nec-	
	propriately	propriately		nect an appropriate External		ion processing	
			Regeneration Resistor. Also, set		capacity because		
			the parameters of the External		operation patterns or the like. Also,		
			Regeneration Resistor to the resistance value of the External Regen-		set the parameter correctly when using the External Regeneration		
			eration Resistor i		Resistor.	ar regeneration	
	Servo Drive fail	ure	If this event occur		None		
			performed all cor	performed all corrections shown			
				e Servo Drive.			
Attached information	None						
Precautions/	AL status code:	-, Error No.: 1200	hex				
Remarks							

Event name	Motor Overheat	Error		Event code	08420000 hex		
Description	The encoder de	tected the temper	ature that exceede	d the protection lev	el of motor.		
Source	EtherCAT Master Function Module		Source details	Source details Slave		Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
indicators							
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed cause		Correction		Prevention		
Cause and	The temperature the motor	The temperature is high around the motor		Adjust the temperature around the motor to be within the range of the operating temperature.		Adjust the ambient temperature to be within the range of the operating temperature before using the motor.	
correction	The motor is overloaded		Adjust the motor load ratio to be within the specified range.		Adjust the operation before use, so that the motor load ratio does not become high for a long time.		
	Encoder failure		Replace the motor if this event occurs repeatedly.		None		
Attached information	None						
Precautions/ Remarks	AL status code: -, Error No.: 1501 hex						

Event name	1-rotation Counter Error			Event code	0843 0000 hex	
Description	The encoder de	tected a one-rotati	on counter error.			_
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log
Effects I	User program	Continues.	Operation	Power drive circu	it is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT
System	Variable		Data type		Name	
	None		None		None	
variables						
1	Assumed cause		Correction		Prevention	
-	There is excessi	ive noise	Take noise countermeasures. If		Take noise countermeasures.	
Cause and	Failure due to vi	bration, impact,	this event occurs	after you per-	Do not use the pr	oduct in an area
correction	condensation, fo	oreign matter, etc.	formed noise cou	ntermeasures,	surrounded by ex	cessive foreign
			the motor is faulty. Replace the		matter. Also, do not allow foreign	
			motor.		matter to enter.	
Attached	Attached information	ation 1: System int	formation			
information						
Precautions/	AL status code:	-, Error No.: 4400	hex			
Remarks						

Event name	Overspeed Erro	r		Event code	08440000 hex		
Meaning	The encoder de	tected the overspe	eed.		•		
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
maicators							
System	Variable	Variable		Data type		Name	
-defined	None		None		None		
variables							
	Assumed cause		Correction		Prevention		
	The motor is rotated by external		Take countermeasures so that the		Take countermeasures so that the		
Cause and	forces		motor is not subjected to external		motor is not rotated by external forces.		
correction			forces if the motor is rotated by external forces.		loices.		
Correction	Encoder failure	and false detec-		rs repeatedly, the	None		
	tion		encoder is faulty. Replace the		T T T T T T T T T T T T T T T T T T T		
			motor.				
Attached	None		1		1		
information							
Precautions/	AL status code:	-, Error No.: 4700	hex				
Remarks							

Event name	Encoder Memory Error			Event code	08450000 hex		
Description		tected a non-volat	ile memory error.				
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circ	uit is OFF		
Indicators	EtherCAT NET RUN		EtherCAT NET E	EtherCAT NET ERR		EtherCAT LINK/ACT	
muicators							
System	Variable		Data type	Data type			
-defined	None		None		None		
variables							
	Assumed caus	Assumed cause		Correction		Prevention	
Cause and	False detection	due to a data	If this event occurs after you		None		
correction	read error that v	vas caused by	cycled the power supply, the				
Correction	excessive noise	:	encoder is faulty. Replace the				
	Non-volatile me	mory failure	motor.				
Attached	None						
information							
Precautions/	AL status code:	-, Error No.: 4301	hex	_			
Remarks							

Event name	Absolute Position	Absolute Position Detection Error			0846 0000 hex		
Description	The encoder de	tected a multi-rota	tion counter error.		•		
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	/ACT	
mulcators							
System	Variable		Data type		Name		
-defined variables	None	one None			None Prevention		
	Assumed cause		Correction	Correction			
	A detection erro	A detection error was detected in		Perform the Absolute Encoder			
	the multi-rotation	n detection sec-	Setup after cycling the power sup-				
Cause and correction	tion of the encoder		ply, and update the multi-rotation number.				
	There is excessive noise		Take noise countermeasures. Replace the motor if this event		Take noise countermeasures.		
			occurs repeatedly.				
Attached	None						
information							
Precautions/	AL status code:	-, Error No.: 4501	hex				
Remarks	L States Sous. , Ellot Hot. 1001 Hox						

Event name	Main Power Sup	oply Undervoltage and N)	(insufficient volt-	Event code	0848 0000 hex	
Meaning		,	tage fell below the	operation guarante	ee range during Se	ervo ON.
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	During Servo ON
Error attributes	Level	Minor fault	Recovery	slave errors)		System log
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET I	RR	EtherCAT LINK/	ACT
ilidicators						
System	Variable		Data type		Name	
-defined variables	None		None	* -		
	Assumed cause		Correction		Prevention	
	Incorrect wiring of the main circuit power supply		If the power supply cables are not wired to the main circuit power supply terminals (L1, L2, L3), connect them.		Check the wiring of the main circuit power supply before use.	
Cause and		The low power supply voltage is applied to the Servo Drive		Increase the power supply capacity if it is small. Measure the applied power supply voltage, and apply the voltage according to the specification.		e appropriate for
correction	tary Hold Time a	The long time was set in Momentary Hold Time and the voltage was decreased momentarily		Remove the cause that momentarily decreased the voltage.  Set a short time in the Momentary Hold Time so as not to detect this error due to a momentary		te value in the Time.
	Servo Drive failu	Servo Drive failure		decrease in voltage.  If this event occurs again after you performed all corrections shown above, replace the Servo Drive.		
Attached information	None					
Precautions/ Remarks	AL status code:	-, Error No.: 1300	hex			

Event name	Overcurrent Error		Event code		0849 0000 hex		
Meaning	The current flow	ving to the motor e	xceeded the prote	ction level.			
Source	EtherCAT Maste	er Function Mod-	Source details	Source details Slave		During Servo ON	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	(after cycling Log category		
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	•	
Indicators	EtherCAT NET	RUN	EtherCAT NET I	RR	EtherCAT LINK	/ACT	
ilidicators							
System	Variable		Data type		Name		
-defined variables	None	e None		None			
	Assumed cause		Correction		Prevention		
	There is a short-circuit, ground fault, or contact failure on the U, V, or W motor cable		Correct the connection of the U, V, or W motor cable.		Confirm that the motor cables are not broken and connect them correctly.		
	There is a short-circuit on the wiring of External Regeneration Resistor		Correct the wiring of External Regeneration Resistor.		Wire the External Regeneration Resistor correctly when using it.		
Cause and correction	The insulation resistance failed between the U, V, or W motor cable and the motor ground wire		Replace the motor	Replace the motor.		Confirm that the insulation resistance is insulated between the U, V, and W motor cable and the motor ground wire before connecting and using the motor.	
	False detection	False detection due to the noise		Take noise countermeasures.		Take noise countermeasures because excessive noise may cause false detection.	
	Servo Drive failure		If this event occurs again after you performed all corrections shown above, replace the Servo Drive.		Do not perform Servo ON/OFF frequently. Doing so may cause a Servo Drive failure.		
Attached information	None						
Precautions/ Remarks	AL status code:	AL status code: -, Error No.: 1400 hex					

Event name	Encoder Comm	unications Disconi	nection Error	Event code	084A0000 hex	
Description	The communication	tions disconnection	n was detected be	tween the encode	and the Servo Drive.	
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously
Error attributes	Level Minor fault		Recovery	Error reset (after cycling slave power)	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT
ilidicators						
System	Variable		Data type		Name	
-defined variables	None		None		None	
	Assumed cause		Correction		Prevention	
	Noise into the encoder cable		the encoder ca bundled togeth • Connect the sh • Check that the	<ul> <li>Separate the motor cable and the encoder cable if they are bundled together.</li> <li>Connect the shield to FG.</li> <li>Check that the motor ground wire is connected to FG.</li> </ul>		notor cable and ble if they are er. nield to FG. motor ground ed to FG.
Cause and	Contact failure	of the signal line,	Replace the enco	der cable if it is	Confirm that the encoder is not	
correction	and disconnection of the encoder		broken. Firmly connect the encoder connector to the Servo Drive.		broken before use, and connect the encoder connector to the Servo Drive securely.	
	Power supply until the encoder	ndervoltage to	Use the recomme cable.	ended encoder	Use the recommended encoder cable.	
	Encoder failure		If this event occurs again after you performed all corrections shown above, replace the motor.		None	
Attached information	None				1	
Precautions/ Remarks	AL status code:	-, Error No.: 2100	hex			

Event name	Encoder Communications Error			Event code	084B 0000 hex	
Description	Illegal data was	received from the	encoder the speci	fied number of tim	nes.	
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously
Error attributes	Level Minor fault		Recovery	Error reset (after cycling slave power)	Log category	System log
Effects	User program	Continues.	Operation	Power drive circ	uit is OFF	
Indicators	EtherCAT NET	EtherCAT NET RUN		RR	EtherCAT LINK	ACT
indicators						
System	Variable		Data type		Name	
-defined variables	None	None		None		
	Assumed caus	е	Correction		Prevention	
	Noise into the encoder cable		<ul> <li>Separate the motor cable and the encoder cable if they are bundled together.</li> <li>Connect the shield to FG.</li> </ul>		<ul> <li>Separate the motor cable and the encoder cable if they are bundled together.</li> <li>Connect the shield to FG.</li> </ul>	
Cause and correction			<ul> <li>Check that the motor ground wire is connected to FG.</li> </ul>		<ul> <li>Confirm that the motor ground wire is connected to FG.</li> </ul>	
Correction	Contact failure of the signal line, and disconnection of the encoder		Replace the encoder cable if it is broken. Firmly connect the encoder connector to the Servo Drive.		Confirm that the encoder is not broken before use, and connect the encoder connector to the Servo Drive securely.	
	Power supply until the encoder	ndervoltage to	Use the recommo	ended encoder	Use the recomm cable.	ended encoder
Attached information	None					
Precautions/ Remarks	AL status code: -, Error No.: 2101 hex					

Event name	Non-volatile Me	mory Hardware Er	ror	Event code	084D0000 hex	
Description	An error occurre	ed on the non-vola	tile memory.	1		
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	At power ON
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT
indicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed caus	е	Correction		Prevention	
	read error that was caused by excessive noise		After you cycled t	the power supply,	None	
Cause and			if this error occur	•		
correction			although the erro			
	Non-volatile me	mory failure	non-volatile memory is faulty.			
			Replace the Servo Drive.			
Attached information	Attached inform	ation 1: System in	formation			
Precautions/	AL status code:	-, Error No.: 3700	hex			
Remarks						
Event name	Absolute Encod	er Multi-rotation C	ounter Error	Event code	18230000 hex	
Meaning	The encoder de	tected a multi-rota	tion counter error.		l	
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously
Бинан		Minor fault		Error reset		System log
Error attributes	Level		Recovery	(after cycling	Log category	
attributes				slave power)		
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT
maicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed caus		Correction		Prevention	
		or occurred in the		continuously if this	-	roduct in an envi-
Cause and		otation detection	event does not occur after improv-		ronment where the temperature	
correction		vibration, impact,	ing the operating	environment.	and vibration res	
	or condensation	1	Replace the motor	or if this event	the specified leve	el.
	Encoder failure		occurs again.			

Attached

Remarks

information Precautions/

None

AL status code: -, Error No.: 4500 hex

Event name	System Error			Event code	1838 0000 hex					
Description	A hardware erro	or due to the self-d	liagnosis and a fata	l software error we	ere detected.					
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	Continuously				
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log				
Effects	User program	Continues.	Operation	Power drive circu	it is OFF					
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT				
illuicators										
System	Variable		Data type	Data type		Name				
-defined variables	None		None		None					
	Assumed caus	Assumed cause			Prevention					
Cause and correction	False detection due to a data read error that was caused by excessive noise  A fatal software error was detected		If this event does not occur after you cycled the power supply, use the product continuously. It is supposed that a temporary error occurred due to a read error.		If the normal operation can restart after you cycled the power supply, consider noise countermeasures. There may be excessive noise around the Servo Drive.					
	Hardware failure		If this event occurs again, a fatal error exists. Replace the Servo Drive.							
Attached information	Attached inform	ation 1: System in	formation							
Precautions/ Remarks	AL status code:	-, Error No.: 3501	hex			AL status code: -, Error No.: 3501 hex				

Event name	Non-volatile Me	mory Data Error		Event code	183A 0000 hex		
Description	An error of data	saved in the non-	volatile memory w	as detected.			
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	At power ON	
Error attributes	Level	Minor fault	Recovery	Recovery Error reset		System log	
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF		
	EtherCAT NET	RUN	EtherCAT NET	RR	EtherCAT LINK	/ACT	
Indicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed caus	е	Correction		Prevention		
	Power interruption or noise		Save data after s	Save data after setting the param-		the power while	
	occurred while parameters other		eter again, and o	ycle the power	the parameter is	saved.	
	than the safety were saved		supply.				
Cause and	Power interrupti		Execute the Motor	• •			
correction	occurred while the motor identity information was saved		cycle the power supply.				
	Power interruption or noise		Clear the FSoE slave address,				
	occurred while safety parameters		execute FSoE Enable Reset, and				
	were saved		cycle the power supply.				
	Attached Inform	ation 1: Cause De	etails				
Attached	1: Data corruption	on of parameters	other than the safe	ty			
information	2: Data corruption	on of the motor ide	entity information				
	3: Data corruption	3: Data corruption of the safety parameters					
Precautions/	AL status code:	-, Error No.: 3600	hex				
Remarks							

Event name	Motor Non-conf	ormity		Event code	246D0000 hex		
Description	The Servo Drive	and motor combi	nation is not correc	ot.			
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	At power ON	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK	ACT	
ilidicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
Cause and	Assumed cause		Correction		Prevention		
correction	The Servo Drive	e and motor com-	Replace the motor with one that		Use a motor that matches the		
CONTOCUON	bination is not correct		matches the Servo Drive.		Servo Drive.		
	Attached Inform	ation 1: Cause De	tails				
Attached	1: Error at a time	e when the capacit	y of the connected	Servomotor does	not conform to the	capacity of Servo	
information	Drive.						
	2: The Servomotor with different operating voltage is connected.						
Precautions/	AL status code:	-, Error No.: 9501	hex				
Remarks							

Event name	Main Circuit Po	wer Supply Phase	Loss Error	Event code	2808 0000 hex	2808 0000 hex	
Description	The phase loss	of the main circuit	power supply was	detected.			
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level Minor fault		Recovery Error reset (after resetting slave errors)		Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET I	RR	EtherCAT LINK	ACT .	
Indicators							
System	Variable		Data type		Name		
-defined variables	None			None			
	Assumed cause		Correction		Prevention		
	Incorrect wiring, for example the single-phase power supply is input to a 3-phase input type Servo Drive		Confirm the Servo Drive specifications, and perform the correct wiring.		Confirm the Servo Drive specifications, and perform the correct wiring.		
Cause and	In the case where the sin- gle-phase power supply is input to a single- and 3-phase input type Servo Drive, the phase loss detection is enabled.		Set Main Circuit Power Supply - Phase Loss Detection Enable (4320-02 hex) to 0 (disabled).		Disable the phase loss detection when you input the single-phase power supply to a single- and 3-phase input type Servo Drive.		
correction	The power supply voltage is low or insufficient		Improve power supply conditions by increasing the power supply capacity or the like.		Improve power supply conditions by increasing the power supply capacity or the like.		
	_	Broken wiring of the main circuit power supply input		Replace the main circuit power supply input cable.		Confirm that the main circuit power supply input cable is not broken before use.	
	Servo Drive failure		If this event occurs again after you performed all corrections shown above, replace the Servo Drive.		None		
Attached information	None				1		
Precautions/ Remarks	AL status code:	-, Error No.: 1301	AL status code: -, Error No.: 1301 hex				

Event name	Runaway Detec	ted		Event code	280D0000 hex*1		
Description	The motor rotate	ed in the direction	opposite to the cor	nmand.			
Source	EtherCAT Maste ule	EtherCAT Master Function Mod- ule		Slave	Detection timing	Continuously	
Error attributes	Level Minor fault		Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	iit is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	ACT	
mulcators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables					_		
	Assumed cause		Correction		Prevention		
	There is incorrect wiring of the			Connect the motor cable as shown		or cable as shown	
	motor cable or a	motor cable or a broken cable.		in the wiring diagram. If the cable		in the wiring diagram. Connect the	
			is broken, replace it.		motor cable and encoder		
			Or, connect the motor cable and encoder cable that are used together to the same motor.		cable/external encoder cable that are used together to the same motor.		
Cause and							
correction							
		ed in the direction		Take countermeasures so that the		asures so that the	
	opposite to the command by		motor is not subjected to external		motor is not rotated by external forces.		
	external forces.	external forces.		forces.			
			_	tection - Enable			
			(3B71-01 hex) to 0 (disabled) when the motor runs as intended.				
Attached	None		when the motor r	uns as miended.			
information	i None						
Precautions/	AL status codo:	-, Error No.: 2000	hov				
Remarks	AL SIAIUS COUE.	-, EITOI NO 2000	HEY				
INCIIIAI NO							

<sup>\*1.</sup> This error can occur in the unit version 1.1 or later.

Event name	DC Setting Erro	r		Event code	357D 0000 hex	
Description	A mistake was r	nade in the DC Mo	ode operation setti	ng.		
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing EtherCAT communications
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF	
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
indicators						
System	Variable		Data type	Data type		
-defined variables	None		None		None	
	Assumed cause		Correction		Prevention	
Cause and correction	A mistake was made in the DC Mode operation setting		Check the DC Mode setting, and then download it to the EtherCAT master again.		Configure the setting of communications to slaves in the EtherCAT master in accordance with ESI data.	
Attached	None				•	
information						
Precautions/ Remarks	AL status code:	0030 hex, Error N	o.: 9003 hex			

Event name	Synchronization	Cycle Setting Erro	or	Event code	357E0000 hex	357E0000 hex	
Description	When the DC m	ode was establish	ed, the cycle time	was set to the inor	oerable value.	_	
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing EtherCAT communications	
Error attributes	Level Minor fault Recove		Recovery	Error reset	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
maicators							
System	Variable		Data type	Data type		Name	
-defined variables	None		None		None		
	Assumed cause		Correction	Correction			
Cause and correction	The variable PDO mapping is used, and the number of objects is more than the maximum number of mapped objects for the cycle time		Set the number of objects to a value smaller than the maximum number of mapped objects for the cycle time.		Confirm the maximum number of mapped objects and the limit on the number of objects before using the variable PDO mapping.		
	The cycle time setting is incorrect		Correct the cycle time setting.		Confirm the EtherCAT slave specifications, and set the cycle time.		
Attached information	None						
Precautions/ Remarks	AL status code:	0035 hex, Error N	o.: 9004 hex				

Event name	Mailbox Setting Error			Event code	357F0000 hex	
Description	An incorrect ma	ilbox setting of Sy	nc Manager was d	etected.		
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing EtherCAT communications
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF	
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
indicators						
System	Variable		None		Name	
-defined variables	None				None	
	Assumed cause		Correction		Prevention	
Cause and correction	Sync Manager was detected		Check the mailbox setting, and then download it to the EtherCAT master again.		Configure the setting of communications to slaves in the EtherCAT master in accordance with ESI data.	
Attached information	None		1		1	
Precautions/ Remarks	AL status code:	0016 hex, Error N	lo.: 9000 hex			

Event name	RxPDO Setting	Error		Event code	3580 0000 hex		
Meaning	, and the second	ng error was dete	cted.				
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing EtherCAT communications	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	ACT	
indicators							
System	Variable	Variable		Data type		Name	
-defined	None	None		None			
variables							
	Assumed cause		Correction		Prevention		
	The RxPDO setting of EtherCAT		Correct the RxPDO setting accord-		Configure the setting of communi-		
	master is incorrect		ing to the definition of ESI of Servo		cations to slaves in the EtherCAT		
Cause and			Drive, and then download it to the EtherCAT master again.		master in accordance with ESI		
correction					data.		
Correction	Servo Drive fail	ure	If this event occurs repeatedly		None		
			after the downloa	after the download to the Ether- CAT master, the Servo Drive is			
			CAT master, the				
			faulty. Replace the Servo Drive.				
	None				_	_	
Attached	INOTIC						
Attached information	None						
7 1111010111010		001D hex, Error N	No.: 9005 hex				

Event name	TxPDO Setting	Error		Event code	3581 0000 hex		
Meaning	A TxPDO setting	g error was detect	ed.		•		
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing EtherCAT communications	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
illuicators							
System	Variable		Data type		Name		
-defined	None	None		None		None	
variables							
	Assumed cause		Correction		Prevention		
	The TxPDO setting of EtherCAT		Correct the TxPDO setting accord-		Configure the setting of communi-		
	master is incorrect		ing to the definition of ESI of Servo		cations to slaves in the EtherCAT		
Cause and			Drive, and then download it to the EtherCAT master again.		master in accordance with ESI		
correction					data.		
	Servo Drive failure		If this event occurs repeatedly		None		
			after the download to the Ether-				
				CAT master, the Servo Drive is			
			faulty. Replace the Servo Drive.				
Attached	None						
information							
Precautions/	AL status code:	001E hex, Error N	lo.: 9006 hex				
Remarks							

Event name	RxPDO Mapping Error			Event code	3582 0000 hex	
Meaning	An incorrect Rx	PDO was set.				_
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	When establishing EtherCAT communications
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	
Indicators	EtherCAT NET RUN		EtherCAT NET E	RR	EtherCAT LINK/	ACT
muicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables					_	
	Assumed cause		Correction		Prevention	
	An incorrect Rx	PDO was set,	Correct the RxPDO setting, and		Confirm the specifications of ETG	
Cause and	such as out of the	he allowable	then download it	to the EtherCAT	· ·	figure the setting
correction	range of Index,	Subindex, or size	master again.			ns to slaves in the
					EtherCAT master	in accordance
					with ESI data.	
Attached	None					
information						
Precautions/	AL status code:	0025 hex, Error N	o.: 9007 hex			
Remarks						

Event name	TxPDO Mapping	g Error		Event code	Event code 3583 0000 hex		
Meaning	An incorrect TxF	PDO was set.					
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	When establishing EtherCAT communications	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	iit is OFF		
Indicators	EtherCAT NET RUN		EtherCAT NET E	RR	EtherCAT LINK/	ACT	
mulcators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed caus	е	Correction		Prevention		
	An incorrect TxF	•	Correct the TxPD	•	Confirm the specifications of ETG		
Cause and	such as out of the	ne allowable	then download it	then download it to the EtherCAT		or FSoE, and configure the setting	
correction	range of Index,	Subindex, or size	master again.		of communications to slaves in the		
					EtherCAT master in accordance		
					with ESI data.		
Attached	None						
information							
Precautions/	AL status code:	0024 hex, Error N	o.: 9008 hex				
Remarks							

Event name	PDO WDT Setting Error			Event code	3584 0000 hex		
Meaning		O WDT setting wa	s detected.				
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing EtherCAT communications	
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT		
indicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed caus	е	Correction		Prevention		
Cause and	An incorrect PD	O WDT setting	Check the PDO WDT setting, and		Configure the setting of communi-		
correction	was detected		then download it	to the EtherCAT	cations to slaves in the EtherCAT		
00110011011				master again.		master in accordance with ESI	
					data.		
Attached	None						
information							
Precautions/	AL status code:	001F hex, Error N	lo.: 9001 hex				
Remarks							

Event name	Node Address Updated			Event code	3585 0000 hex	
Description	The node addre	ss is changed to a	value of the ID sv	vitches.		
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing EtherCAT communications
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log
Effects	User program	Continues.	Operation	Not affected.	· · · · · · · · · · · · · · · · · · ·	
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK	/ACT
ilidicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed caus	е	Correction		Prevention	
Cause and	The node addre	ss is changed	Check the node a	address value.		_
correction	from a set value	in Sysmac Stu-	Set a correct valu	ue if it is wrong.		
	dio to a value of	the ID switches				
Attached	None					
information						
Precautions/	AL status code:	0061 hex, Error N	o.: 9009 hex			
Remarks						

Event name	SM Event Mode Setting Error			Event code	3586 0000 hex	
Meaning	The unsupporte	d SM Event Mode	was set.			
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing EtherCAT communications
Error attributes	Level	Minor fault	Recovery	Error reset	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	EtherCAT NET ERR		ACT
mulcators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed caus	е	Correction		Prevention	
Cause and	The unsupporte	d SM Event	Check the synchronization set-		Configure the setting of communi-	
correction	Mode was set		ting, and then do	ting, and then download it to the		in the EtherCAT
			EtherCAT master again.		master in accordance with ESI data.	
Attached	None					
information						
Precautions/	AL status code:	0028 hex, Error N	o.: 9002 hex			
Remarks						

Event name	Function Setting	g Error		Event code	38570000 hex		
Meaning	The function that	at was set does no	t support the comn	nunications period.			
Source	EtherCAT Maste Module			Slave	Detection timing	When establishing EtherCAT communications	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	Indicators EtherCAT NET RUN		EtherCAT NET E	RR	EtherCAT LINK/	ACT	
maicators,	ON						
System	Variable		Data type		Name		
-defined	None		None		None		
variables						Prevention	
		Assumed cause		Correction			
	_ ~	ear ratio was not		Correct the electronic gear ratio to		Check the Servo Drive	
0	1:1 when the co			1:1, or set the communications		avoid the amused	
Cause and	period was set t	ארו ארוופ	period to longer than 125 µs.		causes of this event, and use the		
		•		·		•	
correction	The Backlash C	ompensation	Disable the Back	lash	Servo Drive corre	•	
correction	The Backlash C was enabled wh	compensation nen the	Disable the Back Compensation, o	lash r set the		•	
correction	The Backlash C was enabled wh communications	ompensation	Disable the Back Compensation, o communications	lash r set the		•	
correction	The Backlash C was enabled wh communications to 125 µs.	compensation nen the s period was set	Disable the Back Compensation, o communications than 125 µs.	lash r set the		•	
Attached	The Backlash C was enabled wh communications to 125 µs. Attached inform	compensation nen the s period was set ation 1: Condition	Disable the Back Compensation, o communications than 125 µs. that was met	lash r set the		•	
	The Backlash C was enabled wh communications to 125 μs. Attached inform 1: The electroni	compensation nen the s period was set ation 1: Condition c gear ratio was no	Disable the Back Compensation, o communications than 125 µs. that was met of 1:1	lash r set the		•	
Attached information	The Backlash C was enabled wh communications to 125 µs.  Attached inform 1: The electroni 2: The Backlash	compensation nen the s period was set ation 1: Condition c gear ratio was no	Disable the Back Compensation, o communications than 125 µs. that was met ot 1:1 as enabled	lash r set the		•	
Attached	The Backlash C was enabled wh communications to 125 µs.  Attached inform 1: The electroni 2: The Backlash	compensation nen the s period was set ation 1: Condition c gear ratio was no	Disable the Back Compensation, o communications than 125 µs. that was met ot 1:1 as enabled	lash r set the		•	

Event name	General Input A	llocation Duplicate	Error	Event code	3878 0000 hex				
Description	More than one f	unction input is all	ocated to one gen	eral input.					
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	At power ON			
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log			
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF	•			
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	/ACT			
ilidicators									
System	Variable		Data type		Name				
-defined variables	None		None		None				
Cause and	Assumed caus	Assumed cause			Prevention				
	More than one function input is		· ·	Correct the duplicate general input		re is no duplicate			
correction	allocated to one	general input	allocation.		allocation when setting a function input.				
	Attached Information 1: Cause Details								
	1: General Inpu	1: General Input 1 (IN1) Allocation Duplicate Error							
	2: General Input 2 (IN2) Allocation Duplicate Error								
	3: General Inpu	3: General Input 3 (IN3) Allocation Duplicate Error							
Attached		4: General Input 4 (IN4) Allocation Duplicate Error							
information	· .	t 5 (IN5) Allocation	·						
		t 6 (IN6) Allocation	•						
		t 7 (IN7) Allocation	-						
5	· ·	t 8 (IN8) Allocation	•						
Precautions/	AL status code:	-, Error No.: 3300	nex						
Remarks									

Event name	General Output	Allocation Duplica	te Error	Event code	3879 0000 hex			
Description	More than one f	unction output is a	allocated to one ge	neral output.		_		
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	At power ON		
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log		
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF			
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	ACT		
maicators								
System	Variable		Data type		Name			
-defined variables	None	None		None		None		
	Assumed cause		Correction		Prevention			
Cause and		unction output is	Correct the duplicate general out-		Confirm that there is no duplicate			
correction	allocated to one	allocated to one general output		put allocation.		setting a function		
	Attached information 1: Cause deta		<u> </u>		output.			
Attached	1: General Outp	out 1 (OUT1) Alloca	ation Duplicate Err	or				
information	2: General Outp	out 2 (OUT2) Alloca	ation Duplicate Err	or				
momution	3: General Outp	out 3 (OUT3) Alloca	ation Duplicate Err	or				
	4: General Outp	4: General Output 4 (OUT4) Allocation Duplicate Error						
Precautions/	AL status code:	-, Error No.: 3309	hex					
Remarks								

Event name	Pulse Output Se	etting Error		Event code 387B 0000 hex			
Description	_		the dividing denon value other than (		ncoder Dividing Pเ	ulse Output -	
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	At power ON	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	iit is OFF		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT		
maicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables			-				
	Assumed caus		Correction		Prevention		
	The dividing nu		Correct the setting of Encoder		Set the Encoder Dividing Pulse		
Cause and		exceeded the dividing denomina-		Dividing Pulse Output - Dividing		Output - Dividing Numerator to a	
correction		coder Dividing		Dividing Numer-	value smaller tha	in the Dividing	
	Pulse Output -	-	ator.		Denominator.		
		<b>Denominator</b> was set to a value					
	other than 0						
Attached	None						
information							
Precautions/	AL status code:	-, Error No.: 2800	hex				
Remarks							

Event name	Motor Replacement Detected			Event code	387C0000 hex		
Description	The connected motor is different from the motor that was connected the last time.					_	
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	At power ON	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET RUN		EtherCAT NET E	RR	EtherCAT LINK/	ACT	
mulcators							
System	ned None		Data type		Name		
-defined variables			None		None		
	Assumed cause		Correction		Prevention		
Cause and	The motor was replaced		Perform the Motor Setup and Absolute Encoder Setup.		After replacing the motor, perform the Motor Setup and Absolute Encoder Setup before use.		
correction	The Servo Drive was replaced		Perform the Motor Setup.		After replacing the Servo Drive, perform the Motor Setup before use.		
Attached	None		•		•		
information							
Precautions/	AL status code:	-, Error No.: 9505	hex				
Remarks						_	

Event name	Electronic Gear	Setting Error		Event code	387F 0000 hex	
Description	The electronic g	ear ratio exceeded	d the allowable ran	ge.		
Source	EtherCAT Maste ule			Slave	Detection timing	At power ON
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
mulcators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed caus	е	Correction		Prevention	
Cause and	The electronic g	jear ratio	Correct the electi	onic gear ratio to	Set the electronic	gear ratio to the
correction	exceeded the al	llowable range	the range from 1/	2,000 to 2,000	range from 1/2,000 to 2,000 times.	
			times.			
Attached	None					
information						
Precautions/	AL status code:	-, Error No.: 9300	hex			
Remarks						

Event name	Servo Drive Ove	erheat		Event code	3880 0000 hex		
Meaning	The internal tem	perature of Servo	Drive exceeded th	e circuit protection	level.		
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
indicators							
System	Variable	Variable		Data type		Name	
-defined variables	None		None		None		
	Assumed cause		Correction		Prevention		
	The ambient temperature of the		Improve the ambient temperature		Check the ambie	nt temperature of	
	Servo Drive exceeded the speci-		and the cooling conditions of the		the Servo Drive and set up the		
Cause and	fied value		Servo Drive.		necessary cooling conditions.		
correction	Overload		Increase the setting of the acceler-		Increase the setting of the acceler-		
			ation/deceleration time or stop-		ation/deceleration time or stop-		
			ping time to lighten the load. Or,		ping time as much as possible to		
			increase the capacities of the		lighten the load.		
			Servo Drive and the motor.				
Attached	None						
information	A1 ( )	E N 4500					
Precautions/	AL status code:	-, Error No.: 1500	nex				
Remarks							

Event name	Overload Error			Event code	38810000 hex		
Meaning	The Load Ratio	of Servo Drive or	motor (4105-81 he	x) exceeded 100%	).		
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	During Servo ON	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects			Power drive circu				
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	ACT	
maioatoro							
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed caus		Correction		Prevention		
	Operation was of long time with h		Perform the followaccordingly.  Increase the seacceleration/deand the stop time. Lighten the load. Adjust the gain	et value of the eccleration time ne.	Check the items given for corrections in advance and take counte measures as required.		
Cause and correction			If torque waveforexcessively, addition to by the tuning so tion does not on.	orms oscillate just the system of that the oscillactur.  riate brake timing. apacities of the			
	There is incorrect wiring of the motor cable or a broken cable		shown in the w the cable is bro Or, connect the encoder cable together to the • Measure the vo brake terminal. applied, release	<ul> <li>Connect the motor cable as shown in the wiring diagram. If the cable is broken, replace it.</li> <li>Or, connect the motor cable and encoder cable that are used together to the same motor.</li> <li>Measure the voltage at the brake terminal. If the brake is applied release it</li> </ul>		Connect the motor cable as shown in the wiring diagram. Connect the motor cable and encoder cable/external encoder cable that are used together to the same motor.	
	Increase in friction		Check machine conditions and remove the cause of the friction.		Take countermed machine distortion ated.		
Attached information	1: The Servo Dr	ation 1: Cause De ive is overloaded tor is overloaded	tails		,		
Precautions/ Remarks	AL status code:	-, Error No.: 1600	hex				

Event name	Regeneration Overload Error Event code				38820000 hex	
Meaning			310-81 hex) excee			
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	During Servo ON
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log
Effects	User program	Continues.	Operation Power drive circu		uit is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	/ACT
System	Variable		Data type		Name	
-defined variables	None		None		None	
	Assumed caus	е	Correction		Prevention	
	The regeneration processing is set inappropriately		as the resistance Regeneration Re	et the same value value of the sistor in use.		given for correc- and take counter- quired.
	The Regeneration Resistor is selected inappropriately		Check the operation pattern by the velocity monitor. Check the load ratio of Regeneration Resistor, and perform the following corrections accordingly.  Increase the deceleration time and stopping time.  Decrease the command velocity to the motor.  Use an External Regeneration Resistor.			
Cause and correction						
			Increase the ca Servo Drive an			
	The Regeneration used for continutive braking		•	The Regeneration Resistor can- not be used for continuous regen- erative braking.		Regeneration inuous regenera-
	The applied pov age is higher the value		Apply the specific voltage.	ed power supply	Review the power to be the specific use.	er supply voltage ed value before
	Regeneration Resistor failure		Check whether the Regeneration Resistor is faulty, and use one without failures.		Confirm that the Resistor is not fa	-
Attached information	None					
Precautions/ Remarks	AL status code:	-, Error No.: 1800	hex			

Event name	Excessive Posit	ion Deviation Erro	r	Event code	3883 0000 hex		
Meaning	The position de	viation is greater th	nan or equal to the	value set in the Fo	ollowing error wind	OW.	
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	During Servo ON	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	iit is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
maicators							
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed caus	е	Correction		Prevention		
	The motor operation does not follow the command		Identify and remove a cause that limits the motor operation.		Adjust the gain and limit values appropriately before use.		
			During the acceleration/decelera-		Set the operation pattern appropri-		
Cause and			tion, the comman lowed depending	•	ately according to	the connected	
correction				•	ioau.		
				patterns. In that case, adjust the gain, increase the accelera-			
			tion/deceleration time or the like.				
	The value of Fo	llowing error win-	Increase the setting of the Follow-		Increase the setting of the Follow-		
	dow is small	-	ing error window	to an acceptable	ing error window	to an acceptable	
				range.		range.	
Attached	None						
information							
Precautions/	AL status code:	-, Error No.: 2400	hex				
Remarks							

Event name	Excessive Spee	Excessive Speed Deviation Error Event code					
Meaning	The speed devi	ation is greater tha	n or equal to the v	alue set in the Exc	essive Velocity D	eviation Detection	
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	During Servo ON	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET B	RR	EtherCAT LINK	/ACT	
ilidicators							
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed caus	e	Correction		Prevention		
	The motor opera	The motor operation does not fol-		improve the fol-	, ,	o improve the fol-	
	low the commar		lowing ability. Or,		lowing ability. Or		
	parameter value	parameter value is inappropriate		acceleration/deceleration time for		acceleration/deceleration time for	
			the internal position command velocity.		the internal position command velocity.		
Cause and	The output axis	The output axis of motor is lim-		Take countermeasures so that the		Take countermeasures so that the	
correction	ited on the oper	ation by external	output axis is not limited on the		output axis is not limited on the		
COLLECTION	forces		operation by external forces.		operation by external forces.		
	The value of the		Increase the setting of the Exces-		Increase the setting of the Exces-		
	Velocity Deviat		sive Velocity Deviation Detection		sive Velocity Deviation Detection		
	Level is inappro	priate	Level to an acceptable range. Dis-		Level to an acceptable range. Dis-		
				able the Excessive Velocity Devia-		able the Excessive Velocity Devia-	
				tion Detection if it is unnecessary to monitor the velocity deviation.		tion Detection if it is unnecessary to monitor the velocity deviation.	
Attached	None		to monitor the ve	iooity deviation.	to monitor the ve	Siddity deviation.	
information	1.3113						
Precautions/	AL status code:	-, Error No.: 2401	hex				

Event name	Excessive Spee	ed Error		Event code	38850000 hex		
Meaning	The feedback m	notor speed is grea	iter than or equal to	the value set in the	ne Excessive Spee	d Detection Level.	
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	During Servo ON	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
indicators							
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed caus	Assumed cause			Prevention		
Cause and	The velocity command value is too large		Do not give the excessive velocity command. Check whether the electronic gear ratio is set correctly.		Set the velocity command value within the range in which the feed-back motor velocity does not exceed the excess velocity detection level.		
correction	Overshooting occurred		If overshooting occurred due to faulty gain adjustment, adjust the gain.		Do not increase t	he gain too much.	
	The motor is rot forces	The motor is rotated by external forces		Check whether the motor is rotated by external forces.		Check whether the motor is rotated by external forces.	
Attached information	None						
Precautions/ Remarks	AL status code:	-, Error No.: 2600	hex				

Event name	Following Error	Counter Overflow		Event code	3886 0000 hex	
Meaning	The following er	ror value exceede	d the range from -2	2147483648 to 214	17483647.	
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	During Servo ON
Error attributes	Level	Minor fault	Recovery	slave errors)		System log
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT
ilidicators						
System	Variable		Data type		Name	
-defined variables	None		None		None	
	Assumed caus	ie .	Correction		Prevention	
Cause and correction	low the comman	r is rotated or lim-	tion/deceleration Take countermea	peration. During deceleration, the of the followed eration patterns. The operation is the acceleratime or the like.  Sures so that the	ately according to load.  Take countermea	ore use.  a pattern appropri- b the connected  asures so that the
	ited on the operation by external forces		motor is not subjected to external forces.		motor operation is not interfered by external forces.	
Attached information	None					
Precautions/ Remarks	AL status code:	-, Error No.: 2903	hex			

Event name	Absolute Encoder Counter Overflo		ow Error Event code		3887 0000 hex		
Meaning	The multi-rotation	on counter of the e	ncoder exceeded	the maximum num	ber of rotations.		
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
ilidicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed caus	Assumed cause			Prevention		
	An inappropriate value was set in		Set the appropriate value in the		Set the appropriate value in the		
	the Encoder - Operation Selec-		Encoder - Operation Selection		Encoder - Operation Selection		
	the <b>Encoder</b> – (	Operation Selec-				when Using Absolute Encoder	
Cause and	the Encoder – tion when Usin	-	when Using Abs		when Using Abs	solute Encoder	
Cause and		g Absolute			when Using Abs (4510-01 hex).	solute Encoder	
Cause and correction	tion when Usin Encoder (4510-	g Absolute	when Using Abs	solute Encoder	(4510-01 hex).	tance so that the	
	tion when Usin Encoder (4510 The multi-rotation	g Absolute -01 hex)	when Using Abs (4510-01 hex).	tance so that the	(4510-01 hex).	tance so that the	
	tion when Usin Encoder (4510 The multi-rotation	ng Absolute -01 hex) on number of the led the maximum	when Using Abs (4510-01 hex). Set the travel dis	tance so that the	(4510-01 hex). Set the travel dis	tance so that the	
	tion when Usin Encoder (4510 The multi-rotation encoder exceed	ng Absolute -01 hex) on number of the led the maximum	when Using Abs (4510-01 hex). Set the travel dis multi-rotation nur	tance so that the	(4510-01 hex).  Set the travel dis multi-rotation nur	tance so that the	
	tion when Usin Encoder (4510 The multi-rotation encoder exceed	ng Absolute -01 hex) on number of the led the maximum	when Using Abs (4510-01 hex). Set the travel dis multi-rotation nur exceed the maxin	tance so that the	(4510-01 hex).  Set the travel dis multi-rotation nur exceed the maximum.	tance so that the	
correction	tion when Usin Encoder (4510 The multi-rotation encoder exceeding number of rotation	ng Absolute -01 hex) on number of the led the maximum	when Using Abs (4510-01 hex). Set the travel dis multi-rotation nur exceed the maxin	tance so that the	(4510-01 hex).  Set the travel dis multi-rotation nur exceed the maximum.	tance so that the	
correction	tion when Usin Encoder (4510- The multi-rotation encoder exceed number of rotation	ng Absolute -01 hex) on number of the led the maximum	when Using Abs (4510-01 hex). Set the travel dis multi-rotation nur exceed the maxin rotations.	tance so that the	(4510-01 hex).  Set the travel dis multi-rotation nur exceed the maximum.	tance so that the	

Event name	Safety Commur	nications Setting E	rror	Event code	38880000 hex		
Meaning	Safety process rect communica		ons were not estab	lished with the Saf	ety CPU Unit beca	ause of an incor-	
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing FSoE communications	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	/ACT	
illuicators							
System	Variable		Data type		Name		
-defined variables	None	None		None		None	
	Assumed caus	Assumed cause			Prevention		
Cause and correction	The watchdog time was set incorrectly		If the watchdog time of the safety process data communications setting is set to a value inappropriate for the communications cycle or the configuration, correct it, and transfer the setting to the Safety CPU Unit.		Set the watchdo ation of the actuand surrounding	•	
	The processing was not com- pleted within the watchdog time because communications were not established due to the noise		If there is no improvement after you performed noise countermeasures, set the longer watchdog time, and transfer the setting to the Safety CPU Unit.				
Attached information	None						
Precautions/	Al status code:	-, Error No.: 7001	hex				
Remarks	, ie siaias code.	, _1101 140 7001	110A				

Event name	Safety Frame E	rror		Event code	3889 0000 hex	_
Meaning	Safety process frame was recei		ons were not estab	lished with the Sat	fety CPU Unit beca	nuse an incorrect
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing FSoE communications
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF	
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
maicators						
System	Variable		Data type	Data type		
-defined variables	None		None		None	
	Assumed cause		Correction	Correction		
Cause and correction	An incorrect frame was received in safety process data communications		The Servo Drive model does not match the safety slave model that is sent from the safety master. Check the connection configuration and configure it correctly.		Set the system of setup according that are given on	to the corrections
	There is excessive noise		Take noise countermeasures.		Take noise countermeasures if excessive noise caused the error.	
Attached information	None					
Precautions/ Remarks	AL status code:	-, Error No.: 7003	hex			

Event name	Safety Parameter Error			Event code	388A 0000 hex				
Description		Safety process data communications were not established with the Safety CPU Unit because an incorrect parameter was received.							
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing FSoE communications			
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log			
Effects	User program	Continues.	Operation	Power drive circu	iit is OFF	_			
lu di a ataua	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT				
Indicators									
System	Variable		Data type		Name				
-defined	None		None		None				
variables									
	Assumed caus	е	Correction		Prevention				
Cause and	The set safety s	lave model is	Check whether the	Check whether the connected		Set the correct safety slave model			
correction	incorrect		safety slave mod	el matches the	that matches the	actual connection			
COTTECTION			safety slave model that is set from		configuration.				
			the Sysmac Stud	io, and correct it.					
Attached	None					_			
information									
Precautions/	AL status code:	-, Error No.: 7000	hex						
Remarks									

Event name	FSoE Slave Add	dress Error		Event code	388B0000 hex		
Description		Safety process data communications were not established with the Safety CPU Unit because of an incorrect FSoE slave address.					
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	When establishing FSoE communications	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT		
indicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed caus	Assumed cause		Correction		Prevention	
	The setting of th	ne FSoE slave	Perform the FSoE Slave Address		If you use a Servo Drive for which		
Cause and	address in the s	afety process	Clear for the Ser	Clear for the Servo Drive.		safety process data communica-	
cause and	data communica	ations settings is				tions were previously established	
Correction	different from the setting in the				in another syster	n, perform the	
	Unit	_				FSoE Slave Address Clear before	
					you use the Serv	o Drive.	
Attached	None						
information							
Precautions/	AL status code:	-, Error No.: 7002	hex				
Remarks							

Event name	FPGA WDT Erro	or		Event code	48080000 hex		
Description	An FPGA error	was detected.					
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
ilidicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed cause		Correction		Prevention		
	False detection	False detection due to a data		If this event does not occur after		If the normal operation can restart	
	read error that v	read error that was caused by		you cycled the power supply, use		after you cycled the power supply,	
Cause and	excessive noise	:		the product continuously. It is sup-		consider noise countermeasures.	
correction	Hardware failure	e	posed that a tem	•	There may be ex		
			occurred due to a read error. If this		around the Servo Drive.		
			_	event occurs again, the hardware is faulty. Replace the Servo Drive.			
Attached	Attached inform	ation 1: System in			1		
information		•					
Precautions/	AL status code:	-, Error No.: 3500	hex				
Remarks	AL Status code, Little No.: 5500 Hex						

	D: D 13133			- 4 1	0.450,0000.1		
Event name	Drive Prohibition			Event code	64E30000 hex		
Description	Both the Positiv	e Drive Prohibition	(POT) and the Ne	gative Drive Prohi	bition Input (NOT)	turned ON.	
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	iit is OFF		
In all a set a ma	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
Indicators							
System	Variable		Data type		Name	Name	
-defined variables	None		None	None		None	
	Assumed caus	Assumed cause			Prevention		
Cause and correction	wire, power sup that were conne tive Drive Prohil	An error occurred on the switch, wire, power supply, and wiring that were connected to the Positive Drive Prohibition (POT) or Negative Drive Prohibition Input		Check and correct an error on the switch, wire, power supply, and wiring that were connected to the Positive Drive Prohibition Input or Negative Drive Prohibition Input.		Confirm that there are not disconnection and incorrect logic setting, and use the Drive Prohibition Input.	
	False detection occurred because the control signal power supply was turned ON slowly		Check whether the control signal power supply (12 to 24 VDC) is turned ON slowly, and adjust the timing if it is slow.		Adjust the timing at which the control signal power supply is turned ON so that the signal can be input correctly.		
Attached information	None		,				
Precautions/ Remarks	AL status code:	-, Error No.: 3800	hex				

Event name	Drive Prohibition	n Detected		Event code	6820 0000 hex		
Description	•	vas stopped accord Prohibition was en	ding to the user set abled.	ting because the r	notor ran in the pro	ohibited direction	
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	iit is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
illuicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed cause		Correction		Prevention		
	Incorrect or broken wiring of Pos-		Correct the wiring if the Positive		Confirm that the Positive Drive		
		itive Drive Prohibition Input		Drive Prohibition Input (POT) or		Prohibition Input (POT) and Nega-	
	` ′	ive Drive Prohibi-	•	Negative Drive Prohibition Input		tive Drive Prohibition Input (NOT)	
Cause and	tion Input (NOT)	)	` ,	(NOT) is wired incorrectly. If the		ly. Confirm that	
correction		(II D: D	cable is broken, r			roken before use.	
		of the Drive Pro-	Review the setting of the drive pro-		Configure the setting of the drive		
	nibition input	hibition Input		hibition input port and set it cor-		prohibition input port to be appro-	
			rectly.	rectly.		priate for the actual connection condition.	
Attached	Attached inform	ation 1: System in	formation		1		
information		-					
Precautions/	AL status code:	-, Error No.: 3801	hex				
Remarks							

Event name	Control Right R	elease Error		Event code 6821 0000 hex					
Description	Communications between the Sysmac Studio and Servo Drive were interrupted while a specific function was used from the Sysmac Studio.								
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	Continuously			
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log			
Effects	User program	Continues.	Operation	Power drive circu	it is OFF				
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT				
System	Variable		Data type		Name				
-defined variables	None		None		None				
Cause and correction	Assumed cause		Correction		Prevention				
	The USB cable or EtherCAT cable was disconnected during the connection with the Sysmac Studio		Connect the USB cable or Ether-CAT cable between the Servo Drive and the computer that controls the Servo Drive if it is disconnected.		Do not disconnect the cable during the operation of Sysmac Studio.				
	There is excessive noise		Take noise countermeasures for the USB cable or EtherCAT cable.		Use the recommended USB cable or EtherCAT cable.				
	A command sent from the Sysmac Studio was not sent to the Servo Drive because the computer was in a busy state or the like		Finish other applications to reduce the processing load of the computer.		Do not use the Sysmac Studio with more than one application active so that the computer does not go into a busy state.				
Attached information	None								
Precautions/ Remarks	AL status code: -, Error No.: 6200 hex								

Event name	Error Stop Input			Event code	68220000 hex			
Meaning		Input (ESTP) is ac						
<u>-</u>		er Function Mod-	Slave		Detection	Continuously		
Source	ule		Source details		timing			
F		Minor fault		Error reset		System log		
rror	Level		Recovery	(after resetting	Log category			
attributes			,	slave errors)	0 0,			
Effects	User program	Continues.	Operation	Power drive circu	it is OFF			
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT			
System	Variable None		Data type		Name			
defined			None		None			
/ariables								
	Assumed cause		Correction		Prevention			
	The Error Stop Input (ESTP) was		Remove the cause of Error Stop		A preventative measure is not			
Cause and	input		Input (ESTP).		required because the purpose is			
correction					detect an error.			
	The Error Stop		Correct the wiring if the Error Stop		Confirm that the Error Stop Inp			
	incorrectly wired	<u> </u>	Input (ESTP) is incorrectly wired.		(ESTP) is correctly wired.			
Attached	None							
nformation								
Precautions/	AL status code:	-, Error No.: 8700	hex					
Remarks								
Event name	Software Limit E	xceeded	<b>Event code</b> 6823 0000 hex					
Description	The Position actual value detected the position that exceeded the value set in the Software Position							
	and stopped the operation according to the user setting.							
Source		er Function Mod-	Slave		Detection	Continuously		
	ule		Source details		timing	,		
_		N 4: £ 14		Error reset		System log		
Error	1	i Minor Tault		I LIIUI IESEL				
	Level	Minor fault	Recovery		Log category	l cyclem log		
	Level	Minor fault	Recovery	(after resetting	Log category	oyelem log		
attributes				(after resetting slave errors)		Cyclem log		
ettributes Effects	Level User program EtherCAT NET	Continues.	Recovery Operation EtherCAT NET E	(after resetting slave errors) Power drive circu				
ettributes Effects	User program	Continues.	Operation	(after resetting slave errors) Power drive circu	uit is OFF			
Effects Indicators System	User program	Continues.	Operation	(after resetting slave errors) Power drive circu	uit is OFF			
ettributes  Effects  ndicators	User program EtherCAT NET	Continues.	Operation EtherCAT NET E	(after resetting slave errors) Power drive circu	it is OFF  EtherCAT LINK			
Effects ndicators System defined	User program EtherCAT NET Variable	Continues.	Operation EtherCAT NET E Data type	(after resetting slave errors) Power drive circu	it is OFF EtherCAT LINK			
ettributes  Effects  ndicators  System	User program EtherCAT NET Variable	Continues. RUN	Operation EtherCAT NET E Data type	(after resetting slave errors) Power drive circu	it is OFF EtherCAT LINK			
Effects ndicators System defined	User program EtherCAT NET Variable None	Continues. RUN	Operation EtherCAT NET E Data type None	(after resetting slave errors) Power drive circuers	it is OFF  EtherCAT LINK Name None	/ACT		
Effects Indicators System Idefined	User program EtherCAT NET Variable None Assumed caus	Continues. RUN	Operation EtherCAT NET E Data type None Correction	(after resetting slave errors) Power drive circuers	EtherCAT LINK Name None Prevention	/ACT		
Effects Indicators System Idefined Variables	User program EtherCAT NET Variable None Assumed caus Incorrect setting Position Limit	Continues. RUN	Operation EtherCAT NET E Data type None Correction Correct the settin Position Limit.	(after resetting slave errors) Power drive circuers	EtherCAT LINK Name None Prevention Confirm that the ware Position Line	Setting of Soft-mit is correct.		
Effects Indicators System Idefined Variables Cause and	User program EtherCAT NET Variable None Assumed caus Incorrect setting Position Limit When the Softw	Continues.  RUN  See  g of Software  are Position Limit	Operation EtherCAT NET E Data type None Correction Correct the settin Position Limit. Set the command	(after resetting slave errors) Power drive circuerre  g of Software	EtherCAT LINK Name None Prevention Confirm that the ware Position Liu Set the comman	setting of Soft-mit is correct.		
Effects ndicators System defined	User program EtherCAT NET Variable None Assumed caus Incorrect setting Position Limit When the Softw - Stop Selection	Continues.  RUN  See  The of Software are Position Limit was set to Stop	Operation EtherCAT NET E Data type None Correction Correct the settin Position Limit. Set the command within the range of	(after resetting slave errors) Power drive circuerre  g of Software	EtherCAT LINK Name None Prevention Confirm that the ware Position Lin Set the comman within the range	setting of Soft-mit is correct.		
Effects Indicators System Idefined Variables Cause and	User program EtherCAT NET Variable None Assumed caus Incorrect setting Position Limit When the Softw - Stop Selection according to the	Continues.  RUN  See  g of Software  are Position Limit a was set to Stop e setting of Fault	Operation EtherCAT NET E Data type None Correction Correct the settin Position Limit. Set the command	(after resetting slave errors) Power drive circuerre  g of Software	EtherCAT LINK Name None Prevention Confirm that the ware Position Liu Set the comman	setting of Soft-mit is correct.		
Effects Indicators System Idefined Variables Cause and	User program EtherCAT NET Variable None Assumed caus Incorrect setting Position Limit When the Softw - Stop Selection according to the reaction option of	Continues.  RUN  See  g of Software  are Position Limit a was set to Stop e setting of Fault code, the position	Operation EtherCAT NET E Data type None Correction Correct the settin Position Limit. Set the command within the range of	(after resetting slave errors) Power drive circuerre  g of Software	EtherCAT LINK Name None Prevention Confirm that the ware Position Lin Set the comman within the range	setting of Soft-mit is correct.		
Effects Indicators System Idefined Variables Cause and	User program EtherCAT NET Variable None Assumed caus Incorrect setting Position Limit When the Softw - Stop Selection according to the reaction option of exceeded the va	Continues.  RUN  See  g of Software  are Position Limit a was set to Stop e setting of Fault code, the position alue set in the	Operation EtherCAT NET E Data type None Correction Correct the settin Position Limit. Set the command within the range of	(after resetting slave errors) Power drive circuerre  g of Software	EtherCAT LINK Name None Prevention Confirm that the ware Position Lin Set the comman within the range	setting of Soft-mit is correct.		
Effects Indicators System Idefined Ivariables Cause and Ivariation	User program EtherCAT NET Variable None Assumed caus Incorrect setting Position Limit When the Softw - Stop Selection according to the reaction option of exceeded the va Software Position	Continues.  RUN  See  g of Software  are Position Limit a was set to Stop e setting of Fault code, the position alue set in the	Operation EtherCAT NET E Data type None Correction Correct the settin Position Limit. Set the command within the range of	(after resetting slave errors) Power drive circuerre  g of Software	EtherCAT LINK Name None Prevention Confirm that the ware Position Lin Set the comman within the range	setting of Soft-mit is correct.		
Effects Indicators System Idefined Variables Cause and	User program EtherCAT NET Variable None Assumed caus Incorrect setting Position Limit When the Softw - Stop Selection according to the reaction option of exceeded the va	Continues.  RUN  See  g of Software  are Position Limit a was set to Stop e setting of Fault code, the position alue set in the	Operation EtherCAT NET E Data type None Correction Correct the settin Position Limit. Set the command within the range of	(after resetting slave errors) Power drive circuerre  g of Software	EtherCAT LINK Name None Prevention Confirm that the ware Position Lin Set the comman within the range	setting of Soft-mit is correct.		

Precautions/

Remarks

AL status code: -, Error No.: 3401 hex

Event name	Pulse Output O	verspeed Error		Event code	7820 0000 hex		
Description	The speed, which tion, was detect		equency that could	d be output by the	Encoder Dividing	Pulse Output func-	
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK	/ACT	
maicators							
System	Variable		Data type		Name		
-defined variables	None		None	ne		None	
	Assumed cause		Correction		Prevention		
Cause and correction	The dividing ratio setting is inap- propriate for the actual usage condition		Correct the setting of Encoder Dividing Pulse Output - Dividing Denominator and Dividing Numerator.		Set the Encoder Dividing Pulse Output - Dividing Denominator and Dividing Numerator to a value appropriate for the maximum speed that is detected during operation.		
Attached information	None						
Precautions/ Remarks	AL status code:	-, Error No.: 2800	hex				

Event name	Brake Interlock	Error		<b>Event code</b> 7821 0000 hex		
Description	The Brake Inter	lock Output (BKIR	) was output by the	Timeout at Servo	OFF.	
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously
Error attributes	Level Minor fault		Recovery	Error reset (after resetting slave errors)	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	iit is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT
maicators						
System	Variable		Data type		Name	
-defined variables	None		None		None	
	Assumed cause		Correction		Prevention	
Cause and correction	The Brake Interlock Output (BKIR) was output because the motor rotation speed did not decrease to or less than the speed set in the Threshold Speed at Servo OFF within the time set in the Timeout at Servo OFF when Servo OFF was per- formed during the motor opera-		Increase the setti at Servo OFF acc operation condition	•	Confirm the corregiven on the left	
Attached information	None					
Precautions/ Remarks	AL status code:	-, Error No.: 9700	hex			

Event name	Command Error			Event code	78230000 hex	
Meaning	A mistake was r	nade in using a co	mmand.			
Source		er Function Mod-	Source details Slave		Detection timing	Continuously
Error attributes	Level Minor fault		Recovery	Error reset	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT
indicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed cause		Correction		Prevention	
Cause and correction	When bit 9 (Remote) of the Statusword was set to 1 (remote), and the Servo Drive was in <i>Operation enabled</i> state (Servo ON), the Servo Drive received a command to change the communications state from Operational to another state (Init, Pre-Operational, or Safe-Operational)  A mode of operation other than the hm mode was set during the homing operation  Modes of operation was set to pp, pv or hm mode when the communications period was set		Check the Servo Drive specifications and use the command correctly.		Check the Servo Drive specifications and use the command correctly.	
Attached	None					
information						
Precautions/	AL status code:	-, Error No.: 9101	hex			
Remarks						

Event name	EtherCAT State	Change Error		Event code 84B10000 hex		
Description	A communication not be changed	•	ommand was rece	ived for which the	current communic	ations state could
Source	EtherCAT Maste	er Function Mod-	Source details	Source details Slave		Continuously
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
indicators						
System	Variable		Data type	Data type		
-defined variables	None		None		None	
	Assumed cause		Correction		Prevention	
Cause and	A communication	ns state change	Check the command specifications		Check the command specifications	
correction	command was r	eceived for which	for communication	ons state transi-	for communications state transi-	
Correction	the current communications state		tions in the host controller and cor-		tions in the host controller and pro-	
	could not be changed		rect host controller processing.		gram host controller processing.	
Attached	None					
information						
Precautions/	AL status code:	0011 hex, Error N	o.: 8301 hex			
Remarks						

Event name	EtherCAT Illegal State Change Error		ror	Event code	84B20000 hex			
Description	An undefined co	An undefined communications state change command was received.						
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	Continuously		
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log		
Effects	User program	Continues.	Operation	Power drive circu	iit is OFF			
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/	ACT		
indicators								
System	Variable		Data type		Name			
-defined variables	None		None		None			
	Assumed cause		Correction		Prevention			
Cause and	An undefined co	ommunications	Check the comma	Check the command specifications		Check the command specifications		
correction	state change co	mmand was	for communication	ns state transi-	for communications state transi-			
COLLECTION	received			controller and cor-	tions in the host controller and pro-			
			rect host controller processing.		gram host controller processing.			
Attached	None							
information								
Precautions/	AL status code:	0012 hex, Error N	o.: 8302 hex			_		
Remarks								

Event name	Synchronization	Error		Event code	84B40000 hex		
Description	A signal for synd	chronous commun	ications could not l	oe detected.			
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)*1	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
illuicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed cause		Correction		Prevention		
	Noise		Take noise countermeasures if		Take noise countermeasures if		
Cause and			excessive noise affects the Ether-		excessive noise affects the Ether-		
correction			CAT communications cable.		CAT communications cable.		
		erCAT slave com-		rs again after you	None		
	munications cor	munications controller		cycled the power supply, replace			
			the Servo Drive.				
Attached	None						
information							
Precautions/	AL status code:	002C hex, Error N	lo.: 8304 hex				
Remarks							

<sup>\*1. &</sup>quot;Error reset (after cycling slave power)" is specified for the unit version 1.0.

Event name	Sync Manager \	NDT Error		Event code	84B50000 hex	
Description	PDO communic	ations were interru	upted for the allowa	ble period or longe	er.	
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT
indicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed cause		Correction		Prevention	
	An EtherCAT communications		Connect the EtherCAT communi-		Connect the EtherCAT communi-	
	cable is disconnected, loose, or		cations cable securely.		cations cable securely.	
Cause and	broken					
correction	Host controller	error	Check the operat		None	
			controller. Take appropriate			
				if there is a prob-		
			lem.			_
Attached	None					
information						
Precautions/	AL status code:	001B hex, Error N	lo.: 8305 hex			
Remarks						

Event name	ESC Initializatio	n Error		Event code	84B60000 hex		
Description	The initialization	of EtherCAT slav	e communications	communications controller failed.			
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	At power ON	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed cause		Correction		Prevention None		
		Data was incorrectly overwritten		If this event does not occur after			
Cause and		ile memory of the	you cycled the po				
cause and correction		communications	•	nuously. It is sup-			
correction	controller	bh a #CAT alays	posed that a temp	•			
	Failure of the EtherCAT slave occurred due to a recommunications controller event occurs again.						
	Communications	s controller	event occurs again, replace the Servo Drive.				
Attached	None		22.70 2.770.		<u>I</u>		
information							
Precautions/	AL status code:	-, Error No.: 8801	hex				
Remarks							

Event name	SII Verification I	Error		Event code	84B70000 hex		
Description	An error occurre	ed in SII data of the	e EtherCAT slave o	EtherCAT slave communications controller.			
Source	EtherCAT Maste ule	er Function Mod-	Source details Slave		Detection timing	At power ON	
Error attributes	Level	Minor fault	Recovery Error reset (after cycling slave power)		Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
maicators							
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed cause		Correction	Correction			
	Data was incorr	Data was incorrectly overwritten		If this event does not occur after			
	in the non-volati	ile memory of the	you cycled the power supply, use				
Cause and	EtherCAT slave	communications	·	nuously. It is sup-			
correction	controller	controller		posed that a temporary error			
	Failure of the EtherCAT slave		occurred due to a read error. If this				
		communications controller or		event occurs again, replace the			
	false detection		Servo Drive.				
Attached	None						
information							
Precautions/	AL status code:	0014 hex, Error N	o.: 8803 hex				
Remarks							

Event name	Synchronization	Interruption Error	-	Event code	84B90000 hex		
Description	-	·	ot occur within the		3.23000 Hox		
Source		er Function Mod-	Source details	Slave	Detection	Continuously	
Source	ule		Source details		timing		
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
	EtherCAT NET		EtherCAT NET E		EtherCAT LINK/	ACT	
Indicators							
System	Variable		Data type		Name		
-defined variables	None		None		None		
variables	Assumed caus	<b>A</b>	Correction		Prevention		
		CAT synchroniza-	Set the synchron	ization setting of		hronization speci-	
		ne host controller	-	r according to the	fications for the E	•	
			synchronization s	•		e synchronization	
			the EtherCAT sla	•	_	nost controller cor-	
					rectly.		
Cause and	Failure of the E	therCAT slave	If this event does	not occur after	None		
correction	communications	s controller or	you cycled the po	ower supply, use			
	false detection		-	nuously. It is sup-			
			posed that a tem				
			occurred due to a read error. If this				
			event occurs aga				
			Drive is faulty. Re	eplace the Servo			
Attached	None		Drive.				
information	None						
Precautions/	AL status code:	002D hex, Error N	No.: 8802 hex				
Remarks		,					
F .	ID 11 011	T :: D		F	I 0.4 D A 0000 I		
Event name	· ·	Transition Reque		Event code	84BA 0000 hex		
Description		• •	d Bootstrap was re			I a	
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error	Level	Minor fault	Becovery	Error reset	Log category	System log	
attributes	Level		Recovery				
Effects	User program		Operation	Power drive circu	iit is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
System	Variable		Data type		Name		
-defined	None		None		None		
variables	A	-	0		D		
	Assumed caus		Check the Ether	CAT moster and	Prevention	CAT moster and	
Cause and	the transition of	naster requested	Check the Ether0 ting so that the E		Check the Ether( ting so that the E		
correction	Bootstrap	unsupporteu	_		-		
	Doolstiap		does not request the transition to Bootstrap.		does not request the transition to Bootstrap.		
Attached	None						
information							
Precautions/	AL status code:	0013 hex, Error N	lo.: 8306 hex				
Remarks	]						

Event name	Communication	s Synchronization	Error	Event code	88100000 hex	
Meaning	Communication ter could not be		shed consecutively	because the sync	hronization with th	e EtherCAT Mas-
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	it is OFF	
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	/ACT
indicators						
System	Variable None		Data type		Name	
-defined variables			None		None	
Cause and	Assumed caus	Assumed cause			Prevention	
	The power supply to the host controller was interrupted during PDO communications		Reset the error in the host control- ler. This event reports an error that was detected when the power sup- ply to the host controller was inter- rupted. It does not indicate that an error currently exists.		If you turn OFF the power supply to the host controller, also turn OFF the power supply to the Servo Drive.	
correction	An EtherCAT communications cable is disconnected, loose, broken, or has a contact failure		Connect the EtherCAT communications cable securely. If the cable is broken, replace it.		Connect the EtherCAT communications cable securely.	
	Noise		Take noise countermeasures if excessive noise affects the Ether-CAT communications cable.		Take noise countermeasures if excessive noise affects the Ether-CAT communications cable.	
Attached information	None					
Precautions/ Remarks	AL status code: 0034 hex, Error No.: 8303 hex					

Event name	Safety Commun	ications Timeout		Event code	88120000 hex		
Meaning	A communicatio	ns timeout occurre	ed in safety proces	s data communica	tions with the Safe	ions with the Safety CPU Unit.	
Source		er Function Mod-	Source details	Slave	Detection timing	When establishing FSoE communications/during FSoE communications	
Error attributes	Level	Minor fault	Recovery	Error reset (after resetting slave errors)	Log category	System log	
Effects		Continues.	Operation	Power drive circu			
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
maicators							
System	Variable		Data type		Name		
-defined variables	None None			None			
	Assumed caus	е	Correction		Prevention		
Course	A setting is not correct. The set- ting of the safety task period of the Safety CPU Unit is too short		Increase the safe the Safety CPU L transfer the settin CPU Unit.	Init and then	Set the system or setup according t that are given on	o the corrections	
Cause and correction	There is excessive noise		Take noise countermeasures.  Check the status of the Safety CPU Unit or safety slave.		Take noise countermeasures if excessive noise caused the error.		
					Refer to troubleshooting information for the Safety CPU Unit or safety slave.		
Attached information	None				1		
Precautions/ Remarks	AL status code:	-, Error No.: 7004	hex				
Remarks							
Event name	Absolute Value	Cleared		Event code	9820 0000 hex		
Meaning	The multi-rotation	on counter of the a	bsolute encoder w	as cleared.	l		
Source		er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Minor fault	Recovery	Error reset (after cycling slave power)	Log category	System log	
Effects	User program	Continues.	Operation	Power drive circu	it is OFF		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT	
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed caus	е	Correction		Prevention		
Cause and correction	The multi-rotation absolute encode	on counter of the er was cleared	This operation is safety and is not	•	A preventative merchanic		
Attached information	None				measure.		
Precautions/ Remarks	AL status code:	-, Error No.: 2701	hex				

Event name	Capacitor Lifetir	ne Warning		Event code	081C0000 hex	
Meaning	The capacitor b	uilt into the Servo	Drive reached the	service life of the n	nanufacturer's gua	ırantee.
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	Continuously
Error attributes	Level	Observation*1	Recovery		Log category	System log
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherCAT NET RUN		EtherCAT NET E	RR	EtherCAT LINK	ACT
ilidicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed cause		Correction		Prevention	
	The operating ti	me of the capaci-	Send the Servo Drive for repair or		None	
Cause and	tor in the Servo	Drive exceeded	replace the Servo Drive with a new			
correction	the service life		one. It is necessary to replace the			
			component that reached the ser-			
			vice life.			
Attached	None					
information						
Precautions/	AL status code:	-, Error No.: A701	hex			
Remarks						

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

Event name	Inrush Current F	Prevention Relay L	ifetime Warning	Event code	081D0000 hex	
Description	The inrush curre guarantee.	ent prevention rela	y built into the Ser	vo Drive reached t	ne service life of the	ne manufacturer's
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	Continuously
Error attributes	Level	Observation*1	Recovery		Log category	System log
Effects	User program	Continues.	Operation	Not affected.		_
Indicators	EtherCAT NET RUN		EtherCAT NET E	EtherCAT NET ERR		ACT
indicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed caus	е	Correction		Prevention	
	The number of o	perating times of	Send the Servo [	Orive for repair or	None	
Cause and	the inrush curre	nt prevention	replace the Servo Drive with a new			
correction	relay in the Ser	o Drive	one. It is necessa	one. It is necessary to replace the		
	exceeded the service life		component that reached the service life.			
Attached	None		•			
information						
Precautions/	AL status code:	-, Error No.: A702	hex			
Remarks						

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

Event name	Brake Interlock	Output Relay Lifet	ime Warning	Event code	081F0000 hex		
Description	The brake interl turer's guarante	. , ,	relay built into the	Servo Drive reach	ed the service life	of the manufac-	
Source	EtherCAT Maste ule			Slave	Detection timing	Continuously	
Error attributes	Level	Observation*1	Recovery		Log category	System log	
Effects	User program	Continues.	Operation	Not affected.			
Indicators	EtherCAT NET RUN		EtherCAT NET E	EtherCAT NET ERR		EtherCAT LINK/ACT	
indicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed caus	Assumed cause		Correction		Prevention	
	The number of o	perating times of	Send the Servo I	Orive for repair or	None		
Cause and	the brake interlo	ock output in the	replace the Servo Drive with a new				
correction	Servo Drive exc	eeded the ser-	one. It is necessary to replace the				
	vice life		component that reached the ser-				
			vice life.				
Attached	None						
information							
Precautions/	AL status code:	-, Error No.: A704	hex				
Remarks							

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

Event name	Encoder Comm	unications Warnin	g	Event code	083A0000 hex			
Description	Encoder commi	unications errors o	ccurred in series m	curred in series more frequently than the specified value.				
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously		
Error attributes	Level	Observation*1	Recovery		Log category	System log		
Effects	User program	Continues.	Operation	Not affected.				
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	ACT		
iliuicators								
System	Variable		Data type		Name			
-defined variables	None None		None					
	Assumed caus	e	Correction		Prevention			
Cause and	Noise into the e	ncoder cable	<ul> <li>Separate the mathematical thread to the encoder cannot be undled togeth</li> <li>Connect the shall the wire is connect</li> </ul>	ble if they are er. ield to FG. motor ground	<ul> <li>Separate the motor cable and the encoder cable if they are bundled together.</li> <li>Connect the shield to FG.</li> <li>Confirm that the motor ground wire is connected to FG.</li> </ul>			
correction	Contact failure of the encoder cable		Check whether the connector is disconnected. Connect the connector securely if it is disconnected or loose. Check that the encoder cable is not broken. Replace the encoder cable if it is broken.		Confirm that the connector is connected. Use the recommended cable and periodically check that the encoder cable is not broken.			
	Power supply u	ndervoltage to	_	Use the recommended encoder		ended encoder		
	the encoder		cable.		cable.			
Attached information	Attached inform	ation 1: System in	formation					
Precautions/ Remarks	AL status code:	-, Error No.: A400	hex					

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

Event name	Encoder Lifetim	e Warning		Event code	08470000 hex		
Description	The encoder life	etime is close to th	e end.				
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Observation*1	Recovery		Log category	System log	
Effects	User program	Continues.	Operation	Not affected.		_	
Indicators	EtherCAT NET RUN		EtherCAT NET E	RR	EtherCAT LINK/ACT		
mulcators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
	Assumed caus	е	Correction		Prevention		
Cause and	Temporary noise	е	If this event occu	If this event occurs repeatedly, the		None	
correction	The end of the	encoder life	lifetime is close to the end.				
			Replace the motor	or.			
Attached	None						
information							
Precautions/	AL status code:	-, Error No.: A706	hex				
Remarks							

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

Event name	Fan Rotation W	arning		Event code	084C0000 hex	
Description	The rotation spe	eed of the fan is 80	% or less of the ra	ting and the coolin	ig performance ded	creases.
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	Continuously
Error attributes	Level	Observation*1	Recovery		Log category	System log
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT
mulcators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed caus	е	Correction		Prevention	
	There is a forei	gn matter in the	Check whether there is a foreign		Do not use the fan in an area sur-	
Cause and	cooling fan and	it blocks the rota-	matter in the fan. If you find a for-		rounded by excessive foreign mat-	
correction	tion		eign matter, remove it.		ter. Also, do not allow foreign	
	Cooling fan failu	ıre	If there is no improvement after		matter to enter.	
			you performed the correction			
			above, replace th	e Servo Drive.		
Attached	None					
information						
Precautions/	AL status code:	-, Error No.: A300	hex			
Remarks						

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

Event name	Absolute Encod	er Counter Overflo	w Warning	Warning <b>Event code</b> 084E 0000 hex			
Description		on counter of the ei ing Level (4510-0		ne value set in <b>En</b>	coder - Absolute	Encoder Counter	
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Observation*1	Recovery		Log category	System log	
Effects	User program	Continues.	Operation	Not affected.			
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	/ACT	
illuicators							
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed caus	e	Correction		Prevention		
	An inappropriate value was set in		Set an appropria	te value in the	Set an appropria	ate value in the	
	the Encoder - Operation Selec-		Encoder - Operation Selection		Encoder - Operation Selection		
	tion when Using Absolute		when Using Absolute Encoder		when Using Absolute Encoder		
Cause and	Encoder (4510-01 hex)		(4510-01 hex).		(4510-01 hex).		
correction		The multi-rotation number of the		Set the travel distance so that the		Set the travel distance so that the	
	encoder exceeded the warning		multi-rotation number does not		multi-rotation number does not		
	level		exceed the value set in the		exceed the value set in the		
			Encoder - Absolute Encoder Counter Overflow Warning		Encoder - Absolute Encoder Counter Overflow Warning		
			<b>Level</b> (4510-02 hex).		<b>Level</b> (4510-02 hex).		
Attached	None						
information							
Precautions/	AL status code:	-, Error No.: AB00	hex				
Remarks							

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

Event name	Lifetime Information Corruption Warning		Event code	18390000 hex		
Description	An error was de	tected in the save	d lifetime informati	on.		
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	At power ON
Error attributes	Level	Observation*1	Recovery		Log category	System log
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	/ACT
mulcators						
System	Variable		Data type		Name	
-defined	None None		None		None	
variables				Prevention		
	Assumed cause		Correction	Correction		
	The lifetime information corrup-		Perform the Lifetime Information		None	
		tion was detected when the		Clear. Note that the lifetime may		
Cause and	power supply was turned ON		not be detected correctly after the			
correction			clear operation because the value			
			of lifetime information is cleared. If			
			this event occurs repeatedly, the			
				area to save lifetime information is faulty. Replace the Servo Drive.		
Attached	None		lauity. Replace tr	le Servo Drive.		
information	I None					
Precautions/	Al status code:	-, Error No.: A705	hex			
Remarks		,				

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

F	D-4- O-44: W	Data 0.45 m Marrian						
Event name	Data Setting Warning			Event code	34E00000 hex			
Description	The object set v	alue is out of the r	ange.					
Source	EtherCAT Maste ule			Slave	Detection timing	Continuously		
Error attributes	Level	Observation*1	Recovery		Log category	System log		
Effects	User programContinues.OperationNot affected.							
Indicators	Indicators EtherCAT NET RUN		EtherCAT NET E	EtherCAT NET ERR		EtherCAT LINK/ACT		
mulcators								
System	Variable		Data type		Name			
-defined	None		None		None			
variables								
Cause and	Assumed caus	e e	Correction		Prevention			
correction	The object set v	alue is out of the	Correct the object	t setting to be	Correct the object setting to be			
COTTCCTION	range		within the specified range.		within the specified range.			
Attached	None							
information								
Precautions/	AL status code:	-, Error No.: B000	hex					
Remarks								

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

Event name	Overload Warni	ng		Event code	387A 0000 hex		
Description		of Servo Drive or vel (4150-01 hex)	motor (4150-81 he	x) exceeded the le	vel set in the Ove	rload - Warning	
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	Continuously	
Error attributes	Level	Observation*1	Recovery		Log category	System log	
Effects	User program		Operation	Not affected.			
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/ACT		
System	Variable		Data type		Name		
-defined variables	None		None		None		
	Assumed caus		Correction		Prevention		
	Operation was		Perform the follow	ving corrections		given for correc-	
	long time with h	iigh load.	accordingly.			and take counter-	
			Increase the se		measures as rec	julieu.	
			acceleration/deceleration time and the stop time.				
			Lighten the load.				
			Adjust the gain				
				<ul> <li>If torque waveforms oscillate excessively, adjust the system</li> </ul>			
			•	that the oscilla-			
				tion does not occur.			
Cause and				• Set the appropriate brake timing.			
correction			<ul> <li>Increase the capacities of the Servo Drive and the motor.</li> </ul>				
	There is incorre	-		Connect the motor cable as		or cable as shown	
	motor cable or a	a broken cable		shown in the wiring diagram. If		in the wiring diagram. Connect the	
			the cable is broken, replace it.  Or, connect the motor cable and encoder cable that are used		motor cable and	encoder ncoder cable that	
					are used together		
			together to the		motor.		
			Measure the vol				
			brake terminal.				
			applied, release				
	Increase in fricti	ion	Check machine or remove the cause		Take countermed		
			remove the cause	e of the inction.	machine distortion ated.	on is not gener-	
Attached	Attached Inform	nation 1: Cause De	etails				
information	1: The Servo Dr	rive is overloaded					
omiation	2: The Servomo	otor is overloaded					
Precautions/ Remarks	AL status code:	-, Error No.: A000	hex				
*4 >4							

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

Event name	Regeneration O	Regeneration Overload Warning			387D0000 hex	
Description	The Regenerat	ion Load Ratio (4	310-81 hex) excee	ded 85% of the re	generation overloa	nd ratio.
Source	EtherCAT Maste ule	er Function Mod-	Source details	Slave	Detection timing	Continuously
Error attributes	Level	Observation*1	Recovery		Log category	System log
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT
System	Variable		Data type		Name	
-defined variables	None		None		None	
	Assumed cause Correction Prevention		Prevention			
	The regeneration set inappropriate	•	Check the regenering setting, and set as the resistance Regeneration Res	et the same value value of the	Check the items tions in advance measures as req	and take counter-
	The Regeneration Resistor is selected inappropriately		velocity monitor. (ratio of Regeneral perform the follow accordingly.  Increase the deand stopping tin	Check the operation pattern by the velocity monitor. Check the load ratio of Regeneration Resistor, and perform the following corrections accordingly.  Increase the deceleration time and stopping time.		
Cause and correction			<ul> <li>Decrease the command velocity to the motor.</li> <li>Use an External Regeneration Resistor.</li> </ul>			
			<ul> <li>Increase the ca Servo Drive and</li> </ul>	•		
	The Regeneration used for continutive braking		•	The Regeneration Resistor can- not be used for continuous regen-		legeneration inuous regenera-
	The applied pov age is higher the value		Apply the powers be the specified v		Review the power supply voltage to be the specified value before use.	
	Regeneration Resistor failure		Check whether the Regeneration Resistor is faulty, and use one without failures.		Confirm that the Resistor is not fa	•
Attached information	None					
Precautions/ Remarks	AL status code:	-, Error No.: A100	hex			

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

Event name	Motor Vibration	Warning		Event code	387E 0000 hex		
Description		tion, which was hi hex), was detecte	-	to the level set in t	ne Vibration Dete	ection - Detection	
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	During Servo ON	
Error attributes	Level	Observation*1	Recovery		Log category	System log	
Effects	User program	Continues.	Operation	Not affected.			
Indicators	EtherCAT NET RUN		EtherCAT NET I	RR	EtherCAT LINK	/ACT	
indicators							
System	Variable	Variable			Name		
-defined	None	None		None		None	
variables							
	Assumed cause		Correction	Correction			
	The control parameter is set		Set the control parameters such as		Set and use the appropriate con-		
	inappropriately		inertia ratio, gain, and filter to		trol parameter.		
			appropriate values by gain tuning				
Cause and			or manually.				
correction	The rigidity deci	reased due to	Check whether the mechanical		Secure the mechanical system		
	mechanical loos	mechanical looseness or wear		system is not loose and secure it		firmly without the looseness.	
			firmly. If the rigidity of mechanical				
			system is changed, adjust the con-				
			trol parameter again.				
Attached	None						
information							
Precautions/	AL status code:	-, Error No.: A600	hex				
Remarks							

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 1 Selection (4020-05 hex).

Event name	Command Warning			Event code	78220000 hex	
Meaning	A command cou	ıld not be executed	d.		•	
Source	EtherCAT Maste	er Function Mod-	Source details	Slave	Detection timing	Continuously
Error attributes	Level	Level Observation*1 Recovery			Log category	System log
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK	ACT
ilidicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed caus	e	Correction		Prevention	
	The Switch on o	command was	Send the Switch	on command with	Use the Servo D	rive after confirm-
	received		the main circuit p	ower supply ON.	ing the correction	ns that are given
	The Enable ope	eration command	Send the Enable		on the left.	
	was received		mand under the f	ollowing condi-		
			tions.			
			In supported operation mode			
			The motor rotation speed is 30			
			r/min or less.  In the free-run mode, the interpolation time period is the inte-			
			gral multiple of the communications cycle.			
Cause and	An operation command in the		Check status of the Drive Prohibi-		-	
correction		tion was received	tion Input and So			
	after the immed		Limit by the Digital inputs, Sta-			
	Drive Prohibition Input or Soft-		tusword, and Software Position			
	ware Position Li		Limit. Then, do not issue the com-			
			mand in the drive prohibition direc-			
			tion.			
	Homing started		Set a supported number of the Homing method for homing. Start homing at the timing of when homing is not performed.		1	
	The positioning	start command	Set a supported value for bit 5 and		1	
	was received in	the Profile posi-	6 in the Controlword.			
	tion mode					
Attached	None					
information						
Precautions/	AL status code:	-, Error No.: B100	hex			
Remarks						

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 3 Selection (4020-07 hex).

Event name	EtherCAT Communications Warning Event code		84B00000 hex	84B00000 hex		
Description	An EtherCAT communications error occurred more than one time.					
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	Continuously
Error attributes	Level	Observation*1	Recovery		Log category System	
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherCAT NET	RUN	EtherCAT NET E	RR	EtherCAT LINK/	ACT
indicators						
System	Variable	Variable Data type		Name		
-defined variables	None		None		None	
	Assumed cause		Correction		Prevention	
Cause and correction	An EtherCAT communications cable has a contact failure, or is connected incorrectly or broken		Connect the EtherCAT communications cable securely. If the cable is broken, replace it.		Confirm that the EtherCAT communications cable is not broken, and connect is securely before use.	
	Noise		Take noise countermeasures so that the noise does not affect the EtherCAT communications cable.		Take noise countermeasures so that the noise does not affect the EtherCAT communications cable.	
Attached information	None					
Precautions/ Remarks	AL status code: -, Error No.: B200 hex					

<sup>\*1.</sup> You can change the level to minor fault by using Warning Level Change 3 Selection (4020-07 hex).

Event name	Unit Restarted			Event code	90A00000 hex	
Description	Restart was performed.					
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	Operation by user
Error attributes	Level	Information	Recovery		Log category	System log
Effects	User program	Continues.	Operation	Not affected.		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
indicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
Cause and	Assumed caus	е	Correction		Prevention	
correction	Restart was per	formed				
Attached	None					
information						
Precautions/	AL status code:	8000 hex, Error N	lo.: -			
Remarks						

Event name	STO Detected		98210000 hex			
Description	The safety input OFF state was detected via the safety input signal or EtherCAT communications.					
Source	EtherCAT Master Function Mod- ule		Source details	Slave	Detection timing	Continuously
Error attributes	Level	Information*1	Recovery		Log category	System log
Effects	User program	Continues.	Operation	Power drive circu	uit is OFF	
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
indicators						
System	Variable		Data type		Name	
-defined	None		None		None	
variables						
	Assumed cause		Correction		Prevention	
	The cable is disconnected or bro-		Reconnect the input wiring for		Connect the input wiring for safety	
	ken		safety inputs 1 and 2. If the cable		inputs 1 and 2 securely.	
Cause and	is broken, replace it.					
correction	The STO input was turned OFF		Remove the cause that turned		Improve the surrounding environ-	
					1 · ·	
	via EtherCAT co		OFF the safety in		ment based on t	
			OFF the safety in Safety Input Unit.			safety input signal
Attached			,		turned OFF the	safety input signal
Attached information	via EtherCAT co		,		turned OFF the	safety input signal
	via EtherCAT co		Safety Input Unit.		turned OFF the	safety input signal

<sup>\*1.</sup> You can change the level to minor fault by using Information Level Change Selection (4030-01 hex).

Event name	Memory All Cleared			Event code	98220000 hex		
Meaning	The Unit setting was cleared.						
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	Operation by user	
Error attributes	Level	Information	Recovery		Log category	System log	
Effects	User program	Continues.	Operation	Not affected.	·		
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT		
indicators							
System	Variable		Data type		Name		
-defined	None		None		None		
variables							
Cause and	Assumed caus	е	Correction		Prevention		
correction	Clear All Memor	ry was performed					
Attached	None						
information							
Precautions/	AL status code:	-, Error No.: -					
Remarks							

Event name	Event Log Cleared			Event code	98240000 hex	
Meaning	The event log was cleared.					
Source	EtherCAT Master Function Module		Source details	Slave	Detection timing	Operation by user
Error attributes	Level	Information	Recovery		Log category	System log
Effects	User program	Continues.	Operation	Not affected.	affected.	
Indicators	EtherCAT NET RUN		EtherCAT NET ERR		EtherCAT LINK/ACT	
indicators						
System	Variable		Data type		Name	
-defined variables	None		None		None	
Cause and	Assumed cause		Correction		Prevention	
correction	Clear Event Log	y was performed				
Attached	None				•	
information						
Precautions/	AL status code:	-, Error No.: -				
Remarks						

Appendices



## Index

## Index

Numerics	<u>w</u>		
7-segment LED Display6-5	Warning List7-8		
A			
Absolute encoder2-4			
Accessories			
AL Status Code List			
C			
Checking the Error Occurrence			
Control Circuit Connector (CND)3-5			
E			
Encoder			
Encoder Connector (CN2)			
Error List			
Event code			
I			
Information7-13			
L			
LED6-5			
M			
Main Circuit Connector (CNA)			
Main Circuit Connector A (CNA)3-5			
Main Circuit Connector B (CNB)3-5			
Motor Connector (CNC)3-4, 3-6			
S			
Servo Drive			
Characteristics3-2			
How to Read Model Numbers2-4			
Replacing7-4			
Servo Drive and Servomotor Combination Tables 2-6			
Servomotor			
Characteristics			
General Specifications			
Installation Conditions			
Model Tables			
Replacing7-4 Servo Drive and Servomotor Combination Tables 2-6			
Servomotor model number 2-4			

Sysmac Studio ......1-2, 2-2, 6-8

## **OMRON Corporation** Industrial Automation Company

Kyoto, JAPAN Contact: www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

438B Alexandra Road, #08-01/02 Alexandra Technopark, Singapore 119968 Tel: (65) 6835-3011 Fax: (65) 6835-2711 OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222 Fax: (86) 21-5037-2200 Authorized Distributor:

©OMRON Corporation 2016-2022 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. I619-E1-02 0922