



Programmable Multi-Axis Controller

Startup Guide for 1S-Series Servo Drive (IDEv4)

CK5M-CPU□1

CK3M-CPU□1

CK3E-□□□□

Startup
Guide

About Copyrights and Trademarks

Microsoft product screen shots are reprinted with permission from Microsoft Corporation.

Windows is a registered trademark of Microsoft Corporation in the United States and other countries.

EtherCAT® is a patented technology and registered trademark licensed by Beckhoff Automation GmbH, Germany.

Sysmac is a trademark or registered trademark of OMRON Corporation in Japan and other countries for OMRON factory automation products.

Company names and product names in this document are trademarks or registered trademarks of their respective companies.

Contents

1.	Related Manuals.....	4
2.	Terms and Definitions.....	5
3.	Precautions	6
4.	Overview	7
5.	Applicable Devices and Device Configuration	8
5.1.	Applicable Devices.....	8
5.2.	Device Configuration.....	9
6.	EtherCAT Connection Procedure	10
6.1.	Workflow	10
6.2.	Preparation for the Controller Setup.....	12
6.3.	Installation of ESI Files.....	17
6.4.	EtherCAT Communications Setup.....	18
6.5.	Controller Settings.....	26
7.	Appendix Saving and Loading a Project.....	37
7.1.	Saving a Project.....	37
7.2.	Loading and Downloading a Project.....	39
8.	Appendix Using Safety Function.....	42
8.1.	Device Configuration.....	42
8.2.	Workflow	42
8.3.	EtherCAT Coupler Unit Settings.....	44
8.4.	Preparation for the Controller Setup.....	56
8.5.	Installation of ESI Files.....	56
8.6.	EtherCAT Communications Setup.....	56
8.7.	Controller Settings.....	67
9.	Appendix Troubleshooting.....	68
9.1.	Factors Causing EtherCAT Communications To Be Unavailable, and Corrective Actions	68
9.2.	How to Check for Errors.....	69
10.	Appendix ECAT[i] Structure Elements	73
11.	Revision History.....	74

1. Related Manuals

To ensure system safety, always read and follow the information provided in all Safety *Precautions* and *Precautions for Safe Use* in the manuals for each device that is used in the system.

The following shows the manuals for OMRON Corporation (hereafter referred to as OMRON) and Delta Tau Data Systems, Inc (DT).

Manufacturer	Manual No.	Model	Manual name
OMRON	I610-E1	Model CK3E-1□10	CK3E-series Programmable Multi-Axis Controller Hardware User's Manual
OMRON	O036-E1	Model CK3M-CPU1□1 Model CK5M-CPU1□1	CK3M-series Programmable Multi-Axis Controller Hardware User's Manual
OMRON	I586-E1	Model R88M-1L□/-1M□ Model R88D-1SN□-ECT	AC Servomotors/Servo Drives 1S-series with Built-in EtherCAT® Communications User's Manual
OMRON	Z930-E1	Model NX-SL□□□□□ Model NX-SI□□□□□ Model NX-SO□□□□□	Safety Control Unit User's Manual
OMRON	Z930-E1	Model NX-SL□□□□□	Safety Control Unit Instructions Reference Manual
DT	O014-E	-	Power PMAC User's Manual
DT	O015-E	-	Power PMAC Software Reference Manual
DT	O016-E	-	Power PMAC IDE Users Manual

2. Terms and Definitions

Term	Explanation and Definition
Slave	Slaves are devices connected to EtherCAT. There are various types of slaves such as servo drivers handling position data and I/O terminals handling the bit signals.
Object	Represents information such as in-slave data and parameters.
PDO communications (Communications using Process Data Objects)	One type of EtherCAT communications in which Process Data Objects (PDOs) are used to exchange information cyclically and in real time. This is also called “process data communications”.
PDO Mapping	The association of objects used for PDO communications.
PDO Entry	PDO entries are the pointers to individual objects used for PDO mapping.
ESI file (EtherCAT Slave Information file)	An ESI file contains information unique to the EtherCAT slaves in XML format. You can load ESI files into the Power PMAC IDE, to easily allocate slave process data and make other settings.
ENI file (EtherCAT Network Information file)	An ENI file contains the network configuration information related to EtherCAT slaves.
Power PMAC IDE	This computer software is used to configure the Controller, create user programs, and monitor the programs. PMAC is an acronym for Programmable Multi-Axis Controller.

3. Precautions

- (1) Understand the specifications of devices that are used in the system. Allow some margin for ratings and performance. Provide safety measures, such as for installing a safety circuit, in order to ensure safety and minimize the risk of abnormal occurrences.
- (2) To ensure system safety, always read and follow the information provided in all *Safety Precautions* and *Precautions for Safe Use* in the manuals for each device that is used in the system.
- (3) The user is encouraged to confirm the standards and regulations that the system must conform to.
- (4) It is prohibited to copy, reproduce, or distribute all or part of this document without the permission of OMRON Corporation.
- (5) The information contained in this document is current as of September 2022.
It is subject to change without prior notice for improvement purposes.

The following notations are used in this document.

 WARNING	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or may result in serious injury or death. Additionally, there may be severe property damage.
 Caution	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or property damage.



Precautions for Correct Use

Precautions on what to do and what not to do to ensure correct operation and performance.



Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operations easier.

Symbols



The filled circle symbol indicates operations that you must carry out.
The specific operation is shown in the circle and explained in text.
This example indicates a “general precaution” for something that you must carry out.

4. Overview

This document describes the procedures used to operate the OMRON servo drivers (1S-series EtherCAT communication built-in type, hereafter referred to as Servo Driver) using the motion program for OMRON Programmable Multi-Axis Controller (hereafter referred to as the Controller), model CK3E-□□□□/CK3M-CPU1□1/ CK5M-CPU1□1/, as well as for checking the operation.

In the document, Servo Driver and servomotors to be connected are collectively called motion control devices. Servo Driver may also be referred to as a slave depending on the explanation.

Refer to *Section 6. EtherCAT Connection Procedure* to learn about the setting methods and key points to perform PDO communications via EtherCAT. In this document, the motion program is used to check operations.

Caution

The range of usage of this document is checking the connection of motion control devices connected via EtherCAT. When using instructions and constructing systems that are not described in this document, always read and follow the information provided in all *Safety Precautions* and *Precautions for Safe Use* in the manuals for each device that is used in the system.



5. Applicable Devices and Device Configuration

5.1. Applicable Devices

The applicable devices are as follows:

Manufacturer	Name	Model
OMRON	Programmable Multi-Axis Controller	Model CK3E-□□□□
OMRON	Programmable Multi-Axis Controller	Model CK3M-CPU1□1 Model CK5M-CPU1□1
OMRON	Servo Driver	Model R88D-1SN□-ECT
OMRON	AC Servomotor	Model R88M-1□□□□□□-□



Precautions for Correct Use

In this document, the devices with models and versions listed in *Section 5.2* are used as examples of applicable devices to describe the procedures to connect the devices and check their connections.

You cannot use devices with versions lower than the versions listed in *Section 5.2*.

To use the devices mentioned above with models not listed in *Section 5.2* or versions higher than those listed in *Section 5.2*, check the differences in the specifications by referring to the manuals before operating the devices.




Additional Information

This document describes the procedures to establish the network connections. It does not provide information on operations, installations, wiring methods, device functionalities, or device operations, which are not related to the connection procedures. For more information, refer to the manuals or contact your OMRON representative.

5.2. Device Configuration

The hardware components to reproduce the connection procedures in this document are as follows:



Manufacturer	Name	Model	Version
OMRON	Programmable Multi-Axis Controller	Model CK□M-CPU1□1	Ver.2.7
OMRON	Servo Driver (1S-series with Built-in EtherCAT Communications)	Model R88D-1SN01L-ECT	Ver.1.0
OMRON	Ethernet cable (with industrial Ethernet connector)	Model XS5W-T421-□M□-K	
DT	Power PMAC IDE		Ver.4.6



Precautions for Correct Use

Prepare the ESI file described in this section in advance. Contact your OMRON representative for information on how to procure the ESI file.



Precautions for Correct Use

Do not share the connection line of EtherCAT communications with other Ethernet networks.
Do not use devices for Ethernet such as a switching hub.
Use the Ethernet cable (double shielding with aluminum tape and braiding) of Category 5 or higher, and use the shielded connector of Category 5 or higher.
Connect the cable shield to the connector hood at both ends of the cable.



Additional Information

This document describes model CK3M-CPU1□1as an example. The same procedures can apply to model CK5M-CPU1□1/CK3E-□□□□□/.

6. EtherCAT Connection Procedure

This section describes the procedures to connect the Controller and Servo Driver via EtherCAT, and to operate the motion control devices. The description assumes that the Controller is set to factory default.

⚠ WARNING

If an uninitialized Controller is used, the motion control devices may perform unexpected operations upon power-on depending on the Controller status, resulting in a personal injury to the user.

To prevent unexpected operations of motion control devices, be sure to initialize the Controller before connecting the motion control devices and the Controller via Ethernet cable.



6.1. Workflow

Take the following steps to operate the motion control devices after connecting the Controller and Servo Driver via EtherCAT.

6.2 Preparation for the Controller Setup

Prepare the Controller settings.



6.2.1 Creation of a New Project



6.2.2 Initial Settings of the Controller



6.3 Installation of ESI Files

Install the ESI file for Servo Driver into Power PMAC IDE.



6.4 EtherCAT Communications Setup

Set up EtherCAT communications.



6.4.1 Communications Setup for the EtherCAT Master



6.4.2 Distributed Clock Setup



6.4.3 PDO Map Settings



6.4.4 Creation of an EtherCAT Network Information File



6.5 Controller Settings

Set up the Controller.



6.5.1 EtherCAT Communications Check

▼

6.5.2 Motor Setup

▼

6.5.3 Creation of Operation Check Programs

▼

6.5.4 Project Data Transfer and Operation Check

6.2. Preparation for the Controller Setup

Prepare the Controller settings.

Install Power PMAC IDE on the computer in advance.

6.2.1. Creation of a New Project

1 Turn on the power to the Controller.


2 Start Power PMAC IDE.

- * If the dialog for confirming access rights appears upon start-up, select starting of Power PMAC IDE.




3 The Communication screen appears. Specify the IP address of the destination Controller and click **Connect**.


- * The IP address of the Controller is set to "192.168.0.200" by default.
- * If necessary, change the Windows IP address to "192.168.0.X".




4 Power PMAC IDE starts, and is online to the Controller.



- 5** From the **File** menu, select **New** then **Project**.



- 6** Enter a project name, and select **OK**.



6.2.2. Initial Settings of the Controller


Configure the initial settings for the Controller.




Precautions for Correct Use

Configuring the initial settings clears all data in the Controller memory. Back up necessary data in advance.

- 1** In the Terminal tab page, type the \$\$\$*** command to reset the Controller to factory default.



- 2** Select **System – CPU – System** in the Solution Explorer.





- 3** Select Clock Settings.





4 Specify **Servo Frequency**.

Select the **Servo Frequency** setting from 4 kHz, 2 kHz, or 1 kHz.




5 Click the **Accept** button.

6 If you have changed the servo frequency setting, type the save command in the Terminal tab page of Power PMAC IDE. When complete, the "Save Complete" message appears in the Terminal tab page.

7 Click **Delta Tau – Communication Setup** on the toolbar to display the Communication Setup dialog box.

-
- 8** In the Device Properties dialog box, click the **No Device** button.

This operation sets the Controller to the offline state.




-
- 9** Restart the Controller.

The servo frequency that has been set is reflected.

-
- 10** Wait until the startup process of the Controller is complete. Then click **Delta Tau – Communication Setup** on the toolbar to display the Device Properties dialog box. In the Communication Setup dialog box, click the **Connect** button.

This operation sets the Controller to the online state.



6.3. Installation of ESI Files


Install the ESI file for Servo Driver into Power PMAC IDE.



Precautions for Correct Use



Prepare the ESI file described in this section in advance. Contact your OMRON representative for information on how to procure the ESI file.

- 1 From the **EtherCAT** menu of Power PMAC IDE, select **ESI Manager**.



- 2 Confirm that *Omron R88D-1SN01L-ECT.xml* is registered in the ESI file list of ESI Manager.

If it is not yet registered, click **Add File** and register *Omron R88D-1SNxxx-ECT.xml*.



- 3 Click **Close** to close the ESI Manager page.

6.4. EtherCAT Communications Setup

Set up EtherCAT communications.

⚠️ WARNING

Depending on the Controller status, unexpected operations of the motion control devices may occur when the power to the Controller is turned on, resulting in a personal injury to the user.



Pay attention to safety when the power is turned on.




Precautions for Correct Use

Before taking the following steps, make sure that the devices are connected via an Ethernet cable. If they are not connected, turn OFF the power to the devices, and connect the Ethernet cable.

6.4.1. Communications Setup for the EtherCAT Master


- 1** Connect the Controller with slave devices using an Ethernet cable.
* Refer to the manuals for slave devices to configure them.
- 2** Select **System – EtherCAT – Master0 (Deactivated)** in the Solution Explorer.



3

In the Master tab page, specify a communication period for **Cycle Time [us]**.

* You must specify the communication period in accordance with the servo frequency of the Controller. 1000 us is set in this document.



Correspondence between the servo frequencies of the Controller and communication periods is as follows:


4 kHz : 250 us

2 kHz : 500 us


1 kHz : 1000 us

4

Select **System – EtherCAT** in the Solution Explorer and right-click on **Master0 (Deactivated)**, then select **Scan EtherCAT Network**.




- 5** Make sure that the slave is displayed in the Solution Explorer.



6.4.2. Distributed Clock Setup


- 1** Setting Distributed Clocks (DC) for Master

In the Master0 (Deactivated) tab page, select **Distributed Clocks** tab.




2

Select Master Shift (EtherCAT Master Time controlled by Reference Clock).




3 Setting Distributed Clock (DC) for the Slave

In the Solution Explorer, select the target slave and display the Distributed Clock tab page.



4 Select the Overwrite Mode check box and specify Shift Time.



Correspondence between the servo frequencies of the Controller and the Shift Time values is as follows:

4 kHz : 125 us

2 kHz : 250 us

1 kHz : 500 us


6.4.3. PDO Map Settings

⚠ Caution

PDO entries without axis settings are subjected to PDO communications as indefinite values. For this reason, unexpected operations of the motion control devices may occur, resulting in a personal injury to the user.
Only objects to be configured in *Section 6.5.2. Motor Setup* must be mapped to PDO entries.



- 1** In the Solution Explorer, select the target slave and display the PDO Mapping tab page.



- 2** Setting PDO mapping (Inputs)

Make sure that the **258th transmit PDO Mapping 0x1B01** check box is selected in the Inputs field.

Inputs		
Touch probe pos1 pos value	0x60BA:00	32
Touch probe pos2 pos value	0x60BC:00	32
Error code	0x603F:00	16
<input checked="" type="checkbox"/> 258th transmit PDO Mapping		0x1B01
Name	Index	Bit Length
Error code	0x603F:00	16
Statusword	0x6041:00	16
Position actual value	0x6064:00	32
Torque actual value	0x6077:00	16
Following error actual value	0x60F4:00	32
Touch probe status	0x60B9:00	16
Touch probe pos1 pos value	0x60BA:00	32
Touch probe pos2 pos value	0x60BC:00	32
Digital inputs	0x60FD:00	32

Clear the **273th transmit PDO Mapping 0x1B10** check box if it is selected in the Inputs field.

Module 1 (Safety Process Data), 273th transmit PDO Mapping		
FSoE Slave Command	0xE600:01	8
STO Active	0x6640:00	1
...	0x0000:00	1
Error	0x6632:00	1
...	0x0000:00	1
Safety Connection Status	0xE601:01	1
FSoE Slave CRC_0	0xE600:03	16
FSoE Slave ConnectionID	0xE600:02	16

3 Setting PDO mapping (Outputs)

Make sure that the **258th receive PDO Mapping 0x1701** check box is selected in the Outputs field.


Outputs		
Name	Index	Bit Length
Controlword	0x6040:00	16
Target position	0x607A:00	32
Touch probe function	0x60B8:00	16
<input checked="" type="checkbox"/> 258th receive PDO Mapping	0x1701	16
Controlword	0x6040:00	16
Target position	0x607A:00	32
Touch probe function	0x60B8:00	16
Physical outputs	0x60FE:01	32

Clear the **273th receive PDO Mapping 0x1710** check box if it is selected in the Outputs field.


Module 1 (Safety Process Data) 273th receive PDO Mapping		
Name	Index	Bit Length
FSoE Master Command	0xE700:01	8
STO	0x6640:00	1
---	0x0000:00	1
Error Ack	0x6632:00	1
---	0x0000:00	1
FSoE Master CRC_0	0xE700:03	16
FSoE Master ConnectionID	0xE700:02	16

6.4.4. Creation of an EtherCAT Network Information File


- Select **System – EtherCAT** in the Solution Explorer and right-click on **Master0 (Deactivated)**, then select **Load Mapping to PowerPMAC**.



- 2** An eni.xml file is added under the **Configuration** directory in the Solution Explorer.



- 3** An ECATMap.pmh file is added under the **PMAC Script Language/Global Includes** directory in the Solution Explorer.




6.5. Controller Settings

6.5.1. EtherCAT Communications Check

Take the following steps to ensure that EtherCAT communications are available.

- 1** From the Terminal tab page, run the ECAT[0].Enable=1 command to start EtherCAT communications.




- 2** In the Terminal tab page or Watch Window, make sure that the ECAT[0].Enable value turns to 1.

*The OP mode is entered and EtherCAT communications are established.

Watch Window	
Command/Query	Response
Sys.ServoCount	6333036
ecat[0].Enable	1
ecat[0].MasterState	8

- 3** After making sure that correct communications are available, run the ECAT[0].Enable=0 command from the Terminal tab page to stop EtherCAT communications.




- 4** In the Terminal tab page or Watch Window, make sure that the ECAT[0].Enable value turns to 0.

Watch Window	
Command/Query	Response
Sys.ServoCount	6370960
ecat[0].Enable	0
ecat[0].MasterState	2

6.5.2. Motor Setup


Configure the motor settings for the Controller.

- 1** Select **System – Motor** in the Solution Explorer and right-click on it, then select **Add a Motor....**




- 2** Adding motor #1

Specify **1** for Motor Number, EtherCAT for Topology and click the **OK** button.



- 3** Select **EtherCAT Slave Drive**.




4


Setting EtherCAT Slave Drive

Specify the slave drive as shown on the right.

Click the **save** button to apply the settings.

**5**


Select Hardware Interface.



6

Specify the settings as shown on the right.

Click the **Accept** button to apply the settings.



Command Signal Channel

Select **#x607A(Target Position)**, and specify the motor control indication value for **Target Position**.

Amplifier Enable Signal Output Channel

Select **#x6040(Controlword)**, and specify **Controlword** for the motor output.

Amplifier Fault Signal Input Channel

Select **#x6041(Statusword)**, and specify **Statusword** for the motor input.

Primary Feedback Channel

Select **#x6064(Position actual value)**, and specify **Position actual value** for the motor control feedback.


6.5.3. Creation of Operation Check Programs

Create programs to be used to check operations.

A specific language is used for the operation check programs. Refer to *Power PMAC User's Manual* and *Power PMAC Software Reference Manual* for details.

1 Creating the Motion program

In the Solution Explorer, open
Project name – PMAC Script
Language – Motion Programs
– prog1.pmc.



2 In the programming area of the prog1.pmc tab page, write a program as shown on the right.


This example program rotates a motor in the normal direction, stops the rotation, then repeats rotation in the reverse direction and stops.

```
&1;  
#1->8388608X;  
  
OPEN PROG 1  
  
INC;  
TA800;  
TS300;  
LINEAR;  
While (1 < 2)  
{  
    TA800;  
    TS300;  
    TM3000;  
    X10;  
    DWELL2000;  
    X-10;  
    DWELL2000;  
}  
  
CLOSE
```

3

Creating the PLC program

In the Solution Explorer, open
**Project name – PMAC Script
Language – PLC Programs –
plc1.plc.**



4

In the programming area of the plc1.plc tab page, write a program as shown on the right.


This example program turns a servo ON, starts user program 1 for the motor, then exits periodic execution of the PLC user program.

open plc 1

```
while(sys.ecatMasterReady==0){};  
ECAT[0].Enable=1;  
P1000=Sys.Time+1;  
while(P1000>Sys.Time){};  
cmd"&1enable";  
P1000=Sys.Time+5;  
while(P1000>Sys.Time){};  
cmd"&1b1r";  
disable plc 1;  
close
```

5 Setting the start of the user program

In the Solution Explorer, open
Project name – Configuration
– **pp_startup.txt**.



6 In the programming area of the **pp_startup.txt** tab page, add the program shown on the right to the last line.


enable plc 1;

The **pp_startup.txt** program is automatically executed when the Controller starts.
This example program runs the PLC1 script.

7

Setting motor control parameters

In the Solution Explorer, open **Project name – PMAC Script Language – Global Includes – global definitions.pmh.**

**8**

In the programming area of the global definitions.pmh tab page, write the set values to be set automatically upon power-on.

Example settings are shown on the right.

```
Motor[1].FatalFeLimit=0;  
Motor[1].AbortTa= -0.1;  
Motor[1].AbortTs= 0;  
Motor[1].MaxSpeed= 5000;  
Motor[1].JogTa= -0.1;  
Motor[1].JogTs= -1;  
Motor[1].JogSpeed= 1000;  
Motor[1].HomeVel= 1000;  
  
Coord[1].Tm=100;  
Coord[1].FeedTime=60000;  
Coord[1].MaxFeedRate=5000;  
Coord[1].Td=-0.1;  
Coord[1].Ta=-0.1;  
Coord[1].Ts=-1;
```

6.5.4. Project Data Transfer and Operation Check

Transfer the created project data to the Controller.

When a project is transferred, the program starts automatically and the motor starts rotating.

⚠ WARNING

When the user program and “configuration and setting” data are transferred from Power PMAC IDE, devices or the machine may perform unexpected operations. Therefore, before you transfer project data, ensure the destination slave is operating safely.



⚠ Caution

Transferring project data restarts the Controller and interrupts communications with slaves. The time that communications are interrupted depends on the EtherCAT network configuration.

Before you transfer project data, make sure that the slave settings will not adversely affect the devices.



⚠ Caution

The procedure provided in this section checks the operations of the motion control devices, which may perform unexpected operations.

Take adequate safety measures before starting the checking process described in this section. Do not start the checking process unless safety is ensured.

When performing the operation check, implement all the steps described in this section in order to put the output into a safe state.



- 1 In the Terminal tab page or Watch Window, make sure that the ECAT[0].Enable value is 0.

If the value is 1, run the ECAT[0].Enable=0 command from the Terminal tab page to stop EtherCAT communications.

Watch Window	
Command/Query	Response
Sys.ServoCount	8460869
ecat[0].Enable	0
ecat[0].MasterState	2


2

Downloading a project

Right-click the project name in the Solution Explorer on the upper right of the IDE screen, and select **Build and Download All Programs** to run the build and download.

* The transferred project is not yet saved on the Controller at this stage.

If you turn OFF the power to the Controller, the transferred project will be discarded.



3

Make sure that there are no errors in the Output Window.

* If the transfer fails, check details of the error in the Output Window.

If the error is a program error, you must review the program.

If the error is related to EtherCAT settings, return to 6.4 EtherCAT Communications Setup and check whether there are any incorrect settings.

4

The program starts running when it has been downloaded successfully.

Make sure that EtherCAT communications are in the OP state, and that the motor rotates.

* If the motor does not rotate, check that the ECAT[0].Enable value is 1 in the Terminal tab page or Watch Window.

If the value is 0, run the following command from the Terminal tab page.


enable plc 1



5 After you have confirmed an appropriate operation, save the project to the Controller.

Run the save command from the Terminal tab page.

* The save command stores the downloaded project in the Controller. This operation saves the settings to be executed automatically when the power to the Controller is turned on.



The screenshot shows a terminal window titled "Terminal". The text in the window reads:

```
Welcome to PowerPMAC terminal  
Select Device to start communication  
SSH communication to PowerPMAC at 192.168.0.200 successful  
disable plc 1  
ECAT[0].Enable = 0
```

In the bottom left corner of the terminal window, the word "save" is typed and highlighted with a red box. Below the terminal window, there is a navigation bar with tabs: "PowerPMAC Messages", "Terminal" (which is selected and highlighted in blue), "Terminal", and "Output".

7. Appendix Saving and Loading a Project

The following describes the procedures to save a Power PMAC IDE project on the computer, and to reuse it.


7.1. Saving a Project

1 Creating a Configuration File


Create a Configuration File to save parameters you have changed.

Right-click **Configuration** in the Solution Explorer, and select **Generate Config File**.


A Configuration File is added to **Configuration**.



2 Enter a file name in the textbox, then click the OK button.




3 Right-click on the Configuration File, and from the menu, select **Check To Download Config File** to include it in files to be downloaded.



4


Saving a Project

In the **File** menu, run **Save All** to save the project on the computer.




7.2. Loading and Downloading a Project


- 1 Start Power PMAC IDE, and connect to the Controller.
- 2 In the Terminal tab page, type the \$\$\$*** command to reset the Controller settings to factory default.



- 3 In the File menu, click Open – Project/Solution to load the project that you saved.




- 4 Right-click Configuration in the Solution Explorer, and select Download Config Files to download the file to the Controller.



- 5** Right-click the project name in the Solution Explorer, and select **Build and Download All Programs** to run the build and download.



When the download process is complete, make sure that there are no errors in the Output Window.





- 6** Stopping a program

If a program is running, execute the following command from the Terminal tab page to stop the program.

```
disable plc 1  
ECAT[0].Enable=0
```




7	<p>Saving the downloaded settings and programs</p> <p>After the download process is complete and you make sure that there are no errors in the Output Window, run the save command from the Terminal tab page.</p> <p>* The save command stores the downloaded project in the Controller. This operation saves the settings to be executed automatically when the power to the Controller is turned on.</p>	 <p>The screenshot shows the PowerPMAC terminal window. The title bar says "Terminal". The main area displays the following text: Welcome to PowerPMAC terminal Select Device to start communication SSH communication to PowerPMAC at 192.168.0.200 successful disable plc 1 ECAT[0].Enable = 0 A cursor is visible in the input field, showing the command "save".</p>
8	<p>Restarting after download</p> <p>Run the following command from the Terminal tab page to restart the Controller with the downloaded project.</p> <p>\$\$\$</p>	 <p>The screenshot shows the PowerPMAC terminal window. The title bar says "Terminal". The main area displays the following text: Saving To Flash: Mounting the flash Saving To Flash: Finished SAVING to flash Save Completed A cursor is visible in the input field, showing the command "\$\$\$".</p>

8. Appendix Using Safety Function


To use the STO function in EtherCAT communications, you need to configure the settings for the EtherCAT master and Safety CPU Unit.


8.1. Device Configuration

The following shows an example of hardware components connected to the safety controller.



8.2. Workflow






8.3. EtherCAT Coupler Unit Settings

Configure the slave terminal settings for the EtherCAT Coupler Unit.

Prepare a computer with Sysmac Studio installed.



Additional Information

For the setting procedures for the EtherCAT Coupler Unit and Safety CPU Unit, also refer to *Programmable Multi-Axis Controller Startup Guide for EtherCAT® Communication Coupler Safety Controllers and I/O Units*.

8.3.1. Creation of a New Project

1 Connect the coupler to the computer using a USB cable.

2 Turn on the power to the coupler and safety controller.


3 Start the Sysmac Studio.

* If the dialog for confirming access rights appears upon start-up, select starting of Sysmac Studio.




- 4** Create a project in the Sysmac Studio.

Enter **Project name** and other items of information. Select **1.10** for **Version**, then, click **Create**.




8.3.2. Network Configuration Settings


- 1** Double-click EtherCAT under **Configurations and Setup** in the Multiview Explorer.



- 2** Select EtherCAT Coupler Unit **NX-ECC203** in the toolbox, and drag and drop it directly below the master in the EtherCAT Configuration Edit tab page.




- 3** Select **R88D-1SN01L-ECT** in the toolbox, and drag and drop it directly below **NX-ECC203** in the EtherCAT Configuration Edit tab page.




Right-click **NX-ECC203** in the Multiview Explorer, and select **Coupler Connection (USB)** then **Online**.

After you have confirmed the destination of the USB connection, click the **OK** button.




4 Double-click **NX-ECC203** in the Multiview Explorer to open the NX-ECC203 edit page.

Right-click in the NX-ECC203 tab page and select **Compare and Merge with Actual Unit Configuration** from the menu.




5 Click **Apply Actual Unit Configuration** to apply the actual unit configuration.

When the setting is complete, click **OK**.



- 6** Right-click **NX-ECC203** in the Multiview Explorer, and select **Coupler Connection (USB)** then **Offline**.



Precautions for Correct Use

You can read only the Unit configuration in the Slave Terminal by comparing and merging with the actual Unit configuration. You cannot read the I/O allocation information, Unit operation settings, and Unit application data.


8.3.3. I/O Map Settings

- 1** Configure the PDO mapping settings for Servo Driver.

Select R88D-1SN01L-ECT, then click **Edit PDO Map Settings**.




- 2** In the Edit PDO Map Settings page, select **output 273th** and **input 273th**, then click **OK**.



- 3** In the Multiview Explorer, select **Configurations and Setup**, then **I/O map** tab page to open the I/O map pane.


Right-click on **NX-ECC203**, and select **Create Device Variable** from the menu.




Similarly, right-click on **R88D-1SN01L-ECT**, and select **Create Device Variable** from the menu.

- 4** From the controller selection box in the Multiview Explorer, select the target Safety CPU Unit.

Double-click **I/O map** to open the Safety I/O map tab page.




- 5** Right-click on **EtherCAT Network**, and select **Create Device Variable** from the menu.




8.3.4. Safety I/O Function Settings

- 1** From the controller selection box in the Multiview Explorer, select the target Safety CPU Unit.


Double-click **Parameters** under NX-SID800 of **Configurations and Setup**.




- 2** Select an output device according to the type of external device that is connected to the safety input terminal from the toolbox, and drag and drop it on to input terminal Si00



- 3** Double-click **Parameters** under NX-SOD400 of **Configurations and Setup**.




- 4** Select an input device according to the type of external device that is connected to the safety output terminal from the tool box, and drag and drop it on to output terminal So00.




8.3.5. Creation of Safety Programs

- 1** Registering programs

Right-click **Programs** under **Programming – POU**s in the Multiview Explorer, and select **Add – Programs** from the menu.



- 2** Drag a SF_EmergencyStop from the ToolBox to a new network where the words **Start Here** are displayed.



- 3** Select the tab for internal variables, and then register and edit the local variables.

Name : s_StartReset

DataType : SAFEBOOL

Initial Value : TRUE

	Name	Data Type	Initial Value	Constant	Comment
Internals	s_StartReset	SAFEBOOL	FALSE	<input type="checkbox"/>	
Externals	s_AutoReset	SAFEBOOL	FALSE	<input type="checkbox"/>	
	SF_EmergencyStop_0	SF_EmergencyStop		<input type="checkbox"/>	

Name : s_AutoReset

DataType : SAFEBOOL

Initial Value : TRUE

- 4** Register and edit the local variables.

Name : activate

DataType : SAFEBOOL

Initial Value : FALSE

	Name	Data Type	Initial Value	Constant	Comment
Internals	s_StartReset	SAFEBOOL	FALSE	<input type="checkbox"/>	
Externals	s_AutoReset	SAFEBOOL	FALSE	<input type="checkbox"/>	
	activate	SAFEBOOL	FALSE	<input type="checkbox"/>	
	SF_EmergencyStop_0	SF_EmergencyStop		<input type="checkbox"/>	

- 5** Select parameters on the FBD network and directly enter the variable names.

Activate : activate

E_StopIn:


N2_Si00_Logical_Value

S_StartReset : s_StartReset

S_AutoReset : s_AutoReset


S_EstopOut : E002_STO

	Name	Data Type	Initial Value	Constant	Comment
Internals	s_StartReset	SAFEBOOL	FALSE	<input type="checkbox"/>	
Externals	s_AutoReset	SAFEBOOL	FALSE	<input type="checkbox"/>	
	activate	SAFEBOOL	FALSE	<input type="checkbox"/>	
	SF_EmergencyStop_0	SF_EmergencyStop		<input type="checkbox"/>	




8.3.6. Transfer via Connection to the Communications Coupler Unit

- 1** From the controller selection box in the Multiview Explorer, select a Safety CPU Unit.




2 Select **Controller**, then **Communications Setup** from the menu.

Select **Connect via Coupler** in the Communications Setup dialog box, then click the **OK** button.




3 Select **Controller**, then **Online** from the menu.


The unit is in online connection with slave terminals.




4 From the controller selection box in the Multiview Explorer, select a Controller Unit.



5 In the edit page for slave terminals, right-click the Communications Coupler Unit, then select **Coupler Connection (USB) – Transfer to Computer**.



Click **Configuration information only** or **Configuration information + Unit operation settings + Unit application data**.




8.3.7. Output of Coupler I/O Allocations

1 Select **Controller**, then **Offline** from the menu.

2 Double-click **EtherCAT** under **Configurations and Setup** in the Multiview Explorer.


Right-click on **Master**, then select **Export All Coupler's I/O Allocations**.




8.3.8. Changing to DEBUG Mode

1 Select the Safety CPU Unit from the Controller Selection Box in the Multiview Explorer.


2 Select **Mode – DEBUG Mode** from **Controller** Menu.




3 The following mode confirmation Dialog Box is displayed. Click the **Yes** Button.




- 4** The following Connect to Safety Device Dialog Box is displayed. Click the **Yes** Button.



- 5** The following transfer confirmation Dialog Box is displayed. Click the safety of the system and then click the **Yes** Button.




- 6** The following password confirmation dialog box is displayed. When you use the DEBUG mode for the first time, or when the safety password is not specified, leave the **Password** field blank and click the **OK** button.




8.3.9. Performing Safety Validation


- 1** Select **Safety Validation** from the Controller Menu.



2 Click the **Yes** Button.




3 Click the **OK** Button




8.3.10. Changing to RUN Mode


1 Select **Mode – RUN Mode** from the **Controller** Menu.




2 Click the **Yes** Button.



3 Click the **Yes** Button.



4 Click the **OK** Button.



5

Click the **OK** Button.



8.4. Preparation for the Controller Setup

Perform the procedure provided in 6.2 *Preparation for the Controller Setup*.

8.5. Installation of ESI Files

Perform the procedure provided in 6.3 *Installation of ESI Files*.

8.6. EtherCAT Communications Setup

8.6.1. Communications Setup for the EtherCAT Master

Perform the procedure provided in 6.4.1 *Communications Setup for the EtherCAT Master*.

8.6.2. Synchronous Communications Setup

Perform the procedure provided in 0

Distributed Clock Setup.

8.6.3. Safety Controller Variable Settings

(1) Checking the coupler I/O allocations


Decompress the ZIP file you saved in 0

Output of Coupler I/O Allocations, open the expanded “CouplerMemoryMap.xml”, and check the contents.

(2) Setting Input Data

Register the following input data.


- Slot1(NX-SL3500)\Input Data Set1
- Slot1(NX-SL3500)\Input Data Set2

1	<p>Select a safety controller in the Solution Explorer of Power PMAC IDE.</p> <p>Display the Variables tab page.</p> 
---	--

2 [Slot1(NX-SL3500)Input Data Set1]

Registering Node1/Unit2
(NX-SID800)

Click **New** in the Variables tab page, and register 4 variables shown on the right.



FSoE Slave CMD	#x6020:01	USINT
----------------	-----------	-------

Group: Module 1(NX-SL3500).Input Data Set 1

Datatype: USINT

Count: 1

Safety Input 1st Word	#x6021:01	UINT
FSoE Slave CRC_0	#x6020:03	UINT
FSoE Slave Conn_ID	#x6020:02	UINT

Group: Module 1(NX-SL3500).Input Data Set 1

Datatype: UINT

Count: 3

3 [Slot1(NX-SL3500)Input Data Set1]

Registering Node1/Unit3
(NX-SOD400)

Click **New** in the Variables tab page, and register 4 variables shown on the right.

FSoE Slave CMD	#x6040:01	USINT
Safety Input 1st Byte	#x6041:01	USINT

Group: Module 1(NX-SL3500).Input Data Set 1

Datatype : USINT

Count : 2

FSoE Slave CRC_0	#x6040:03	UINT
FSoE Slave Conn_ID	#x6040:02	UINT

Group: Module 1(NX-SL3500).Input Data Set 1

Datatype : UINT

Count : 2

4

[Slot1(NX-SL3500)Input Data

Set1]

Registering Node2

Click **New** in the Variables tab page, and register 19 variables shown on the right.

FSoE Master CMD	#xE700:01	USINT
-----------------	-----------	-------

Group: Module 1(NX-SL3500).Input Data Set 1

Datatype : USINT

Count : 1

STO Command	#x6640:00	BOOL
-	-	BOOL
Error acknowledge	#x6632:00	BOOL
-	-	BOOL

Group: Module 1(NX-SL3500).Input Data Set 1

Datatype : BOOL

Count : 16

FSoE Slave CRC_0	#xE600:03	UINT
FSoE Slave Conn_ID	#xE600:02	UINT

Group: Module 1(NX-SL3500).Input Data Set 1

Datatype : UINT

Count : 2

5

[Slot1(NX-SL3500)Input Data

Set2]

Registering Safety CPU Status

Click **New** in the Variables tab page, and register the variable shown on the right.

Safety CPU Status	#x6004:01	UINT
-------------------	-----------	------

Group: Module 1(NX-SL3500).Input Data Set 2


Datatype: UINT

Count: 1

6

Checking Input Data

Make sure that the settings (Input) in the Variables tab page are correct.



(3) Setting Output Data


Register the following output data.

- Slot1(NX-SL3500)Output Data Set1
- Slot1(NX-SL3500)Output Data Set2

7

Select a safety controller in the Solution Explorer pane of Power PMAC IDE.

Display the Variables tab page.



8

[Slot1(NX-SL3500)Output Data Set1]

Registering Node1/Unit2 (NX-SID800)

Click **New** in the Variables tab page, and register 4 variables shown on the right.

FSoE Master CMD	#x7020:01	USINT
-----------------	-----------	-------

Group: Module 1(NX-SL3500).Output Data Set 1

Datatype: USINT

Count: 1

Safety Output 1st Word	#x7021:01	UINT
FSoE Master CRC_0	#x7020:03	UINT
FSoE Master Conn_ID	#x7020:02	UINT

Group: Module 1(NX-SL3500).Output Data Set 1

Datatype: UINT

Count: 3

9

[Slot1(NX-SL3500)Output Data

Set1]

Registering Node1/Unit3
(NX-SOD400)

Click **New** in the Variables tab
page, and register 4 variables
shown on the right.

FSoE Master CMD	#x7040:01	USINT
Safety Output 1st Byte	#x7041:01	USINT

Group: Module 1(NX-SL3500).Output Data Set 1

Datatype : USINT

Count : 2

FSoE Master CRC_0	#x7040:03	UINT
FSoE Master Conn_ID	#x7040:02	UINT

Group: Module 1(NX-SL3500).Output Data Set 1

Datatype : UINT

Count : 2

10 [Slot1(NX-SL3500)Output Data

Set1]

Registering Node2

Click **New** in the Variables tab page, and register three variables shown on the right.

FSoE Slave CMD	#xE600:01	USINT
----------------	-----------	-------

Group: Module 1(NX-SL3500).Output Data Set 1

Datatype : USINT

Count : 1

STO Command	#x6640:00	BOOL
-	-	BOOL
Error acknowledge	#x6632:00	BOOL
-	-	BOOL
Safety Connection Status	#x6010:01	BOOL

Group: Module 1(NX-SL3500).Output Data Set 1

Datatype : BOOL

Count : 16

FSoE Slave CRC_0	#xE600:03	UINT
FSoE Slave Conn_ID	#xE600:02	UINT

Group: Module 1(NX-SL3500).Output Data Set 1

Datatype : UINT

Count : 2


11 [Slot1(NX-SL3500)Output Data

Set2]

* *Output Data Set2* is not used and does not need to be set.

12 Checking Output Data

Make sure that the settings (Output) in the Variables tab page are correct.



8.6.4. PDO Map Settings


⚠ Caution

PDO entries without axis settings are subjected to PDO communications as indefinite values. For this reason, unexpected operations of the motion control devices may occur, resulting in a personal injury to the user.

Only objects to be configured in *Section 6.5.2. Motor Setup* must be mapped to PDO entries.



- In the Solution Explorer, select the target slave and display the PDO Mapping tab page.



2 Setting PDO mapping (Inputs)

Make sure that the **258th transmit PDO Mapping 0x1B01**, **273th transmit PDO Mapping 0x1B10** check boxes are selected.

Inputs		
Name	Index	Bit Length
Touch probe pos1 pos value	0x60BA:00	32
Touch probe pos2 pos value	0x60BC:00	32
Error code	0x603F:00	16
<input checked="" type="checkbox"/> 258th transmit PDO Mapping	0x1B01	
Name	Index	Bit Length
Error code	0x603F:00	16
Statusword	0x6041:00	16
Position actual value	0x6054:00	32
Torque actual value	0x6077:00	16
Following error actual value	0x60F4:00	32
Touch probe status	0x60B9:00	16
Touch probe pos1 pos value	0x60BA:00	32
Touch probe pos2 pos value	0x60BC:00	32
Digital inputs	0x60FD:00	32

3 Setting PDO mapping (Outputs)

Make sure that the **258th receive PDO Mapping 0x1701** and **273th receive PDO Mapping 0x1710** check boxes are selected.

Outputs		
1st receive PDO Mapping (excluded by 0x1701)		
Name	Index	Bit Length
Controlword	0x6040:00	16
Target position	0x607A:00	32
Touch probe function	0x60D8:00	16
<input checked="" type="checkbox"/> 258th receive PDO Mapping	0x1701	
Name	Index	Bit Length
Controlword	0x6040:00	16
Target position	0x607A:00	32
Touch probe function	0x60B8:00	16
Physical outputs	0x60FE:01	32

8.6.5. Coupler I/O and Variable Allocations

(1) Checking the coupler I/O allocations

Decompress the ZIP file you saved in 0

Output of Coupler I/O Allocations, open the expanded “CouplerCopyInfo.xml”, and check the contents.

(2) Setting Input Data

Associate the following items:

- **Module 1 (NX-SL3500).Input Data Set 1**, and **Module 2 (NX-SID800).Output Data Set 1**
- **Module 1 (NX-SL3500).Input Data Set 1**, and **Module 3 (NX-SOD400).Output Data Set 1**

1 Select Master in the Solution Explorer of Power PMAC IDE.

Display the Slave to Slave tab page.

2 Expand Slave_1001 [NX-ECC203] – Module 1 (NX-SL3500).Input Data Set 1 in Inputs.

Expand Slave_1001 [NX-ECC203] – Module 2 (NX-SID800).Output Data Set 1 in Outputs.

Select an Inputs item, then select the corresponding Outputs item and click >>.

3 Expand Slave_1001 [NX-ECC203] – Module 1 (NX-SL3500).Input Data Set 1 in Inputs.

Expand Slave_1001 [NX-ECC203] – Module 3 (NX-SOD400).Output Data Set 1 in Outputs.

Select an Inputs item, then select the corresponding Outputs item and click >>.

Associate the following items:


Inputs	Outputs
Variable 0	FSoE Master CMD
Variable 1	Safety Output 1st Word
Variable 2	FSoE Master CRC_0
Variable 3	FSoE Master Conn_ID

Associate the following items:

Inputs	Outputs
Variable 4	FSoE Master CMD
Variable 5	Safety Output 1st Word
Variable 6	FSoE Master CRC_0
Variable 7	FSoE Master Conn_ID

- 4** Expand Slave_1001
[NX-ECC203] – Module 1
(NX-SL3500).Input Data Set 1
in Inputs.
Expand **Slave_002 – Module 1**
(Safety Process Data). 273th
receive PDO Mapping in
Outputs.

Select an Inputs item, then select the corresponding Outputs item and click **>>**.



Associate the following items:

Inputs	Outputs
Variable 8	FSoE Master Command
Variable 9	
Variable 10	

(3) Setting Output Data

Associate the following items:


- **Module 2 (NX-SID800).Input Data Set 1, and Module 1 (NX-SL3500).Output Data Set 1**
- **Module 3 (NX-SOD400).Input Data Set 1, and Module 1 (NX-SL3500).Output Data Set 1**

- 5** Expand Slave_1001
[NX-ECC203] – Module 2
(NX-SID800).Input Data Set 1
in Inputs.

Expand **Slave_1001**
[NX-ECC203] – Module 1
(NX-SL3500).Output Data Set

1 in Outputs.

Select an Inputs item, then select the corresponding Outputs item and click **>>**.



Associate the following items:


Inputs	Outputs
FSoE Slave CMD	Variable 0
Safety Input 1st Word	Variable 1
FSoE Slave CRC_0	Variable 2
FSoE Slave Conn_ID	Variable 3

- 6** Expand Slave_1001
[NX-ECC203] – Module 3
(NX-SOD400).Input Data Set 1
in Inputs.

Expand **Slave_1001**
[NX-ECC203] – Module 1
(NX-SL3500).Output Data Set

1 in Outputs.

Select an Inputs item, then select the corresponding Outputs item and click **>>**.



Associate the following items:

Inputs	Outputs
FSoE Slave CMD	Variable 4
Safety Input 1st Word	Variable 5
FSoE Slave CRC_0	Variable 6
FSoE Slave Conn_ID	Variable 7

7 Expand

Slave_1001[R88D-1SN01L-EC]

T] – Module 1 (Safety Process


Data). 273th receive PDO

Mapping in Inputs.

**Expand Module 1
(NX-SL3500).Output Data Set**

1 in Outputs.

Select an Inputs item, then
select the corresponding
Outputs item and click **>>**.



Associate the following items:

Inputs	Outputs
FSoE Slave Command	Variable 8
	Variable 9
	Variable 10
	Variable 11

8.6.6. Creation of ENI Files and Download to the Controller

Perform the procedure provided in *6.4.4 Creation of an EtherCAT Network Information File*.

8.7. Controller Settings

Perform the procedure provided in *6.5 Controller Settings*.

9. Appendix Troubleshooting

9.1. Factors Causing EtherCAT Communications To Be Unavailable, and Corrective Actions


Description	Factor	Corrective Action
The link is not established.	The Ethernet cable is broken or the specified cable is not being used.	If the Ethernet cable is broken or if the specified cable was not used, replace the cable.
	A connector on the Ethernet cable used for EtherCAT communications is disconnected, the contact is faulty, or parts are faulty.	Reconnect the connector and make sure it is mated correctly.
	A slave within the EtherCAT network configuration failed.	Replace the slave.
EtherCAT communications do not start.	ECAT[0].Enable is set to 0.	From the Terminal tab page, run the ECAT[0].Enable=1 command to start EtherCAT communications.
	The EtherCAT network configuration in the Controller does not agree with the physical network configuration.	Review the settings according to the procedures provided in 6.4 EtherCAT Communications Setup .
	The Ethernet cable is broken at a slave in the network, or a connector is disconnected.	Connect the Ethernet cable correctly.
	Some errors have occurred, and the ECAT[0].error is set to a value other than 0.	Check the ECAT[0].error value.
A synchronization error occurs at a slave.	The distribution clock is not set correctly.	Review the settings according to the procedures provided in 0 Distributed Clock Setup .
	A slave in Free-Run Mode is set to the reference clock.	
	The servo task processing time exceeds the set period.	Review the program or servo frequency to adjust it, so that the servo task processing time does not exceed the period.

9.2. How to Check for Errors

9.2.1. Checking the EtherCAT Status

You can check the EtherCAT status from **Diagnosis Mode** of Power PMAC IDE.

Right-click on **Master0 (Deactivated)** under **EtherCAT** in the Solution Explorer, then select **Diagnosis Mode** to open the Diagnosis Mode page



You can check the status of the slaves in the Diagnosis Mode page.

Master0 (Diagnosis) ■ X

Device Editor

General Process Data Image Watch list Performance Variables CoE Object-Dictionary History

State Machine

Current State	Pre-Op
Requested State	Pre-Op
	Init Bootstrap
Change State	Pre-Op Safe-Op
	Op

Information

Number of found slaves	2
Number of slaves in configuration	2
Number of DC slaves	2
DC in-sync	Yes
Topology Ok	Yes
Link Connected	Yes
Slaves in Master State	No

Frame Counter

Sent frames	93542
Lost frames	0
Cyclic frames	56498
Acyclic frames	37044

[Clear counters](#)

9.2.2. Checking the Controller Status

In the Status page of Power PMAC IDE, you can check the status of the motor, coordinate system, and system.

To display the Status page, click **Status** on the toolbar.

■ Global Status

You can check system errors such as the WDT error.

Global Status			
Description	Status	Description	Status
AbortAll	False	HWChangeErr	False
BuSizeErr	False	NoClocks	False
ConfigLoadErr	False	ProjectLoadErr	False
Default	True	PwrOnFault	False
FileConfigErr	False	WDTFault	NoFault
FlashSizeErr	False		

■ Motor Status

You can check deviation errors, limit errors, and other states of the motor.

Status			
Motor Status Coordinate Status Global Status MACRO Status			
Motor	1	● Motor activated	
Description	Status	Description	Status
AmpEna	False	I2tFault	False
AmpFault	False	InPos	False
AmpWarn	False	InterlockStop	False
AuxFault	False	LimitStop	False
BIDir	Plus	MinusLimit	False
BlockRequest	False	PhaseFound	False
ClosedLoop	False	PlusLimit	False
Csolve	False	SoftLimit	False
DacLimit	False	SoftLimitDir	Plus
DesVelZero	True	SoftMinusLimit	False
EncLoss	False	SoftPlusLimit	False
Fefatal	False	SpindleMotor	False
FeWarn	False	TraceCount	0
GantryHomed	False	TriggerMove	False
HomeComplete	False	TriggerNotFound	False
HomeInProgress	False	TriggerSpeedSel	MaxSpeed

■ Coordinate Status

You can check deviation errors, limit errors and other states of the coordinate system.

Status			
Motor Status Coordinate Status Global Status MACRO Status			
Coordinate System	0		
Description	Status	Description	Status
AddedDwellDis	True	LinTpPvtBuf	False
AmpEna	False	LookAheadActive	False
AmpFault	False	LookAheadChange	False
AmpWarn	False	LookAheadDir	Forward
AuxFault	False	LookAheadFlush	False
BlockActive	False	LookAheadLookBack	False
BlockRequest	False	LookAheadReCalc	False
BufferWarn	0	LookAheadStop	False
CC3Active	False	LookAheadWrap	False
CCAddedArc	False	MinusLimit	False
CCMode	Off	MoveMode	LineCircle
CCMoveType	Dwell	PlusLimit	False
CCOffReq	False	ProgActive	False
ClosedLoop	False	ProgProceeding	False
ContMotion	False	ProgRunning	False
Csolve	False	SegEnabled	False
DesVelZero	False	SegHaltReq	False
EncLoss	False	SegMove	Off
EndDelayActive	False	SegMoveAccel	False
ErrorStatus	NoError	SegMoveDecel	False
FeedHold	Off	SegStopReq	False
Fefatal	False	SharpCornerStop	False
FeWarn	False	SoftMinusLimit	False
HomeComplete	False	SoftPlusLimit	False
HomeInProgress	False	TimerEnabled	False
I2tFault	False	TimersEnabled	False
InPos	False	TriggerMove	False
InterlockStop	False	TriggerNotFound	False

10. Appendix ECAT[i] Structure Elements

The Controller uses motion controller technology developed by Delta Tau Data Systems, Inc., (hereafter referred to as DT) in the U.S., however, the ECAT[i] structure elements differ from those of DT controllers. The following table shows the major changes that have been made from DT controllers.

Element name	Description	Change
ECAT[i].Enable	Enabling the EtherCAT network	0: Disable, 1: Enable (2 and 3 are not supported.)
ECAT[i].LPIO[k]	Elements of low priority I/O module	Not supported
ECAT[i].Slave[j]	Slave elements	Not supported
ECAT[i].Error	Error code of enabling EtherCAT network	\$ 9811000C: Invalid network configuration \$ 9811002E: Disconnected network connection
ECAT[i].LinkUp ECAT[i].LPDomainOutputState ECAT[i].LPDomainState ECAT[i].LPRxTime ECAT[i].LPTxTime ECAT[i].MasterStat ECAT[i].RTDomainOutputState ECAT[i].RTDomainState	Status data structure elements	Not supported

11. Revision History

Revision code	Revised date	Revised content
01	Apr, 2019	First edition
02	Jan, 2023	<ul style="list-style-type: none">▪ Made changes accompanying the addition of CK5M-CPU1 □ 1 Unit.▪ Made changes accompanying the modification of GUI of PowerPMAC IDE.
03	April 10, 2023	Corrected mistakes.

Note: Do not use this document to operate the Unit.

OMRON Corporation Industrial Automation Company

Kyoto, JAPAN

Contact : www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.
Wegalaan 67-69, 2132 JD Hoofddorp
The Netherlands
Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

OMRON ASIA PACIFIC PTE. LTD.
438B Alexandra Road, #08-01/02 Alexandra
Technopark, Singapore 119968
Tel: (65) 6835-3011 Fax: (65) 6835-2711

OMRON ELECTRONICS LLC
2895 Greenspoint Parkway, Suite 200
Hoffman Estates, IL 60169 U.S.A.
Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.
Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China Tel:
(86) 21-6023-0333 Fax: (86) 21-5037-2388

Authorized Distributor:

©OMRON Corporation 2019-2023 All Rights Reserved.
In the interest of product improvement,
specifications are subject to change without notice.

Cat. No. 0039-E1-03 0423 (0419)