

Programmable Multi-Axis Controller

Startup Guide for DirectPWM Interface

CK3W-AX1313 □

CK3W-AX2323 □

**Startup
Guide**

NOTE

- All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.
- No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice.
- Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Trademarks


- Microsoft, Windows, Windows Vista, Excel, and Visual Basic are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- EtherCAT[®] is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Copyrights

- Microsoft product screen shots reprinted with permission from Microsoft Corporation.
- This product incorporates certain third party software. The license and copyright information associated with this software is available at http://www.fa.omron.co.jp/nj_info_e/.

Sections in this Manual



CONTENTS

Sections in this Manual	3
Related Manuals.....	5
Revision History.....	6
Terms and Definitions.....	7
Precautions	8

Section 1 Summary of Materials

1-1 Summary of Materials.....	1-2
1-1-1 Intended Audience	1-2

Section 2 Target Equipment and Device Configuration

2-1 Device Configuration.....	2-2
--------------------------------------	------------

Section 3 DirectPWM Interface Connection Procedure

3-1 Work Flow.....	3-2
3-2 Controller Setting Preparations.....	3-3
3-2-1 Creation of a New Project	3-3
3-2-2 Controller Initial Setting	3-4
3-3 Various Equipment Connection.....	3-6
3-4 Various Controller Settings.....	3-8
3-4-1 Notes List	3-13
3-5 Confirmation of Settings	3-17
3-6 Motor Tuning	3-19
3-6-1 Open Loop Test.....	3-19
3-6-2 Current Loop Gain Setting	3-20
3-6-3 Bandwidth Automatic Setting	3-21
3-6-4 Manual Setting of Bandwidth	3-23
3-6-5 Feed-Forward Value Setting.....	3-25
3-6-6 Checking of Operation and Creation of Tuning Parameter Project	3-27

Related Manuals

To safely utilize the system, obtain a manual or user's guide for each device and piece of equipment, confirm their content, including "Safety Precautions", "Precautions for Safe Use", and other precautions related to safety, and then proceed with use.

The manuals for OMRON Corporation (hereafter, "OMRON") and Delta Tau Data Systems Inc. (hereafter "DT") are as shown below.

Manufacturer	Cat. No.	Model	Manual Name
OMRON	O036	CK3M-□ CK3W-□	Programmable Multi-Axis Controller Hardware User's Manual
DT	O014	---	Power PMAC User's Manual
DT	O015	---	Power PMAC Software Reference Manual
DT	O016	---	Power PMAC IDE User's Manual

Revision History

A manual revision code appears as a suffix to the catalog number on the front and back covers.

Cat. No.	O047-E1-01
-----------------	-------------------

↑
Revision code

Revision code	Revision date	Revised content
01	July 2019	Original production

Terms and Definitions

Terms	Descriptions and Definitions
PMAC	This is the acronym for Programmable Multi-Axis Controller.
Power PMAC IDE	This is computer software that is used to configure the Motion Controller, create user programs, and perform monitoring.
DirectPWM	This is a proprietary interface method developed by Delta Tau Data Systems, Inc. for connecting Servo Drives.
Digital Quadrature Encoder	This is a type of encoder that outputs pulse signals.

Precautions

- For actual system construction, check the specifications for each device and piece of equipment that makes up the system, use a method with sufficient margin for ratings and performance, and adopt safety circuits and other safety measures to minimize risks even if a breakdown occurs.
- To safely utilize the system, obtain a manual or user's guide for each device and piece of equipment that makes up the system, confirm and understand their content, including "Safety Precautions", "Precautions for Safe Use", and other precautions related to safety, and then proceed with use.
- The customer must check all regulations, laws, and rules that are applicable to the system themselves.
- Copying, duplication, or redistribution of part or all of these materials without the permission of OMRON Corporation is prohibited.
- The content listed in these materials is valid as of July 2019.
The content listed in these materials may be changed without notice for purposes of improvement.

The marks used in these materials are defined as follows.



Precautions for Correct Use

Precautions on what to do and what not to do to ensure correct operation and performance.



Additional Information

Additional information to read as required.

This information is provided to increase understanding and make operation easier.



Summary of Materials

This section lists a summary of these materials.

1-1	Summary of Materials	1-2
1-1-1	Intended Audience	1-2

1-1 Summary of Materials

This document summarizes the procedures and confirmation methods for connecting a Servo Drive that is compatible with the DirectPWM interface method to the OMRON Programmable Multi-Axis Controller CK3M-□□□□ (hereinafter called “Controller”).

By understanding the setting content and setting procedure points described in *Section 3 DirectPWM Interface Connection Procedure* on page 3-1, you can configure the Controller to send commands to the DirectPWM interface-capable Servo Drive and control Servomotors.

The connection procedure in this document describes an example when a digital quadrature encoder is used to perform position and velocity feedback for CK3W-AX1313□. *1

*1. If CK3W-AX2323□ is used, the same DirectPWM interface as CK3W-AX1313□ is available but the encoder setting needs to be changed because a different type of encoder needs to be connected. Refer to the following documents for encoder settings.

- *Startup Guide Sinusoidal Encoder*
- *Startup Guide for SSI/Mitutoyo/EnDat 2.1/2.2 Serial Encoder*

1-1-1 Intended Audience

This guide is intended for the following personnel, who must also have knowledge of electrical systems (electrical or the equivalent).

- Personnel in charge of introducing FA systems.
- Personnel in charge of designing FA systems.
- Personnel in charge of installing and maintaining FA systems.
- Personnel in charge of managing FA systems and facilities.

Also, this guide is intended for personnel who understand the contents described in the DT manual.



Target Equipment and Device Configuration


This section lists the target equipment and system configurations for connections in these materials.

2-1	Device Configuration	2-2
-----	----------------------------	-----

2-1 Device Configuration

The configuration devices for reproducing the connection procedures in this document are shown below.

This example shows a DirectPWM interface setting using the configuration where the digital quadrature encoder is connected to the output axis of a motor. This configuration is used only to show a setting example and is not a standard configuration.



Precautions for Correct Use

Always secure a Servomotor and encoder. Starting the motor that is not secured leads to a failure.

Manufacturer	Name	Model	Version
OMRON	Programmable Multi-Axis Controller CPU Unit	CK3M-CPU1□1	Version 2.5.2 or later
OMRON	Programmable Multi-Axis Controller Axis Interface Unit	CK3W-AX1313□	---
OMRON	Programmable Multi-Axis Controller Power Supply Unit	CK3W-PD048	---
OMRON	Programmable Multi-Axis Controller End Cover	CK3W-TER11	---
OMRON	DirectPWM Cable	CK3W-CAAD0□□A	---
OMRON	Motor Cable	R88A-CAKA0□□S	---
OMRON	Encoder Cable	CK3W-CAES03A	---
Servotronix	Servo Drive	CDHD-0032APB0	---
OMRON	Servomotor	R88M-K05030T	---
OMRON	Digital Quadrature Encoder	E6B2-CWZ1X	---
OMRON	Coupling	E69-C68B	---
OMRON	Switching Power Supply	S8VK-□	---

Manufacturer	Name	Model	Version
---	Windows PC	---	---
DT	Power PMAC Setting Tool	Power PMAC IDE	Version 4.3 or later

3

DirectPWM Interface Connection Procedure

This section describes the procedures for connecting the Controller and Servo Drive, and operating the motion control equipment with the DirectPWM interface. The description assumes that the Controller is set to factory default.

3-1	Work Flow	3-2
3-2	Controller Setting Preparations	3-3
3-2-1	Creation of a New Project.....	3-3
3-2-2	Controller Initial Setting.....	3-4
3-3	Various Equipment Connection	3-6
3-4	Various Controller Settings	3-8
3-4-1	Notes List.....	3-13
3-5	Confirmation of Settings	3-17
3-6	Motor Tuning.....	3-19
3-6-1	Open Loop Test	3-19
3-6-2	Current Loop Gain Setting	3-20
3-6-3	Bandwidth Automatic Setting	3-21
3-6-4	Manual Setting of Bandwidth	3-23
3-6-5	Feed-Forward Value Setting	3-25
3-6-6	Checking of Operation and Creation of Tuning Parameter Project.....	3-27

3-1 Work Flow

The procedures for connecting the Controller and Servo Drive, and operating the motion control equipment with the DirectPWM interface, are shown below.




3-2 Controller Setting Preparations on page 3-3	Perform the Controller setting preparations.
▼	
3-2-1 Creation of a New Project on page 3-3	
▼	
3-2-2 Controller Initial Setting on page 3-4	
▼	
3-3 Various Equipment Connection on page 3-6	Perform connection and wiring for each device.
▼	
3-4 Various Controller Settings on page 3-8	Perform the Controller settings.
▼	
3-5 Confirmation of Settings on page 3-17	Check that the settings up to here are correct.
▼	
3-6 Motor Tuning on page 3-19	Use Power PMAC IDE tuning tools to tune the motor.
▼	
3-6-1 Open Loop Test on page 3-19	
▼	
3-6-2 Current Loop Gain Setting on page 3-20	
▼	
3-6-3 Bandwidth Automatic Setting on page 3-21	
▼	
3-6-4 Manual Setting of Bandwidth on page 3-23	
▼	
3-6-5 Feed-Forward Value Setting on page 3-25	
▼	
3-6-6 Checking of Operation and Creation of Tuning Parameter Project on page 3-27	

3-2 Controller Setting Preparations


Perform the Controller setting preparations.
Install the Power PMAC IDE on the PC beforehand.

3-2-1 Creation of a New Project

Follow the procedure below to create a new project.


1	Connect the Controller and computer with an Ethernet cable.	
2	Turn ON the power supply to the Controller.	
3	Start up Power PMAC IDE. <ul style="list-style-type: none"> If a dialog for checking access rights is displayed at the time of startup, select the option for starting up. 	
4	The Communication screen is displayed, so specify the IP address of the Controller to be connected to, and click the Connect button. <ul style="list-style-type: none"> The default IP address for the Controller is "192.168.0.200". If necessary, change the Windows IP address to "192.168.0.X". 	 <p>For detailed setup options go to Tools menu -> Options -> PowerPMAC</p>
5	Power PMAC IDE starts up, and the Controller will come online.	

6 From the **File** menu, select **New – Project**.



The screenshot shows the PowerPMAC IDE interface. The 'File' menu is open, and the 'New' option is selected. A sub-menu is visible with 'Project...' highlighted in red, and the keyboard shortcut 'Ctrl+Shift+N' is shown next to it. The background shows the IDE's main window with a terminal at the bottom displaying a successful SSH connection to the PowerPMAC controller at IP 192.168.0.200.

7 Input a project name and save destination, and select the **OK** button.



The screenshot shows the 'New Project' dialog box. The 'Name' field contains 'PowerPMAC1', the 'Location' field contains 'C:\Users\904PP5256\Documents\PowerPMAC IDE', and the 'Solution name' field contains 'PowerPMAC1'. The 'OK' button is highlighted in red. The dialog also shows a list of installed templates on the left and a 'Type' dropdown set to 'PowerPMAC'.

3-2-2 Controller Initial Setting


Follow the procedure below to perform the initial settings for the Controller.





Precautions for Correct Use

Since all memory is cleared by the initial settings, be sure to save any data remaining in the Controller that you may need.

1 Type the **\$\$\$***** command from the Terminal, and set the Controller to the factory default state.




The screenshot shows a terminal window titled 'Terminal: Online [192.168.0.200 : SSH]'. The terminal output reads: 'Welcome to PowerPMAC terminal', 'Select Device to start communication', and 'SSH communication to PowerPMAC at 192.168.0.200 successful'. The prompt '\$\$\$***' is entered at the bottom of the terminal and is highlighted with a red box.

<p>2</p> <p>Type the save command in the Power PMAC IDE Terminal.</p> <ul style="list-style-type: none"> When the save is completed, "Save Completed" is displayed in the Terminal. 	 <p>Terminal: Online [192.168.0.200 : SSH]</p> <p>Saving To Flash: Finished SAVING to flash</p> <p>Save Completed</p> <p>save</p>
<p>3</p> <p>Type the \$\$\$ command in the Power PMAC IDE Terminal.</p> <ul style="list-style-type: none"> When the reset is completed, "PowerPMAC Reset complete" is displayed in the Terminal. 	 <p>Terminal</p> <p>Saving To Flash: Finished SAVING to flash</p> <p>Save Completed</p> <p>\$\$\$</p> <p>Resetting PowerPMAC</p> <p>PowerPMAC Reset complete</p> <p>\$\$\$</p>

3-3 Various Equipment Connection

The following diagram shows the connection between the axis interface unit and various equipment.



Follow the instructions below to connect a, b, c, and d shown in the diagram above.

a. Connection between the Controller and Servo Drive

Use the following dedicated cables to connect the CK3W-AX1313□ amplifier connector to the Servo Drive C2 connector.

Manufacturer	Name	Model	Length
OMRON	DirectPWM Cable	CK3W-CAAD009A	0.9 m
		CK3W-CAAD018A	1.8 m
		CK3W-CAAD036A	3.6 m

b. Connection between the Servo Drive and Servomotor

Use the following dedicated cables to connect the Servo Drive P2 connector to the Servomotor connector.

Manufacturer	Name	Model	Length
OMRON	Motor Cable	R88A-CAKA003S	3 m
		R88A-CAKA005S	5 m
		R88A-CAKA010S	10 m
		R88A-CAKA015S	15 m
		R88A-CAKA020S	20 m
		R88A-CAKA030S	30 m
		R88A-CAKA040S	40 m
R88A-CAKA050S	50 m		

c. Connection between the Servomotor and Encoder

Use the following coupling to connect the rotary axes of the Servomotor and digital quadrature encoder.


Coupling: E69-C68B

d. Wiring between the Controller and Encoder

Use the following dedicated cable to connect CK3W-AX1313□ to the digital quadrature encoder.

Manufacturer	Name	Model	Length
OMRON	Encoder Cable	CK3W-CAES03A	3 m

Follow the wiring diagram below to connect the dedicated cable (CK3W-CAES03A) to the digital quadrature encoder.



3-4 Various Controller Settings

Follow the procedure below to perform the settings for the Controller when a Servomotor is controlled by the DirectPWM interface and digital quadrature encoder.



Precautions for Correct Use

- For items to be written in the global definitions.pmh in step 2 in the following procedure, set appropriate values depending on the motor and Servo Drive used. If the set value is not appropriate, an excessive current flows, which may cause the equipment to fail. Refer to Notes *24 through *26 in 3-4-1 Notes List on page 3-13 for the settings.
- If **Motor[1].IaBias** and **Motor[1].IbBias** are set to other than 0 in the following step 9 and 11, the motor may rotate. Make sure that no problem occurs and the equipment is safe if the motor rotates before the setting.

1 Open the global definitions.pmh under **PMAC Script Language – Global Includes** in the Solution Explorer.

2 Write the text on the right to the global definitions.pmh.

- Refer to *3-4-1 Notes List* on page 3-13 for details on setting items with Notes *1 through *30 shown in the text on the right.

```

Sys.WpKey = $AAAAAAAA

//global setting
Gate3[0].PhaseServoDir = 0;
Gate3[0].PhaseFreq = 10000; //10kHz
Gate3[0].ServoClockDiv = 9; //1kHz
Sys.PhaseOverServoPeriod = 0.1;
Sys.ServoPeriod = 1;

//Encoder Setting
EncTable[1].Type = 1; /*1
EncTable[1].pEnc = Gate3[0].Chan[0].ServoCapt
.a; /*2
EncTable[1].ScaleFactor = 1/exp2(8); /*3
Gate3[0].EncClockDiv = 5; //3.125MHz
Gate3[0].Chan[0].EncCtrl = 7; /*4

//DirectPWM AD Convertor setting
Gate3[0].AdcAmpStrobe = $ffffffc; /*5
Gate3[0].AdcAmpHeaderBits = 2; /*6
Gate3[0].AdcAmpClockDiv = 5; //3.125MHz

//DirectPWM PWM output setting
Gate3[0].Chan[0].PwmFreqMult = 2; /*7
Gate3[0].Chan[0].PwmDeadTime = 15; /*8
Gate3[0].Chan[0].PackInData = 2; /*9
Gate3[0].Chan[0].PackOutData = 1; /*10

```






```






Sys.WpKey=$0



//Motor setting
Motor[1].ServoCtrl = 1; //Enable the Motor[1]
.
Motor[1].PhaseCtrl = 1; //Enable the commutator task.
Motor[1].pPhaseEnc = Gate3[0].Chan[0].PhaseCapt.a; /*11
Motor[1].PhasePosSf = 2048/(256*2000*4/5); /*12
Motor[1].PwmSf = 13458; /*13
Motor[1].PhaseOffset = 683; /*14
Motor[1].AmpFaultLevel = 1; /*15
Motor[1].pLimits = 0; //Disable the Overtravel limit.
Motor[1].WarnFeLimit = 4000; /*16
Motor[1].FatalFeLimit = 8000; /*17
Motor[1].pAmpEnable = Gate3[0].Chan[0].OutCtrl.a;
Motor[1].pAmpFault = Gate3[0].Chan[0].Status.a;
Motor[1].pCaptFlag = Gate3[0].Chan[0].Status.a;
Motor[1].pCaptPos = Gate3[0].Chan[0].HomeCapt.a;
Motor[1].pEncCtrl = Gate3[0].Chan[0].OutCtrl.a;
Motor[1].pEncStatus = Gate3[0].Chan[0].Status.a;
Motor[1].pMasterEnc = EncTable[1].a;
Motor[1].CurrentNullPeriod = 1; /*18
Motor[1].pEnc = EncTable[1].a /*19
Motor[1].pEnc2 = EncTable[1].a /*20
Motor[1].pDac = Gate3[0].Chan[0].Pwm[0].a; /*21
Motor[1].pAdc = Gate3[0].Chan[0].AdcAmp[0].a; /*22
Motor[1].AdcMask = $FFFC0000; /*23
Motor[1].MaxDac = 28377 * 3.33 / 11.25; /*24
Motor[1].I2tSet = 28377 * 1.1 / 11.25; /*25
Motor[1].I2tTrip = (Motor[1].MaxDac * Motor[1].MaxDac - Motor[1].I2tSet * Motor[1].I2tSet) * 3; /*26
Motor[1].AbsPhasePosOffset = 400; /*27
Motor[1].PhaseFindingDac = 4000; /*28
Motor[1].PhaseFindingTime = 1000; /*29
Motor[1].PowerOnMode = 1; /*30
Motor[1].InPosBand = 100;

// Setting Coordinate System
&1
#1->x
&1%100;

```


<p>3</p>	<p>Right click on the Solution Explorer project name at the upper right of the Power PMAC IDE screen, select Build and Download All Programs, and execute Build and Download.</p>											
<p>4</p>	<p>Make sure that there are no errors in the Output Window.</p> <ul style="list-style-type: none"> If the transfer failed, check the content of the error in the Output Window. If there is a program error, fix the program. 											
<p>5</p>	<p>Type the save command in the Power PMAC IDE Terminal.</p> <ul style="list-style-type: none"> When the save is completed, "Save Completed" is displayed in the Terminal. 											
<p>6</p>	<p>Type the \$\$\$ command in the Terminal.</p>											
<p>7</p>	<p>To determine a sign for Motor[1].PhaseOffset, paste Motor[1].PhasePos, Motor[1].IaBias, and Motor[1].IbBias in the Watch window.</p>	 <table border="1"> <thead> <tr> <th>Command/Query</th> <th>Response</th> </tr> </thead> <tbody> <tr> <td>Svs.ServoCount</td> <td>159954</td> </tr> <tr> <td>Motor[1].PhasePos</td> <td>1.9199999999999993</td> </tr> <tr> <td>Motor[1].IaBias</td> <td>0</td> </tr> <tr> <td>Motor[1].IbBias</td> <td>0</td> </tr> </tbody> </table>	Command/Query	Response	Svs.ServoCount	159954	Motor[1].PhasePos	1.9199999999999993	Motor[1].IaBias	0	Motor[1].IbBias	0
Command/Query	Response											
Svs.ServoCount	159954											
Motor[1].PhasePos	1.9199999999999993											
Motor[1].IaBias	0											
Motor[1].IbBias	0											

<p>8</p>	<p>Type the #1out0 command in the Terminal.</p>	 <pre>Terminal: Online [192.168.0.200 : SSH] Welcome to PowerPMAC terminal Select Device to start communication SSH communication to PowerPMAC at 192.168.0.200 successful \$\$\$ Resetting PowerPMAC PowerPMAC Reset complete #1out0</pre>										
<p>9</p>	<p>Set Motor[1].IaBias=200 and Motor[1].IbBias=0 in the Terminal.</p>	 <pre>Terminal: Online [192.168.0.200 : SSH] SSH communication to PowerPMAC at 192.168.0.200 successful \$\$\$ Resetting PowerPMAC PowerPMAC Reset complete #1out0 Motor[1].IaBias=200 Motor[1].IbBias=0</pre>										
<p>10</p>	<p>Check the Motor[1].PhasePos value in the Watch window.</p>	 <table border="1"> <thead> <tr> <th>Command/Query</th> <th>Response</th> </tr> </thead> <tbody> <tr> <td>Sys.ServoCount</td> <td>230995</td> </tr> <tr> <td>Motor[1].PhasePos</td> <td>1505.92000000008966</td> </tr> <tr> <td>Motor[1].IaBias</td> <td>200</td> </tr> <tr> <td>Motor[1].IbBias</td> <td>0</td> </tr> </tbody> </table>	Command/Query	Response	Sys.ServoCount	230995	Motor[1].PhasePos	1505.92000000008966	Motor[1].IaBias	200	Motor[1].IbBias	0
Command/Query	Response											
Sys.ServoCount	230995											
Motor[1].PhasePos	1505.92000000008966											
Motor[1].IaBias	200											
Motor[1].IbBias	0											
<p>11</p>	<p>Set Motor[1].IbBias=200 in the Terminal.</p> <ul style="list-style-type: none"> • Motor[1].IaBias remains 200. 	 <pre>Terminal: Online [192.168.0.200 : SSH] \$\$\$ Resetting PowerPMAC PowerPMAC Reset complete #1out0 Motor[1].IaBias=200 Motor[1].IbBias=0 Motor[1].IbBias=200</pre>										
<p>12</p>	<p>Check the Motor[1].PhasePos value in the Watch window.</p>	 <table border="1"> <thead> <tr> <th>Command/Query</th> <th>Response</th> </tr> </thead> <tbody> <tr> <td>Sys.ServoCount</td> <td>320449</td> </tr> <tr> <td>Motor[1].PhasePos</td> <td>1503.36000000008971</td> </tr> <tr> <td>Motor[1].IaBias</td> <td>200</td> </tr> <tr> <td>Motor[1].IbBias</td> <td>200</td> </tr> </tbody> </table>	Command/Query	Response	Sys.ServoCount	320449	Motor[1].PhasePos	1503.36000000008971	Motor[1].IaBias	200	Motor[1].IbBias	200
Command/Query	Response											
Sys.ServoCount	320449											
Motor[1].PhasePos	1503.36000000008971											
Motor[1].IaBias	200											
Motor[1].IbBias	200											

13	<p>Type Motor[1].IaBias=0 and Motor[1].IbBias=0 in the Terminal to return the phase A and B bias currents to 0.</p>	 <pre>Terminal: Online [192.168.0.200 : SSH] PowerPMAC Reset complete #1out0 Motor[1].IaBias=200 Motor[1].IbBias=0 Motor[1].IbBias=200 Motor[1].IaBias=0 Motor[1].IbBias=0 Motor[1].IbBias=0</pre>												
14	<p>If the Motor[1].PhasePos value decreases when values in step 10 and 12 are compared, set the sign of Motor[1].PhaseOffset to + (addition); if the value increases, set the sign to - (subtraction).</p> <ul style="list-style-type: none"> Since the value decreases in this example, set Motor[1].PhaseOffset=683 in the global definitions.pmh. If a sign of Motor[1].PhaseOffset needs to be changed, change the sign in the global definitions.pmh and perform download again following the procedure in step 3 through 6. 													
15	<p>Manually rotate the coupling that connects the motor to encoder and check that the desired scale is applied to the current position in the Position window.</p> <ul style="list-style-type: none"> The EncTable[1].ScaleFactor value is set to 8000 counts per rotation in this example, so 8000 mu is added to the current position per rotation. 	 <table border="1"> <thead> <tr> <th colspan="2">Position</th> </tr> <tr> <th colspan="2">Position</th> </tr> </thead> <tbody> <tr> <td>#1</td> <td>632.00 mu</td> </tr> <tr> <td>#2</td> <td>0.00 mu</td> </tr> <tr> <td>#3</td> <td>0.00 mu</td> </tr> <tr> <td>#4</td> <td>0.00 mu</td> </tr> </tbody> </table>	Position		Position		#1	632.00 mu	#2	0.00 mu	#3	0.00 mu	#4	0.00 mu
Position														
Position														
#1	632.00 mu													
#2	0.00 mu													
#3	0.00 mu													
#4	0.00 mu													



Precautions for Correct Use

If the **save** command is not successfully completed, the transferred project is not saved in the Controller. If the power to the Controller is switched OFF without the project being saved, the transferred project is destroyed.



Additional Information

To change the counting direction of the digital quadrature encoder (clockwise/counterclockwise), change the sign of the following set values to write in the global definitions.pmh in step 2 to - (subtraction).

- EncTable[1].ScaleFactor
- Motor[1].PhasePosSf

3-4-1 Notes List

The following table shows details on notes (description of set items) in step 2.






No.	Set item	Set value	Description
*1	EncTable[1].Type	1	Enable EncTable[1] as single-word (32 bits) read.
*2	EncTable[1].pEnc	Gate3[0].Chan[0].ServoCapt.a	Assign the digital quadrature encoder data to EncTable[1].
*3	EncTable[1].Scale-Factor	1/exp2(8)	<p>Calculate a scale factor set value in accordance with the following formula because EncTable[1] is 32 bits and Gate3[0].Chan[0].ServoCapt (digital quadrature encoder data) is 24 bits.</p> $\text{Set value} = \frac{1}{2^{(32 \text{ bits} - 24 \text{ bits})}}$
*4	Gate3[0].Chan[0].EncCtrl	7	Set the digital quadrature encoder conversion method to four multiplication, counterclockwise.
*5	Gate3[0].AdcAmpStrobe	\$ffffc	Specify AMP Strobe Word. If \$ffffc is set, the Controller is compatible with all AD converters.
*6	Gate3[0].AdcAmpHeaderBits	2	Set the header length of analog to digital conversion data to 2 bits. Set it depending on the Servo Drive specifications.
*7	Gate3[0].Chan[0].PwmFreqMult	2	<p>Set the PWM frequency to 15 kHz. Calculate the PWM frequency in accordance with the formula below.</p> $f_{\text{PWM}} = \frac{\text{Gate3[0].Chan[0].PwmFreqMult} + 1}{2} \times f_{\text{IntPhase}}$ <p>f_{IntPhase} : Internal phase clock frequency</p> <p>Make sure that the value is 40 kHz or less and the same as the Servo Drive maximum input frequency or less.</p>
*8	Gate3[0].Chan[0].PwmDeadTime	15	<p>Set the PWM signal dead time to 800 ns. Calculate the dead time in accordance with the formula below.</p> <p>Dead time = 0.0533 μs \times Gate3[0].Chan[0].PwmDeadTime</p> <p>Set it depending on the Servo Drive specifications.</p>
*9	Gate3[0].Chan[0].PackInData	2	<p>AdcAmp compression: Enabled</p> <p>If the digital current loop is implemented, enable data compression that improves algorithm efficiency.</p>
*10	Gate3[0].Chan[0].PackOutData	1	Enable PWM/DAC compression. If the commutation and digital current loop are calculated, enable data compression that improves algorithm efficiency.
*11	Motor[1].pPhaseEnc	Gate3[0].Chan[0].PhaseCapt.a	Use the digital quadrature encoder for commutation position feedback.
*12	Motor[1].PhasePosSf	2048/ (256*2000*4/5)	<p>Set a scale factor (Sf) of the commutation position (angle). Use the following formula to calculate the scale factor if 24 bits digital quadrature encoder (Gate3[0].Chan[0].ServoCapt) is assigned to 32 bits EncTable[1] as this example.</p> $\text{Sf} = \frac{2048 \times \text{Number of motor pole pairs}}{256 \times \text{Encoder resolution} \times \text{Encoder multiplication setting}}$ <p>Set it depending on the specifications of equipment used.</p> <p>The following shows parameters for equipment used in this example.</p> <p>256: $2^{(32 \text{ bits} - 24 \text{ bits})} = 256$</p> <p>Encoder resolution: 2000 pulses per rotation</p> <p>Encoder multiplication: 4 multiplication</p> <p>Number of motor pole pairs: 5 pairs (10 poles)</p>

No.	Set item	Set value	Description
*13	Motor[1].PwmSf	13458	Set a scale factor for PWM output. The full range is 16384. The scale factor is normally set to less than 95% of the full range so that PWM waveform cannot reach the duty cycle of 0% or 100%. It is set to approximately 82% in this example. Set it depending on the Servo Drive specifications.
*14	Motor[1].PhaseOffset	683	For a three-phase motor, set to 683 or -683.
*15	Motor[1].AmpFaultLevel	1	Specify a logic of AMP Fault detection. Set it depending on the Servo Drive specifications. 0: Negative logic is used to detect AMP Fault. 1: Positive logic is used to detect AMP Fault.
*16	Motor[1].WarnFeLimit	4000	The status bit Motor[1].AmpWarn is set when the positional deviation exceeds this value. The value for a half-rotation of the motor is set in this example. Set it depending on applications used.
*17	Motor[1].FatalFeLimit	8000	The motor is killed and the status bit Motor[1].FeFatal is set when the positional deviation exceeds this value. The value for a half-rotation of the motor is set in this example. Set it depending on applications used.
*18	Motor[1].CurrentNullPeriod	1	Motor[1].IaBias and Motor[1].IbBias are set in Motor[1].PhaseFindingStep=1 during phase search.
*19	Motor[1].pEnc	EncTable[1].a	Specify the digital quadrature encoder as an address used for loop feedback to control the motor position. The digital quadrature encoder is assigned to EncTable[1] in Notes *2 in this example.
*20	Motor[1].pEnc2	EncTable[1].a	Specify the digital quadrature encoder as the address used for loop feedback to control the motor velocity. The digital quadrature encoder is assigned to EncTable[1] in Notes *2 in this example.
*21	Motor[1].pDac	Gate3[0].Chan[0].Pwm[0].a	Assign DirectPWM to the motor command output register.
*22	Motor[1].pAdc	Gate3[0].Chan[0].AdcAmp[0].a	Specify the DirectPWM interface AD converter as an AD converter used for digital current feedback.
*23	Motor[1].AdcMask	\$FFFC0000	Specify which bit of 32 bits current feedback word is used as the actual current value. The 14 bits AD converter is set in this example. Set it depending on the Servo Drive specifications.
*24	Motor[1].MaxDac	28377*3.33/11.25	Set an instantaneous current limit value (root mean square: RMS). Compare those of the Servo Drive and the motor, and use a smaller value. The motor has a smaller value in this example. Use the following formula for calculation. $\text{MaxDac} = \frac{\cos(30^\circ) \times 32767 \times \text{Maximum instantaneous current}}{\text{Servo driver ADC full-range current}}$ Determine parameters depending on the equipment used. The following shows parameters for equipment used in this example. Maximum instantaneous current for R88M-K05030T: 4.7 A (p-p)/ $\sqrt{2}$ = 3.33 A (RMS) ADC full range current for CDHD-0032APB0: 11.25 A (RMS)

No.	Set item	Set value	Description
*25	Motor[1].I2tSet	28377*1.1/11.25	<p>Set a rated current limit value (RMS). Compare those of the Servo Drive and the motor, and use a smaller value. The motor has a smaller value in this example.</p> <p>Use the following formula for calculation.</p> $I2tSet = \frac{\cos(30^\circ) \times 32767 \times \text{Rated current}}{\text{Servo driver ADC full-range current}}$ <p>Determine parameters depending on the equipment used. The following shows parameters for equipment used in this example. Rated current for R88M-K05030T: 1.1 A (RMS) ADC full range current for CDHD-0032APB0: 11.25 A (RMS)</p>
*26	Motor[1].I2tTrip	(Motor[1].MaxDac*Motor[1].MaxDac - Motor[1].I2tSet*Motor[1].I2tSet)*3	<p>Set a motor integrated current limit. Use the following formula for calculation.</p> $I2tTrip = (\text{MaxDAC}^2 + \text{IdCmd}^2 - I2tSet^2) \times \text{allowable time (second)}$ <p>Allowable time for R88M-K05030T: 3 seconds</p>
*27	Motor[1].AbsPhasePosOffset	400	<p>Specify the minimum operation that is considered to be an efficient phase search. Although the commutation cycle (2048) 1/4 = 512 (90°) is ideal, it is set to approximately 80% in this example considering that problems such as friction can prevent the operation.</p> <p>If Motor[1].PhaseFindingStep=1 displacement is smaller than this value during phase search, the phase search is considered to be failed by Power PMAC.</p>
*28	Motor[1].PhaseFindingDac	4000	<p>Set the size of phase-sequence current that is output to each motor phase in phase search. Adjust it depending on the equipment used.</p>
*29	Motor[1].PhaseFindingTime	1000	<p>Set duration of each step during phase search. Adjust it depending on the equipment used.</p> <p>The following duration is used in this example. Duration = Servo cycle × Motor[1].PhaseFindingTime = 1 ms × 1000 = 1000 ms</p>
*30	Motor[1].PowerOn-Mode	1	<p>1: Enables the motor after phase search. 0: Kills the motor after phase search.</p>

3-5 Confirmation of Settings

Follow the procedure below to check that the settings up to here are correct.

<p>1</p> <p>Type the Motor[1].PhaseFindingStep=1 command from the Terminal to perform a phase search.</p> <ul style="list-style-type: none"> The Motor[1].PhaseFindingStep value changes to 1, 6, 7, and 0. When the phase search succeeds, the Motor[1].ClosedLoop and Motor[1].PhaseFound values change from 0 to 1. In addition, the Motor[1].New[0].Pos value becomes larger than the Motor[1].AbsPhasePosOffset set value. The AMP ENAB 0 LED is turned on at that time. *1 	 <p>Terminal: Online [192.168.0.200 : SSH] Motor[1].PhaseFindingStep=1</p> <p>Motor[1].PhaseFindingStep=1</p>  <table border="1"> <thead> <tr> <th>Command/Query</th> <th>Response</th> </tr> </thead> <tbody> <tr> <td>Sys.ServoCount</td> <td>644992</td> </tr> <tr> <td>Motor[1].PhaseFindingStep</td> <td>0</td> </tr> <tr> <td>Motor[1].ClosedLoop</td> <td>1</td> </tr> <tr> <td>Motor[1].PhaseFound</td> <td>1</td> </tr> <tr> <td>Motor[1].New[0].Pos</td> <td>467.199999999999989</td> </tr> </tbody> </table>	Command/Query	Response	Sys.ServoCount	644992	Motor[1].PhaseFindingStep	0	Motor[1].ClosedLoop	1	Motor[1].PhaseFound	1	Motor[1].New[0].Pos	467.199999999999989
Command/Query	Response												
Sys.ServoCount	644992												
Motor[1].PhaseFindingStep	0												
Motor[1].ClosedLoop	1												
Motor[1].PhaseFound	1												
Motor[1].New[0].Pos	467.199999999999989												
<p>2</p> <p>Type the #1 out1 command from the Terminal.</p>	 <p>Terminal: Online [192.168.0.200 : SSH] \$\$\$ Resetting PowerPMAC PowerPMAC Reset complete #1 out1</p> <p>#1 out1</p>												
<p>3</p> <p>Make sure that the motor is rotating. In addition, check that the Position window Position value is increasing in the positive direction.</p> <ul style="list-style-type: none"> If the motor does not rotate even after typing the #1 out1 command, increase the value gradually as #1 out2, #1 out3. 	 <table border="1"> <thead> <tr> <th colspan="2">Position</th> </tr> </thead> <tbody> <tr> <td>#1</td> <td>2,176,411.25 mu</td> </tr> <tr> <td>#2</td> <td>0.00 mu</td> </tr> <tr> <td>#3</td> <td>0.00 mu</td> </tr> <tr> <td>#4</td> <td>0.00 mu</td> </tr> </tbody> </table>	Position		#1	2,176,411.25 mu	#2	0.00 mu	#3	0.00 mu	#4	0.00 mu		
Position													
#1	2,176,411.25 mu												
#2	0.00 mu												
#3	0.00 mu												
#4	0.00 mu												
<p>4</p> <p>Type the kill command from the Terminal to stop the motor.</p>	 <p>Terminal: Online [192.168.0.200 : SSH] #1 out3 #1 out4 #1 out5 #1 out6 kill</p> <p>kill</p>												

*1. If **Motor[1].PhaseFound** does not indicate 1, the phase search has failed. Check if the set value is appropriate.

The following shows some examples of set value adjustment when a phase search fails.



- If the **Motor[1].New[0].Pos** value is smaller than the **Motor[1].AbsPhasePosOffset** set value after phase search, increase the **Motor[1].PhaseFindingDac** value. In addition, check that the **Motor[1].PhasePosSf** set value is appropriate.
- If an error occurs in I2tFault status during phase search, decrease the value of **Motor[1].PhaseFindingDac** or **Motor[1].PhaseFindingTime**.
- If the **Motor[1].New[0].Pos** value indicates – (subtraction) after phase search, change signs of **Motor[1].PhasePosSf** and **EncTable[1].ScaleFactor**.

3-6 Motor Tuning

Follow the procedure below to use Power PMAC IDE tuning tools for tuning the motor.

3-6-1 Open Loop Test

Follow the procedure below to operate the motor in an open loop, and check that each setting is correct.

<p>1</p>	<p>From the Tools menu in Delta Tau, select Advanced Tuning to open the Tune screen, and then select Open LoopTest – Step Test.</p>	 <p>The screenshot shows the 'Tune' window with the 'Open Loop Test' option highlighted in red. Below it, the 'Open Loop Step Test Parameters' are visible, with 'Test Amplitude' set to 100%, 'Test Time' at 100 ms, and 'Number of Repetitions' at 1.</p>
<p>2</p>	<p>Set the following tuning parameters. Test Amplitude: 1.0%*1 Test Time: 100 ms Number of Repetitions: 2 *1. If the motor does not rotate, set a large value.</p>	 <p>The screenshot shows the 'Open Loop Step Test Parameters' window with the 'Test Amplitude' set to 1.0%, 'Test Time' at 100 ms, and 'Number of Repetitions' at 2. These three parameters are highlighted with a red box.</p>

3 Click the **Open Loop Step Test** button.

Step Test | Sinusoidal Test | Sine Sweep Test

Open Loop Step Test Parameters


Test Amplitude: 1.0 %

Test Time: 100 ms

Number of Repetitions: 2

Open Loop Step Test

- The motor is performing reciprocating operation and the test result on the right is displayed.
- If the motor does not rotate, change the **Test Amplitude** parameter to a large value.
- The test result is when the **Test Amplitude** parameter is set to 8.0%.



3-6-2 Current Loop Gain Setting

Follow the procedure below to perform current loop gain settings and adjust them to achieve desired response characteristics.

1 In the Tune screen, select **Current Loop Tuning – Interactive Tune**.

Tune - Online(192.168.0.200)

Select Motor: Motor1

Current Loop Tuning | Interactive Tune

Auto-tune Parameters

Integral Gain (IiGain): 0.009999998

Forward Path Proportional Gain (IpfGain): 1

Back Path Proportional Gain (IpbGain): 0

Phase Current Bias Offsets

Phase A (IaBias): 0.44

Phase B (IbBias): -0.88

Current Loop Step Parameter Setup

Magnitude: 3000 bits

Rough Freesing Magnitude: 1000 bits

Dwell Time: 50 ms

Do A Current Loop Step

Kill Motor

- #### 2 Set the following parameters.
- IiGain:** 0.009999998 (Default)
 - IpfGain:** 0
 - IpbGain:** 0
 - Magnitude:** 3000 bits
 - Dwell Time:** 50 ms

Simple Auto-tune | Auto-tune | Interactive Tune

Auto-tune Parameters

Integral Gain (IiGain): 0.009999998

Forward Path Proportional Gain (IpfGain): 0

Back Path Proportional Gain (IpbGain): 0

Phase Current Bias Offsets

Phase A (IaBias): 0

Phase B (IbBias): 0

Current Loop Step Parameter Setup

Magnitude: 3000 bits


Rough Freesing Magnitude: 1000 bits

Dwell Time: 50 ms


Do A Current Loop Step

Kill Motor


3 Click the **Do A Current Loop Step** button.




- The current step response is displayed.



4 Adjust the **IliGain**, **IpfGain**, and **IpbGain** parameters to achieve the desired response characteristics.



- If the startup response is slow, increase the **IliGain** parameter.
- If the overshooting or vibration is large, increase the **IpfGain** or **IpbGain** parameter.
- Increase each gain parameter gradually starting from a small value.



3-6-3 Bandwidth Automatic Setting

Follow the procedure below to use the auto-tuning function for setting the servo loop bandwidth automatically.

1

In the Tune screen, select **Position Loop Auto-tune – Advance Auto-tune**.

2

Set the following parameters.

Amplifier Type: Direct PWM

Auto Select Bandwidth: Select the check box.

Encoder Resolution: 8000 cts/rev

Excitation Magnitude: 8.0%*1

Iteration No.: 2

*1. Select the value rotated in the open loop in step 3 in 3-6-1 *Open Loop Test* on page 3-19.

- For **Encoder Resolution**, set the pulse counts per one motor rotation. In this example, 2000 pulses per rotation of the digital quadrature encoder is set to be multiplied by four, so **Encoder Resolution** indicates 8000.

3

Click the **Auto-tune Motor** button.

4


If the message on the right appears, click the **Yes** button.

Position AutoTune Message

We have chosen a safe and conservative bandwidth of 4.6 Hz. You may choose a larger bandwidth of up to 4 times this value and Click Begin Tuning again. Do you wish to go back and change this bandwidth (if you choose No the auto-tuning process will continue?)


Yes
No

5 If the screen on the right appears, click the **Implement** button.



	Current Gains	Previous Gains	Recommended Gains
Proportional (Kp)	4	4	0.70337219665314
Derivative (Kvfb)	40	40	17.2223454109807
Integral (Ki)	9.9999997e-05	9.9999997e-05	0
Velocity feedforward (Kvff)	40	40	0
Acceleration feedforward (Kaff)	0	0	0
Derivative Gain 2 (Kvfb2)	0	0	0
Velocity feedforward into Integrator (KvffI)	0	0	0

6 Check that the **Recommended Gains** values are applied to **Current Gains**, and then click the **OK** button.




	Current Gains	Previous Gains	Recommended Gains
Proportional (Kp)	0.70337219665314	4	0.70337219665314
Derivative (Kvfb)	17.2223454109807	40	17.2223454109807
Integral (Ki)	0	9.9999997e-05	0
Velocity feedforward (Kvff)	0	40	0
Acceleration feedforward (Kaff)	0	0	0
Derivative Gain 2 (Kvfb2)	0	0	0
Velocity feedforward into Integrator (KvffI)	0	0	0


3-6-4 Manual Setting of Bandwidth

Follow the procedure below to set a more appropriate bandwidth, while monitoring the step response characteristic.


1 Select **Position Loop Interactive Tuning – Step** in the Tune screen.




2 Set the following parameters.
Step Size: 2500 mu




3 Click the **Step Move** button.




4 Check the step response characteristic.




5 If the target position has not been reached, return to the **Advance Auto-tune** screen, and set an even larger value for **Bandwidth**.



6 Click the **Recalculate** button.




7 If the screen on the right appears, click the **Implement** button.




	Current Gains	Previous Gains	Recommended Gains
Proportional (Kp)	0.70337272	0.70337272	1.91110810197676
Derivative (Kvfb)	17.222345	17.222345	29.3884814465067
Integral (Ki)	0	0	0
Velocity feedforward (Kvff)	0	0	0
Acceleration feedforward (Kaff)	0	0	0
Derivative Gain 2 (Kvfb2)	0	0	0
Velocity feedforward into Integrator (Kviff)	0	0	0

8 Check that the **Recommended Gains** values are applied to **Current Gains**, and then click the **OK** button.




9 Return to step 1 and repeat the procedure until the desired responsiveness is obtained.




3-6-5 Feed-Forward Value Setting

Follow the procedure below to set a more appropriate bandwidth, while monitoring the step response characteristic.

1 In the Tune screen, select **Position Loop Auto-tune – Advance Auto-tune**, and insert checks into **Velocity FF** and **Acceleration FF**.



2 Click the **Recalculate** button.



3

If the screen on the right appears, click the **Implement** button.

4

Check that the **Recommended Gains** values are applied to **Current Gains**, and then click the **OK** button.

5

Select **Position Loop Interactive Tuning – Parabolic Vel.** and set the following parameters.
Move Size: 2500 mu
Move Time: 500 ms
Left Axis: Velocity
Right Axis: Following Error

6

Click the **Parabolic Velocity Move** button.

7

Check the parabolic response characteristic of velocity.

3-26

CK3M-series Startup Guide DirectPWM Interface (O047)

8 If **Following Error** has a positive correlation to the velocity, make **Kvff** larger. If it has a reverse correlation, make **Kvff** smaller.

Current Loop Tuning | Open Loop Test | Position Loop Auto-tune | Position Loop Interactive Tuning | Pre-filter S

FeedBack Gains


Proportional Gain (Kp)	1.9111081
Derivative Gain 1 (Kvfb)	28.388461
Derivative Gain 2 (Kvfb)	0
Integral Gain (Ki)	0

FeedForward Gains

Velocity Feedforward Gain 1 (Kvff)	60
Velocity Feedforward Gain 2 (Kvff)	0
Acceleration Feedforward Gain (Kaff)	215.15082
Friction Feedforward Gain (Kfff)	0

9 Click the **Parabolic Velocity Move** button again.

- Repeat this until the correlation of **Following Error** to the velocity disappears.



10 In the same way, if **Following Error** has a correlation to **Acceleration**, **Position**, etc., increase or decrease the **Kaff** and **Kfff** values.

Trajectory Selection

Step Ramp Parabolic Vel Trapezoidal Vel S-Curve Sinusoidal Sine Sweep User Defined

Select Parabolic Move Parameters

Move Size: 2500 mu

Move Time: 500 ms

Parabolic Velocity Move

Move Options

Kill Motor After the Move

Dwell Time After the Move: 500 ms

Move in One Direction Only

Repetitive Move

Filter Calculator

Set Gantry Cross-Coupling Gains

Show Servo Block Diagram

Select Plot Items

- Left Axis
- Right Axis
- Plot to New Chart

Velocity

Position

Velocity






Acceleration



Following Error

None

3-6-6 Checking of Operation and Creation of Tuning Parameter Project

Follow the procedure below to check operations and create a tuned parameter project.

<p>1</p> <p>Type the Motor[1].PhaseFindingStep=1 command from the Terminal to perform a phase search.</p> <ul style="list-style-type: none"> • The Motor[1].PhaseFindingStep value changes to 1, 6, 7, and 0. • When the phase search succeeds, the Motor[1].ClosedLoop and Motor[1].PhaseFound values change from 0 to 1. In addition, the Motor[1].New[0].Pos value becomes larger than the Motor[1].AbsPhasePosOffset set value. The AMP ENAB 0 LED is turned on at that time. 	 <p>Terminal: Online [192.168.0.200 : SSH]</p> <pre>Motor[1].PhaseFindingStep=1</pre>  <table border="1"> <thead> <tr> <th>Command/Query</th> <th>Response</th> </tr> </thead> <tbody> <tr> <td>Sys.ServoCount</td> <td>4088603</td> </tr> <tr> <td>Motor[1].PhaseFindingStep</td> <td>0</td> </tr> <tr> <td>Motor[1].ClosedLoop</td> <td>1</td> </tr> <tr> <td>Motor[1].PhaseFound</td> <td>1</td> </tr> <tr> <td>Motor[1].New[0].Pos</td> <td>469.75999999999991</td> </tr> </tbody> </table>	Command/Query	Response	Sys.ServoCount	4088603	Motor[1].PhaseFindingStep	0	Motor[1].ClosedLoop	1	Motor[1].PhaseFound	1	Motor[1].New[0].Pos	469.75999999999991
Command/Query	Response												
Sys.ServoCount	4088603												
Motor[1].PhaseFindingStep	0												
Motor[1].ClosedLoop	1												
Motor[1].PhaseFound	1												
Motor[1].New[0].Pos	469.75999999999991												
<p>2</p> <p>Type the #1 j+ command from the Terminal.</p>	 <p>Terminal: Online [192.168.0.200 : SSH]</p> <pre>Motor[1].PhaseFindingStep=1</pre> <pre>#1 j+</pre>												
<p>3</p> <p>Make sure that the motor is rotating. In addition, confirm that the #1 Velocity value is around 32 in the Position window.</p> <ul style="list-style-type: none"> • Velocity depends on Motor[1].JogSpeed (32 by default). 	 <table border="1"> <thead> <tr> <th></th> <th>Position</th> <th>Velocity</th> </tr> </thead> <tbody> <tr> <td>#1</td> <td>10,608,759.57 mu</td> <td>31.32 mu/msec</td> </tr> <tr> <td>#2</td> <td>0.00 mu</td> <td>0.00 mu/msec</td> </tr> </tbody> </table>		Position	Velocity	#1	10,608,759.57 mu	31.32 mu/msec	#2	0.00 mu	0.00 mu/msec			
	Position	Velocity											
#1	10,608,759.57 mu	31.32 mu/msec											
#2	0.00 mu	0.00 mu/msec											
<p>4</p> <p>Type the kill command from the Terminal to stop the motor.</p>	 <p>Terminal: Online [192.168.0.200 : SSH]</p> <pre>Motor[1].PhaseFindingStep=1</pre> <pre>#1 j+</pre> <pre>kill</pre>												

5	Open the global definitions.pmh under PMAC Script Language – Global Includes in the Solution Explorer.	 <p>The screenshot shows the Solution Explorer window with the following structure:</p> <ul style="list-style-type: none"> Documentation <ul style="list-style-type: none"> note.txt Log PMAC Script Language <ul style="list-style-type: none"> Global Includes <ul style="list-style-type: none"> global definitions.pmh (highlighted with a red box) Kinematic Routines Libraries Motion Programs PLC Programs
6	Add the gain values obtained from tuning to the global definitions.pmh.	<pre>Motor[1].IiGain = *** Motor[1].IpfGain = *** Motor[1].IpbGain = *** Motor[1].Servo.Kp = *** Motor[1].Servo.Kvfb = *** Motor[1].Servo.Kaff = *** Motor[1].Servo.Kvff = ***</pre>
7	Open the pp_startup.txt under Configuration in the Solution Explorer.	 <p>The screenshot shows the Solution Explorer window with the following structure:</p> <ul style="list-style-type: none"> C Language Configuration <ul style="list-style-type: none"> pp_custom_save.cfg pp_custom_save.tpl pp_disable.txt pp_inc_disable.txt pp_inc_startup.txt pp_save.cfg pp_startup.txt (highlighted with a red box) systemsetup.cfg Documentation
8	Write the phase search implementation command shown on the right.	<pre>Motor[1].PhaseFindingStep = 1</pre>

9

Select the project and execute Build and Download.

- Refer to step 3 through 6 in *3-4 Various Controller Settings* on page 3-8 for the Build and Download method.
- As shown in step 5 and 6, gains can be downloaded on PMAC as a program if you write gains in the global definitions.pmh.
- As shown in step 7 and 8, the phase search is automatically performed after the power is turned ON or reset to enable Motor[1] if you write the phase search implementation command in the pp_startup.txt.

OMRON Corporation Industrial Automation Company
Kyoto, JAPAN

Contact: www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp
The Netherlands
Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200
Hoffman Estates, IL 60169 U.S.A.
Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2),
Alexandra Technopark,
Singapore 119967
Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower,
200 Yin Cheng Zhong Road,
PuDong New Area, Shanghai, 200120, China
Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2019 All Rights Reserved.
In the interest of product improvement,
specifications are subject to change without notice.

Cat. No. O047-E1-01

0719