Vision Sensor FH/FHV Series

Robot Vision Application Construction Guide

OMRON Corporation Edition

TABLE OF CONTENTS

INT	roi	DUCTION	1
TEF	RMS	AND CONDITIONS AGREEMENT	2
S	OFT	WARE LICENSE AGREEMENT	5
REC	GUL	ATIONS AND STANDARDS	12
SA	FET	PRECAUTIONS	13
1.	ov	ERVIEW	16
1	.1.	Overview	16
1	.2.	TARGET READERS	18
2.	SYS	STEM CONFIGURATION	19
2	.1.	WHEN USING VISION SENSOR FH SERIES	19
2	.2.	When using Vision Sensor FHV Series	20
3.	ST/	ARTUP PROCEDURES	22
3	.1.	WORK FLOW	22
3	.2.	What You Can Obtain by This Startup Procedure	22
3	.3.	PRECONDITIONS	25
4.	CR	EATING DATA SET FOR ROBOT VISION	26
4	.1.	CREATING DATA SET	26
5.	CO	NNECTING VISION SENSOR TO ROBOT CONTROLLER	28
5	.1.	SETTING COMMUNICATIONS FOR VISION SENSOR	29
5	.2.	SETTING COMMUNICATIONS FOR ROBOT CONTROLLER	30
5	.3.	CONNECTING AND CHECKING VISION SENSOR AND ROBOT CONTROLLER	33
6.	SE	TTING VISION SENSOR	38
6	.1.	Overview	38
6	.2.	PICK/PLACE WITH FIXED CAMERA	46
6	.3.	GRIP CORRECTION WITH FIXED CAMERA	65
6	.4.	PICK/PLACE WITH ON-HAND CAMERA	82
6	.5.	BACKING UP SETTINGS	. 103
7.	DE	SIGNING ROBOT PROGRAMS	. 105
7	.1.	CONNECTING VISION SENSOR TO ROBOT CONTROLLER	. 106
7	.2.	SWITCHING SCENES ON VISION SENSOR	. 107
7	.3.	MOVING ROBOT TO ROBOT IMAGE POSITION	. 108
7	.4.	EXECUTING MEASUREMENTS ON VISION SENSOR AND GETTING MEASUREMENT RESULTS	. 109
7	.5.	MOVING ROBOT TO ROBOT APPROACH POSITION AT MEASUREMENT	. 110
7	.6.	MOVING ROBOT TO ROBOT COMMAND POSITION AT MEASUREMENT	. 111

	7.7.	DISCONNECTING VISION SENSOR FROM ROBOT CONTROLLER	112
8.	REF	FERENCE INFORMATION	113
9.	RE۱	VISION HISTORY	114

Copyrights and Trademarks

Microsoft product screen shots reprinted with permission from Microsoft Corporation. **Windows** is either registered trademarks or trademarks of **Microsoft Corporation** in the United States and other countries.

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Introduction

Thank you for purchasing the FH/FHV.

This manual provides information regarding functions, performance, and operating methods that are required for using the FH/FHV Series product. When using the FH/FHV Series product, be sure to observe the following:

- The FH/FHV Series product must be operated by personnel knowledgeable in electrical engineering.
- To ensure correct use, please read this manual thoroughly to deepen your understanding of the product.
- Please keep this manual in a safe place so that it can be referred to whenever necessary.

This Manual does not contain safety information and other details that are required for actual use of a FH/FHV Series Controller. Thoroughly read and understand the manuals for all of the devices that are used in this Manual to ensure that the system is used safely. Review the entire contents of these materials, including all safety precautions, precautions for safe use, and precautions for correct use.

Any part or whole of this operation manual may not be copied, reproduced, or reprinted without permission. The contents of this manual, including product specifications, are subject to change based on improvements of the product without prior notice. Your understanding is appreciated

We are committed to providing precise information. Should you have any questions or concerns regarding the contents of this document, please do not hesitate to contact us. When you contact us, please be sure to provide us with the Catalog number printed on the back cover.

Terms and Conditions Agreement

Warranties.

(a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.

(b) Limitations. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right.

(c) Buyer Remedy. Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See <u>http://www.omron.com/global/</u> or contact your Omron representative for published information.

Limitation on Liability; Etc.

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Suitability of Use.

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products.

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Performance Data.

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications.

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions.

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Even if it conforms to all instructions in this safety guide, it isn't possible to guarantee that a robot system will be free from an accident resulting in injury or death or considerable damage to property caused by the industrial robot. It is the customer's responsibility to implement appropriate security measures based on their own risk assessment.

READ CAREFULLY

You (either an individual or a legal entity) may use the Licensed Software defined below as a Licensee, only when you agree to the SOFTWARE LICENSE AGREEMENT (this "Agreement) set forth below.

This Agreement is a legal agreement between you and OMRON Corporation. By breaking the seal of this package, clicking "I Agree", downloading, installing, copying or otherwise using this Licensed Software, you agree to be bound by and comply with the terms and conditions of this Agreement. If you do not agree with such terms and conditions, do not install, copy, or use any part of this Licensed Software.

SOFTWARE LICENSE AGREEMENT

Subject to the aforementioned compliance by Licensee, Omron grants to Licensee a non-exclusive and non-transferable license to use internally the Licensed Software only on the Designated Equipment as follows:

Section 1 DEFINITION

Terms	Meanings		
Omron	Omron Corporation		
this Agreement	SOFTWARE LICENSE AGREEMENT		
Licensee	a person (either an individual or a legal entity) who		
	agrees to this Agreement and obtains "Licensed		
	Software" to install, copy or otherwise use		
Licensed Software	the measurement data collection software, robot		
	program, sample scene data, sample macro		
	program, related documentation and any derivative		
	works thereto to which this Agreement relates		
Intellectual Property	any patent, copyright, trade secret, trademark or		
Rights	other intellectual property rights (including, without		
	limitation, applications thereof) in any idea, design,		
	concept, method, technique, invention, discovery,		
	improvement, technical information, software (in		
	whatsoever form or media) and related algorithms,		
	flow charts, logic diagrams and specifications, mask		
	works, graphics or other works of authorship		

As used herein, the following terms shall have the following meanings:

Affiliate	an entity (i) which is directly or indirectly controlling
	a party; or (ii) which is under the same direct or
	indirect ownership or control as a party; or (iii)
	which is directly or indirectly owned or controlled by
	a party. For these purposes, "control" of an entity
	means either (i) having the right to vote a majority
	of the voting securities of such entity or (ii) for
	entities with no voting securities, having the right to
	a majority of the ownership interests representing
	the right to make decisions for such entity.

Section 2 GRANT

- 2.1 Subject to the terms and conditions in this Agreement, Omron hereby grants to Licensee the following limited, revocable, non-transferable, non-exclusive and "as-is" to use, copy, modify and sublicense the Licensed Software. Licensee may use the Licensed Software free of charge unless otherwise specified by Omron.
- 2.2 Except as expressly permitted by this Agreement, Licensee shall not:
 - (a) distribute, publish, sell, assign, transfer, rent, lease or upload to any website or server the Licensed Software;
 - (b) reverse engineer, de-compile or disassemble the Licensed Software; or
 - (c) use or reproduce the Licensed Software, in whole or in part, other than as expressly permitted by this Agreement.
- 2.3 Licensee shall not use the Licensed Software for any unlawful, illegal or unethical activity, nor develop any Licensed Software which promotes or facilitates the commission of a crime, or other tortious, unlawful, illegal or unethical act.
- 2.4 Licensee shall not disclose or publish any information that helps any third party do prohibited activities of Licensee in this Agreement.

Section 3 NO WARRANTY AND DISCLAIMER

OMRON LICENSES THE LICENSED SOFTWARE TO LICENSEE ON AN "AS IS" BASIS WITH ALL FAULTS, AND WITHOUT WARRANTY OF ANY KIND. LICENSEE ACKNOWLEDGES AND AGREES THAT LICENSEE SHALL USE, COPY, MODIFY AND SUBLICENSE THE LICENSED SOFTWARE, SOLELY ON ITS OWN RESPONSIBILITY, AND AT ITS SOLE COST AND RISK. OMRON DOES NOT MAKE, AND HEREBY DISCLAIMS, ANY EXPRESS OR IMPLIED WARRANTEIS INCLUDING, BUT NOT LIMITED TO, TITLE AND NONINFRINGEMENT OF THIRD PARTY'S RIGHTS, THE WARRANTY OF DESIGN, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. OMRON DOES NOT WARRANT THAT LICENSED SOFTWARE WILL MEET LICENSEE'S REQUIREMENTS, THAT ITS OPERATION WILL BE UNINTERRUPTED OR ERROR-FREE, THAT ITS DEFECTS WILL BE CORRECTED, OR THAT IT WILL BE COMPATIBLE WITH ANY OR FUTURE OMRON PRODUCTS. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY OMRON OR ITS AUTHORIZED REPRESENTATIVES SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF OMRON'S OBLIGATIONS UNDER THIS AGREEMENT. LICENSEE HEREBY WAIVES ANY AND ALL CLAIMS THAT LICENSEE MAY HAVE AGAINST OMRON ARISING OUT OF THIS AGREEMENT.

Omron may extend, enhance, or otherwise modify the Licensed Software at any time without notice, but Omron has no obligation to provide Licensee with any updates or changes. If updated or changes are made available by Licensee, the terms and conditions in this Agreement shall govern such updates or changes, unless the updates or changes are accompanied by a separate license in which case the terms and conditions of such license will govern.

Omron has no obligation to provide any support or engineering assistance of any sort to Licensee.

The terms and conditions in this Agreement shall govern the Licensed Software that Licensee has copied, modified and/or sublicensed.

Section 3-2 Australian Consumer Law (for Licensee in Australia)

- 3-1.1 In the event that this Agreement constitutes or involves a supply of goods or services to a consumer as defined in the Australian Consumer Law ("ACL"), nothing contained in this Agreement excludes, restricts or modifies any condition, guarantee, warranty or other obligation which is applicable to or is conferred on Omron pursuant to the ACL where to exclude, restrict or modify any such condition, warranty or other obligation is unlawful.
- 3-1.2 To the extent that Licensee is a consumer for the purposes of the ACL:
 - (a) Omron goods come with guarantees that cannot be excluded under the ACL. Licensee is entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. Licensee is also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
 - (b) To the full extent permitted by Law, where the benefit of any such condition, warranty or other obligation is conferred upon Licensee pursuant to the ACL, Omron's sole liability for breach of any such condition, warranty, guarantee or

other obligation will be limited to: (A) the replacement of the goods or the supply of equivalent goods or payment of the cost of replacing the goods or acquiring equivalent goods; or (B) the repair of the goods or payment of the cost of having the goods repaired.

Section 3-3 Consumer Guarantees Act (for Licensee in New Zealand)

In the event that Licensee is using Licensed Software for a business purpose, Licensee is deemed to accept and have acknowledged that the Consumer Guarantees Act in New Zealand will not apply to the usage of Licensed Software. For the avoidance of doubt, Licensee shall be deemed to be using Licensed Software for a business purpose if Licensee is acquiring, or hold itself out to be acquiring, the Licensed Software for the purposes of:

- (1) resupplying them in trade;
- (2) consuming them in the course of a process of production or manufacture; or
- (3) repairing or treating in trade other goods or fixtures on land.

Section 4 DAMAGE LIMITATION

THE LICENSED SOFTWARE IS PROVIDED AS A CONVENIENCE AND ACCOMMODATION TO LICENSEE. TO THE EXTENT NO PROHIBITED BY LAW, IN NO EVENT SHALL OMRON, ITS AFFILIATES, OR ANY OF ITS OR THEIR RESPECTIVE DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS, BE LIABLE TO LICENSEE OR ANY THIRD PARTY FOR ANY CAUSE WHATSOEVER, INCLUDING BUT NOT LIMITED TO PERSONAL INJURY OR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL OR PUNITIVE DAMAGES WHATSOEVER, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, LOSS OF DATA, BUSINESS INTERRUPTION OR ANY OTHER COMMERCIAL DAMAGES OR LOSSES, ARISING OUT OF OR RELATING TO THE LICENSED SOFTWARE, OR OTHERWISE UNDER OR IN CONNECTION WITH THIS AGREEMENT, HOWEVER CAUSED, WHETHER UNDER A THEORY OF CONTRACT, WARRANTY, TORT, NEGLIGENCE, PRODUCT LIABILITY, STATUTORY OR OTHERWISE, EVIN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND NOTWITHSTANDING THE FAILURE OF ESSENTIAL PURPOSE OF ANY REMEDY. IN ANY EVENT, THE MAXIMUM LIABILITY OF ANY OF THE FOREGOING PARTIES FOR ALL CLAIMS OF EVERY KIND (INCLUDING THOSE ARISING IN TORT) ARISING OUT OF THIS AGREEMENT SHALL NOT EXCEED THE AMOUNT PAID BY LICENSEE FOR THE LICENSED SOFTWARE.

Section 5 INTELLECTUAL PROPERTY RIGHTS

Title and ownership of all Intellectual Property Rights in the Licensed Software will at all times remain with Omron. The rights granted to Licensee by Omron under such Intellectual Property Rights are only for the purposes set forth in Section 2. Licensee shall not remove any copyright, patent, trade secret, proprietary and/or other legal notices contained on or in the Licensed Software, including any associated software, programming, or documentation. Licensee shall not use any information or data disclosed by Omron in connection with this Agreement to contest the validity of any Omron intellectual property rights. Any such use of Omron's information and data shall constitute a material, non-curable breach of this Agreement. Licensee shall not use any Confidential Information disclosed by Omron intellectual property, including the Licensed Software. Any such use of Omron's information and data shall constitute a material, non-curable breach of this Agreement.

Section 6 INDEMNIFICATION

Licensee agrees to indemnify, defend and hold harmless Omron (including its Affiliates, directors, officers or employees) (collectively, the "Omron Indemnitees") from actual or alleged claims, losses, liabilities, damages, expenses and costs, including reasonable attorney's fees and expert costs, incurred by any Omron Indemnitees as a result of (a) a breach of this Agreement by Licensee, (b) Licensee's violation of applicable law, or (c) the negligence or other wrongful conduct of Licensee.

Section 7 EXPORT/IMPORT CONTROL

Licensee shall comply fully with all relevant export and import laws and regulations of the place of residence and all other relevant jurisdictions ("Export/Import Laws") in the case of export/import or taking action deemed as export/import by Export/Import Laws. Licensee shall indemnify, defend and hold harmless Omron from and against any claims, demands, fines, sanctions, damages, or costs arising out of Licensee's breach of this Section.

Section 8 TERM

- 8.1 This Agreement is effective until terminated.
- 8.2 Omron may terminate this Agreement immediately, in case that:
 - a) Licensee fails to comply with any term in this Agreement;
 - b) there is a threat of or actual lawsuit relating to the Licensed Software; or

c) there shall be filed by or against Licensee application for bankruptcy, dissolution, liquidation, compositions or company reorganization

Section 9 EFFECT OF TERMINATION

- 9.1 Upon termination of this Agreement for any reason or for convenience, the license and rights granted hereunder shall automatically and immediately terminate and expire and Licensee shall immediately (i) cease using the Licensed Software in any manner, (ii) return to Omron or destroy under Omron's instruction the Licensed Software (including all copies thereof) to Omron.
- 9.2 The rights and obligations under Section 3(WARRANTY AND DISCLAIMER), 4(DAMAGE LIMITATION), 5(INTELLECTUAL PROPERTY RIGHTS), 6(INDEMNIFICATION), 10(MISCELLANEOUS) and this Section shall survive expiration or termination of this Agreement and bind the parties and their legal representatives, successors and assigns thereafter.

Section 10 MISCELLANEOUS

- 10.1 If the performance of this Agreement or any obligation hereunder is prevented, delayed or restricted by reason of the cause beyond the reasonable control of the party so affected, including, but not limited to, war, hostility, riot, revolution, embargo, enforcement of any law, order or regulation, fire, wind, earthquake, flood, severe weather or other acts of God, the party so affected shall be excused from such performance to the extent of such prevention, delay or restriction and shall not constitute a breach of this Agreement.
- 10.2 Licensee shall not assign to a third party this Agreement, or any rights or obligations hereunder, in whole or in part, without the prior written approval of Omron. Any attempted assignment without such approval shall be wholly void and totally ineffective for all purposes. Omron may assign this Agreement, without Licensee's consent, to any Affiliate, or in the event of a merger, acquisition, or sale of all or substantially all of its assets.
- 10.3 If, at any time, any provision hereof is or becomes illegal, invalid or unenforceable in any respect under the law of any jurisdiction, the legality, validity or enforceability of the remaining provisions shall in no way be affected or impaired thereby. The invalid provision shall be replaced by a valid one which achieves to the extent possible the original purpose of the invalid provision.

- 10.4 Any failure of either party hereto to enforce at any time or for any period of time, any of the provisions of this Agreement shall not be construed as a waiver of such provision or right or remedy of the party to enforce such provision.
- 10.5 This Agreement does not authorize either party an agent, partner or employee or legal representative of the other party for any purpose whatsoever. Neither party is granted any right or authority to assume or create any obligation or responsibility, expressly or impliedly, on behalf of or in the name of the other party or to bind the other party in any manner or thing whatsoever.
- 10.6 Any and all disputes, controversies or differences which may arise between the parties hereto out of or in relation to or in connection with this Agreement shall be finally and exclusively settled by the competent courts of Japan.
- 10.7 The formation, validity, construction and performance of this Agreement and all amendments and supplements hereto shall be governed and interpreted by and in accordance with the laws of Japan without reference to conflict of law rules.
- 10.8 The prevailing party in any judicial action, if any, brought to enforce or interpret this Agreement or for relief for the breach hereof shall be entitled to recover its reasonable attorney's fees therein incurred.
- 10.9 The headings of this Agreement and respective Section hereof are used for convenience only and shall not affect in any way the construction of the provisions to which they refer.
- 10.10 This Agreement constitutes the final and entire agreement between the parties hereto with respect to the subject matter hereof and supersedes all previous negotiations, representations, statements, agreement or commitments, whether oral or in writing and whether express or implied, between the parties hereto.
- 10.11 Omron may, at its discretion, change this Agreement at any time by any reason. Licensee is deemed to agree to all provisions of the changed Agreement if Licensee uses the Licensed Software after such changes are made.

End

Regulations and Standards

The FH/FHV Vision Sensor Controllers do not conform to laws and regulations relating to the safety of industrial robot application.

When you use the FH/FHV Vision Sensor Controllers in robot systems that use industrial robots, be sure to verify the conformance to laws and regulations relating to the safety of industrial robot application. Take measures to ensure safety as required.

Safety Precautions

• Symbols and the meanings for safety precautions described in this manual.

In order for the product to be used safely, the following indications are used in this book to draw your attention to the cautions. The cautions with the indications describe the important contents for safety.

A WARNING Indicates a potentially hazardous situation which, if not avoided, will result in minor or moderate injury, or may result in serious injury or death. Additionally there may be significant property damage.



Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in property damage.

• Meaning of Alert Symbols.

The following alert symbols are used in this manual.

	General Prohibition
(\mathbf{N})	Indicates general prohibitions, including warnings, for which there is
0	no specific symbol.
^	General Caution
	Indicates general cautions, including warnings, for which there is no
	specific symbol.
Δ	Electrical Hazard
14	Indicates the possible danger of electric shock under specific
	conditions.
Δ	Explosion Hazard
	Indicates the possible danger of explosion under specific conditions.
^	Laser Radiation Hazard
*	Indicates the possible danger of laser radiation or light.
^	High Temperature Caution
	Indicates the possible danger of injury by high temperature under
	specific conditions.
	The filled circle symbol indicates operations that you must do.
	The specific operation is shown in the circle and explained in the text.
	This example shows a general precaution for something that you
	must do.

Precautions for Correct Use

Precautions on what to do and what not to do to ensure proper operation and performance.

Additional Information

Additional information to read as required.

This information is provided to increase understanding or make operation easier.

• Alert statements in this Manual

The following alert statements apply to the products in this manual. Each alert statement also appears at the locations needed in this manual to attract your attention.

A WARNING	
This product must be used according to this manual or Instruction	•
sheet.	
Failure to observe this may result in impairment of functions and performance of the product.	
This product is not designed or rated for ensuring safety of persons. Do not use it for such purposes.	\bigcirc
Never connect the AC power supply with this product.	٨
When the AC power supply is connected, it causes the electric shock	14
and a fire.	
A lithium battery is built into the Controller and may occasionally	
combust, explode, or burn if not treated properly. Dispose of the	Δ
Controller as industrial waste, and never disassemble, apply	A
pressure that would deform, heat to 100°C or higher, or incinerate	
the Controller.	
Since camera that can be connected with this product emits a visible	•
light that may have an adverse effect on the eyes, do not stare	
directly into the light emitted from the LED. If a specular object is	/赤
used, take care not to allow reflected light enter your eyes.	
Do not touch the terminals while the power supply is ON. Doing so may result in electrical shock.	

Please take external safety measures so that the system as a whole should be on the safe side even if a failure of a Sensor Controller or an error due to an external factor occurred. An abnormal operation may result in serious accident.

Please take fail-safe measures on your side in preparation for an abnormal signal due to signal conductor disconnection and/or momentary power interruption. An abnormal operation may result in a serious accident.

Danger of burns. Do not touch the case while the LED is ON or just after power is turned OFF, since it remains extremely hot.







1. Overview

1.1. Overview

This document describes procedures for connections and settings required for constructing robot vision applications by connecting your robot controller to the Vision Sensor FH/FHV (hereafter referred to as Vision Sensor).

Utilizing this document at startup can reduce man-hours to connect the Vision Sensor to your robot controller, set the Vision Sensor, and create robot programs.

Application	Description		
Pick/Place with a fixed	In a robot vision system with a fixed camera mounted,		
camera	the robot can pick and place a workpiece.		
	The Vision Sensor measures the target workpiece for		
	Pick/Place and outputs a robot position for Pick/Place to		
	the robot controller.		
	/ Imaging (Measurement) Pick		
	(Measurement) Place		
Grip Correction with a	In a robot vision system with a fixed camera mounted,		
fixed camera	a position deviation from the reference position of a		
	picked workpiece can be corrected.		
	The Vision Sensor measures the workpiece, calculates		

Robot Vision applications described in this document are as follows.

	an amount of the position deviation from the reference		
	from the reference position for the workpiece position		
	to the robot controller.		
	Imaging		
	(Measurement)		
	Grip Correction		
	When combining the Grip Correction and Place, the		
	Vision Sensor outputs a placing position considering		
	positioning deviation to the robot controller.		
Pick/Place with an	In a robot vision system with a camera mounted on the		
on-hand camera	robot hand, the robot can pick and place a workpiece.		
	Imaging '(Measurement) Pick		
	Imaging '(Measurement) Place		

1.2. Target Readers

Target readers for this document are who are responsible for connecting the Vision Sensor and the robot controller, executing calibration between a camera and a robot using the robot control by the Vision Sensor, and construct robot vision applications. Additionally, the readers need to have understood the use and implementation methodology for robot programs of the targeted robot controller.

2. System Configuration

This chapter describes the system configuration and target devices to construct robot vision applications.

2.1. When using Vision Sensor FH Series

2.1.1. System Configuration



2.1.2. Target Devices

Device name	Manufacturer	Name	Model	Remarks
Vision		Vision Sensor		Ver. 6.21 or
Sensor	OMRON	FH Series		later
Robot		Robot controller	10200 000	
controller	OMRON	SmartController EX	19300-000	
	OMRON	Vertical multi-joint	1720□-36000	
		robot	1720□-36020	
Dehet		Viper 650	1720□-36010	
RODOL			1720 - 38000	
		Viper 850	1720□-38020	
			1720□-38010	
Teaching		Tooching pondant T20	10046 010	
pendant	OMIKUN	reaching pendant 120	10040-010	

PC software	OMRON	Data set output tool for Robot vision	_	Please contact us for how to obtain it.
	OMRON	Software Automation Control Environment (ACE)	_	Ver. 3.7 or later
Switching hub	OMRON	Industrial switching hub	W4S1-□□□	Recommended product
USB memory	OMRON	USB memory	FZ-MEM2G FZ-MEM8G	Recommended product

2.2. When using Vision Sensor FHV Series

2.2.1. System Configuration



2.2.2. Target Devices

Device name	Manufac turer	Name	Model	Re	emarks	5
Vision		Vision Sensor	FHV7□-M□□-C	Ver.	6.21	or
Sensor	OMRON	FHV Series	FHV7□-C□□□-C	later		
Ethernet		Ethernet Cable	FHV-VNB			
Cable	OMRON		FHV-VNLB			
Robot		Robot controller	10200 000			
controller	OPIKUN	SmartController EX	19300-000			

		Vertical multi-joint robot Viper 650	1720 - 36000	
			1720 - 36020	
Dobot			1720□-36010	
RUDUL	OMRON		1720 - 38000	
		Viper 850	1720□-38020	
			1720□-38010	
Teaching		Teaching pendant T20	10046 010	
pendant	OMRON		10046-010	
	OMRON	Data set output tool for Robot vision	-	Please contact
				us for how to
PC coftwara				obtain it.
FC SUITWATE	OMRON	Software		
		Automation Control	_	Ver. 3.7 or later
		Environment (ACE)		
Switching		Industrial switching hub	W4S1-□□□	Recommended
hub	UMRUN			product
USB		LICP momon	FZ-MEM2G	Recommended
memory	UNIKUN		FZ-MEM8G	product

Precautions for Correct Use

Do not use any device except mentioned above for each device of the system configuration.

Additional Information

This document does not provide operations, installation, and wiring methods for each device.

For details, refer to manuals noted in Chapter 8 Reference Information.

3. Startup Procedures

This chapter describes the work flow, preconditions, and what can be achieved by Startup Procedures in each chapter.

3.1. Work Flow

Please follow the flow below for constructing robot vision applications



3.2. What You Can Obtain by This Startup Procedure

3.2.1. Creating Data for the Robot Vision

When following the procedures in Chapter 4, you can create robot programs (sample programs) for the robot controller and data (environment data) for the Vision Sensor corresponding to the type of robot vision applications and camera mounting method.



3.2.2. Connecting Vision Sensor and Robot Controller

When following the procedures in Chapter 5, you can complete necessary settings for communications by loading environment data to the Vision Sensor and robot programs to the robot controller. Additionally, executing a robot program for startup establishes TCP/IP connection between the Vision Sensor as a server and the robot controller as a client.



3.2.3. Setting Vision Sensor

When following the procedures in Chapter 6, you can complete settings for the Vision Sensor required for application construction, calibration between camera and robot, and controlling the robot such as driving robot by the Vision Sensor's operation. Additionally, you can check the setting results of the Vision Sensor by actually moving the robot.



3.2.4. Designing Robot Programs

Described in the following figure, when following the procedures in Chapter 7, you can understand an implementation methodology for robot programs to control the Vision Sensor such as switching scenes or executing measurements by running robot programs in the robot controller described in the following figure.



The implementation procedures for robot programs noted in Chapter 7 are a reference. You should design, implement, and test actual operated robot programs based on the used environment and robot applications.

3.3. Preconditions

The following conditions shall be satisfied.

The installation, wiring, and operation verification for each device have been finished.

The robot controller is in auto mode and the high-power is turned on.

Additional Information

This document does not provide operations, installation, and wiring methods for each device.

For details, refer to manuals noted in Chapter 8 Reference Information.

4. Creating Data Set for Robot Vision

This chapter describes procedures to create robot programs (sample program) for the robot controller and data (environment data) for the Vision Sensor to construct robot vision applications.

Please follow the flow below for the settings.



4.1. Creating Data Set

Follow the procedures below to create a data set for the robot vision.

1	Launch the output tool for the data set for the robot vision.	Name Jata Janguage RobotSettingTool.exe
2	Select a robot manufacturer to connect from the combo box.	Select robot maker Adept_6 axis Adept_6 axis Adept_6 axis Adept_4 axis Select application FANUC 6 axis Compare province
3	Select an application to construct by clicking the radio button at the left of the application name. Select a camera mounting method from the combo box at the right.	 Pick Grip Correction Place Pick + Place Pick + Qrip Correction Grip Correction + Place Pick + Grip Correction + Place Pick + Grip Correction + Place Pick + Grip Correction + Place Pick : Fix Grip Correction : Fix Place : Fix Pick : Fix Grip Correction : Fix Place : Fix Pick : Fix Grip Correction : Fix Place : On hand Pick : On hand Grip Correction : Fix Place : On hand

	Click [Output] after selecting the output path for the data set.	Output path Cutput
4	Click [OK] when the "Check" dialog is displayed after the data set was output.	Check
	Check that a folder was created	20180525150608
5	day, hour, minute, and second"	RobotProgram
	in the specified output path and	
	there are "FHdata" and	
	"RobotProgram" in it.	

5. Connecting Vision Sensor to Robot Controller

This chapter describes procedures to connect the Vision Sensor to the robot controller. Please follow the flow below for the settings.

5.1	Setting communications for the Vision Sensor	To reflect the communication settings, load the environment data created by the data set output tool for the robot vision, and then restart the Vision Sensor.
	▼	
5.2	Setting communications for the robot controller	To modify the communication settings for the robot controller, connect the PC (ACE) and the robot controller. Modify the default IP address of the robot controller with PC (ACE) according to the communication settings in the Vision Sensor.
	▼	
5.3	Connecting and checking the Vision Sensor and the robot controller	Check the connection status of Ethernet using PING command. Run a robot program for startup to establish the TCP/IP connection between the Vision Sensor and the robot controller. Check the communication status by sending and receiving commands.

5.1. Setting Communications for Vision Sensor

Please follow the procedures below to set the communications for the Vision Sensor.

	Select [Tool] - [Configuration	FZ-PanDA
1	copy] in the menu bar.	File Function Tool Window TDM Editor System Settings Security settings Scene Group Saving Destination Settings NG analyzer User data tool Define displa User data tool Settings download and upload tools Layout download and upload tools Image file save Registered Image Manager Communication Command Macro Flow viewer Calibration support tool Update standard position tool Conversion scene group data tool Custom dialog Scene Control Macro Tool Configuration copy Line Maintenance
2	Select "Select a sensor controller project" in the [Load] tab. Select the FHdata folder in the folder outputted by using the data set output tool for the robot vision.	Configuration copy Save Load Select a sensor controller project FHORICAL FHORICAL Dat a0 FHORICAL Dat a1 FHORICAL Dat a3
3	Click [Execute] to restart it.	Execute

5.2. Setting Communications for Robot controller

Please follow the procedures below to set the communications for the robot controller.



	The dialog shown on the right will be displayed, set the IP address and the subnet mask for the PC so that the IP address and network part of the referred robot controller are the same but the host part is different.	Internet Protocol Version 4 (TCP/IPv4) Properties General You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings. Obtain an IP address automatically IP address: IP address automatically IP Use the following DNS server: IP referred DNS server: IP address automatically IP address automatically IP addressettings up
		OK Cancel
4		
5	Enter the IP address of the robot controller and click [OK].	Cetting Started Cetting Started Cetting Started Cetting Started Cetting Started Cetting Started Cetting Cetting Started Cetting Cetting Started Cetting Cetting Started Cetting Cettin
6	Select "SmartController" in the Workspace Explorer and click [Configure]. The right dialog will be displayed, select "Configure Controller" and click [Finish].	Workspace Explorer Image: Control in the i

	The right dialog will be displayed, select "SYSTEM SECTION" in the "Section" area and "ipaddress" in the "Statements" area and click [Edit].	V V- System Configuration X Configuration Statements Variable Scottant Captoristant Druck (splostant) Variable Scottant Chapter Scottant Variable Scottant Chapter Scottant Statements Captoristant Druck (splostant) Statements Chapter Scottant Statements
	The right dialog will be displayed, change the ipaddress and click [Accept].	Edit Statement - ipaddress
	Set the IP address not to overlap with other devices.	Composed Statement <pre>(paddress>10.5.5.101 Accept Cancel</pre>
7	Change the IP address of the PC again based on the changed one for the robot controller.	
8	Reconnect to the robot controller.	
9	Right-click "V+ User Module" in the Workspace Explorer and select "Load from V+ File".	Image: Signart Controller 101 Image: Configuration Image: System Configuration Image: Configuration Image: System Configuration Image: Configuration Image: System Configuration Image: Configuration
	Select a robot program in the folder outputted by using the data set output tool for the robot vision.	Name OmronAdept_FHRobotLib.v2 OmronAdept_FHRobotSample.v2

Additional Information

This document does not provide operation, installation, and wiring methods for each device.

For details, refer to manuals noted in Chapter 8 Reference Information.
5.3. Connecting and Checking Vision Sensor and Robot Controller

Follow the procedures below to connect the Vision Sensor and the robot controller and to check the connection status.

5.3.1. Verifying Ethernet Communication (FH Series Vision Sensor)



When 32-byte data cannot be sent/received four times and PING command timed out, check whether or not the robot controller is turned on, the wiring was correctly done, or communication settings are correct.

5.3.2. Verifying Ethernet Communication (FHV Series Vision Sensor)

	Connect the vision sensor,	
1	robot controller and PC by LAN	
	cables.	
	(Operation of the PC)	
	Press the [R] key while	
	pressing and holding the	
r	[Windows] key to display the	
Ζ	"Run with file name" window.	
	Type "cmd" and press the OK	
	button to launch the	
	[Command Prompt] window.	
	(Operation of the PC)	Administrator: C:WWindowsVSystem32Ycmd exe Wicrosoft Windows [Version 6.1.7601]
	Execute PING command to the	Copyright (c) 2009 Microsoft Corporation. All rights reserved. C:\Windows\system32>ping 10.5.5.101
	IP address of the robot	
2	controller.	
3		
	(Operation of the PC)	Administrator: C:WWindowsVsystem32¥cmd.exe Wicrosoft Mindows [Version 6.1.7601]
	When 32-byte data could be	Copyright (c) 2009 Microsoft Corporation. All rights reserved. C:\Windows\system32>ping 10.5.5.101
	successfully	Pinging 10.5.5.101 with 32 bytes of data: Reply from 10.5.5.101: bytes=32 time<1ms TIL=128 Reply from 10.5.5.101: bytes=32 time=1ms TIL=128
	transmitted/received four	Reply from 10.5.5.101: bytes=32 time=1ms III=128 Reply from 10.5.5.101: bytes=32 time=1ms TIL=128 Ping statistics for 10.5.5.101.
_	times like the right figure, that	Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minium = 0ms, Maximum = 1ms, Aperage = 0ms
4	means that the	C:\Windows\system32>
	communications have been	
	established and the wiring and	
	settings of Ethernet is correctly	

	When 22 buts data appret he	Administrator: C:#Windows#System32#cmd.exe	
	When 32-byte data cannot be transmitted/received four times and PING command timed out, check whether or not the robot controller is turned on, the wiring was	<pre>Wicrosoft Windows [Version 6.1.7601] Copuright (c) 2009 Microsoft Corporation. All rights reserved. C:\Windows\system32>ping 10.5.5.101 Pinging 10.5.5.101 with 32 bytes of data: Request timed out. Request timed out. Request timed out. Ping statistics for 10.5.5.101: Packets: Sent = 4, Received = 0, Lost = 4 (100% loss). C:\Windows\system32></pre>	
	correctly done, or communication settings are correct.		¥
5	(Operation of the PC) Execute PING command to the IP address of the Vision Sensor.	■ Administrator C:WVindows¥System324cmd.exe Wicrosoft Windows [Version 6.1.7601] Copyright (c) 2009 Wicrosoft Corporation. All rights reserved. C:\Windows\system32>ping 10.5.5.100	
6	(Operation of the PC) When 32-byte data could be successfully transmitted/received four times like the right figure, that means that the communications have been established and the wiring and settings of Ethernet is correctly done.	<pre>main administrator: C:WWindowsVsystem32*cnd.exe Wicrosoft Windows [Version 6.1.7601] Copyright (c) 2009 Microsoft Corporation. All rights reserved. C:\Windows\system32>ping 10.5.5.100 Pinging 10.5.5.100 with 32 bytes 32 times(lms TIL=128 Reply from 10.5.5.100: bytes=32 times(lms TIL=128 Reply from 10.5.5.100: bytes=32 times(lms TIL=128 Reply from 10.5.5.100: bytes=32 times(lms TIL=128 Ping statistics for 10.5.5.100: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli=seconds: Minimum = 0ms, Maximum = 1ms, Average = 0ms C:\Windows\system32></pre>	
U	When 32-byte data cannot be transmitted/received four times and PING command timed out, check whether or not the robot controller is turned on, the wiring was correctly done, or communication settings are correct.	Administrator: C:WVindows*System32¥cmd.exe C: Windows\system32>ping 10.5.5.100 Pinging 10.5.5.100 with 32 bytes of data: Request fimed out. Request fimed out. Ping statistics for 10.5.5.100: Packets: Sent = 4, Received = 0, Lost = 4 (100% loss). C:\Windows\system32>	

5.3.3. Verify Commands Sent/Received



Like shown on the right figure, if an error message is displayed on the ACE's monitor window, the connection has failed. Check the wiring and others.



(Operation of the Vision Sensor and ACE)

Like shown on the right figure, when [Get] is clicked on the Main Window of the Vision Sensor and the current position of the robot on ACE's monitor window is displayed at the same position on the Main Window of the Vision Sensor, sending/receiving commands between them have been succeeded.

* Correspondence relation of notation

Vision Sensor	ACE
W	yaw
Р	pitch
R	roll

FZ-PanDA						
File Function Tool W	indow					
0.S 0.F			2		Edit flow	
	L	.ayoı	ut0	Sv	vitch layout	
Robot Operation			Robot	Current P	os.	Get
Calibration	_		х :	300.0000	₩ :	0.0000
Robot Ref. Positio	on FH Macro Ver.	1.00	Υ:	0.0000	Р:	180.0000
Robot Operation Che	eck RB Prog. Ver.	1.00	z :	350.0000	R :	0.0000



Additional Information

4

This document does not provide operation, installation, and wiring methods for each device.

For details, refer to manuals noted in Chapter 8 Reference Information.

6. Setting Vision Sensor

This chapter describes by each application type, the setting procedures for the Vision Sensor required for constructing robot vision applications.

Application	Where to find
Pick/Place with a fixed camera	Chapter 6.2
Grip Correction with a fixed camera	Chapter 6.3
Pick/Place with an on-hand camera	Chapter 6.4

6.1. Overview

The settings for the Vision Sensor use a special data set for robot vision applications. By loading the environment data according to the procedures in Chapter 5, scene group data and user dialog data are loaded. Thereby, you can start the setting without designing measurement flow from scratch. Additionally, with jog operation and auto-calibration of robot by user dialog, and controlling robot by operation of the Vision Sensor, the design man-hour can be reduced.

6.1.1. Scene Data Configuration

Scene data is assigned to fixed scene per application. When setting it, switch scenes with reference to the following.

No.	Scene name	Description
0.	Pick	Perform Pick
1.	Grip Correction	Perform Grip Correction
2.	Place	Perform Place

125.	Calibration and Place	Calibrate a camera to be used in Place
126.	Calibration and Crin Correction	Calibrate a camera to be used in Grip
		Calibrate a camera to be used in Place Calibrate a camera to be used in Grip Correction Calibrate a camera to be used in Pick
127.	Calibration and Pick	Calibrate a camera to be used in Pick

6.1.2. User Dialog

On the Main Window of the Vision Sensor, launch buttons for the user dialog are arranged like below.

FZ-PanDA											
File Function Tool Window											
0.Scene group 0 📃			Ec	litflow	D	ata save	Sce	ne switch	Camera image mea	<mark>s.</mark> Image file meas.	
	ms	Layou	ıt0	Swit	ch layout						Measure
Robot Operation	Robot Error	Robot	Current Po	os.	Get	Robot	Command P	os.			
Calibration		x :	400.0000	₩ :	0.0000	х :	0.0000	₩ :	0.0000		
Robot Ref. Position	FH Macro Ver. 1	.01 Y :	0.0000	Р:	90.0000	Υ:	0.0000	Р:	0.0000	Output	Continuous meas.
Robot Operation Check	RB Prog. Ver. 1	.00 Z :	500.0000	R :	0.0000	Ζ:	0.0000	R :	0.0000	1st. NG unit	Next NG unit

Dialog name	Description		
Debat Operation	Sets the jog operation, target position movement, and		
	operation speed and so on.		
Calibration	Calibrates a camera and the robot automatically with		
	operations of the Vision Sensor.		
	Registers the reference position of a workpiece and the robot		
Robot Ref. Position	needed to correctly operate the robot with robot vision		
	applications.		
Robot Operation	Checks the setting results of the Vision Sensor by the robot		
Check	moved actually.		
Dobot Error	You can check for an error caused by an operation in the		
	above dialog.		

Terms used in this dialog are defined as follows.

Term	Description
Robot Reference Position (Robot Ref.	Generic name for the reference position of a workpiece and the robot needed to correctly operate the robot with robot vision applications. This consists of Robot Image Position, Workpiece Reference
Position)	By registering these, the command position to operate the robot at executing measurements is correctly output.







Robot Operation Dialog

Robot Operation Setting Dialog

In the robot operation dialog, the following items are possible to do using basic functions for operating the robot by operations of the Vision Sensor.

Function	Description
	Execute the jog operation of the robot. By clicking [Jog
	operation], the robot is operated according to the settings in the
Jog operation	jog operation setting.
	* The robot will not operate even if you are holding down the
	[Jog operation].
	The robot performs the jog operation to the position set as a
Towart position	target position. The movement amount with one-click action
	follows the setting value of the jog operation setting.
movement	* The robot will not operate even if you are holding down the
	[Jog operation].
	In the jog operation and target position movement, the unit
	distance, unit rotate, speed, jog mode per one-click action can
	be set.
	In the jog mode, "World coordinate system" or "Tool coordinate
Jog operation setting	system" can be selected.

* For each coordinate system, the orientation of each axis differs depending on the robot manufacturer and axis configuration. For the detailed definition of the coordinate systems, please refer to the manual of your robot.

[World coordinate system]

The base of the robot is the reference position in this coordinate system. The jog operation with [Rx], [Ry], or [Rz] rotates the robot around X-axis, Y-axis, and Z-axis respectively. In the case of 4-axis robot, [Rx] and [Ry] are not supported.



[Tool coordinate system]

The flange position and posture of the robot is the reference position in this coordinate system. The jog operation with [Rx], [Ry], or [Rz] rotates the robot around X-axis, Y-axis, and Z-axis respectively. In the case of 4-axis robot, [Rx] and [Ry] are not supported.

	6-axis robot	
	4-axis robot	
Communication		
settings (Comm. setting)	The timeout for communications between the Vision Senso the robot controller can be set.	r and

Clicking [Jog operation] or [Robot move] drives the robot. Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.

When the robot moves to Z-axis direction, check its motion by visual observation and not by camera image.

Precautions for Correct Use

Even if the robot controller changes the reference position from the flange of the tool coordinate system, it will not be reflected to the jog operation setting of the Vision Sensor.

These features are only available in a connection status that is established between the Vision Sensor and the robot controller with TCP no-procedure protocol invoked by steps in Chapter 5.3.

External trigger inputs or communications with outside will be disabled when operating the robot.

Operations except for the Main Window of the Vision Sensor such as opening setting screens for processing units is not executed.

If communications was disconnected during operations of the user dialog, operations of the Vision Sensor may be unavailable for the time period (initial value: 60,000 [ms]) set in the communication timeout in the communication setting. Please change the value as necessary.

6.2. Pick/Place with Fixed Camera

In the case of Pick/Place with a fixed camera, first calculate the relative positional relationship between the workpiece position and the actual robot position according to the workpiece reference position and the robot grip position. Second, output to the robot controller the robot command position o or picking or placing he measured workpiece.

Precautions for Correct Use

When selecting "Grip Correction + Place" or "Pick + Grip correction + Place" in Chapter 4.1, output a position considering an amount of deviation calculated in Grip Correction at Place.

Please follow the flow below for the settings.

6.2.1	Setting Calibration	Set a scene for the Vision Sensor calibration to execute. Perform settings related to camera, target, and calibration operation.
	\blacksquare	
6.2.2	Executing and Checking Calibration	Check the results after executing the calibration with operations of the Vision Sensor to handle data in the robot base coordinate system.
	▼	
6.2.3	Setting Applications	Set a scene for applications of the Vision Sensor to pick or place a workpiece. Register the reference position of the robot operation and set a camera and workpiece.
	\blacksquare	
6.2.4	Checking Application Operations	To check the correctness of the settings, check whether or not the robot actually moves to the Pick/Place position with operations of the Vision Sensor.
	▼	
6.5	Backing up Settings	Back up the setting results of the Vision Sensor done in this Chapter.

6.2.1. Setting Calibration

Follow the procedures below to set a scene for Calibration.



Click the "0. Camera Image Input FH" icon on the Main Window of the Vision Sensor to open the setting screen.

* When using the FHV Series Smart Camera Vision Sensor, delete the "0. Camera Image Input FH" unit and in its place set "Camera Image Input FHV" as Unit 0.

Check the set "Camera No." by clicking [Select camera] tab.

3 * Change the camera number based on the actual environment.

Select the set camera number tab on the "Camera" tab.

Adjust the focus and iris of the camera while watching the image displayed.

Adjust the shutter speed and gain of the camera on the "Camera settings" area.

Change the image mode to "Through" on the "Image Window Setting" dialog on the Main Window of the Vision Sensor to display the camera image.

4

Click [Robot Operation] on the Main Window of the Vision Sensor to open the "Robot Operation" dialog.

ę	0.Camera Image Input FH
\$ 0	1.Robot Data
	2.Shape Search III
	3.Vision Master Calibration
	4.Calculation

).Camera Image Input FH					
Camera	Select camera				
Select setting Camera No.:	Camera0 -				

0.Camera Image Input FH						
Camera	Select camera					
Camera0	Camera1	Camera2				
Camera setting	Screen adjust	White balance				
Camera settings Shutterspeed: Gain:		2000 _ us 85 _ >				

FZ-PanDA						
File Function Tool Window						
0.Scene g 0.Pick_Fix			2		Edit flow	
	ms	L	.ayoı	ıt0	S	vitch layout
Robot Operation			Robot	Current P	os.	Get
Calibration			х :	0.0000	₩ :	0.0000
Robot Ref. Position	FH Macro Ver.	1.00	Υ:	0.0000	Р:	0.0000
Robot Operation Check	RB Prog. Ver.	1.00	z :	0.0000	R :	0.0000

	On the "Robot Operation" dialog, operate the robot to move the calibration target close to the center of the field of view. * After checking the position, return the image mode from "Through" to "Freeze". • These operations drive the re • Operate the robot in the [Emergency stop] button car	Rotot Operation Target Posk: 0.000 Imaget Posk:
	When the robot moves to Z-ax visual observation and not by c Precautions for Correct U Adjust the Z-axis direction so the	is direction, check its motion by amera image.
	as the imaging surface of a wor	kpiece for Pick/Place.
5	Click the "2. Shape search III" icon on the Main Window of the Vision Sensor to open the setting screen.	0.Camera Image Input FH 1.Robot Data 2.Shape Search III 3.Vision Master Calibration 1.Robot Data 4.Calculation
	Select a registering figure by clicking [Edit] on the [Model] tab.	2.Shape Search III Model Region setting Detection point Input type Input image C Create image Registered figure Edit

Register it as a model by clicking [OK] after fitting the registering figure on the calibration target.

Click [Edit] on the [Region setting] tab to set the measurement region according to the field of view for a camera to use. Click [OK] after setting.

Click [Measurement] on the [Measurement] tab and check that the "Count" becomes one.

* If it does not become one, the settings are not proper. Therefore execute the model registration again.

Click the "3. Vision Master Calibration" icon on the Main Window of the Vision Sensor to open the setting screen.

Select the [Sampling setting] tab and set "First calibration setting", "Effective field of view", "Translation sampling setting", "Detection point number" according to the actual environment.

6

	ОК		Cancel		pply	
2.Shape Searc	h III					
Model		Region	setting	De	etection poi	
Registered fi Rectangle				Edit		
2.Shape Search III						

Test measu	Measure		
<mark>r</mark> Judgement			
Count :	0		
		0	1000



3.Vision Master Calib	vration						
Machine setting	Calibration	Sampling setting					
First calibrat X-direction move Y-direction move Rotation start an	First calibration setting X-direction movement: Y-direction movement: Rotation start angle : 10.0000 <> Precise calibration setting						
Precise calibr. Effective field of 50.0000 Sampling metho © One by one	ation setting view(%): 70.0000 _ od: C All at	Detail Setting					
Trans lat i on s X division nur Y division nun	sampling setting nber:	3 - < >					
Rotation sam Machine mov Rotation or Division point	oling setting ementmethod: Ny CRotat number:	ion+translation					

* When using the FHV Series Smart Camera Vision Sensor, select the "Calibration" tab and in the field for "Image Input" select "Camera Image Input FHV".

Click [Get] on the Main Window of the Vision Sensor to get the current position of the robot.

Click [Calibration] to open the "Calibration" dialog.

Click [Edit] in the "Calibration" dialog to open the "Calib. Start Pos." dialog.

Check that the dialog displays the current position of the robot and click [Reg. Calib. Start Pos.].

7

After clicking [Close], check that the "Calib. Start Position" in the "Calib. Start Pos." dialog has been updated.



FZ-Pan	DA												
File	Function	Tool	Wi	ndow									
			0.S 0.P	cene g ick_Fix	roup 0 (ed_6axis					2			Edit flow
					ms		L	.ay	0	ut0		Sw	vitch layout
	Robot Op	erati	on					Rob	oot	Current P	os.		Get
	Calibr	ation						Х	:	300.0000	W	:	0.0000
Ro	bot Ref.	Posi	tio	n	FH Macro	Ver.	1.00	Y	:	0.0000	Ρ	:	180.0000
Rob	ot Opera	tion	Che	ck	RB Prog.	Ver.	1.00	Ζ	:	350.0000	R	:	0.0000

🖳 Calibra	tion	×	📴 Calib. Sta	ərt	Pos.		×
Calib. St	tart Position		Robot	. (Durre	ent Pos.	
x :	0.0000		x	:	:	300.0000	
Y:	0.0000		Y	:	I	0.0000	
Z:	0.0000		Z	:	:	350.0000	
w·	0 0000		W	:	I	0.0000	
	0.0000		P	:		180.0000	
г. 	0.0000		R	:	I	0.0000	
R:	0.0000		Po	a	Cal	ih Start Bac	
	Robot Mov	e	Ke	ē.	Uar	np. otait ros.	
						Close	٦
	Edit						

An operation of the dialog will automatically set values to Scene and System variables previously set in the scenes loaded by the environment copy feature in Chapter 5.1. Do not directly set the values by TDM editor or setting screens for processing items. If proceeding to the following steps without registering the calibration start position, the robot would produce unexpected motion. Please be sure to register the position.



6.2.2. Executing and Checking Calibration

Follow the procedures below to execute and check the calibration.





In the [Data setting] tab, set the unit No. to the "3. Vision Master Calibration" to check the relationship between the camera and robot coordinate systems got from the calibration.

* Regarding the robot base coordinate system shown on the right figure, set the "Rotation" at the "Standard axis" on the "Display setting" tab in the "Calibration support tool" to "Anticlockwise".

If the relation such as directions and camera coordinate origin position between the camera and the robot base coordinate systems is the same as the actual system configuration, the calibration has succeeded.

* Like the NG example, if the relation between the camera and the robot base coordinate systems is different, the calibration has failed. Review the camera settings, model registration, and environment of lightings and then execute the calibration again.

Calibration support t	cool				
Data setting	Display setting				
Display data s Display data No. :	Display data setting Display data No.: 0_ <>				
ſ ^{Calib.} data se	tting				
Unit No. :	<none></none>				
Data No. :	<none> 0 Camera Image Input FH 2 Vision Master Calibration</none>				





	* When using the FHV Series
	Smart Camera Vision Sensor,
	you can use the Simulation
	Software to load a settings data
	file that has been saved for
	backup. This will allow you to
	launch the "Calibration Support
	Tool" from the "Tool" menu. For
	additional information on
	backing up settings data,
	please refer to Section 6.5
F	Remove the calibration target
С	from the robot.

6.2.3. Setting Applications

Follow the procedures below to set a scene for applications.

	Click [Scene switch] on the	0 1_Pick_Fixed_6axis	_ZYZ	2	Ed	it flow	D	ata save	Scen	e switch	Came
	Main Window of the Vision	ns	Layo	ut0	Swite	h layout					
	Sensor		Robo	t Current F	Pos.	Get	Robot	Command P	os.		
		Nooro Vor	x :	0.0000	w :	0.0000	x :	0.0000	w :	0.0000	
		Prog. Ver.	z :	0.0000	R :	0.0000	z :	0.0000	R :	0.0000	🗆 Ou
		Culture							_	(*	15
	Select target scenes. The target	Switch scene									
	scenes are as follows.	Scene group :		0.Scene gro	up O					Switch	
	Pick:	Scene :		127.Calibrat	tion_Pick	_Fixed_6a	xis_ZY	Z 🔹			
1	0 Bick Eixed x x			1.GripCorrec	t_6axis			Ĵ	1	0	
Ŧ				3.Scene 3 4.Scene 4						Cancer	
	Place:			6.Scene 6 7.Scene 7				Ŧ		_	
	2 Place_Fixed_x x										
		Switch scene	_				-				
	Click [OK] to switch scenes.										
		Scene group	:	0.Scene g	roup 0					Switch	
		Scene :		0.Pick_Fix	ed_6axis	6			•		
								OK		Cance	
								JK		Cance	
											-



	Click [Edit] on the "Robot Ref. Position" dialog to open the "Robot Image Pos." dialog. Click [Reg. Robot Image Pos.] on the "Robot Image Pos." dialog to register the current position of the robot. After clicking [Close], check that the "Robot Image Pos." on the "Robot Ref. Position" dialog has been updated. An operation of the dialog will a and System variables previously environment copy feature in Cha values by TDM editor or setting If application operations are pe "Robot Image Pos.", the robot motion. Please be sure to regist	Robot Ref. Position Robot Image Pos. X: 0.0000 Y: 0.0000 Y: 0.0000 P: 0.0000 Robot Move Image Pos. Edit 0.0000 Robot Move P: Edit 0.0000 Robot Move P: Edit 0.0000 Robot Image Pos. X: Source Robot 0000 R: 0.0000 R: 0.0000
6	Place a workpiece for Pick/ Place into the field of view. Click the "0. Camera Image Input FH" icon on the Main Window of the Vision Sensor to open the setting screen. * When using the FHV Series Smart Camera Vision Sensor, delete the "0. Camera Image Input FH" unit and in its place set "Camera Image Input FHV" as Unit 0. Check the set "Camera No." by clicking [Select camera] tab. * Change the camera number based on the actual environment.	0.Camera Image Input FH 1.Calibration Data Reference 2.Calibration Data Reference 3.Shape Search III 4.Calc Axis Move 5.Calculation 5.Calculation O.Camera Image Input FH Camera Select camera Select setting Camera No.:

	Select the set camera number tab on the "Camera" tab.	Camera Select camera Camera0 Camera1 Camera setting Screen adjust
	Adjust the shutter speed and gain of the camera on the "Camera settings" area.	Camera settings Shutter speed : 2000 - µs Gain : 85 - >
7	Register a workpiece as a model for Pick/Place on Shape Search III by operations as same as those at step 5 in Chapter 6.2.1.	
	Select [Camera image meas.] on the Main Window of the Vision Sensor and detect a workpiece position for Pick/Place with clicking [Measure].	Camera image meas. Image file meas. Measure
	Click [Robot Ref. Position] on the Main Window of the Vision Sensor to open the "Robot Ref. Position" dialog.	F2-PanDA File Function Tool Window O.Scene group 0 0.Pick_Fixed_6axis Editflow Switch layout Robot Operation Robot Current Pos. Get X : 0.0000 W : 0.0000 Robot Ref. Position H Macro Ver. 1.00 Y : 0.0000 P : 0.0000 Robot Operation Check RB Prog. Ver. 1.00 Z : 0.0000 R : 0.0000
8	Click [Edit] on the "Robot Ref. Position" dialog to open the "Workpiece Ref. Pos." dialog. Click [Reg. Workpiece Ref. Pos.] on the "Workpiece Ref. Pos." dialog to register the measurement position of the workpiece.	Workpiece Ref. Pos. X X: 0.0000 X: 370.5740 Y: 0.0000 Y: -358.066 TH: 0.0000 TH: -1.7221 Reg. Workpiece Ref. Pos.
		Close

After clicking [Close], check that the "Workpiece Ref. Pos." on the "Robot Ref. Position" dialog has been updated.

An operation of the dialog will automatically set values to Scene and System variables previously set in the scenes loaded by the environment copy feature in Chapter 5.1. Do not directly set the values by TDM editor or setting screens for processing items. If application operations are performed without registering the "Workpiece Ref. Pos.", the robot would produce unexpected motion. Please be sure to register the position.



Click [Robot operation] on the Main Window of the Vision Sensor to open the "Robot Operation" dialog.

File Function Tool Window						
0.Scene g 0.Pick_Fix	roup 0 ed_6axis			2		Editflow
	ms	L	.ayo	ut0	Sv	vitch layout
Robot Operation			Robot	t Current P	os.	Get
Calibration			х :	0.0000	₩ :	0.0000
Robot Ref. Position	FH Macro Ver.	1.00	Υ:	0.0000	Р:	0.0000
Robot Operation Check	RB Prog. Ver.	1.00	Ζ:	0.0000	R :	0.0000

Move the robot to a position to grip a workpiece for Pick/Place on the "Robot Operation" dialog.

9



- These operations drive the robot.
- Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.



When the robot moves to Z-axis direction, check its motion by visual observation and not by camera image.



Click [Get] on the Main Window of the Vision Sensor to get the current position of the robot.

Click [Robot Ref. Position] on the Main Window of the Vision Sensor to open the "Robot Ref. Position" dialog.

Click [Edit] on the "Robot Ref. Position" dialog to open the "Robot Grip Pos." dialog.

Click [Reg. Robot Grip Pos.] on the "Robot Image Pos." dialog to register the current position

10 to register the of the robot.

After clicking [Close], check that the "Robot Image Pos." on the "Robot Ref. Position" dialog has been updated.

FZ-PanDA File Function Tool Window	-				
0.Scene 0.Pick_Fi	group 0 xed_6axis		2	E	Edit flow
	ms	Layo	ut0	Sw	itch layout
Robot Operation		Robot	. Current P	os.	Get
Calibration		х:	300.0000	₩ :	0.0000
Robot Ref. Position	FH Macro Ver.	1.00 Y :	0.0000	Р:	180.0000
Robot Operation Check	RB Prog. Ver.	1.00 Z :	350.0000	R :	0.0000
in the second	🔜 Robot Grip	Pos.	x		
Robot Grip Pos.	Robot Cur	rent Pos.			
X: 0.0000	x :	300.0000			
Y: 0.0000	Υ:	0.0000			
Z: 0.0000	z :	350.0000			
W: 0.0000	w :	0.0000			
P: 0.0000		100 0000			
R: 0.0000	r۰	100.0000			
Rebet Meye	R :	0.0000			
Robot Move	Reg. Ro	bot Grip	Pos.		
Edit					
		CI	ose		

An operation of the dialog will automatically set values to Scene and System variables previously set in the scenes loaded by the environment copy feature in Chapter 5.1. Do not directly set the values by TDM editor or setting screens for processing items. If application operations are performed without registering the "Robot Grip Pos.", the robot would produce unexpected motion. Please be sure to register the position.



Click [Edit] for "Robot Approach Dist." on the "Robot Ref. Position" dialog to open the "Robot Approach Dist." dialog.

Settherobotapproach11distanceonthe"RobotApproachDist.".

After clicking [Close], check that the "Robot Approach Dist." on the "Robot Ref. Position" dialog has been updated.

Click [Robot Move] of the "Robot Image Pos." on the "Robot Ref. Position" dialog to check that the robot moves to the imaging position registered.

Click [Robot Move] of the "Robot Grip Pos." on the "Robot Ref. Position" dialog to check that the robot moves to the grip position registered.

Click [Robot Move] of the

12 "Robot Approach Dist." on the "Robot Ref. Position" dialog to check that the robot moves toward + Z direction by a value set in "Robot Approach Dist." from the robot gripping position.





* If the robot produced unexpected motion, please register the robot approach distance again.

- These operations drive the robot.
- Operate the robot in the whereby pressing the [Emergency stop] button can stop its motion anytime.



6.2.4. Checking Application Operations

Follow the procedures below to check that scenes for applications are operable.

	Click [Robot Operation Check] on the Main Window of the Vision Sensor to open the "Robot Operation Check" dialog.	FZ-PanDA File Function Tool Window O.Scene group 0 O.Pick_Fixed_6axis MS L Robot Operation Calibration Robot Ref. Position FH Macro Ver. 1.00	Layout0 Robot Current Por X : 0.0000 1 Y : 0.0000 1	Edit flow Switch layout s. Get V : 0.0000 o : 0.0000
1	Click [Robot Move] of the "Robot Image Pos." on the "Robot Operation Check" dialog and move the robot to the imaging position.	Robot Operation Check RB Prog. Ver. 1.00 Robot Operation Check X Robot Image Pos. Robot Move Robot Approach Pos. Robot Move Robot Command Pos. Robot Move Close Close	Z : 0.0000 I	R : 0.0000
	 These operations drive the ro Operate the robot in the why stop] button can stop its mote 	WARNING boot. ereby pressing the [Emerge tion anytime.	ncy	0
2	Select [Camera image meas.] on the Main Window of the Vision Sensor and detect a workpiece position for Pick/Place with clicking [Measure].	Camera image meas. Image file meas. Measure		



6.3. Grip Correction with Fixed Camera

For Grip Correction with a fixed camera, calculate a grip deviation amount from the workpiece reference position of a measured workpiece, and outputs to the robot controller the robot command position to correct the grip deviation amount.

Precautions for Correct Use

ſħ

When you would like to relatively move the robot to a Place position fixed from the Grip Correction, first correct the position deviation with the grip correction and then move the robot to the Place position relatively.

Please follow the flow below for the settings.

6.3.1	Setting Calibration	Set a scene for the Vision Sensor calibration to execute. Perform settings related to camera, target, and calibration operation.
	\blacksquare	
6.3.2	Executing and Checking Calibration	Check the results after executing the calibration with operations of the Vision Sensor to handle data in the robot base coordinate system.
	\blacksquare	
6.3.3	Setting Applications	Set a scene for applications of the Vision Sensor for the Grip Correction. Register the reference position of the robot operation and set a camera and workpiece.
	\blacksquare	
6.3.4	Checking Application Operations	To check the correctness of the settings, check whether or not the robot actually moves to the Grip Correction position with operations of the Vision Sensor.
6.5	Backing up Settings	Back up the setting results of the Vision Sensor performed in this Chapter.

6.3.1. Setting Calibration

Follow the procedures below to set a scene for Calibration.



Click the "0. Camera Image Input FH" icon on the Main Window of the Vision Sensor to open the setting screen.

* When using the FHV Series Smart Camera Vision Sensor, delete the "0. Camera Image Input FH" unit and in its place set "Camera Image Input FHV" as Unit 0.

Check the set "Camera No." by clicking [Select camera] tab.

3 * Change the camera number based on the actual environment.

Select the set camera number tab on the "Camera" tab.

Adjust the focus and iris of the camera while watching the image displayed.

Adjust the shutter speed and gain of the camera on the "Camera settings" area.

ę	0.Camera Image Input FH
<u></u>	1.Robot Data
ш 	2.Shape Search III
	3.Vision Master Calibration
	4.Calculation

D.Camera Image Input FH							
Camera	Select camera						
Select setting Camera No.:	Camera0 🗸						

0.Camera Image Input FH								
Camera Select camera								
Camera0	Camera2							
Camera setting	Camera setting Screen adjust White balance							
Camera settings Shutter speed : 2000 - µs Gain : 85 - < -								

Change the image mode to "Through" on the "Image Window Setting" dialog on the Main Window of the Vision Sensor to display the camera image.

Click [Robot Operation] on the Main Window of the Vision Sensor to open the "Robot Operation" dialog.

On the "Robot Operation" dialog, operate the robot to move the calibration target close to the center of the field of view.

4 * After checking the position, return the image mode from "Through" to Freeze".

FZ-PanDA						
File Function Tool Window						
0.Scene g	roup 0			1		Edit flow
0.Pick_Fix	ed_6axis					
	ms	L	ayoı	ut0	Sv	vitch layout
Robot Operation			Robot	Current P	os.	Get
Calibration			х:	0.0000	₩ :	0.0000
Robot Ref. Position	FH Macro Ver.	1.00	Υ:	0.0000	Р:	0.0000
Robot Operation Check	RB Prog. Ver.	1.00	z :	0.0000	R :	0.0000

💀 Robot Operation				
Jog Operation		Target Position		
-x	+X	Target PosX :	0.0000	
		Target PosY :	0.0000	
-Y	+Y	Target PosZ :	0.0000	
-Z	+Z	Target PosW :	0.0000	
		Target PosP :	0.0000	
-Rx	+Rx	Target PosR :	0.0000	
-Ry	+Ry	Robot Move		
-Rz	+Rz	Edit		
Jog Operation Setting				
Unit	Distance (mr	m): 10	10.0000	
Unit Rotate (deg) :		: 3.0	3.0000	
Speed (%) :		1	1	
Jog Mode :		0		
Comm. Setting				
Timeout (ms) :		60	000	
			Close	

- These operations drive the robot.
- Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.



When the robot moves to Z-axis direction, check its motion by visual observation and not by camera image.



Precautions for Correct Use

Adjust the Z-axis direction so that the calibration target will be the same height as the imaging surface of a workpiece for Grip Correction.
Click the "2. Shape search III" icon on the Main Window of the Vision Sensor to open the setting screen.

 0.Camera Image Input FH

 1.Robot Data

 2.Shape Search III

 3.Vision Master Calibration

 1.Calculation

Select a registering figure by clicking [Edit] on the [Model] tab.

Register it as a model by clicking [OK] after fitting the registering figure to the calibration target.

5

Click [Edit] on the [Region setting] tab to set the measurement region according to the field of view for a camera to use. Click [OK] after the setting.

Click [Measurement] on the [Measurement] tab and check the "Count" becomes one.

* If it does not become one, the settings are not proper. Therefore execute the model registration again.

2.Shape Search III				
Model	Region	setting	De	tection point
Input type © Inputimage		0.0	Create	image
Registered figure			C	Edit
	ок	Canc	el	Apply

2.Shape Search III		_
Model	Region setting	Detection poi
Registered figure Rectangle		Edit

pe Search II				
Model	Region setting	Detection point	Ref.setting	Measuremen

Test measu	iring of this item.		Measure
Judgement Count:	0		
		0	1000

Click the "3. Vision Master 0.Camera Image Input FH NŞ Calibration" icon on the Main <u>ل</u>م 1.Robot Data Window of the Vision Sensor to open the setting screen. ш 2.Shape Search III Ь 3. Vision Master Calibration **⊷**⊞ 4.Calculation 3.Vision Master Calibration Select the [Sampling setting] Calibration Sampling setting Machine setting tab and set "First calibration First calibration setting setting", "Effective field of X-direction movement : view", "Translation Y-direction movement: 10.0000 sampling 10.0000 Rotation start angle setting", "Division point Precise calibration setting number" according to the Effective field of view(%) : 50.0000 - - 70.0000 -Detail Setting 6 actual environment. Sampling method : One by one All at once Translation sampling se<u>tting</u> X division number : 3 < > < > Y division number Rotation sampling setting Machine movement method : Rotation only C Rotation+translation Division point number : 3 ... < > .Vision Master Calibrati * When using the FHV Series Machine setting Calibration Sampling setting Ca Smart Camera Vision Sensor, Calibration target No. Input image unit Position X select the "Calibration" tab and **V** 0. 0.Camera Image Input FHV SY.RBVAR_RES_ ♥ 0. 1. 2. 3. 4. 5. 6. 7. <Nothing> <Nothing> in the field for "Image Input" <Nothing> <Nothing> <Nothing> select "Camera Image Input <Nothina> <Nothing> FHV". No. Input image unit : Position X 0. 0.Camera Image Input FHV SY.RBVAR_RES. movement output method Absolute position C Relative position Click [Get] on the Main Window Function Tool File Winde 0.Scene group 0 of the Vision Sensor to get the Edit flow 0.Pick_Fixed_6axis current position of the robot. Switch layout ms Layout0 Robot Operation Robot Current Pos. Get 300.0000 W : 0.0000 Calibration х : Click [Calibration] to open the 7 Robot Ref. Position FH Macro Ver. 1.00 Y : 0.0000 P : 180.0000 "Calibration" dialog. Robot Operation Check RB Prog. Ver. 1.00 Z : 350.0000 R : 0.0000 Click [Edit] in the calibration dialog to open the "Calib. Start Pos." dialog.

Check that the dialog displays the current position of the robot and click [Reg. Calib. Start Pos.].

After clicking [Close], check that the "Calib. Start Position" in the "Calib. Start Pos." dialog has been updated.

Calibration	🔛 Calib. Start Pos.
Calib. Start Position	Robot Current Pos.
X: 0.0000	X : 300.0000
Y: 0.0000	Y : 0.0000
Z: 0.0000	Z : 350.0000
W · 0.0000	W : 0.0000
R: 0.0000	P : 180.0000
P 0.0000	R : 0.0000
R: 0.0000	Reg Calib Start Poc
Robot Move	Reg. Vally. Start Pos.
	Close
Edit	

An operation of the dialog will automatically set values to Scene and System variables previously set in the scenes loaded by the environment copy feature in Chapter 5.1. Do not directly set the values by TDM editor or setting screens for processing items. If proceeding to the following steps without registering the calibration start position, the robot would produce unexpected motion. Please be sure to register the position.



6.3.2. Executing and Checking Calibration

Follow the procedures below to execute and check the calibration.



FZ-Pan	DA						
File	Fund	tion	Tool	Window			
		Measure					
		Scene switch					
		Scene maintenance					
		Edit flow					
		Switch layout					
		Clear	measur	ement			
R		Clear	logging	image			



Click the "3. Vision Master Calibration" icon on the Main Window of the Vision Sensor to open the setting screen.

P	0.Camera Image Input FH
4 0	1.Robot Data
ш 	2.Shape Search III
4	3.Vision Master Calibration
	4.Calculation

Select the [Calibration result] tab to check whether or not the "Error evaluation" has converged within the accuracy required.

3.Vision Master Calibration						
Machine setting	Calibration	Sampling setting	Calibration result			
Precise calibrati	on data]			
A :	-0.000830	D :	0.082671			
в:	-0.083012	E:	-0.000893			
С:	608.155268	F:	-56.239040			
X magnification :	0.082675	X-axis angle :	90.575483			
Y magnification :	0.083017	Y-axis angle :	180.616381			
Origin X :	-608.155268	XY-axis angle :	90.040899			
Origin Y :	56.239040	Error evaluation	0.341182			
X max error :	0.215955					
Y max error :	0.246423					
			Edit			

4

Select [Tool] - [Calibration support tool] from the menu bar.

In the [Data setting] tab, set the unit No. to the "3. Vision Master Calibration" to check the relationship between the camera and robot coordinate systems got from the calibration.

FZ-PanDA	
File Function	Tool Window
	TDM Editor
	System Settings
	Security settings
	Scene Group Saving Destination Settings
Robot Op	NG analyzer
Calibr	User data tool
	Settings download and upload tools
Robot Kef.	Layout download and upload tools
Robot Opera	Image file save
	Registered image Manager
Staa	Elow viewer
First	
First	Update standard position tool
Calibration sup	port tool
Data se	tting Display setting
Display da Display data	ata setting
Calib. dat	a setting
Unit No. :	<none> 💌</none>
Data No. :	<none> 0 Camera Image Input FH 3.Vision Master Calibration</none>

* Regarding the robot base coordinate system shown on the right figure, set the "Rotation" at the "Standard axis" on the "Display setting" tab in the "Calibration support tool" to "Anticlockwise".

If the relation such as directions and camera coordinate origin position between the camera and the robot base coordinate systems is the same as the actual system configuration, the calibration has succeeded.

* Like the NG example, if the relation between the camera and the robot base coordinate systems is different, the calibration has failed. Review the camera settings, model registration, and environment of lightings and then execute the calibration again.

* When using the FHV Series Smart Camera Vision Sensor, you can use the Simulation Software to load a settings data file that has been saved for backup. This will allow you to launch the "Calibration Support Tool" from the "Tool" menu. For additional information on backing up settings data, please refer to Section 6.5



F	Remove the calibration target	
Э	from the robot.	

6.3.3. Setting Applications

Follow the procedures below to set a scene for applications.

	Click [Scene switch] on the	0 1_Pick_Fixed_6axis_	_zyz	Edit flow	Data save	Scene switch	Came
	Main Window of the Vision	ns	Layout0	Switch layout			
	Sensor.		Robot Current Po	os. Get	Robot Command F	'os.	
		Macro Ver.	Y : 0.0000	P: 0.0000	Y : 0.0000	P: 0.0000	
		Prog. Ver.	z: 0.0000	R : 0.0000	z: 0.0000	R : 0.0000	I_ Ou
	Select the target scene,	Switch scene	-	-	-		
	1 Grip correction_XX	Scene group :	0.Scene grou	p 0		Switch	
1	Click [OK] to switch scenes.	Scene : Switch scene	127.Calibrativ 0.Pick_Fixed 2.Place Fixed 3.Scene 3 4.Scene 4 5.Scene 5 6.Scene 5 6.Scene 6 7.Scene 7	on_Pick_Fixed_6a 6axis _ Conto d 6axis	xis_ZYZ •	Cancel	
		Scene group : Scene :	0.Scene gro	oup 0 ect_6axis		Switc	h
					ок	Canc	el

Check that the check box for Continuous meas. Output "Output" is not checked. The serial data for the measurement value is not output until the Vision Sensor 2 setting is completed. Place a check in the check box when executing a robot sample program described in Chapter 7. Click [Robot Operation] on the File Function Tool Window 0.Scene group 0 Main Window of the Vision Edit flow 0.Pick_Fixed_6axis Sensor to open the "Robot Switch layout ms Layout0 Operation" dialog. Robot Current Pos. Get Robot Operation 0.0000 W : 0.0000 Calibration X : FH Macro Ver. 1.00 Y : 0.0000 P : 0.0000 Robot Ref. Position RB Prog. Ver. 1.00 Z : 0.0000 R : Robot Operation Check 0.0000 With workpiece ideally Robot Operation а Jog Operation Target Positio gripped, move the robot to a Target PosX 0.0000 -X +X Target PosY 0.0000 position to image (measure) -Y +Y Target PosZ : 0.0000 Target PosW 0.0000 the workpiece for the Grip -Z +Z 0.0000 Target PosP -Rx +Rx on 0.0000 Correction the "Robot Target PosR 3 -Ry +Ry Robot Move operation" dialog. -Rz +Rz Edit Jog Operation Setting Unit Distance (mm) 10.0000 Unit Rotate (deg) 3.0000 Speed (%) Joa Mode nm. Setting Fimeout (ms) 60000 Close • These operations drive the robot. • Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.

Click [Get] on the Main Window of the Vision Sensor to get the current position of the robot.

Click [Robot Ref. Position] on the Main Window of the Vision Sensor to open the "Robot Ref. Position" dialog.

Click [Edit] of "Robot Image Pos." on the "Robot Ref. Position" dialog to open the "Robot Image Pos." dialog.

Click [Reg. Robot Image Pos.] on the "Robot Image Pos." dialog to register the current position of the robot.

4

5

After clicking [Close], check that the "Robot Image Pos." on the "Robot Ref. Position" dialog has been updated.

FZ-PanDA						
File Function Tool Window						
0.Scene g 0.Pick_Fix	roup 0 ed_6axis			2		Edit flow
l	ms	L	.ayo	ut0	Sv	vitch layout
Robot Operation			Robot	: Current P	os.	Get
Calibration			х:	300.0000	₩ :	0.0000
Robot Ref. Position	FH Macro Ver.	1.00	Υ:	0.0000	Р:	180.0000
Robot Operation Check	RB Prog. Ver.	1.00	z :	350.0000	R :	0.0000

🖳 Robot F	Ref. Position	Robo	t In	nage Pos.	×
Robot Image Pos.		Robo	t (Current Pos.	
X :	0.0000	Х	:	300.0000	
Υ:	0.0000	Y	:	0.0000	
Ζ:	0.0000	Z	:	350.0000	
W :	0.0000	W	:	0.0000	
P :	0.0000	Р	:	180.0000	
R:	0.0000	P		0.0000	
R	obot Move		•	0.0000	
		Rea	g.	Robot Image Pos.	
	Edit			Close	

An operation of the dialog will automatically set values to Scene and System variables previously set in the scenes loaded by the environment copy feature in Chapter 5.1. Do not directly set the values by TDM editor or setting screens for processing items. If application operations are performed without registering the "Robot Image Pos.", the robot would produce unexpected motion. Please be sure to register the position.



Click the "0. Camera image input FH" icon on the Main Window of the Vision Sensor to open the setting screen.



* When using the FHV Series Smart Camera Vision Sensor, delete the "0. Camera Image Input FH" unit and in its place set "Camera Image Input FHV" as Unit 0.

Check the set "Camera No." by clicking [Select camera] tab.

* Change the camera number based on the actual environment.

Select the set camera number tab on the "Camera" tab.

Adjust the shutter speed and gain of the camera on the "Camera settings" area.

Register a workpiece as a model for Grip Correction by operations as same as those at step 5 in Chapter 6.3.1.

6

Select [Camera image meas.] on the Main Window of the Vision Sensor and detect a workpiece position for Grip Correction with clicking [Measure].

7 Click [Robot Ref. Position] on the Main Window of the Vision Sensor to open the "Robot Ref. Position" dialog.

0.Camera Image Inp	out FH	
Camera	Select camera	
Select setting Camera No. :	Camera	0







FZ-PanDA			
File Function Tool V	lindow		
0.9	Scene group 0		Edit flow
0.1	Pick_Fixed_6axis		Edition
	ms	Layout0	Switch layout
Robot Operation		Robot Cur	rent Pos. Get
Calibration		X : 0	.0000 W : 0.0000
Robot Ref. Positi	on 🛛 FH Macro Ver.	1.00 Y : 0	.0000 P : 0.0000
Robot Operation Ch	eck RB Prog. Ver.	1.00 Z : 0	.0000 R : 0.0000

Click [Edit] on the "Robot Ref. Position" dialog to open the "Workpiece Ref. Pos." dialog.

Click [Reg. Workpiece Ref. Pos.] on the "Workpiece Ref. Pos." dialog to register the measurement position of the workpiece.

After clicking [Close], check that the "Workpiece Ref. Pos." on the "Robot Ref. Position" dialog has been updated.

	Workpiece Ref. Pos.
Workpiece Ref. Pos.	Workpiece Meas. Pos.
X: 0.0000	X : 370.5740
Y: 0.0000	Y : -358.066
TH : 0.0000	TH : -1.7221
Edit	Reg. Workpiece Ref. Pos.
	Close

An operation of the dialog will automatically set values to Scene and System variables previously set in the scenes loaded by the environment copy feature in Chapter 5.1. Do not directly set the values by TDM editor or setting screens for processing items. If application operations are performed without registering the "Workpiece Ref. Pos.", the robot would produce unexpected motion. Please be sure to register the position.



Click [Robot Move] of the "Robot Image Pos." on the "Robot Ref. Position" dialog to check that the robot moves to the imaging position registered.

* If the robot produced unexpected motion, please register the workpiece reference position again.

8





Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.



6.3.4. Checking Application Operations

Follow the procedures below to check that scenes for applications are operable.



2	Click [Robot Move] of the "Robot Command Pos." on the "Robot Operation Check" dialog and move the robot to the command position.	Robot Operation Check Robot Image Pos. Robot Move Robot Approach Pos. Robot Move Robot Command Pos. Close
5	 These operations drive the role Operate the robot in the [Emergency stop] button can Check the measurement resure The robot may produce unexp Change positions and angle Correction to check the operation 	bot. state whereby pressing the stop its motion anytime. Its before the robot operation. Dected motion. es of the workpiece for Grip tion sufficiently.
4	Stop the robot program launched by procedures in Chapter 5.3.	

6.4. Pick/Place with On-hand Camera

In the case of Pick/Place with an on-hand camera, first calculate the relative positional relationship between the workpiece position and the actual robot position according to the workpiece reference position and the robot grip position. Second, output to the robot controller the robot command position for picking or placing the measured workpiece.

Precautions for Correct Use

1P

When selecting "Grip Correction + Place" or "Pick + Grip Correction + Place" in Chapter 4.1, output a position considering an amount of deviation calculated in Grip Correction at Place.

Please follow the flow below for the settings.

6.4.1	Setting Calibration	Set a scene for the Vision Sensor calibration to execute. Perform settings related to camera, target, and calibration operation.
	\blacksquare	
6.4.2	Executing and Checking Calibration	Check the results after executing the calibration with operations of the Vision Sensor to handle data in the robot base coordinate system.
	▼	
6.4.3	Setting Applications	Set a scene for applications of the Vision Sensor to pick or place a workpiece. Register the reference position of the robot operation and set a camera and workpiece.
	\blacksquare	
6.4.4	Checking Application Operations	To check the correctness of the settings, check whether or not the robot actually moves to the Pick/Place position with operations of the Vision Sensor.
_	•	
6.5	Backing up Settings	Back up the setting results of the Vision Sensor done in this Chapter.

6.4.1. Setting Calibration

Follow the procedures below to set a scene for Calibration.



Click the "0. Camera image input FH" icon on the Main Window of the Vision Sensor to open the setting screen.

* When using the FHV Series Smart Camera Vision Sensor, delete the "0. Camera Image Input FH" unit and in its place set "Camera Image Input FHV" as Unit 0.

Check the set "Camera No." by clicking [Select camera] tab.

3 * Change the camera number based on the actual environment.

Select the set camera number tab on the "Camera" tab.

Adjust the focus and iris of the camera while watching the image displayed.

Adjust the shutter speed and gain of the camera on the "Camera settings" area.

Change the image mode to "Through" on the Image Window Setting dialog in the Main Window of the Vision Sensor to display the camera image.

4

Click [Robot Operation] on the Main Window of the Vision Sensor to open the "Robot Operation" dialog.

ę	0.Camera Image Input FH
ب	1.Robot Data
	2.Shape Search III
4	3.Vision Master Calibration
111	4.Calculation

0.Camera Image Input FH				
Camera Select camera				
Select setting Camera No. :	Camera	0 🗸		

0.Camera Image Input FH					
Camera	Select camera				
Camera0	Camera1	Camera2			
Camera setting	White balance				
Camera settings Shutterspeed: Gain:	[2000 _ µs 85 _ >			

FZ-Pan	DA											
File	Function	Tool	Window									
	0.Scene group 0 0.Pick_Fixed_6axis							2			Edit flow	
				ms		L	.ay	0	ut0		Sv	vitch layout
	Robot Op	erati	on				Rol	bot	. Current P	os.		Get
	Calibr	ation					х	:	0.0000	W	:	0.0000
Ro	obot Ref.	Posi	tion	FH Macr	o Ver.	1.00	Y	:	0.0000	Ρ	:	0.0000
Rok	oot Opera	tion	Check	RB Prog	. Ver.	1.00	Z	:	0.0000	R	:	0.0000

On the "Robot Operation"	Robot Operation
dialog anarata the rebet to	Jog Operation Target Position
	-X +X Target PosX: 0.0000
move the calibration target	-Y +Y Target PosZ : 0.0000
close to the center of the field	-7 +7 Target PosW: 0.0000
of view.	Target PosP : 0.0000
	-Rx +Rx Target PosR : 0.0000
* After checking the position	-Ry +Ry Robot Move
Arter checking the position,	-Rz +Rz Edit
return the image mode from	Jog Operation Setting
"Through" to Freeze".	Unit Distance (mm) : 10.0000
	Unit Rotate (deg) : 3.0000
	Speed (%): 1 Jog Mode : 0
	Comm. Setting
	Timeout (ms) : 60000
	Close
<u> </u>	WANNING
These operations drive the re-	obot.
Operate the robot in the	state whereby pressing the
[Emergency stop] button car	n stop its motion anytime
/!	CAUTION
When the robot moves to Z-axi	is direction, check its motion by

visual observation and not by camera image.

Precautions for Correct Use

Adjust the Z-axis direction so that the calibration target will be the same height as the imaging surface of a workpiece for Pick/Place.

Click the "2. Shape search III" icon on the Main Window of the Vision Sensor to open the setting screen.

P	0.Camera Image Input FH
۶. 40	1.Robot Data
ш Д	2.Shape Search III
	3.Vision Master Calibration
	4.Calculation

Select a registering figure by clicking [Edit] on the [Model] tab.

Register it as a model by clicking [OK] after fitting the registering figure to the calibration target.

5

Click [Edit] on the [Region setting] tab to set the measurement region according to the field of view for a camera to use. Click [OK] after the setting.

Click [Measurement] on the [Measurement] tab and check the "Count" becomes one.

* If it does not become one, the settings are not proper, so execute the model registration again.

2.Shape Search II	I		_
Model	Region	setting	Detection point
Input type - Inputimag	je	0.0	Create image
Registered figu	ıre		Edit
	ОК	Canc	cel Apply



Model	Region setting	Detection point	Ref.setting	Measureme
Test me	asuring of this	item.	Me	asure
Judgemen Count:	nt — ()		
Count:	()		

86

Click the "3. Vision Master Calibration" icon on the Main Window of the Vision Sensor to open the setting screen.

Select [Sampling setting] tab and set "First calibration setting", "Effective field of view", "Translation sampling setting", "Division point number" according to the actual environment.

6

* When using the FHV Series Smart Camera Vision Sensor, select the "Calibration" tab and in the field for "Image Input" select "Camera Image Input FHV".

Click [Get] on the Main Window of the Vision Sensor to get the current position of the robot.

7 Click [Calibration] to open the "Calibration" dialog.

Click [Edit] in the calibration dialog to open the "Calib. Start Pos." dialog.

١ <u></u>	0.Camera Image Input FH
۴ 0	1.Robot Data
ш <u>Д</u>	2.Shape Search III
	3.Vision Master Calibration
	4.Calculation

3.Vision Master Calib	ration			
Machine setting	Calibration	Sampling	setting	
First calibrat	ion setting —			
X-direction move	ement:	10.0000	< >	
V-direction move	ment :	10,0000		
Potetion start on	ale :	10.0000		
Rotation start an	gie.	10.0000 -	<u>ìí</u>	J
Precise calibra	ation setting -			1
Effective field of	view(%):	Detail	Setting	
50.0000	70.0000		-	
One by one	а. С АІІ	ationce		
Translation	amnling cotti	10		
X division nun	nber:	3	< >	
	_			
Y division nun	iber:	3 _		
Rotation same	ling setting -			
Machine mov	ement method :			
 Rotation on 	ly O Ro	tation+translatio	n	
Division point	number :	3	< >	
				J
3.Vision Master Calibr	ation	_		
Machine setting	Calibration	Sampling sett	ing Ca	
Calibration targ	jet			
No. Input ima	ge unit	Position	n X	
1. <nothing< td=""><td>> > ></td><td>ST.RBV</td><td>AR_RES_</td><td></td></nothing<>	> > >	ST.RBV	AR_RES_	
2. <nothing< td=""><td>></td><td></td><td></td><td></td></nothing<>	>			
4. <nothing< td=""><td>></td><td></td><td></td><td></td></nothing<>	>			
5. <nothing< td=""><td>></td><td></td><td></td><td></td></nothing<>	>			
7. <nothing< td=""><td>></td><td></td><td></td><td></td></nothing<>	>			
No. Input imag	e unit :	Positio	on X :	
0. 0.Camera	Image Input FHV	▼ SY.RE	VAR_RES	
movement output	method			
 Absolute position 	n	C Relative posi	tion	
FZ-PanDA				
File Function To	ol Window			
	0.Scene grou	ip 0		1
	0.Pick_Fixed	_6axis		
	n	าร	Lay	out0
Robot Oper	ation		Rob	oot Current P
Calibrat	ion		x	: 300.0000
ournorat				

FH Macro Ver. 1.00 Y :

RB Prog. Ver. 1.00 Z : 350.0000 R :

Edit flow

0.0000 P :

witch layout Get

0.0000

180.0000

0.0000

Robot Ref. Position

Robot Operation Check

Check that the dialog displays the current position of the robot and click "Reg. Calib. Start Pos."

After clicking [Close], check that the "Calib. Start Position" in the "Calib. Start Pos." dialog has been updated.

Calibration	Calib. Start Pos.
Calib. Start Position	Robot Current Pos.
X · 0 0000	X : 300.0000
X: 0.0000	Y : 0.0000
1. 0.0000	Z : 350.0000
Z: 0.0000	W : 0.0000
W: 0.0000	P : 180.0000
P: 0.0000	R : 0.0000
R: 0.0000	
Pahat Maya	Reg. Calib. Start Pos.
Robot Move	
Edit	Close

An operation of the dialog will automatically set values to Scene and System variables previously set in the scenes loaded by the environment copy feature in Chapter 5.1. Do not directly set the values by TDM editor or setting screens for processing items. If proceeding to the following steps without registering the calibration start position, the robot would produce unexpected motion. Please be sure to register the position.



6.4.2. **Executing and Checking Calibration**

Follow the procedures below to execute and check the calibration.



[Clear measurement] on the Main Window menu to clear the previous measurement results.

FZ-Pan	DA			-					
File	Fun	ction	Tool	Window					
		Mea	sure						
		Scer	Scene switch						
		Scer	cene maintenance						
		Edit	it flow						
		Swit	ch layou	t					
		Clea	r measu	rement					
R		Clea	Clear logging image						



Click the "3. Vision Master Calibration" icon on the Main Window of the Vision Sensor to open the setting screen.



Select [Calibration result] tab to check whether or not the "Error evaluation" has converged within the accuracy required.

3.Vision Master Calibration											
Machine setting	Calibration	Sampling setting	Calibration result								

Precise calibrati	on data 🗕 🚽		
A:	0.000092	D :	-0.094711
в:	-0.094511	E:	0.000028
С:	172.544331	F:	94.855758
X magnification :	0.094711	X-axis angle :	270.055656
Y magnification :	0.094511	Y-axis angle :	179.983025
Origin X :	-172.544331	XY-axis angle :	90.072630
Origin Y :	-94.855758	Error evaluation	0.235365
X max error :	0.575387		
Y max error :	0.496552		
			Edit

4

Select [Tool] - [Calibration support tool] from the menu bar.

FZ-PanDA	-					
File Function	Tool	Window				
		TDM Editor				
		System Settings				
		Security settings				
		Scene Group Saving Destination Settings				
Robot Op		NG analyzer				
Calibr		User data tool				
		Settings download and upload tools				
Robot Ref.		Layout download and upload tools				
Robot Opera		Image file save				
		Registered Image Manager				
D		Communication Command Macro				
Stan		Flow viewer				
First		Calibration support tool				
Data		Update standard position tool				

In the [Data setting] tab, set the unit No. to the "3 Vision Master Calibration" to check the relationship between the camera coordinate system and robot coordinate system got from the calibration.

* Regarding the robot base coordinate system shown on the right figure, set the "Rotation" at the "Standard axis" on the "Display setting" tab in the "Calibration support tool" to "Anticlockwise".





If the relation such as directions and camera coordinate origin position between the camera and the robot flange coordinate systems is same as the actual system configuration, the calibration has succeeded.

* Like the NG example, if the relation between the camera and the robot flange coordinate systems is different, the calibration has failed. Review the camera settings, model registration, and environment of lightings and then execute the calibration again.



	* When using the FHV Series
	Smart Camera Vision Sensor,
	you can use the Simulation
	Software to load a settings data
	file that has been saved for
	backup. This will allow you to
	launch the "Calibration Support
	Tool" from the "Tool" menu. For
	additional information on
	backing up settings data,
	please refer to Section 6.5
F	Remove the calibration target
С	from the robot.

6.4.3. Setting Applications

Follow the procedures below to set a scene for applications.

	Click [Scene switch] on the	0 Edit flow Data save Scene switch Came
	Sensor.	Robot Current Pos. Get Robot Command Pos. X : 0.0000 W : 0.0000 X : 0.0000 W : 0.0000 V : Macro Ver. Y : 0.0000 P : 0.0000 Y : 0.0000 P : 0.0000 P : Prog. Ver. Z : 0.0000 R : 0.0000 Z : 0.0000 R : 0.0000 II :
1	Select target scenes. The target scenes are as follows. Pick: 0. Pick_On-hand_xx Place: 2. Place_On-hand_xx	Switch scene Image: Constraint of the scene scen
	Click [OK] to switch scenes.	Scene group : 0.Scene group 0 Switch Scene : 0 Pick_Onhand_6axis OK Cancel
2	Check that the check box for "Output" is not checked. The serial data for the measurement value is not output until the Vision Sensor setting is completed. Place a check in the check box when executing a robot sample program described in Chapter 7.	Output 🗖 Continuous meas.
	Click [Robot Operation] on the Main Window of the Vision Sensor to open the "Robot Operation" dialog.	FZ-PanDA File Function Tool Window 0.Scene group 0 0.Pick_Fixed_6axis MS Layout0 Switch layout Robot Operation Robot Current Pos. Get
3		Calibration X : 0.0000 W : 0.0000 Robot Ref. Position FH Macro Ver. 1.00 Y : 0.0000 P : 0.0000 Robot Operation Check RB Prog. Ver. 1.00 Z : 0.0000 R : 0.0000



obot Opera

WARNING

- These operations drive the robot.
- Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.



Click [Robot Ref. Position] on the Main Window of the Vision Sensor to open the "Robot Ref. Position" dialog.

Click [Edit] of "Robot Image Pos." on the "Robot Ref. Position" dialog to open the "Robot Image Pos." dialog.

4

	-Z-Pa	nDA															
ļ	File	Fun	ction	Tool	Window	v									_		
l					0.Scene 0.Pick_	e gro Fixe	oup (ed_6;) axis						2			Edit flow
r							ms				L	.ay	οι	ut0		S١	vitch layout
		Robe	ot Op	erat	on							Rob	ot	Current P	os	•	Get
		Ca	alibr	ation	ı							Х	:	300.0000	W	:	0.0000
Į	F	Robot	Ref.	Pos	ition		FH M	lacro	Ver	•	1.00	Y	:	0.0000	Ρ	:	180.0000
	Ro	obot (Opera	tion	Check		RB P	rog.	Ver	•	1.00	Ζ	:	350.0000	R	:	0.0000
Ī	e R	obot	Ref.	Positi	on												
ſ	Ro	bot Ir	nage	Pos.			•	Robo	st Ir	nag	je Po	s.		×	1		
		X :	0	.0000)			Robo	ot	Cur	rent	Po	s	•			
		Y:	0	.0000)			Х	:		300	.00	00				
		Z :	0	.0000)			Y	:		0.00	000					
		W :	0	.0000)			Z	:		350	.00	00				
		P :	0	.0000)			₩	:		0.00	000					
		R:	0	.0000)			Ρ	:		180	.00	00				
		F	lobot	Move	,			R	:		0.00	000					
	Ē	_	E	dit				Re	g.	Rol	bot I	[ma	ge	Pos.			
											[С	lose			

Click [Reg. Robot Image Pos.] on the "Robot Image Pos." dialog to register the current position of the robot. After clicking [Close], check that the "Robot Image Pos." on the "Robot Ref. Position" dialog has been updated.

An operation of the dialog will automatically set values to Scene and system variables previously set in the scenes loaded by the environment copy feature in Chapter 5.1. Do not directly set the values by TDM editor or setting screens for processing items. If application operations are performed without registering the "Robot Image Pos.", the robot would produce unexpected motion. Please be sure to register the position.



5 Place a workpiece for Pick/Place into the field of view.

> Click the "0. Camera image input FH" icon on the Main Window of the Vision Sensor to open the setting screen.

> * When using the FHV Series Smart Camera Vision Sensor, delete the "0. Camera Image Input FH" unit and in its place set "Camera Image Input FHV" as Unit 0.

O.Camera Image Input FH
1.Calibration Data Reference
2.Calibration Data Reference
3.Shape Search III
4.Transfer Position Data
5.Calc Axis Move

0.Camera Image Input FH		
Camera	Select camera	
Select setting Camera No. :	Camera	a0 🔽

6

Check the set "Camera No." by clicking [Select camera] tab.

* Change the camera number based on the actual environment.

	Select the set camera number tab on the "Camera" tab. Adjust the shutter speed and gain of the camera on the "Camera settings" area.	Camera Image Input FH Camera Select camera Camera0 Camera1 Camera2 Camera setting Screen adjust White balance Camera sett ings Shutter speed : Gain : 2000 µs 85
7	Register a workpiece as a model for Pick/Place on Shape Search III by operations as same as those at step5 in Chapter 6.4.1	
8	Select [Camera image meas.] on the Main Window of the Vision Sensor and detect a workpiece position for Pick/Place with clicking [Measure]. Click [Robot Ref. Position] on the Main Window of the Vision Sensor to open the "Robot Ref. Position" dialog. Click [Edit] on the "Robot Ref. Position" dialog to open the "Workpiece Ref. Pos." dialog. Click [Reg. Workpiece Ref. Pos.] on the "Workpiece Ref. Pos." dialog to register the measurement position of the workpiece.	Camera image meas. image file meas. Measure Output Continuous meas.

After clicking [Close], check that the "Workpiece Ref. Pos." on the "Robot Ref. Position" dialog has been updated.

An operation of the dialog will automatically set values to Scene and System variables previously set in the scenes loaded by the environment copy feature in Chapter 5.1. Do not directly set the values by TDM editor or setting screens for processing items. If application operations are performed without registering the "Workpiece Ref. Pos.", the robot would produce unexpected motion. Please be sure to register the position.

Click [Robot Operation] on the Main Window of the Vision Sensor to open the "Robot Operation" dialog.

File Function Tool Window 0.Scene group 0 Edit flow 0.Pick Fixed 6axis Switch layout ms Layout0 Robot Operation Robot Current Pos. Get Calibration X : 0.0000 W : 0.0000 0.0000 P : 0.0000 Robot Ref. Position FH Macro Ver. 1.00 Y : 0.0000 R : Robot Operation Check RB Prog. Ver. 1.00 Z : 0.0000

Move the robot to a position to grip the workpiece for Pick/Place on the "Robot Operation" dialog.

🛃 Robot Op	eration	-	×
Jog Opera	tion	Target Position	
-X	+X	Target PosX :	0.0000
		Target PosY :	0.0000
-Y	+Y	Target PosZ :	0.0000
-Z	+Z	Target PosW :	0.0000
		Target PosP :	0.0000
-Rx	+Rx	Target PosR :	0.0000
-Ry	+Ry	Robot M	love
-Rz	+Rz	Edit	
Jog Operation Setting			
Unit Distance (mn		n): 10.0	000
Unit Rotate (deg) :		3.00	00
Speed (%) :		1	
Jog Mode :		0	
Comm. Setting			
Tin	neout (ms) :	6000	00
			Close

- These operations drive the robot.
- Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.



When the robot moves to Z-axis direction, check its motion by visual observation and not by camera image.



Click [Get] on the Main Window of the Vision Sensor to get the current position of the robot.

Click [Robot Ref. Position] on the Main Window of the Vision Sensor to open the "Robot Ref. Position" dialog.

Click [Edit] on the "Robot Ref. Position" dialog to open the "Robot Grip Pos." dialog.

10 Click [Reg. Robot Grip Pos.] on the "Robot Grip Pos." dialog to register the current position of the robot.

> After clicking [Close], check that the "Robot Grip Pos." on the "Robot Ref. Position" dialog has been updated.

File Function Tool Windov 0.Scene group 0 Edit flow 0.Pick_Fixed_6axis Switch layout ms Layout0 Get Robot Operation Robot Current Pos. Calibration х : 300.0000 W : 0.0000 Robot Ref. Position FH Macro Ver. 1.00 Y : 0.0000 P : 180.0000 RB Prog. Ver. 1.00 Z : 350.0000 R : Robot Operation Check 0.0000 x Robot Current Pos. Robot Grip Pos. X : 300.0000 **X** : 0.0000 Y: 0.0000 Υ: 0.0000 Ζ: 0.0000 Ζ: 350.0000 w: 0.0000 ₩ : 0.0000 **P** : 0.0000 180.0000 P : 0.0000 R: R : 0.0000 Robot Move Reg. Robot Grip Pos. Edit Close

An operation of the dialog will automatically set values to Scene and System variables previously set in the scenes loaded by the environment copy feature in Chapter 5.1. Do not directly set the values by TDM editor or setting screens for processing items. If application operations are performed without registering the "Robot Grip Pos.", the robot would produce unexpected motion. Please be sure to register the position.



Dist." on the "Robot Ref.

Set 11 distance the "Robot on Approach Dist.".

> After clicking [Close], check that the "Robot Approach Dist." on the "Robot Ref. Position" dialog has been updated.

Click [Robot Move] of the "Robot Image Pos." on the "Robot Ref. Position" dialog to check that the robot moves to the imaging position registered.

Click [Robot Move] of the "Robot Grip Pos." on the "Robot Ref. Position" dialog to check that the robot moves to the grip position registered.

Click [Robot Move] of the

12 "Robot Approach Dist." on the "Robot Ref. Position" dialog to check that the robot moves to + Z direction for the value set in "Robot Approach Dist." from the robot gripping position.



🖶 Robot Ref. Position			×
Robot Image Pos.	Workpiece Ref. Pos.	Robot Grip Pos.	Robot Approach Dist.
X : 300.0000	X : 371.2034	X : 300.0000	D : 50.0000
Y: 0.0000	Y: -356.249	Y : 0.0000	
Z : 350.0000	TH : -0.3952	Z : 350.0000	
W : 0.0000		W : 0.0000	
P: 180.0000		P: 180.0000	
R : 0.0000		R : 0.0000	
Robot Move		Robot Move	Robot Move
Edit	Edit	Edit	Edit
			Close

* If the robot produced unexpected motion, please register the robot approach distance again.

- These operations drive the robot.
- Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.



6.4.4. Checking Application Operations

Follow the procedures below to check that scenes for applications are operable.

	Click [Robot Operation Check]	FZ-PanDA File Function Tool Window	
	on the Main Window of the	0.Scene group 0	flow
	Vision Sensor to open the	ms Layout0 Switch	layout
	"Robot Operation Check"	Robot Operation Robot Current Pos.	Get
	dialog.	Calibration X : 0.0000 W :	0.0000
		Robot Ref. Position FH Macro Ver. 1.00 Y : 0.0000 P :	0.0000
		Köbot Uperation Check	0.0000
		💀 Robot Operation Check	
	Click [Robot Move] of the	Robot Image Pos.	
	"Robot Image Pos" on the	Robot Move	
	"Robot Operation Check" dialog		
1	and mays the rebet to the	Robot Approach Pos.	
	imaging position	Robot Move	
	inaging position.	Robot Command Pos.	
		Robot Move	
		Close	
	/!	WARNING	
	These operations drive the ro	obot. 🦳	
	Operate the robot in the	state whereby pressing the	
	[Emergency stop] button car	ı stop its motion anytime.	



	Stop the robot program	
5	launched by procedures in	
	Chapter 5.3.	

6.5. Backing up Settings

When backing up the settings of the Vision Sensor done in Chapter 6.2, 6.3, and 6.4 into an external storage, use the configuration copy feature.

Precautions for Correct Use

r 🗖

Saving an individual scene or individual scene groups cannot back up all of settings done in Chapter 6. Be sure to use the configuration copy feature.

Select [Tool] - [Configuration File Funct Tool Vindow Editflow Data save copy] on the Main Window of System Setting Security settings Switch layout Scene Group Sav ing De the Vision Sensor to open the Robot Op NG analyzer Current Pos. Get Robot Command User data too 0.0000 X : 0.0000 V : 0.0000 Calibr Settings download and upload tools "Configuration copy" screen. Robot Ref. Layout download and upload tools 0.0000 P : 0.0000 Y : 0.0000 image file save 0.0000 R : 0.0000 Z : 0.0000 Robot Opera Registered Image Manager Communication Command Macro Flow viewer Calibration support tool Update standard position too Conversion scene group data tool Custom dialog tool ·uetom dialog 1 Configuration conv Keyboard layout selection too Device information storage too A "Confirm" dialog is displayed. Confirm Settings created by this function will be applied only to data saved directly Click [Continue]. in the controller.If any BKD files are read, or settings are modified in the way that requires restart, use this function after the restart. If you continue, the settings for the current line will be saved. Continue without save Continue Cancel Configurati In the [Save] tab on the Save Load "Configuration copy" screen, E. Setting Template Set the "3. Line 0" for a 3.Line (• Syste System variable Scene group s scene group Save to template setting. Set the Communication -Custom dialog destination device to the "Save Security sett Security security Sensor controller project name to" and the project name for SAMPLE the backup to the "Sensor E Line 4 Note 2 -controller project name". E Registered image Execute For selecting saving items shown on the right, place a check to the following items only.

Follow the procedures below to back up the settings.

System setting
 System variable
 Scene group
 Communication command
 macro
 Custom dialog
 Click [Execute] to save the settings.
7. Designing Robot Programs

This chapter describes design examples of robot programs to construct applications using a sample program (fhsample_main()).

Precautions for Correct Use

The implementation procedures for robot programs noted in this chapter are a reference. You should design, implement, and test actually operating robot programs based on your specific environment and applications.

In the Main Window or "Layout setup" of the Vision Sensor, check that the "Output" of the current layout is ON. If the setting were OFF, the Vision Sensor will not output measurement values.

The sample program (fhsample_main()) is implemented with the following procedures.

7.1	Connecting the Vision Sensor to the robot controller	Declare internal variables and initialize external variables. Set IP addresses and port numbers as arguments of a connection function to the Vision Sensor and execute the function.	
	$\mathbf{\nabla}$		
7.2	Switching scenes on the Vision Sensor	Set a switching destination scene number as arguments of a scene switching command execution sample function and execute the function.	
	▼		
7.3	Moving the robot to the robot image position	Read the robot imaging position from the Vision Sensor, set it as arguments of a robot motion sample function and execute the function.	
	▼		
7.4	Executing measurements on the Vision Sensor and Getting the measurement results	Execute a current position registration command execution sample function and a measurement command execution sample function. Set the measurement results to variables.	

		Read the robot approach distance from
	Moving the robot to the robot	the Vision Sensor and add the reading to
7.5	approach position at	the measurement results. Set it as
	measurement	arguments of a robot motion sample
		function and execute the function.
	▼	
	Moving the robot to the robot	Set the measurement results as
7.6	command position at	arguments of a robot motion sample
	measurement	function and execute the function.
	▼	
	Disconnecting the Vision Sensor	Execute a disconnection function to the
7.7	from the robot controller	Vision Sensor.

7.1. Connecting Vision Sensor to Robot Controller

For connecting the Vision Sensor to the Robot Controller, follow the procedures below.





7.2. Switching Scenes on Vision Sensor

For a processing to switch scenes on the Vision Sensor, follow the procedures below.



7.3. Moving Robot to Robot Image Position

For a processing to move the robot to the robot image position, follow the procedures below.



Set the variables as arguments for the robot motion sample function (fhsample_move) and execute it.

- These operations drive the robot.
- Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.

7.4. Executing Measurements on Vision Sensor and Getting Measurement Results

For a processing to execute measurements on the Vision Sensor and to get the measurement results, follow the procedures below.

1	; (3)Register the current position of the robot to the FH before measurement		
	CALL fhsample_chgscn(socket_no, retry_count, time_out, scene_no, err_no)		
	; Error check IF err_no <> success THEN GOTO 10		
	END		
	TYPE "Register the current robot position Done."		
Before executing measurements, execute the current position re			
	command execution sample function (fhsmaple_regpos) to the Vision Sensor.		
2	(A) For the momentum and and the momentum the of the FU		
	CALL fbsample_chascn(socket_no, retry_count, time_out, scene_no, err_no)		
		Maccurement command evecution comple function	
	; Error check IF err_no <> success THEN		
	TYPE "ERROF	R: fhsample_main(): Measure on the Vision controller failed:", err_no	
	GOTO 10		
	END		
	Execute the measur	rement command execution sample function (fhsmaple_trig)	
	to the Vision Senso	r.	
2	; Measurement re	esulte	
2	res_cmd_pos_x =	param [0]	
	res_cmd_pos_x =	param [1]	
	res_cmd_pos_x =	param [2]	
	res_cmd_pos_x =	param [3]	
	res_cmd_pos_x =	param [4]	
	res_cmd_pos_x =	param [5]	
	TYPE "Measurement Done"		
	Set the measurement results to the variables.		

7.5. Moving Robot to Robot Approach Position at Measurement.

For a processing to move the robot to the robot approach position at measurement, follow the procedures below.

1	By the procedures in Chapter 7.4, check that the measurement results are stored in the variables	
2	Click [Robot Ref. Position] on the Main Window of the Vision Sensor to refer to the set robot approach distance.	
3	 ; (5)Move the robot to the approach position ; You have to configure the following robot approach distance for your application. std_appro_dist = 30 Set the robot approach distance to the variable. res_appro_pos_x = res_cmd_pos_x results. Set the referenced robot approach distance to the variable and add the robot approach distance to the measurement results acquired at step 3 in Chapter 7.4	
4	<pre>;!!!!!!!!! ; The following function drives a robot motion immediately. ; Confirm the settings before execution. ;!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!</pre>	

Set the variable as arguments for the robot motion sample function (fhsample_move) and execute it.



- These operations drive the robot.
- Operate the robot in the state whereby pressing the [Emergency stop] button can stop its motion anytime.



7.6. Moving Robot to Robot Command Position at Measurement

For a processing to move the robot to the robot command position at measurement, follow the procedures below.



7.7. Disconnecting Vision Sensor from Robot Controller

For a processing to disconnect the Vision Sensor from the Robot Controller, follow the procedures below.



8. Reference Information

Man. No.	Model	Manual name	
	Vertical multi-joint		
I599-E	robot, Viper 650/850	User's manual	
	eMB-60R		
1601-E	Teaching pendant	User's manual	
1001-L	Т20		
1602-5	Robot controller,	Licor's manual	
1002-L	SmartController EX	User's manual	
1602-E	Automation control	Operation manual	
1003-L	environment (ACE)		
I604-E	eV+ language	User's manual	
I590-E	Robot	Robot Safety Guide	

Man. No.	Model	Manual name	
7265	Vision Sensor		
2305	FH/FHV series	Oser's manual	
7242	Vision Sensor	User's manual Communication	
2342	FH/FHV series	settings	
2102260 48		Image Processing System	
5102209-4D		Instruction Sheet	
0607470 OR		Image Processing System	
960/4/9-9B FH-I[][][](-[][])/FH-3[][][](-[][])		Instruction Sheet	
0606621 18	FH-L550/L550-10	Image Processing System	
9000031-18		Instruction Sheet	
3129404-0C	FHV7[]-[][][][]-C	Smart Camera Instruction Sheet	

9. Revision History

Revision Symbol	Revision Date	Description
А	July 2018	First Edition
В	November	Add Vision Sensor FHV Series
	2018	
С	November	Add support for FH/FHV Series version 6.21
	2019	

OMRON Corporation Kyoto, JAPAN

Industrial Automation Company

Contact: www.ia.omron.com

Regional Headquarters OMRON EUROPE B.V. Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD. No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2018-2019 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Cat. No. Z403-E1-03