


Relays with Forcibly Guided Contacts

G7SA

Compact, Slim Relays Conforming to EN Standards

- Additional Push-In Plus terminal sockets are used to save wiring work in comparison with traditional screw terminals. (Wiring time is reduced by 60%* in comparison with traditional screw terminals.)
- Relays with forcibly guided contacts (EN 61810-3, Certified by VDE).
- Supports the CE marking of machinery (Machinery Directive).
- Helps avoid hazardous machine status when used as part of an interlocking circuit.
- Four-pole and six-pole Relays are available.
- The Relay's terminal arrangement simplifies PWB pattern design.
- Reinforced insulation between inputs and outputs.
 Reinforced insulation between some poles of different polarity.

* According to OMRON actual measurement data



Note: Sockets are sold separately.

For the most recent information on models that have been certified for safety standards, refer to your OMRON website.

 \triangle

Be sure to read the Safety Precautions on page 13.

Model Number Structure

Model Number Legend

Main unit

Relays with forcibly guided contacts

 $G7SA- \square A \square B \square$

Specify the power supply voltage (coil rated voltage) when ordering.

1. NO Contact Poles 2. NC Contact Poles 3. Coil Rated Voltage (V)

2: DPST-NO 1: SPST-NC 12 VDC
3: 3PST-NO 2: DPST-NC 18 VDC
4: 4PST-NO 3: 3PST-NC 21 VDC
5: 5PST-NO 24 VDC
48 VDC
110 VDC

Relays use PCB terminals.

This allows for mounting on PCBs and for connection to optional dedicated sockets (order separately).

Options (order separately)

Sockets

1. Basic Model Name

P7SA: Socket for G7SA

2. Number of Poles

10: 4 poles (10 terminals)14: 6 poles (14 terminals)

3. Mounting Type F: Front-mounting P: Back-mounting

4. LED Indicator

None: None

ND: With operation indicator/coil surge absorbing diode

5. Terminal Type

Blank: Screw terminals when 3. is F type

PCB terminals when 3. is P type

PU: Push-In Plus terminals

6. Coil Rated Voltage (V)

24 VDC: When 4. is ND

G7SA

Ordering Information

Main unit

Relays with Forcibly Guided Contacts Specify the coil rated voltage when ordering.

Terminal type	Sealing	Poles	Contact configuration	Coil rated voltage	Model
PCB terminals	Flux-tight	4 poles	3PST-NO, SPST-NC	12, 18, 21, 24, 48, 110 VDC	G7SA-3A1B
		4 poles	DPST-NO, DPST-NC	12, 18, 21, 24, 48, 110 VDC	G7SA-2A2B
		Flux-tight 6 poles	5PST-NO, SPST-NC	12, 18, 21, 24, 48, 110 VDC	G7SA-5A1B
			4PST-NO, DPST-NC	12, 18, 21, 24, 48, 110 VDC	G7SA-4A2B
			3PST-NO, 3PST-NC	12, 18, 21, 24, 48, 110 VDC	G7SA-3A3B

Options (order separately) Sockets

Mounting	Terminal Type	With operation indicator/coil surge absorbing dioder	Poles	Coil rated voltage	Appearance	Model
	Push-In Plus terminals	Yes	4 poles			P7SA-10F-ND-PU DC24
	T usir-iii T us terminais		6 poles	24 VDC		P7SA-14F-ND-PU DC24
Front-mounting	Screw terminals	Yes	4 poles			P7SA-10F-ND DC24
			6 poles			P7SA-14F-ND DC24
		No	4 poles	_		P7SA-10F
			6 poles	_		P7SA-14F
Back-mounting	PCB terminals	No	4 poles			P7SA-10P
			6 poles	_		P7SA-14P

Socket Accessories

Short Bars (For P7SA-□F-ND-PU)

Pitch	No. of poles	Colors	Model*1*2
	2		XW5S-P2.5-2□
5.2 mm	3	Red (RD) Blue (BL)	XW5S-P2.5-3□
5.2 111111	4	Yellow (YL)	XW5S-P2.5-4□
	5	, ,	XW5S-P2.5-5□

Note: Use for crossover wiring of adjacent contact terminals (bottom) within one Socket.

Parts for DIN Track Mounting

Туре		Model	Minimum Order (quantity)
DIN Tracks	1 m	PFP-100N	1
DIN Tracks	0.5 m	PFP-50N	'
End Plate *		PFP-M	10
Spacer		PFP-S	10

^{*}When mounting DIN track, please use End Plate (Model PFP-M).

^{*1.} Replace the box (□) in the model number with the code for the covering color. Color Options: RD = red, BL = blue, YL = yellow Example: XW5S-P2.5-10RD when the covering color is red.

^{*2.} XW5S-P2.5-5□ cannot be used with P7SA-10F-ND-PU.

Specifications

Ratings

Safety Relay Unit

Coil (4 poles)

Rated voltage	Item	Rated current (mA)	Coil resistance (Ω)	Max. voltage (V)	Power consumption (mW)
12 VDC		30	400		
18 VDC		20	900		
21 VDC		17.1	1,225	110%	Approx. 360
24 VDC		15	1,600	11070	
48 VDC		7.5	6,400		
110 VDC		3.8	28,810		Approx. 420

Contacts

Resistive load
6 A at 250 VAC, 6 A at 30 VDC
6 A
250 VAC, 125 VDC
6 A
Au plating + Ag alloy

Coil (6 poles)

Rated voltage	m	Rated current (mA)	Coil resistance (Ω)	Max. voltage (V)	Power consumption (mW)
12 VDC		41.7	288		
18 VDC		27.8	648		
21 VDC		23.8	882	110%	Approx. 500
24 VDC		20.8	1,152	11070	
48 VDC		10.4	4,606		
110 VDC		5.3	20,862		Approx. 580

Note: 1. The rated current and coil resistance are measured at a coil

temperature of 23°C with tolerances of ±15%.

2. The maximum voltage is based on an ambient operating temperature of 23°C maximum.

Characteristics Safety Relay Unit

Contact resistance >	k1	100 mΩ max.				
Operating time *2		20 ms max.				
Response time *3		10 ms max.				
Release time *2		20 ms max.				
Must operate voltage	9	75% max.				
Must release voltage)	10% min.				
Maximum operating	Mechanical	36,000 operations/h				
frequency	Rated load	1,800 operations/h				
Insulation resistance	e *4	1,000 MΩ min.				
	Between coil and contacts	4,000 VAC, 50/60 Hz for 1 min.				
Dielectric Strength	Between	,000 VAC, 50/60 Hz for 1 min. (except for followings)				
*5 *6	contacts of	4 poles (for poles 3-4 in 4-pole Relays),				
	different polarity	6 poles (for poles 3-5, 4-6, and 5-6 in 6-pole Relays): 2,500 VAC, 50/60 Hz for 1 min.				
	Between contacts of the same polarity	500 VAC, 50/60 Hz for 1 min.				
Vibration resistance		10 to 55 to 10 Hz, 0.75-mm single amplitude (1.5-mm double amplitude)				
Shock resistance	Destruction	1,000 m/s²				
Onock resistance	Malfunction	100 m/s ²				
Durability *7	Mechanical	10,000,000 operations min. (at approx. 36,000 operations/h)				
Durability */	Electrical	100,000 operations min. (at the rated load)				
Inductive load switchin (IEC60947-5-1)	ng capability *8	AC15 240 VAC, 2 A DC13 24 VDC, 1 A/48 VDC, 0.5 A/110 VDC, 0.2 A				
Failure rate (P level) (reference value *9)		5 VDC, 1 mA				
Ambient operating temp	perature *10	12 to 48 VDC: -40 to 85°C (with no icing or condensation) 110 VDC: -40 to 60°C (with no icing or condensation)				
Ambient operating h	umidity	5% to 85%				
Weight		4 poles: Approx. 22 g 6 poles: Approx. 25 g				


Note: 1. The above values are initial values.

- 2. Performance characteristics are based on coil temperature of 23°C.

- Performance characteristics are based on coil temperature of 23°C.
 The contact resistance was measured with 1 A at 5 VDC using the voltage-drop method.
 These times were measured at the rated voltage and an ambient temperature of 23°C. Contact bounce time is not included.
 The response time is the time it takes for the normally open contacts to open after the coil voltage is turned OFF. Contact bounce time is included. Measurement conditions: Rated voltage operation, Ambient temperature: 23°C
 The insulation resistance was measured with a 500-VDC megohmmeter at the same locations as the dielectric strength was measured.
 Pole 3 refers to terminals 31-32 or 33-34, pole 4 refers to terminals 43-44, pole 5 refers to terminals 53-54, and pole 6 refers to terminals 63-64.
 When using a P7SA Socket, the dielectric strength between coil contacts/between contacts of different polarity is 2,500 VAC, 50/60 Hz for 1 min.
 The durability is for an ambient temperature of 15 to 35°C and an ambient humidity of 25% to 75%. For the durability performance to the load.

- *7. The durability is for an ambient temperature of 15 to 35°C and an ambient humidity of 25% to 75%. For the durability performance to the load, refer to the Durability Curve.
- ***8.** AC15: $\cos \phi = 0.3$, DC13: L/R = 48-ms.
- ***9.** The failure rate is based on an operating frequency of 300 operations/min.
- *10. 12 to 48 VDC: When operating between 70 and 85°C, reduce the rated carry current of 6 A by 0.1 A for each degree above 70°C. (See Fig. 1.) 110 VDC: When operating between 40 and 60°C, reduce the rated carry current of 6 A by 0.27 A for each degree above 40°C. (See Fig. 1.)

(Fig. 1) Ambient temperature and contact current



Options (order separately)

Sockets

		Push-In Plu	ıs terminals	Screw to	erminals	PCB te	erminals	
		4 poles	6 poles	4 poles	6 poles	4 poles	6 poles	
Items	Models	P7SA-10F-ND-PU	P7SA-14F-ND-PU	P7SA-10F(-ND)	P7SA-14F(-ND)	P7SA-10P	P7SA-14P	
Ambient operating temperature		P7SA-□F-ND(-PU): -20 to +70°C P7SA-□F: -40 to +85°C (with no icing or condensation)			-40 to +85°C (with no icing or condensation)			
Ambient o	perating humidity	25% to 85%				5% to 85%		
Continuou	s carry current	6 A * 1						
	Between coil and contact terminals	4,000 VAC for 1 min.						
Dielectric strength	Between contact terminals of different polarity	2,500 VAC	of for 1 min.	2,500 VAC for 1 min.				
	Between contact terminals of same polarity	1,500 VAC for 1 min.						
Insulation resistance		1,000 MΩ min. * 2						
Weight		Approx. 58 g	Approx. 70 g	Approx. 44 g	Approx. 59 g	Approx. 9 g	Approx. 10 g	

^{*1.} When operating the P7SA- \Box F-ND-PU at a temperature between 50 and 70°C, reduce the continuous current (6 A at 50°C or less) by 0.25 A for each degree above 50°C.

When operating the P7SA- \Box F-ND at a temperature between 50 and 70°C, reduce the continuous current (6 A at 50°C or less) by 0.3 A for each degree above 50°C.

When operating the P7SA-□F at a temperature between 50 and 85°C, reduce the continuous current (6 A at 50°C or less) by 0.1 A for each degree above 50°C.

*2. Measurement conditions: For 500 VDC applied to the same location as for dielectric strength measurement.

Short Bars (for P7SA-□F-ND-PU)

Application	Applicable sockets	Models	Maximum carry current	Ambient operating temperature	Ambient operating humidity
Crossover wiring of contact terminals (bottom)		XW5S-P2.5-2□	- 24 A	–40 to 55°C	5% to 95%
	P7SA-□F-ND-PU	XW5S-P2.5-3□			
		XW5S-P2.5-4□			
		XW5S-P2.5-5□			

Certified Standards

Safety Relay Unit EN Standards, VDE Certified

Models	Ratings	Standard number	Certification No.	Operating coil	Contact ratings
G7SA-2A2B					
G7SA-3A1B		EN/IEC 61810-1 Electromagnetic relay	125547	12, 18, 21, 24, 48, 110 VDC	6 A, 240 VAC (Resistive) 6 A, 30 VDC (Resistive)
G7SA-3A3B	12, 18, 21, 24, 48, 110 VDC	EN 61810-3			
G7SA-4A2B		Relays with forcibly guided contacts			
G7SA-5A1B					

UL Standards Certification (File No. E41515) Industrial Control Devices

Models	Category	Listed/Recognized	Contact ratings	Operating Coil ratings
G7SA-2A2B				
G7SA-3A1B				
G7SA-3A3B	E41515	Recognized	6 A, 250 VAC (Resistive) 6 A, 30 VDC (Resistive)	12, 18, 21, 24, 48, 110 VDC
G7SA-4A2B				
G7SA-5A1B				

CSA standard CSA C22.2 No.14 Industrial Control Devices

Models	Class number	File No.	Contact ratings	Operating Coil ratings
G7SA-2A2B				
G7SA-3A1B	3211-07	LR35535	6 A, 250 VAC (Resistive)	12, 18, 21, 24, 48,
G7SA-4A2B	3211-07	LK33333	6 A, 30 VDC (Resistive)	110 VDC
G7SA-5A1B				

South Korea S-mark certified (Rated voltage 24VDC only)

Models	Applicable standard number
G7SA-2A2B DC24	
G7SA-3A1B DC24	
G7SA-3A3B DC24	KS C IEC 61810-1
G7SA-4A2B DC24	
G7SA-5A1B DC24	

CQC

Models	Standard number	Certification No.	
G7SA	GB/T, 21711.1	CQC14002119869	

Sockets

CE Marking Compliance

Models EMC Directive		Low Voltage Directive	Machinery Directive	
P7SA (Excluding -P type) Not applicable		Applicable	Not applicable	
P7SA-PU	Not applicable	Applicable	Not applicable	

The CE compliance declaration was made in combination with the Safety Relay.

EN Standards, VDE Certified

Models Ratings		Standard number	Certification No.	
P7SA		EN61984	40007586	

EN Standards, TÜV Certified

Models Ratings		Standard number	Certification No.	
P7SA-PU		EN61984	R50356981	

UL Standards Certification (File No. E87929) Industrial Control Devices

Models	Category	Listed/Recognized
P7SA	SWIV2	Recognized
P7SA-PU	SWIV2, SWIV8	Recognized

CSA standard CSA C22.2 No.14 Industrial Control Devices


Models	Class number	File No.
P7SA	3211-07, 3211-87	LR35535
P7SA-PU	3211-07, 3211-87	LR35535

Engineering Data (Reference Value)

Safety Relay Unit

Durability Curve

G7SA-□A□B




Options (order separately)


Sockets

Front-connecting Sockets

Ambient temperature and contact current P7SA-□F-ND-PU








- *1. When using a G7SA-5A1B relay, be careful not to exceed the total current (24 A). (Example: at 50°C, 5 contacts × 4.8 A)
- *2. Certification conditions for the TÜV certification. Care should be taken not to exceed the total current.

Dimensions (Unit: mm)

Safety Relay Unit


4 poles G7SA-3A1B G7SA-2A2B






Terminal Arrangement/ Internal Connection Diagram (Bottom View)

G7SA-3A1B




G7SA-2A2B



Printed Circuit Board Design Diagram (Bottom View) (±0.1 tolerance)


Ten, 1.4 dia.



2. The colors of the cards inside the Relays are as follows: G7SA-3A1B: Blue and G7SA-2A2B: White.


6 poles G7SA-5A1B G7SA-4A2B G7SA-3A3B






Terminal Arrangement/ Internal Connection Diagram (Bottom View)

G7SA-5A1B



Printed Circuit Board Design Diagram (Bottom View) (±0.1 tolerance)



G7SA-4A2B




Note: 1. Terminals 23-24, 33-34, 43-44, 53-54, and 63-64

are normally open. Terminals 11-12, 21-22, and 31-32 are normally closed.

2. The colors of the cards inside the Relays are as follows: G7SA-5A1B: Blue, G7SA-4A2B: White, and G7SA-3A3B: Yellow.


G7SA-3A3B




Options (order separately)

Sockets


Front-mounting Sockets Push-In Plus terminals 4 poles P7SA-10F-ND-PU






35.4


Terminals Arrangement/Internal Connections Diagram (Top View)




Note: 1. The numbers in parentheses are traditionally used terminal numbers.
2. Terminals 23-24, 33-34, and 43-44 are normally open. Terminals 11-12 and 21-22 are normally closed.


Push-In Plus terminals 6 poles P7SA-14F-ND-PU







Terminals Arrangement/Internal Connections Diagram (Top View)




Note: 1. The numbers in parentheses are traditionally used terminal numbers.
2. Terminals 23-24, 33-34, 43-44, 53-54, and 63-64 are normally open. Terminals 11-12, 21-22, and 31-32 are normally closed.

Accessories for Push-In Plus Sockets

Short Bars (for P7SA-□F-ND-PU)

XW5S-P2.5-□□




Pitch	Compatible models	No. of poles	P(mm)	Colors	Model *
5.2 mm	For P7SA-□F-ND-PU	2	5.2	Red (RD) Blue (BL) Yellow (YL)	XW5S-P2.5-2□
		3	10.4		XW5S-P2.5-3□
		4	15.6		XW5S-P2.5-4□
		5	20.8		XW5S-P2.5-5□

Note: Use for crossover wiring of adjacent contact terminals (bottom) within one Socket.


★ Replace the box (□) in the model number with the code for the covering color.

Color Options: RD = red, BL = blue, YL = yellow

Front-mounting Sockets Screw terminals 4 poles P7SA-10F, P7SA-10F-ND




The above figure shows with the finger cover mounted.




Note 1: The front view shows with the finger cover removed. 2: Only the -ND Sockets have operation indicators (orange).

Terminal Arrangement/Internal Connection Diagram (Top View) G7SA-3A1B Mounted G7SA-2A2B Mounted





* This display circuit is available only for "-ND" models. Note: Terminals 23-24, 33-34, and 43-44 are normally open. Terminals 11-12 and 21-22 are normally closed.

Mounting Hole Placement Diagram (Top View)




Screw terminals 6 poles P7SA-14F, P7SA-14F-ND






Note 1: The front view shows with the finger cover removed.
2: Only the -ND Sockets have operation indicators (orange).

Terminal Arrangement/Internal Connection Diagram (Top View)




* This display circuit is available only for "-ND" models. **Note:** Terminals 23-24, 33-34, 43-44, 53-54, and 63-64 are normally open. Terminals 11-12, 21-22, and 31-32 are normally closed.


Mounting Hole Placement Diagram (Top View)



Parts for DIN Track Mounting


DIN Track PFP-100N






DIN Track PFP-100N2








End Plate PFP-M







Spacer PFP-S









Back-mounting Sockets (for PCB) PCB terminals 4 poles **P7SA-10P**








Mounting Hole Placement (Bottom View)

(±0.1 tolerance)




Note: Terminals 23-24, 33-34, and 43-44 are normally open. Terminals 11-12 and 21-22 are normally closed.


PCB terminals 6 poles P7SA-14P


4.1

24.8

-39.9







Terminal Arrangement/ Internal Connection Diagram (Bottom View)




33 34 53 54



Mounting Hole Placement (Bottom View)

(±0.1 tolerance)



Note: Terminals 23-24, 33-34, 43-44, 53-54, and 63-64 are normally open. Terminals 11-12, 21-22, and 31-32 are normally closed.

Safety Precautions

Be sure to read the Common Precautions for All Relays with Forcibly Guided Contacts at the following URL: http://www.ia.omron.com/.

Warning Indications

Precautions for Safe Use	Supplementary comments on what to do or avoid doing to use the product safely.
Precautions for Correct Use	Supplementary comments on what to do or avoid doing to prevent failure to operate, malfunction, or undesirable effects on product performance.

Precautions for Safe Use

Push-In Plus Terminal Sockets (P7SA-□F-ND-PU)

- Do not wire anything to the release holes.
- Do not tilt or twist a flat-blade screwdriver while it is inserted into a release hole on the terminal block. The terminal block may be damaged.
- Insert a screwdriver into the release holes at an angle. The terminal block may be damaged if the flat-blade screwdriver is inserted straight in.
- Do not allow the flat-blade screwdriver to fall when you are holding it in a release hole.
- Do not bend a wire past its natural bending radius or pull on it with excessive force. Doing so may cause the wire disconnection.
- Do not insert more than one wire into each terminal insertion hole.
- To prevent wiring materials from smoking or igniting, confirm wire ratings and use the wiring materials given in the following table.


Recommended wire	Stripping length (Ferrules not used)
0.5 to 1.5mm ² /AWG20 to 16	8 mm

- Insert a flat-blade screwdriver all the way to the bottom of the release hole. If the flat-blade screwdriver is not inserted correctly, the wire may not be connected correctly.
- When crossover wiring with wires or short bars, make sure not to insert them in the wrong position. It may cause a short circuit, a malfunction, or a failure.

Precautions for Correct Use

Wiring

- The coil terminals have polarity (+, -). Inverting the polarity when wiring the terminals will cause the unit not to operate.
- The release time and the response time of the G7SA will be longer when using the P7SA-□F-ND(-PU), a socket with operation indicator/coil surge absorbing diode, because it has a built-in diode to absorb coil surge. Because of that, confirm operation under actual conditions before using the P7SA-□F-ND(-PU).
- <using with P7SA-□F-ND-PU Push-In Plus terminal sockets>
- If there is lubrication, such as oil, on the tip of the flat-blade screwdriver, the flat-blade screwdriver may fall and possibly injure a worker
- Do not insert short bar in the hole for wire or screw driver, it may cause the result of failure of pull out. If insert short bar in the hole for wire or screw driver and try to pull out, it may cause damage for short bar or socket.



Screw Terminal Sockets (P7SA-□F(-ND))

- Use one of the following wires to connect to the P7SA-□F(-ND).
 - Stranded wire: 0.75 to 1.5 mm²
 Solid wire: 1.0 to 1.5 mm²
- Tighten the screws of the P7SA-□F(-ND) to a torque of 0.78 to 0.98 N·m.

Tighten firmly so as not to have any loose wires.

Cleaning

The G7SA is not of enclosed construction. Therefore, do not wash the G7SA with water or detergent.

Mounting

The G7SA can be installed in any direction.

Mounting and Removing the Relays to and from the Socket


<Using with front-connecting sockets, Push-In Plus terminal sockets (P7SA-□F-ND-PU)>

- After mounting the relay, make sure to lock the lock hook. If not, the relay may become loose upon vibration or impact.
- When removing the relay, (1) unlock the lock hook on the release side, (2) then press the release lever.
- You can release the locked block easily by inserting a tip of a flat screwdriver into the square hole.

With the relay mounted Removing the relay









<Using with front-connecting sockets, screw terminal sockets (P7SA-10F(-ND), P7SA-14F (-ND))>

Refer to Common Precautions for All Relays with Forcibly Guided Contacts at the following URL: http://www.ia.omron.com/.

- 5-1-1. Front-connecting Sockets
- 5-1-2. Direction for Inserting and Removing Relays
- 5-3. Common Items


<Using with back-connecting sockets, PCB terminal sockets (P7SA-10P, P7SA-14P)>

Refer to Common Precautions for All Relays with Forcibly Guided Contacts at the following URL: http://www.ia.omron.com/.

- 5-1-3. Soldering of Terminals
- 5-2. PCB Relays
- 5-3. Common Items


Push-In Plus Terminal Sockets (P7SA-□F-ND-PU)

1. Connecting Wires to the Push-In Plus Terminal Block Part Names of the Terminal Block



Connecting Wires with Ferrules and Solid Wires

Insert the solid wire or ferrule straight into the terminal block until the end strikes the terminal block.





 If a wire is difficult to connect because it is too thin, use a flat-blade screwdriver in the same way as when connecting stranded wire.

Connecting Stranded Wires

Use the following procedure to connect the wires to the terminal block.

- 1. Hold a flat-blade screwdriver at an angle and insert it into the release hole.
 - The angle should be between 10° and 15°. If the flat-blade screwdriver is inserted correctly, you will feel the spring in the release hole.
- With the flat-blade screwdriver still inserted into the release hole, insert the wire into the terminal hole until the end strikes the terminal block.
- 3. Remove the flat-blade screwdriver from the release hole






Checking Connections


- After the insertion, pull gently on the wire to make sure that it will
 not come off and the wire is securely fastened to the terminal block.
- If you use a ferrule with a conductor length of 10 mm, part of the conductor may be visible after the ferrule is inserted into the terminal block, but the product insulation distance will still be satisfied.

2. Removing Wires from the Push-In Plus Terminal Block

Use the following procedure to remove wires from the terminal block. The same method is used to remove stranded wires, solid wires, and ferrules.

- Hold a flat-blade screwdriver at an angle and insert it into the release hole.
- 2. With the flat-blade screwdriver still inserted into the release hole, remove the wire from the terminal insertion hole.
- 3. Remove the flat-blade screwdriver from the release hole.






3. Recommended Ferrules and Crimp Tools Recommended ferrules

Applicable wire		Ferrule Conductor	Stripping length (mm)	Recommended ferrules		
(mm²)	(AWG)	Length (mm)	(Ferrules used)	Phoenix Contact product	Weidmuller product	Wago product
0.5	20	8	10	AI 0,5-8	H0.5/14	216-201
0.0	20	10	12	AI 0,5-10	H0.5/16	216-241
0.75	18	8	10	AI 0,75-8	H0.75/14	216-202
0.75	10	10	12	AI 0,75-10	H0.75/16	216-242
1/1.25	18/17	8	10	AI 1-8	H1.0/14	216-203
1/1.25	10/17	10	12	AI 1-10	H1.0/16	216-243
1.25/1.5	17/16	8	10	AI 1,5-8	H1.5/14	216-204
1.23/1.3	17/10	10	12	AI 1,5-10	H1.5/16	216-244
Recommended crimp tool			CRIMPFOX6 CRIMPFOX6T-F CRIMPFOX10S	PZ6 roto	Variocrimp4	

- **Note: 1.** Make sure that the outer diameter of the wire coating is smaller than the inner diameter of the insulation sleeve of the recommended ferrule.
 - Make sure that the ferrule processing dimensions conform to the following figures.




Recommended Flat-blade Screwdriver

Use a flat-blade screwdriver to connect and remove wires.

Use the following flat-blade screwdriver.

The following table shows manufacturers and models as of 2015/Dec.



Model	Manufacturer
SZS 0,4×2,5 SZF 0-0,4×2,5 *	Phoenix Contact
ESD 0,40×2,5	Wera
0.4×2.5×75 302	Wiha
AEF.2,5×75	Facom
210-719	Wago
SDI 0.4×2.5×75	Weidmuller

^{*}OMRON's exclusive purchase model XW4Z-00B is available to order as SZF 0-0,4×2,5 (manufactured by Phoenix Contact).

Terms and Conditions Agreement

Read and understand this catalog.

Please read and understand this catalog before purchasing the products. Please consult your OMRON representative if you have any questions or comments.

Warranties.

- (a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.
- (b) Limitations. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right. (c) Buyer Remedy. Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

Limitation on Liability; Etc.

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY.

Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

Suitability of Use.

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

Programmable Products.

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

Performance Data.

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

Change in Specifications.

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

Errors and Omissions.

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

Note: Do not use this document to operate the Unit.

OMRON Corporation Industrial Automation Company

Kyoto, JAPAN Contact : www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

438B Alexandra Road, #08-01/02 Alexandra Technopark, Singapore 119968 Tel: (65) 6835-3011 Fax: (65) 6835-3011 OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.
Room 2211, Bank of China Tower,

200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-6023-0333 Fax: (86) 21-5037-2388 Authorized Distributor:

©OMRON Corporation 2000-2025 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

CSM_12_12

Cat. No. J120-E1-11 0525 (0100)